

IABU Headquarters

Delta Electronics, Inc.

Taoyuan3 No.18, Xinglong Rd., Taoyuan City, Taoyuan County 330, Taiwan, R.O.C. TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.

Wujiang Plant3 1688 Jiangxing East Road, Wujiang Economic Development Zone Wujiang City, Jiang Su Province, People's Republic of China (Post code: 215200) TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.

238 Min-Xia Road, Cao-Lu Industry Zone, Pudong, Shanghai, People's Republic of China Post code: 201209 TEL: 021-58635678 / FAX: 021-58630003

Delta Electronics (Japan), Inc.

Tokyo Office 2-1-14 Minato-ku Shibadaimon, Tokyo 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

234-9, Duck Soo Building 7F, Nonhyun-Dong, Kangnam-Gu, Seoul, Korea 135-010 TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd

4 Kaki Bukit Ave 1, #05-05, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No. 43, Sector - 35, HSIIDC, Gurgaon122001, Haryana, India TEL: 1-919-767-3800 / FAX: 91-124-403-6045

Americas

Delta Products Corporation (USA)

Raleigh Office P.O. Box 12173,5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S.A

Sao Paulo Office Rua Itapeva, 26-30 Andar Edificio Itapeva One-Bela Vista 01332-000-Sao Paulo-SP-Brazil TEL: +55 11 3568-3850/FAX: +55 11 3568-3865

Europe

Deltronics (The Netherlands) B.V.

Eindhoven Office

De Witbogt 15, 5652 AG Eindhoven, The Netherlands TEL: 31-40-2592850 / FAX: 31-40-2592851

COMTECH

Via Polesine, 1/4 10020 Cambiano (TO) Italy +39 011 9454523

www.e-comtech.it

info@e-comtech.it

DELTA_IA-ASDA_A2_UM_EN_20170209

Application

erie

Manual

www.delta.com.tw/ia



Delta High Resolution AC Servo Drive for **Network Communication Applications** ASDA-A2 Series User Manual



Preface

Thank you for purchasing ASDA-A2. This user manual provides the related information of ASDA-A2R series servo drive and ECMA series servo motors. This manual includes:

- Installation and inspection of servo drive and servo motor
- The configuration of servo drive
- Procedures of trial run
- Control function and adjustment methods of servo drive
- Parameters
- Communication protocol
- Maintenance and inspections
- Troubleshooting

This manual addresses personnel with the following qualifications:

- Servo system designers
- Installation or wiring personnel
- Trial and tuning personnel
- Maintenance and inspection personnel

Before using the product, please read through this manual carefully in order to ensure the correct use of the product. In addition, please place this manual safely for quick reference whenever is needed. Please follow the rules below if you have not finished reading this manual yet.

- No water, corrosive gas and inflammable gas are allowed in installation environment.
- Three-phase power is prohibited to connect to U, V and W connector when wiring. It is possible to damage the servo drive.
- Ground is a must.
- Do not disconnect the servo drive, motor or change the wiring when connecting to the power.
- Be ensured that the emergency stop can be activated anytime before connecting to the power and operation.
- Do not touch the heat sink to avoid scald before connecting to the power and operation.

If you have any enquiry, please contact the distributors or DEALTA customer service center.

Revision February, 2017

Preface ASDA-A2

Safety Precautions

ASDA-A2 series is the high resolution and open type servo drive. It should be installed in a shielded control box during operation. This servo drive uses precise feedback control and the digital signal processor with high-speed calculation function to control the current output which generated by IGBT so as to operate three-phase permanent magnet synchronous motors (PMSM) and to achieve precise positioning.

ASDA-A2 is applicable on industrial application and is suggested to be installed in the panel-board of the user manual. (Servo drives, wire rod and motors all should be installed in the environment which complies with the minimum requirement of UL Level 1.)

Pay special attention to the following safety precautions anytime during inspection, installation, wiring, operation and examination.

The symbol of danger, warning and stop represent:



It indicates the potential hazards. It is possible to cause severe injury or fatal harm if not follow the instructions.



It indicates the potential hazards. It is possible to cause minor injury or lead to serious damage of the product or even malfunction if not follow the instructions.



It indicates the absolute prohibited activity. It is possible to damage the product or cannot be used due to malfunction if not follow the instructions.

Inspection




Please follow the instruction when using servo drive and servo motor, or it is possible to cause fire or malfunction.

Installation



It is prohibited to expose the product with the environment which containing water, corrosive gas, inflammable gas, etc. Or it is possible to cause electric shock or fire.

Wiring






- Do not connect the three-phase source to the motor output terminal U, V and W. Or it is possible to cause personnel injury or fire.
- Please tighten the screws of the power and motor output terminal. Or it is possible to cause fire.
- > Please connect wiring according to the wire rod in order to prevent any danger.

ii Revision February, 2017

ASDA-A2 Preface

Operation





- > Before the machine starts to operate, please be ensured the emergency stop can be activated anytime.
- When power on, please make sure the motor shaft stands still and will not operate because of mechanical inertia or other causes.



- During the operation, it is prohibited to touch any rotating motor parts. Or it is possible to cause personnel injury.
- In order to prevent any accident, please separate the couplings and belts of the machine and isolate them. Then conduct the initial trial run.



- > If users fail to operate the machine properly after the servo motor connects to the equipment, it would cause the damage of the equipment and lead to the personnel injury.
- > In order to prevent the danger, it is strongly recommended to check if the motor can operate normally without load first. Then, operate the motor with load.
- > Do not touch the heat sink of the servo drive. Or it is possible to cause scald due to the high temperature.

Maintenance and Inspection

- > It is prohibited to touch the internal parts of the servo drive and servo motor. Or it is possible to cause electric shock.
- > It is prohibited to disassemble the panel of the servo drive when turning on the power. Or it is possible to cause electric shock.



- > Do not touch the ground terminal within 10 minutes after turning off the power. Or the residual voltage may cause electric shock.
- > Do not disassemble the motor. Or it is possible to cause electric shock or personnel injury.
- > Do not change the wiring when the power is on. Or it is possible to cause electric shock or personnel injury.
- Only the qualified electrical and electronics professionals can install, wire and maintain the servo drive and servo motor.

Preface ASDA-A2

Main Circuit Wiring

> Do not put the power cable and the encoder cable in the same channel and bond them together. Please separate the power cable and the encoder cable for at least 30 centimeters (= 11.8 inches) when wiring.




- Please use stranded wires and multi-core shielded-pair wires for the encoder cables and encoder feedback cables. The maximum length of command input cable is 3 meters (= 9.84 feet) and the maximum length of feedback cable is 20 meters (= 65.62 feet).
- The high voltage might remain in the servo motor even when the power is off. Do not touch the power terminal temporally (at least 10 minutes). Please conduct the inspection not until the indicator light, CHARGE is off.



> Do not turn the power on and off too often. If continuous power on and off is needed, please be ensured the interval is one minute at most.

Terminal Wiring of the Main Circuit





- One terminal of the terminal socket for one electric wire only.
- > When inserting the electric wires, do not connect the conductor to the adjacent wire.
- Before connecting to the power, please inspect and be ensured the wiring is correct.



If there is any difference of each version, please refer to DELTA's website (http://www.delta.com.tw/industrialautomation/) for the latest information.

İV Revision February, 2017

Table of Contents

Chapter 1	I Inspection and Model Explanation1-	1
1.1	Inspection1-1	
1.2	Product Model	
1.2.	.1 Nameplate Information	
1.2.	.2 Model Explanation1-4	
1.3	Servo Drive and Corresponding Servo Motor	
1.3.	.1 220 V Series	
1.3.	.2 400 V Series	
1.4	Each Part of the Servo Drive1-9	
1.4.	.1 220 V Series	
1.4.	2 400 V Series1-1	2
Chapter 2	2 Installation2-	1
2.1	Notes	
2.2	Ambient Conditions of Storage2-1	
2.3	Ambient Conditions of Installation	
2.4	Installation Direction and Space	
2.5	Specification of Circuit Breaker and Fuse	
2.6	EMI Filter Selection	
2.7	Selection of Regenerative Resistor	
Chapter 3	3 Wiring3-	1
3.1	Connections – 220V series	
3.1.	.1 Connecting to Peripheral Devices	

	3.1.2	Connectors and Terminals of Servo Drive	. 3-2
	3.1.3	Wiring Method	. 3-4
	3.1.4	Specification of Motor Power Cable	. 3-6
	3.1.5	Specification of Encoder Cable Connector	. 3-8
	3.1.6	Selection of Wiring Rod	. 3-12
3.2	2 Co	onnections – 400V series	. 3-14
	3.2.1	Connecting to Peripheral Devices	. 3-14
	3.2.2	Connectors and Terminals of the Servo Drive	. 3-16
	3.2.3	Wiring Method	. 3-18
	3.2.4	Specification of Motor Power Cable	. 3-19
	3.2.5	Specification of Encoder Connector	. 3-21
	3.2.6	Selection of Wiring Rod	. 3-23
3.3	B Ba	asic Wiring	. 3-25
	3.3.1	220V series	. 3-25
	3.3.2	400V series	. 3-28
3.4	1 I/C	Signal (CN1) Connection	. 3-30
	3.4.1	I/O Signal (CN1) Connector Terminal Layout	. 3-30
	3.4.2	Signals Explanation of Connector CN1	. 3-32
	3.4.3	Wiring Diagrams (CN1)	. 3-42
	3.4.4	DI and DO Signal Specified by Users	. 3-50
	3.4.5	Application: Using CN1 Quick Connector for Wiring	. 3-50
3.5	5 CI	N2 Connector	. 3-54
3.6	6 W	iring of CN3 Connector	. 3-57
	3.6.1	Layout of CN3 Connector	. 3-57
	3.6.2	Connection between PC and Connector CN3	. 3-58

3.7	CN4 Serial Connector (USB)	3-59
3.8	CN5 Connector (Full-closed loop)	3-60
3.9	CN6 Connector (CANopen)	3-61
3.10	Extension Digital Input Connector of CN7	3-63
3.11	CN8 Connector of Battery Box	3-64
3.12	Standard Connection Example – 220V series	3-65
3.1	2.1 Position (PT) Control Mode	3-65
3.1	2.2 Position (PR) Control Mode	3-66
3.1	2.3 Speed Control Mode	3-67
3.1	2.4 Torque Control Mode	3-68
3.1	2.5 Communication Mode	3-69
3.13	Standard Connection Example – 400V series	3-70
3.1	3.1 Position (PT) Control Mode	3-70
3.1	3.2 Position (PR) Control Mode	3-71
3.1	3.3 Speed Control Mode	3-72
3.1	3.4 Torque Control Mode	3-73
3.1	3.5 Communication Mode	3-74
Chapter 4	4 Panel Display and Operation	4-1
4.1	Panel Description	4-1
4.2	Parameter Setting Procedure	4-2
4.3	Status Display	4-5
4.3	3.1 Save Setting Display	4-5
4.3	2.2 Decimal Point	4-5
4.3	3.3 Alarm Message	4-5
4.3	8.4 Positive and Negative Sign Setting	4-5

	4.3	.5	Monitor Display	4-6
	4.4	Ge	eneral Function	4-9
	4.4	.1	Operation of Fault Record Display	4-9
	4.4	.2	JOG Mode	4-10
	4.4	.3	Force DO Output	4-11
	4.4	.4	Digital Input Diagnosis Operation	4-12
	4.4	.5	Digital Output Diagnosis Operation	4-12
C	hapter	5	Trial Operation and Tuning	5-1
	5.1	Ins	spection without Load	5-1
	5.2	Ар	plying Power to the Servo Drive	5-2
	5.3	JO	OG Trial Run without Load	5-6
	5.4	Tri	al Run without Load (Speed Mode)	5-7
	5.5	Tri	al Run without Load (Position Mode)	5-9
	5.6	Tu	ning Procedure	5-11
	5.6	.1	Flowchart of Tuning Procedure	5-12
	5.6	.2	Inertia Estimation Flowchart (with Mechanism)	5-13
	5.6	.3	Flowchart of Auto Tuning	5-14
	5.6	.4	Flowchart of Semi-Auto Tuning	5-15
	5.6	.5	Limit of Inertia Ratio	5-16
	5.6	.6	Mechanical Resonance Suppression Method	5-18
	5.6	.7	Tuning Mode and Parameters	5-19
	5.6	.8	Tuning in Manual Mode	5-20
C	hapter	6	Control Mode of Operation	. 6-1
	6.1	Se	election of Operation Mode	6-1
	6.2	Ро	sition Mode	6-3

(6.2.1	Position Command in PT Mode	. 6-3
(6.2.2	Position Command in PR Mode	. 6-7
(6.2.3	Control Structure of Position Mode	. 6-8
(6.2.4	S-curve Filter (Position)	. 6-9
(6.2.5	Electronic Gear Ratio	. 6-12
(6.2.6	Low-pass Filter	. 6-15
(6.2.7	Timing Diagram in Position Mode (PR)	. 6-16
(6.2.8	Gain Adjustment of Position Loop	. 6-17
(6.2.9	Low-frequency Vibration Suppression in Position Mode	. 6-19
6.3	Sp	eed Mode	. 6-24
(6.3.1	Selection of Speed Mode	. 6-24
(6.3.2	Control Structure of Speed Mode	. 6-25
(6.3.3	Smooth Speed Command	. 6-26
(6.3.4	The Scaling of Analog Command	. 6-30
(6.3.5	Timing Diagram in Speed Mode	. 6-31
(6.3.6	Gain Adjustment of Speed Loop	. 6-31
(6.3.7	Resonance Suppression	. 6-38
6.4	То	rque Mode	. 6-45
(6.4.1	Selection of Torque Command	. 6-45
(6.4.2	Control Structure of Torque Mode	. 6-46
(6.4.3	Smooth Torque Command	. 6-47
(6.4.4	The Scaling of Analog Command	. 6-47
(6.4.5	Timing Diagram in Torque Mode	. 6-48
6.5	Du	al Mode	. 6-49
6	651	Speed / Position Dual Mode	6-50

6.5	5.2 Speed / Torque Dual Mode	6-50
6.5	5.3 Torque / Position Dual Mode	6-51
6.6	Others	6-52
6.6	5.1 The Use of Speed Limit	6-52
6.6	5.2 The Use of Torque Limit	6-52
6.6	6.3 Analog Monitor	6-53
6.6	5.4 The Use of Brake	6-57
Chapter	7 Motion Control	7-1
7.1	Motion Control Functions of ASDA-A2	7-1
7.2	System Information	7-1
7.2	2.1 Description of Monitoring Variables	7-2
7.2	2.2 Description of Data Array	7-8
7.3	Description of Motion Axes	7-11
7.4	Description of PR Mode	7-12
7.5	The Difference between General PR Mode and the One in ASDA-A2	7-12
7.6	The Position Unit of PR Mode	7-13
7.7	Description of Register in PR Mode	7-13
7.8	Homing Description of PR Mode	7-15
7.9	DI/DO Provided by PR Mode and Diagrams	7-16
7.10	Parameter Settings	7-18
7.1	0.1 The Relation between the Previous Path and the Next Path	7-25
7.1	0.2 Programming the Path in PR Mode	7-26
7.11	The Description of E-Cam Function	7-27
7.1	1.1 Function Description of CAPTURE (Data Capture)	7-34
7.1	1.2 Function Description of COMPARE (Data Compare)	7-36

Chapter	8 Parameters	8-1
8.1	Parameter Definition	.8-1
8.2	List of Parameters	.8-2
8.3	Parameter Description	8-13
P0	-xx Monitor Parameters	8-13
P1-	-xx Basic Parameters	8-40
P2	-xx Extension Parameters	.8-91
P3-	-xx Communication Parameters	8-136
P4-	-xx Diagnosis Parameters	8-147
P5	-xx Motion Setting Parameters	8-161
P6	-xx PR Parameters	8-225
P7-	-xx PR Parameters	8-267
Tal	ole 8.1 Function Description of Digital Input (DI)	8-279
Tal	ole 8.2 Function Description of Digital Output (DO)	8-288
Chapter	9 Communications	9-1
9.1	RS-485 & RS-232 Communication Hardware Interface	9-1
9.2	RS-485 & RS-232 Communication Parameters Setting	9-3
9.3	MODBUS Communication Protocol	9-6
9.4	Write-in and Read-out Communication Parameters	9-18
Chapter	10 Troubleshooting	10-1
10.1	Alarm of Servo Drive	10-1
10.2	Alarm of CANopen Communication	10-5
10.3	Alarm of Motion Control	10-7
10.4	Causes and Corrective Actions	10-10
10.5	Corrective Actions after the Alarm Occurs	10-29

Chapter 11	Specifications	11-1
11.1 Sp	ecifications of Servo Drives	11-1
11.1.1	ASDA-A2 220V Series	11-1
11.1.2	ASDA-A2 400V Series	11-4
11.2 Sp	ecifications of Servo Motors (ECMA Series)	11-7
11.2.1	ECMA 220V Series	11-7
11.2.2	ECMA 400V Series	11-17
11.3 To	rque Features (T-N Curves)	11-25
11.3.1	220V Series	11-25
11.3.2	400V Series	11-27
11.4 Ov	rerload Features	11-29
11.5 Dir	mensions of Servo Drive	11-31
11.5.1	220V Series	11-31
11.5.2	400V Series	11-38
11.6 Dir	mensions of Servo Motor (ECMA Series)	11-41
11.6.1	220V Series	11-41
11.6.2	400V Series	11-48
Chapter 12	Absolute System	12-1
12.1 Ba	ckup Battery Boxes	12-2
12.1.1	Specifications	12-2
12.1.2	Battery Box Dimensions	12-4
12.1.3	Connection Cables for Absolute Encoder	12-5
12.1.4	Battery Box Cords	12-7
12.2 Ins	stallation	12-8
12.2.1	Connection Examples	12-8

12.	2.2	How to Install a Battery1	2-12
12.	2.3	How to Replace a Battery1	2-13
12.3	Syst	tem Initialization Procedure and Operation1	2-15
12.	3.1	System Initialization Procedure	2-15
12.	3.2	Pulse Counting	2-16
12.	3.3	PUU Counting1	2-17
12.	3.4	Use Digital Inputs/Outputs to Initialize an Absolute System 1	2-18
12.	3.5	Use Parameters to Initialize an Absolute System 1	2-18
12.	3.6	Use Digital Inputs/Outputs to Read the Absolute Coordinate Data 1	2-19
12.	3.7	Use Parameter to Read the Absolute Coordinate Data 1	2-23
12.4	Rela	ated Parameters for Absolute System 1	2-24
12.5	Digit	tal Input (DI) Function Definition (for Absolute System)	2-30
12.6	Digit	tal Output (DO) Function Definition (for Absolute System)	2-31
12.7	Alar	ms for Absolute System	2-32
12.	7.1	Causes and Corrective Actions	2-33
12.8	Rela	ated Monitoring Variables1	2-35
Appendix	KA /	Accessories	A-1
Appendix	кВІ	Maintenance and Inspection	B-1

Revision February, 2017 Xiii

ASDA-A2 Table of Contents

About this Manual

User Information

Be sure to store this manual in a safe place.

Due to constantly growing product range, technical improvement and alteration or changed texts, figures and diagrams, we reserve the right of this manual contained information change without prior notice.

Coping or reproducing any part of this manual, without written consent of Delta Electronics Inc. is prohibited.

Technical Support and Service

Welcome to contact us or visit our web site (http://www.delta.com.tw/ia/) if you need any technical support, service and information, or, if you have any question in using the product. We are looking forward to serve you needs and willing to offer our best support and service to you. Reach us by the following ways.

ASIA

DELTA ELECTRONICS, INC.

Taoyuan Plant 1

31-1, XINGBANG ROAD,

GUISHAN INDUSTRIAL ZONE,

TAOYUAN COUNTY 33370, TAIWAN, R.O.C.

TEL: 886-3-362-6301 FAX: 886-3-362-7267 JAPAN

DELTA ELECTRONICS (JAPAN), INC.

Tokyo Office

DELTA SHIBADAIMON BUILDING

2-1-14 SHIBADAIMON, MINATO-KU,

TOKYO, 105-0012, JAPAN

TEL: 81-3-5733-1111

FAX: 81-3-5733-1211

NORTH/SOUTH AMERICA

DELTA PRODUCTS CORPORATION (USA)

Raleigh Office

P.O. BOX 12173

5101 DAVIS DRIVE.

RESEARCH TRIANGLE PARK, NC 27709,

U.S.A.

TEL: 1-919-767-3813 FAX: 1-919-767-3969 EUROPE

DELTRONICS (THE NETHERLANDS) B.V.

Eindhoven Office

DE WITBOGT 15, 5652 AG EINDHOVEN,

THE NETHERLANDS

TEL: 31-40-259-2850

FAX: 31-40-259-2851

XİV Revision February, 2017

Chapter 1 Inspection and Model Explanation

1.1 Inspection

In order to prevent the negligence during purchasing and delivery, please inspect the following items carefully.

- Please check if the product is what you have purchased: check the part number of the motor and the servo drive on the nameplate. Refer to the next page for the model explanation.
- Check if the motor shaft can rotate smoothly: Rotate the motor shaft by hand. If it can be rotated smoothly, it means the motor shaft is normal. However, it cannot be rotated by hand if the motor has an electromagnetic brake.
- Check if there is any damage shown on its appearance: visually check if there is any damage or scrape of the appearance.
- Check if there is any loose screw: If the screws are un-tightened or fall off.

If any of the above situations happens, please contact the distributors to solve the problems.

A complete and workable servo set should include:

- (1) A Servo drive and a servo motor
- (2) A UVW motor power cable, the U, V and W wires can connect to the socket attached by the servo drive and another side is the plug which could connect to the socket of the motor. And a green ground wire which should be locked to the ground terminal of the servo drive. (selective purchase)
- (3) An encoder cable which connects to the socket of the encoder. One side of it connects to CN2 servo drive and another side is the plug. (selective purchase)
- (4) 50-PIN connector which is used in CN1 (selective purchase)
- (5) 20-PIN connector which is used in CN2 (selective purchase)
- (6) 6-PIN connector which is used in CN3 and is for general communication (RS-485) (selective purchase)
- (7) 4-PIN connector which used in CN4 (USB Type B product) (selective purchase)
- (8) RJ45 connector which used in CN6 and is for high-speed communication (selective purchase)
- (9) 7-PIN connector which used in CN7, for extension DI. (-U model) (selective purchase)

(10) Servo drive power input:

220V:

	Control circuit power	Main circuit power
100 W ~ 3 kW	L1c, L2C,	R, S, T fast connector
405 kW ~ 15 kW	L1c, L2C, ⊖ terminal block	R, S, T terminal block

400V:

	Control circuit power	Main circuit power
750 W ~ 1.5 kW	DC24V, DC0V,	R, S, T fast connector
2 kW ~ 7.5 kW	DC24V, DC0V,	R, S, T terminal block

- (11) 3-PIN fast connector (U, V, W)
- (12) 3-PIN fast connector (P⊕, D, C)
- (13) A plastic lever (for 220V 100 W ~ 3 kW and 400V 750 W ~ 1.5 kW)
- (14) A metal short-circuit chip (for 220 V 100 W \sim 4.5 kW and 400 V 750 W \sim 1.5 kW)
- (15) An installation manual


1-2 Revision February, 2017

1.2 Product Model


1.2.1 Nameplate Information

ASDA-A2 Series Servo Drive

■ Nameplate Information




Serial Number




ECMA Series Servo Motor

■ Nameplate Information




Serial Number



1.2.2 Model Explanation

ASDA-A2 Series Servo Drive



Model Type


	Туре	RS-485 (CN3)	Full-closed control (CN5)*1	Extension Port for Digital Input (CN7)	EtherCAT	CANopen	DMCNET	Analog Voltage Control	Pulse Input Port	PR Mode*2	E-Cam*3
Standard	L	0	0	Х	Х	Х	Х	0	0	0	Х
Model	U	0	0	0	Х	Х	Х	0	0	0	0
Network	Е	Х	0	0	0	Х	Х	Х	Х	0	0
Model	F	0	0	Х	Х	Х	0	Х	Х	0	Х
	М	0	0	Х	Х	0	Х	0	0	0	0



- 1. In PR mode, only A2-F supports full-closed control function.
- 2. PR parameters can be read and written through communication by DMCNET only.
- 3. E-cam function can only be used in PR mode.

1-4 Revision February, 2017

ECMA Series Servo Motor



1.3 Servo Drive and Corresponding Servo Motor

1.3.1 220V Series

	Motor							Servo Drive			
_	otor	Power	Output (W)	Model Number	Rated Current (Arms)	Max. Instantaneous current (A)	Model Number	Continuous Output Current (Arms)	Max. Instantaneous output current (A)		
			50	ECMA-C1040F□S	0.69	2.05	ASD-A2-0121-□		2.70		
			100	ECMA-C∆0401□S	0.90	2.70		0.90			
			200	ECMA-C∆0602□S	1.55	4.65	ASD-A2-0221-□	1.55	4.65		
	nin		400	ECMA-C∆0604□S	2.60	7.80	ACD A2 0424	2.00	7.00		
tia	3000 r/min	Cinglo	400	ECMA-C∆0804□7	2.60	7.80	ASD-A2-0421-□	2.60	7.80		
Low Inertia		Single- /Three- phase	750	ECMA-C∆0807□S	5.10	15.30	AOD AO 0704	5.40	45.00		
Lov	ECMA-C		750	ECMA-C∆0907□S	3.66	11.00	ASD-A2-0721-□	5.10	15.30		
	ECI		1000	ECMA-C∆0910□S	4.25	12.37	ASD-A2-1021-□	7.00	21.90		
			1000	ECMA-C∆1010□S	7.30	21.90		7.30			
			2000	ECMA-C∆1020□S	12.05	36.15	ASD-A2-2023-□	13.40	40.20		
			3000	ECMA-C∆1330□4	17.2	47.5	ASD-A2-3023-□	19.40	58.20		
	ECMA-E 2000 r/min	Single- /Three- phase	500	ECMA-E∆1305□S	2.90	8.70	ASD-A2-0421-□	2.60	7.80		
			1000	ECMA-E∆1310□S	5.60	16.80	ASD-A2-1021-□	7.30	21.90		
ertia			1500	ECMA-E∆1315□S	8.30	24.90	ASD-A2-1521-□	8.30	24.90		
Medium Inertia			2000	ECMA-E∆1320□S	11.01	33.03	ASD-A2-2023-□	13.40	40.00		
Medi			2000	ECMA-E∆1820□S	11.22	33.66			40.20		
			3000	ECMA-E∆1830□S	16.10	48.30		40.40	58.20		
			3500	ECMA-E∆1835□S	19.20	57.60	ASD-A2-3023-□	19.40			
			500	ECMA-F∆1305□S	3.90	12.10	ASD-A2-0721-□	5.10	15.30		
			850	ECMA-F∆1308□S	7.10	19.40	ASD-A2-1021-□	7.30	21.90		
			1300	ECMA-F∆1313□S	12.60	38.60	400 40 0000	40.40	40.00		
ertia	r/min		1800	ECMA-F∆1318□S	13.00	36.00	ASD-A2-2023-□	13.40	40.20		
Medium-high inertia	1500 r/min	Single-	3000	ECMA-F∆1830□S	19.40	58.20	ASD-A2-3023-□	19.40	58.20		
nm-h		/Three- phase	4500	ECMA-F∆1845□S	32.50	81.30	ASD-A2-4523-□	32.50			
Medi	ECMA-F		5500	ECMA-F∆1855□3	40.00	100.00	ASD-A2-5523-□	40.00			
	"		7500	ECMA-F∆1875□3	47.50	118.80	ASD-A2-7523-□	47.50			
			11000	ECMA-F1221B□3	51.80	129.50	ASD-A2-1B23-□	54.40			
			15000	ECMA-F1221F□S	61.50	145.70	ASD-A2-1F23-□	70.00			

1-6 Revision February, 2017

				Servo Drive					
Motor series		Power Output (W)		Model Number	Rated Current (Arms)	Max. Instantaneous current (A)	Model Number	Continuou s Output Current (Arms)	Max. Instanta neous output current (A)
	ECMA-C/G 3000 r/min		400	ECMA-C∆0604□H	2.60	7.80	ASD-A2-0421-	2.60	7.80
rtia		Single-	750	ECMA-C∆0807□H	5.10	15.30	ASD-A2-0721-□	5.10	15.30
High Inertia		/Three-	300	ECMA-G∆1303□S	2.50	7.50	ASD-A2-0421-□	2.60	7.80
Hig		phase	600	ECMA-G∆1306□S	4.80	14.40	ASD-A2-0721-□	5.10	15.30
			900	ECMA-G∆1309□S	7.50	22.50	ASD-A2-1021-□	7.30	21.90



- 1. The boxes (□) at the ends of the servo drive model names are for optional configurations. For the actual model name, please refer to the ordering information of the actual purchased product.
- The boxes (△) in the model names are for encoder resolution types. △= 1: Incremental type, 20-bit; △= 2: Incremental type, 17-bit; △= 3: 2500 ppr; △= A: Absolute type). The listed motor model name is for information searching, please contact to your local distributors for actual purchased product.
- 3. The boxes (\Box) in the model names represents brake or keyway oil seal.
- 4 *11kw and 15kW will be available soon.

The above table shows the specification of servo drive which has triple rated current. For detailed specification of the servo motor and servo drive, please refer to Chapter 11.

1.3.2 400V Series

				Motor	Servo Drive				
	Motor series		Output (W)	Model Number	Rated Current (Arms)	Max. Instantaneous current (A)	Model Number	Continuous Output Current (Arms)	Max. Instantaneous output current (A)
			400	ECMA-J∆0604 S	1.62	4.85	ASD-A2-0743-□	3.07	9.21
	nin		750	ECMA-J∆0807 S	3.07	9.5	ASD-A2-0743-□	3.07	9.21
rtia	ECMA-J 3000 r/min		750	ECMA-J∆0907 S	2.16	6.37	ASD-A2-0743-□	3.07	9.21
Low Inertia	300	Three- phase	1000	ECMA-J∆0910 S	2.4	7.17	ASD-A2-1043-□	3.52	9.86
Lov	MA-		1000	ECMA-J∆1010 S	4.15	12.46	ASD-A2-1543-□	5.02	10.04
	ECI		2000	ECMA-J∆1020 S	7.09	21.28	ASD-A2-2043-□	6.66	18.65
			3000	ECMA-J∆1330 4	9.8	29.99	ASD-A2-3043-□	11.9	33.32
	ECMA-K 2000 r/min		750	ECMA-K∆1305 S	1.7	5.2	ASD-A2-0743-□	3.07	9.21
Medium Inertia			1000	ECMA-K∆1310 S	3.52	10.56	ASD-A2-1043-□	3.52	9.86
ᄪ		Three- phase	1500	ECMA-K∆1315 S	5.02	15.06	ASD-A2-1543-□	5.02	10.04
Mediu		·	2000	ECMA-K∆1320 S	6.66	19.98	ASD-A2-2043-□	6.66	18.65
			2000	ECMA-K∆1820 S	6.6	19.88	ASD-A2-2043-□	6.66	18.65
			750	ECMA-L∆1305 S	2.1	6.1	ASD-A2-0743-□	3.07	9.21
<u>t</u> ia	nin		850	ECMA-L∆1308 S	3.4	8.85	ASD-A2-1043-□	3.52	9.86
Medium-high Inertia	ECMA-L 1500 r/min		1300	ECMA-L∆1313 S	5.02	15	ASD-A2-1543-□	5.02	10.04
-high		151	Three- phase	3000	ECMA-L∆1830 S	11.53	34.6	ASD-A2-3043-□	11.9
dium	MA-L		4500	ECMA-L∆1845 S	20.8	52	ASD-A2-4543-□	20	44
Me	EC		5500	ECMA-L∆1855 3	22.37	56	ASD-A2-5543-□	22.04	48.49
			7500	ECMA-L∆1875 3	27.3	68.3	ASD-A2-7543-□	28.39	62.46
High Inertia	3000 r/min ECMA-G 1000	Three- phase	900	ECMA-M∆1309 S	4.4	13.1	ASD-A2-1543-□	5.02	10.04



- 1. The boxes (\square) at the ends of the servo drive model names are for optional configurations. For the actual model name, please refer to the ordering information of the actual purchased product.
- The boxes (△) in the model names are for encoder resolution types. △= 1: Incremental type, 20-bit; △= 2: Incremental type, 17-bit; △= 3: 2500 ppr; △= A: Absolute type). The listed motor model name is for information searching, please contact to your local distributors for actual purchased product.
- 3. The boxes (\Box) in the model names represents brake or keyway oil seal.


The above table shows the specification of servo drive which has triple rated current. For detailed specification of the servo motor and servo drive, please refer to Chapter 11.

1-8 Revision February, 2017

1.4 Each Part of the Servo Drive


1.4.1 220V Series

220V Series - Front View




Please see the figure of Bottom View.

220V Series - Top View



1-10 Revision February, 2017

220V Series - Bottom View



1.4.2 400V Series

400V Series - Front View

Charge LED
A lit LED indicates that either power is connected to the servo drive or a residual charge is present in the drive's internal power components.
DO NOT TOUCH ANY ELECTRICAL CONNECTIONS WHILE THIS LED IS LIT.

Full-Close Control Interface Used to connect optical linear scale and encoder for controlling A, B, Z phase signals.

High-speed Communication Port For CANopen communication.

External Digital Input Terminal Used to connect removable digital input terminal block. Up to 6 digital inputs could be added.

of Top View.

Please see the figure

LED Display The 5 digit, 7 segment LED displays the servo status or fault codes

Operation Panel

Used function keys to perform status display, monitor and diagnostic, function and parameter setting.

Function Keys:

MODE : Press this key to select/change mode

SHIFT: Shift Key has several functions: moving the cursor and indexing through the parameter groups Press this key to shift cursor to the left

UP : Press this key to increase values on the display

DOWN: Press this key to decrease values on the display

SET: Press this key to store data

I/O Interface

Used to connect external controller (PLC) or control I/O signal.

Encoder Interface
Used to connect encoder of servo motor.


Serial Communication Interface Used to connect other controllers for RS-485 and RS-232 serial communication.

USB Connection Port Used to connect personal computer, such as desktop or notebook.


Please see the figure of Bottom View.

1-12

400V Series - Top View



400V Series - Bottom View



1-14 Revision February, 2017

Chapter 2 Installation

2.1 Notes

Please pay special attention to the followings:

■ If the connection between the servo drive and the servo motor is over 20 meters, please thicken the connecting wire, UVW as well as the encoder cable. Please refer to section 3.1.6 for further information.

2.2 Ambient Conditions of Storage

Before the installation, this product has to be kept in shipping carton. In order to retain the warranty coverage and for the maintenance, please follow the instructions below when storage, if the product is not in use temporally:

- Store the product within an ambient temperature range of -20 °C to +65 °C.
- Store the product within a relative humidity range of 0% to 90% and a non-condensing environment.
- Avoid storing the product in the environment of corrosive gas and liquid.

2.3 Ambient Conditions of Installation

The ambient conditions of installing and operating the servo drive:

Location has no over-heat device, no water drop, vapor, dust and oily dust, no corrosive and inflammable gas and liquid, no airborne dust and metal particles, no interference of electromagnetic noise and has solid foundation and no vibration.

The ambient conditions of operating the servo motor:

The ambient temperature is between 0 °C and 40 °C. And the ambient location shall has no overheat device, no water drop, vapor, dust and oily dust, no corrosive and inflammable gas and liquid, no airborne dust and metal particles.

The best temperature of this servo drive is between 0 $^{\circ}$ C and 55 $^{\circ}$ C. If the temperature is over 45 $^{\circ}$ C, please place the product in a well-ventilated environment so as to ensure its reliability performance. If the product is installed in an electric box, make sure the size of the electric box and its ventilation condition will not overheat and endanger the internal electronic device. Also, pay attention to the vibration of the machine. Check if the vibration will influence the electronic device of the electric box.


ASDA-A2 Chapter 2 Installation


2.4 Installation Direction and Space

Notes:

Incorrect installation may result in a drive malfunction or premature failure of the drive and motor.

- The ASDA-A2 servo drive should be mounted perpendicular to the wall or in the control panel. In order to ensure the drive is well ventilated, ensure that the all ventilation holes are not obstructed and sufficient free space is given to the servo drive. Do not install the drive in a horizontal position or malfunction and damage will occur.
- Do not parallel connect the servo drive, or it might burn out the soft-start resistance or the commutator and danger will occur.






2-2 Revision February, 2017 Chapter 2 Installation ASDA-A2

Scheme of Installation:


In order to have smaller wind resistance of the fan and increase the ventilation, please follow the suggested clearance value when installing one or more than one servo drives. (Refer to the following diagrams)





The above diagrams are not in equal proportion. Please refer to the annotation.

ASDA-A2 Chapter 2 Installation



NOTE

The above diagrams are not in equal proportion. Please refer to the annotation.

2-4 Revision February, 2017

Chapter 2 Installation ASDA-A2

2.5 Specification of Circuit Breaker and Fuse

220V Series

Caution: Please use the fuse and circuit breaker that is recognized by UL/CSA.

Servo Drive Model	Circuit Breaker	Fuse (Class T)
Operation Mode	General	General
ASD-A2-0121-□	5A	5A
ASD-A2-0221-□	5A	5A
ASD-A2-0421-□	10A	10A
ASD-A2-0721-□	10A	20A
ASD-A2-1021-□	15A	25A
ASD-A2-1521-□	20A	40A
ASD-A2-2023-□	30A	50A
ASD-A2-3023-□	30A	70A
ASD-A2-4523-□	70A	140A
ASD-A2-5523-□	75A	150A
ASD-A2-7523-□	95A	175A
ASD-A2-1B23-□	-	-
ASD-A2-1F23-□	-	-



If the servo drive equips with earth leakage circuit breaker for avoiding electric leakage, please choose the current sensitivity which is over 200 mA and can continue up to 0.1 seconds.

400V Series

Caution: Please use the fuse and circuit breaker that is recognized by UL/CSA.

Servo Drive Model	Circuit Breaker	Fuse (Class T)
Operation Mode	General	General
ASD-A2-0743-□	10A	20A
ASD-A2-1043-□	15A	25A
ASD-A2-1543-□	20A	40A
ASD-A2-2043-□	30A	50A
ASD-A2-3043-□	30A	70A
ASD-A2-4543-□	70A	140A
ASD-A2-5543-□	75A	150A
ASD-A2-7543-□	95A	175A



If the servo drive equips with earth leakage circuit breaker for avoiding electric leakage, please choose the current sensitivity which is over 200 mA and can continue up to 0.1 seconds.

ASDA-A2 Chapter 2 Installation

2.6 EMI Filter Selection

220V Series

Item	Power	Servo Drive Model	Recommende	FootPrint	
пеш	Powei	Servo Drive Moder	1PH	3PH	FOOLFIIII
1	100W	ASD-A2-0121-□	RF007S21AA	RF022B43AA	N
2	200W	ASD-A2-0221-□	RF007S21AA	RF022B43AA	N
3	400W	ASD-A2-0421-□	RF007S21AA	RF022B43AA	N
4	750W	ASD-A2-0721-□	RF007S21AA	RF037B43BA	N
5	1.0kW	ASD-A2-1021-□	RF007S21AA	RF037B43BA	N
6	1.5kW	ASD-A2-1521-□	RF007S21AA	RF037B43BA	N
7	2.0kW	ASD-A2-2023-□	-	RF037B43BA	N
8	3.0kW	ASD-A2-3023-□	-	RF037B43BA	N
9	4.5kW	ASD-A2-4523-□	-	RF075M43BA	N
10	5.5kW	ASD-A2-5523-□	-	RF075M43BA	Υ
11	7.5kW	ASD-A2-7523-□	-	30TDRT1W4	Υ
12	11.0kW	ASD-A2-1B23-□	-	50TDS4W4C	-
13	15.0kW	ASD-A2-1F23-□	-	50TDS4W4C	-

400V Series

Item	Power	Servo Drive Model	Recommended EMI Filter	FootPrint
1	750W	ASD-A2-0743-□	RF007S43AA	N
2	1000W	ASD-A2-1043-□	RF007S43AA	N
3	1500W	ASD-A2-1543-□	RF022B43AA	N
4	2000W	ASD-A2-2043-□	RF037B43BA	N
5	3000W	ASD-A2-3043-□	RF037B43BA	N
6	4500W	ASD-A2-4543-□	RF075M43BA	N
7	5500W	ASD-A2-5543-□	RF075M43BA	Υ
8	7500W	ASD-A2-7543-□	RF075M43BA	Υ

2-6 Revision February, 2017

Chapter 2 Installation ASDA-A2

EMI Filter Installation

All electronic equipment (including servo drive) generates high or low frequency noise during operation and interfere the peripheral equipments via conduction or radiation. With EMI Filter and the correct installation, much interference can be eliminated. It is suggested to use Delta's EMI Filter to suppress the interference better.

When installing servo drive and EMI Filter, please follow the instructions of the user manual and make sure it meets the following specification:

- 1. EN61000-6-4 (2001)
- 2. EN61800-3 (2004) PDS of category C2
- 3. EN55011+A2 (2007) Class A Group 1

General Precaution

In order to ensure the best performance of EMI Filter, apart from the instructions of servo drive installation and wiring, please follow the precautions mention below:


- 1. The servo drive and EMI Filter should be installed on the same metal plate.
- 2. When installing servo drive and EMI Filter, the servo drive should be installed above the EMI Filter.
- 3. The wiring should be as short as possible.
- 4. The metal plate should be well grounded.
- 5. The metal cover of the servo drive and EMI Filter or grounding should be firmly fixed on the metal plate. Also, the contact area should be as large as possible.

ASDA-A2 Chapter 2 Installation

Motor Cable Selection and Installation Precautions

The selection of motor cables and installation affect the performance of EMI Filter. Please follow the precautions mention below.

- 1. Use the cable that has braid shielding (The effect of double shielding is better)
- 2. The shield on both sides of the motor cable should be grounded in the shortest distance and the largest contact area.
- 3. The protective paint of the U-shape saddle and metal plate should be removed in order to ensure the good contact. Please see figure 1.
- 4. It should have correct connection between the braid shielding of the motor cable and the metal plate. The braid shielding on both sides of the motor cable should be fixed by the U-shape saddle and metal plate. Please see figure 2 for the correct connection.



2-8 Revision February, 2017

Chapter 2 Installation ASDA-A2

2.7 Selection of Regenerative Resistor

When the direction of pull-out torque is different from the rotation, it means the electricity is sent back to the servo drive from the load-end. It becomes the capacitance of DC Bus and increases the voltage. When the voltage increases to a specific value, the come-back eletricity can only be consumed by regenerative resistor. There is a built-in regenerative resistor in the servo drive. Users can also use the external regenerative resistor if needed.

Specification of built-in regenerative resistor provided by ASDA-A2 220V Series

Servo Drive	•	uilt-in regenerative stor	*1The capacity of built-	Minimum allowable
(kW)	Resistance (P1-52) (Ohm)	Capacity (P1-53) (Watt)	in regenerative resistor (Watt)	resistance (Ohm)
0.1	-	-	-	30
0.2	-	-	-	30
0.4	40	40	20	30
0.75	40	60	30	20
1.0	40	60	30	20
1.5	40	60	30	20
2.0	20	100	50	10
3.0	20	100	50	10
4.5	20	100	50	10
5.5	-	-	-	8
7.5	-	-	-	5
11	-	-	-	8
15	-	-	-	5

Specification of built-in regenerative resistor provided by ASDA-A2 400V Series


-		•	<u> </u>
Servo Drive	Specification of bu	Minimum allowable	
(kW)	Resistance (P1-52) (Ohm)	Capacity (P1-53) (Watt)	resistance (Ohm)
0.75	80	100	60
1.0	80	100	60
1.5	80	100	40
2.0	-	-	40
3.0	-	-	30
4.5	-	-	20
5.5	-	-	20
7.5	-	-	15

ASDA-A2 Chapter 2 Installation

When the regenerative resistor exceeds the capacity of built-in regenerative resistor, the external regenerative resistor should be applied. Please pay special attention to the followings when using the regenerative resistor.

- 1. Please correctly set up the resistance (P1-52) and capacity (P1-53) of regenerative resistor. Or it might influence the performance of this function.
- 2. If users desire to use the external regenerative resistor, please make sure the applied value should not smaller than the built-in regenerative resistor. In general application, more than one resistor will be serial connected. If the value (from serial connected resistors) exceeds the setting range, users can reduce the value by parallel connecting the resistor. If users desire to connect it in parallel to increase the power of regenerative resistor, please make sure the capacitance meets the requirements.

Please refer to the followings for the calculation when serial / parallel connecting regenerative resistors:



3. In natural environment, if the capacity of regenerative resistor (the average value) is within the rated capacity, the temperature of the capacitance will increase to 120°C or even higher (under the condition of regenerative energy keeps existing). For safety concerns, please apply the method of forced cooling in order to reduce the temperature of regenerative resistor. Or, it is suggested to use the regenerative resistor which is equipped with thermal switches. Please contact the distributors for load characteristics of the regenerative resistor.

When using the external regenerative resistor, the resistor should connect to P, C terminal and the contact of P, D terminal should be opened. It is recommended to choose the above mentioned capacitance. For easy calculation of regenerative resistor capacity, except the energy consumed by IGBT, two ways are provided to select the capacity of external regenerative resistor according to the selected linear motor or rotary motor.

2-10 Revision February, 2017

Chapter 2 Installation ASDA-A2

(1) Regenerative Power Selection

(a) When the external load on torque does not exist

If the motor operates back and forth, the energy generated by the brake will go into the capacitance of DC bus. When the voltage of the capacitance exceeds a specific value, the redundant energy will be consumed by regenerative resistor. Two ways of selecting regenerative resistor are provided here. The table below provides the energy calculation method. Users can refer to it and calculate the selected regenerative resistor.

220V

	ervo Drive Rotor Retia fro		Regenerative power from empty load 3000r/min to stop Eo (joule)	The maximum regenerative power of capacitance Ec (joule)	
	0.1	ECMA-C∆040F□□	0.021	0.10	4.21
	0.1	ECMA-C∆0401□□	0.037	0.18	4.21
	0.2	ECMA-C∆0602□□	0.177	0.87	5.62
	0.4	ECMA-C∆0604□□	0.277	1.37	8.42
Low	0.4	ECMA-C∆0804□□	0.68	3.36	8.42
Inertia	0.75	ECMA-C∆0807□□	1.13	5.59	17.47
	1.0	ECMA-C△1010□□	2.65	13.10	21.22
	1.0	ECMC-C∆0910□□	2.62	12.96	21.22
	2.0	ECMA-C∆1020□□	4.45	22.0	25.58
	3.0	ECMA-C∆1330□□	12.7	62.80	25.58
	0.4	ECMA-E△1305□□	8.17	40.40	8.42
	1.0	ECMA-E△1310□□	8.41	41.59	21.22
	1.5	ECMA-E∆1315□□	11.18	55.29	25.58
Medium Inertia	2.0	ECMA-E∆1320□□	14.59	72.15	25.58
	2.0	ECMA-E∆1820□□	34.68	171.49	25.58
	3.0	ECMA-E∆1830□□	54.95	271.73	31.20
	3.0	ECMA-E△1835□□	54.95	271.73	31.20
	1.0	ECMA-F△1308□□	13.6	67.25	21.22
	2.0	ECMA-F△1313□□	20.0	98.90	25.58
Medium	2.0	ECMA-F△1318□□	24.9	123.13	31.20
–High	3.0	ECMA-F△1830□□	54.95	271.73	28
Inertia	4.5	ECMA-F△1845□□	77.75	384.48	25
	5.5	ECMA-F△1855□□	99.78	493.42	27
	7.5	ECMA-F△1875□□	142.7	705.66	93

ASDA-A2 Chapter 2 Installation

Servo D (kW)		Motor	Rotor Inertia J (× 10- 4kg.m2)	Regenerative power from empty load 3000r/min to stop Eo (joule)	The maximum regenerative power of capacitance Ec (joule)
Medium -High	11.0	ECMA- F∆221B□□	329.0	723.08	117
Inertia	15.0	ECMA- F∆221F□□	553.0	1215.38	156
	0.4	ECMA-G△1303□□	8.17	17.96	8.42
High	0.75	ECMA-F△1305□□	10.3	22.64	17.47
Inertia	0.75	ECMA-G△1306□□	8.41	18.48	17.47
	1.0	ECMA-G△1309□□	11.18	24.57	21.22

Eo= $J*wr^2/182$ (joule), Wr: r/min

400V

Servo D (kW)		Motor	Rotor Inertia J (× 10- 4kg.m2)	Regenerative power from empty load 3000r/min to stop Eo (joule)	The maximum regenerative power of capacitance Ec (joule)
	0.75	ECMA-J∆0604□□	0.277	1.37	42.43
	0.75	ECMA-J∆0807□□	1.13	5.59	42.43
Low	0.75	ECMA-J∆0907□□	1.93	9.54	42.46
Inertia	1.0	ECMA-J△1010□□	2.65	13.10	42.43
	1.5	ECMA-J△1010□□	2.65	13.10	42.43
	2.0	ECMA-J△1020□□	4.45	22.01	42.43
	0.75	ECMA-K△1305□□	8.17	40.40	51.17
	1.0	ECMA-K△1310□□	8.41	41.59	51.17
Medium Inertia	1.5 1.5 1.5 1.5 1.315 1.1 1.5 1.315 1.1 1.5 1.5 1.315 1.1 1.5 1.5 1.315 1.1 1.5 1.5 1.315 1.1 1.5 1.315 1.1 1.5 1.5 1.315 1.1 1.5 1.315 1.1 1.1 1.5		11.18	55.29	57.41
	2.0	ECMA-K∆1320□□	14.59	72.15	34.94
	2.0	ECMA-K∆1820□□	34.68	171.49	34.94

2-12 Revision February, 2017

Chapter 2 Installation ASDA-A2

Servo E (kW	-	Motor	Rotor Inertia J (× 10- 4kg.m2)	Regenerative power from empty load 3000r/min to stop Eo (joule)	The maximum regenerative power of capacitance Ec (joule)
	0.75	ECMA-L∆1305□□	13.1	16.20	42.43
	1.5	ECMA-L△1313□□	23.6	29.18	42.43
Medium	3.0	ECMA-L∆1830□□	54.95	67.93	42.43
–High	3.0	ECMA-J△1330□□	12.7	15.70	42.43
Inertia	4.5	ECMA-L∆1845□□	77.75	96.12	51.17
	5.5	ECMA-L∆1855□□	99.78	123.35	57.41
	7.5	ECMA-L∆1875□□	142.7	176.41	62.40
High	1.0	ECMA-L∆1308□□	17.1	84.56	42.43
Inertia	1.5	ECMA-M△1309□□	11.18	55.29	57.41

Eo= J*wr²/182 (joule), Wr: r/min

Assume that the load inertia is N times to the motor inertia and the motor decelerates from 3000r/min to 0, its regenerative energy is (N+1) x Eo. The consumed regenerative resistor is (N+1) x Eo - Ec joule. If the cycle of back and forth operation is T sec, then the power of regenerative resistor it needs is $2 \times ((N+1) \times Eo - Ec) / T$.

Followings are the calculation procedure:


Steps	Item	Calculation and Setting Method
1	Set the capacity of regenerative resistor to the maximum	Set P1-53 to the maximum value
2	Set T cycle of back and forth operation	Enter by the user
3	Set the rotational speed wr	Enter by the user or read via P0-02
4	Set the load/motor inertia ratio N	Enter by the user or read via P0-02
5	Calculate the maximum regenerative energy Eo	Eo= J*wr²/182
6	Set the absorbable regenerative energy Ec	Refer to the above table
7	Calculate the needful capacitance of regenerative resistor	2 x ((N+1) xEo – Ec) / T

ASDA-A2 Chapter 2 Installation

Take 400W as the example, the cycle of back and forth operation is T = 0.4sec, the maximum speed is 3000r/min and the load inertia is 7 times to the motor inertia. Then, the needful power of regenerative resistor is $2 \times ((7+1) \times 1.68 - 8) / 0.4 = 27.2$ W. If it is smaller than the built-in capacity of regenerative resistor, the built-in 60W regenerative resistor will do. Generally speaking, when the need of the external load inertia is not much, the built-in regenerative is enough. The diagram below describes the actual operation. The smaller power of the regenerative resistor it is, the more energy it accumulates and the higher temperature it will be. When the temperature is higher than a specific value, ALE05 occurs.

(b) If the external load torque exists, the motor is in reverse rotation.

Usually, the motor is in forward rotation, which means the torque output direction of the motor is the same as the rotation direction. However, in some applications, the direction of torque output is different from the rotation. In this situation, the motor is in reverse rotation. The external energy goes into the servo drive through the motor. The diagram below is one example. When the external force direction is the same as the moving direction, the servo system has to use the force of the opposite direction to keep the speed and stability. Huge amount of energy will return to the servo drive at the moment. When DC-BUS is full and unable to store the regenerative energy, the energy will be leaded to regenerative resistor and consumed.



Negative torque: TL × Wr TL: external load torque

For safety reasons, please calculate it by considering the safest situation.

For example, when the external load torque is the +70% rated torque and the rotation reaches 3000 r/min, then take 400 W (the rated torque is 1.27 Nt-m) as the example, the user has to connect the regenerative resistor of 40Ω , which is $2 \times (0.7 \times 1.27) \times (3000 \times 2 \times \pi / 60) = 560$ W.

2-14 Revision February, 2017

Chapter 2 Installation ASDA-A2

(2) Simple Selection

Choose the appropriate regenerative resistor according to the allowable frequency and empty load frequency in actual operation. The so-called empty allowable frequency is the frequency of continuous operation when the servo motor runs from 0r/min to the rated speed and then decelerates from the rated speed to 0r/min within the shortest time. The following table lists the allowable frequency when the servo drive runs without load (times/min).

Allow	Allowable frequency when the servo motor runs without load (times/min)												
	and uses a built-in regenerative resistor												
Motor Capacity	600W	750W	900W	1.0 kW	1.5 kW	2.0 kW	2.0 kW	3.0 kW	4.5 kW	5.5 kW	7.5 kW	11.0 kW	15.0 kW
Servo Motor	06	07	09	10	15	20	20	30	45	55	75	1B	1F
ECMA□□C	-	312	-	137	_	83 (F100)	-	-	-	-	-	-	-
ECMA□□E	-	_	-	42	32	24 (F130)	10 (F180)	11	-	-	-	-	-
ECMA□□F	-	-	-	-	-	-	-	11	8	-	-	-	-
ECMA□□G	42	-	31	-	-	-	-	-	-	-	-	-	-
ECMA□□J	-	537	-	-	-	-	-	-	-	-	-	-	-
ECMA□□K	-	-	-	162	122	-	-	-	-	-	-	-	-
ECMA□□L	_	_	-	-	-	-	-	-	_	_	_	_	-

When the servo motor runs with load, the allowable frequency will be different according to different load inertia or speed. The following is the calculation method.

m represents load / motor inertia ratio.

$$\text{Allowable frequency} = \frac{\text{Allowable frequency when servo motor run without load}}{\text{m+1}} \times \left(\frac{\text{Rated speed}}{\text{Operating speed}} \right)^2 \frac{\text{times}}{\text{min.}}$$

The comparison table of external regenerative resistor is provided below. Please choose the appropriate regenerative resistor according to the allowable frequency.

The table below describes the suggested allowable frequency (times/min) of regenerative resistor when the servo drive runs without load.

Allowable frequency of regenerative resistor when the servo drive runs without load (times/min)											
		ECMA□□C									
Motor Capacity Corresponding Motor	100W	200W	400W (F60)	400W (F80)	750W	1.0kW	2.0kW				
Corresponding Motor	01	02	04	04	07	10	20				
BR400W040 (400W 40Ω)	-	-	8608	3506	2110	925	562				
BR1K0W020 (1kW 20Ω)	-	-	-	8765	5274	2312	1406				

ASDA-A2 Chapter 2 Installation

Materia Competition	ECMA□□E							
Motor Capacity Corresponding Motor	0.5kW	1kW	1.5kw	2.0kW (F130)	2.0kW (F180)	3.0kW		
Corresponding Motor	05	1.0	15	20	20	30		
BR400W040 (400W 40Ω)	291	283	213	163	68	-		
BR1K0W020 (1kW 20Ω)	729	708	533	408	171	-		
BR1K5W005*2 (3kW 10Ω)	-	-	-	-	-	331		

Motor Capacity		ECMA□□F						
	3.0KW	4.5KW	5.5KW	7.5kW	11.0kW	15.0kW		
Corresponding Motor	30	45	55	75	1B	1F		
BR1K5W005*2 (3kW 10Ω)	331	234	182	127	124	74		

Allowable frequency of regenerative resistor when the servo drive runs without load (times/min)								
Motor Capacity		ECMA□□G						
	0.3kW	0.6kW	0.9kW					
Corresponding Motor	03	06	09					
BR400W040 (400W 40Ω)	292	283	213					
BR1K0W020 (1kW 20Ω)	729	708	533					

Matan Oanasita		ECMA□□K	
Motor Capacity Corresponding Motor	1.0kW	1.5kW	2.0kW
	10	15	20
BR400W040 (400W 40Ω)	-	488	665

Motor Capacity	ECMA□□L				
	3.0KW	4.5KW	5.5KW	7.5kW	
Corresponding Motor	30	45	55	75	
BR400W040 (400W 40Ω)	177	-	-	-	
BR1K0W020 (1kW 20Ω)	-	312	243	170	

If watt is not enough when using regenerative resistor, connecting the same regenerative resistor in parallel can increase the power.


2-16 Revision February, 2017

Chapter 2 Installation ASDA-A2

Dimensions of Regenerative Resistor


Delta Part Number : BR400W040 (400W 40Ω)

L1	L2	Н	D	W	MAX. WEIGHT (g)
265	250	30	5.3	60	930




Delta Part Number : BR1K0W020 (1kW 20Ω)

L1	L2	Н	D	W	MAX. WEIGHT (g)
400	385	50	5.3	100	2800



ASDA-A2 Chapter 2 Installation

Delta Part Number : BR1K5W005 (3kW 10 Ω)




2-18 Revision February, 2017

Chapter 3 Wiring

This chapter provides information on wiring ASDA-A2 series products, the descriptions of I/O signals and gives typical examples of wiring diagrams.

3.1 Connections - 220V series

3.1.1 Connecting to Peripheral Devices





Installation notes:

1. Check if the power and wiring among R, S, T and L1c, L2c are correct.

Please refer to Chapter 11 for Specifications. Make sure the input voltage is correct, or it might damage the servo drive or danger may occur.

- 2. Please check if the output terminal U, V, W of the servo motor is correctly wired. The incorrect wiring may disable the operation of the motor or cause malfunction.
- 3. When applying to the external regenerative resistor, the contact between P ⊕ and D should be opened and the external regenerative resistor should connect to terminal P⊕ and C. When applying to the internal regenerative resistor, the contact between P⊕ and D should be closed and the contact between P⊕ and C should be opened.
- 4. When an alarm occurs or the system is in emergency stop status, use ALARM or WARN to output and disconnect the power of magnetic contactor in order to disconnect the power of servo drive.

3.1.2 Connectors and Terminals of Servo Drive

Terminal Signal	Name	Description				
L1c, L2c	Power input of the control circuit	Connect to single-phase AC power (select the appropriate voltage specification according to the product)				
R, S, T	Power input of the main circuit	Connect to three-phase AC power (select the appropriate voltage specification according to the product)				
		Connect to the se	ervo motor			
	U, V, W FG	Terminal Symbol	Wire Color	Description		
II V W		U	Red	Three-phase main		
		V	White	power cable of the		
FG		W	Black	motor.		
		FG	Green	Connect to ground terminal (⊕) of the servo drive.		
		Internal resistor	The contact between P⊕ and D end should be closed; contact between P⊕ and C end should be opened.			
P⊕, D, C, ⊝		External resistor	Connect P⊕, C ends to the resist and the contact between P⊕ and end should be opened.			
,		External braking unit	P⊕ and P⊕ of the brake unit should connect to P⊕ and P⊕ respectively. The contact between P⊕ and D and P⊕ and C should be opened.			

3-2 Revision February, 2017

(1)	Ground terminal	Connect to the ground wire of power and servo motor.
CN1	I/O connector (Option)	Connect to the host controller. Please refer to section 3.4.
CN2	Connector (Option)	Connect encoder of the motor. Please refer to section 3.5.
CN3	Connector Option)	Connect to RS-485 or RS-232. Please refer to section 3.6.
CN4	USB connector (Type B) (Option)	Connect to personal computer (PC or notebook). Please refer to section 3.7.
CN5	Connector (Option)	Connect to linear scale or encoder for full-closed loop and motor feedback. Please refer to section 3.8.
CN6	CANopen connector (Option)	RJ45 connector. Please refer to section 3.9.
CN7	Extension digital input connector (Option)	Extension DI connector. Please refer to section 3.10.
CN8	Battery connector	Connector for absolute type of battery box


Pay special attention to the followings when wiring:

- 1. When the power is cutoff, do not touch R, S, T and U, V, W since the capacitance inside the servo drive still contains huge amount of electric charge. Wait until the charging light is off.
- 2. Separate R, S, T and U, V, W from the other wires. The interval should be at least 30 cm (11.8 inches).
- 3. If the wire of encoder CN2 or CN5 connecter is not long enough, please use shielded twisted-pair cable which cannot exceed 20 meters (65.62 inches). If it exceeds 20 meters, please choose the bigger wire diameter of signal cable to ensure it will not cause signal fading. As for the encoder wiring specification of 20-meter-long cable, please use AWG26 of wire size and metal braided shield twisted-pair cable which complies with the standard of UL 2464.
- 4. When using CANopen, please use the standard shielded twisted-pair cables to ensure the communication quality.
- 5. When selecting the wire rod, please refer to Section 3.1.6.
- 6. Do not install the plug-in capacitance in servo drive. It might burn out the soft-start resistance and danger will occur.

3.1.3 Wiring Method


The wiring method of 220V servo drive is divided into single-phase and three-phase. In the diagram below, Power On is contact **a**, Power Off and ALRM_RY are contact **b**. MC is the coil of magnetic contactor and self-remaining power and is the contact of main power circuit.

Wiring Method of Single-phase Power Supply (suitable for 1.5 kW and models below 1.5 kW)



Revision February, 2017

■ Wiring Method of Three-phase Power Supply (suitable for all series)



3.1.4 Specification of Motor Power Cable

Motor Model	U, V, W / Connector of Brake	Terminal Definition
ECMA-C1040F□S (50W) ECMA-C△0401□S (100W) ECMA-C△0602□S (200W) ECMA-C△0604□S (400W) ECMA-C△0604□H (400W) ECMA-C△0804□7 (400W) ECMA-C△0807□S (750W) ECMA-C△0807□S (750W) ECMA-C△0907□S (750W) ECMA-C△0910□S (1000W)	24 13 	Α
ECMA-C1040F□S (50W) ECMA-C△0401□S (100W) ECMA-C△0602□S (200W) ECMA-C△0604□S (400W) ECMA-C△0804□7 (400W) ECMA-C△0807□S (750W) ECMA-C△0910□S (1000W) *□ : with brake	36 25 14	В
ECMA-G△1303□S (300W) ECMA-E△1305□S (500W) ECMA-F△1305□S (500W) ECMA-G△1306□S (600W) ECMA-F△1308□S (850W) ECMA-G△1309□S (900W) ECMA-C△1010□S (1000W) ECMA-E△1310□S (1000W) ECMA-E△1315□S (1500W) ECMA-E△1315□S (1500W) ECMA-C△1020□S (2000W) ECMA-E△1320□S (2000W) ECMA-C△1330□A (3000W)	3106A-20-18S	С
ECMA-E△1820□S (2000W) ECMA-E△1830□S (3000W) ECMA-F△1830□S (3000W) ECMA-E△1835□S (3500W) ECMA-F△1845□S (4500W)	3106A-24-11S	D

3-6 Revision February, 2017

Motor Model	U, V, W / Connector of Brake	Terminal Definition
ECMA-F△1855□3 (5500W) ECMA-F△1875□3 (7500W) ECMA-F1221B□3 (11kW) ECMA-F1221F□S (15kW)	32-17S A D B C 3106A-32-17S	E
ECMA-F21855□3(5500W) ECMA-F21875□3(7500W)	3106A-10SL-4S	F

Wiring	U	V	W	CASE GROUND	BRAKE1	BRAKE2
Name	(Red)	(White)	(Black)	(Green)	(Yellow)	(Blue)
Α	1	2	3	4	-	-
В	1	2	4	5	3	6
С	F	I	В	E	G	Н
D	D	Е	F	G	Α	В
Е	Α	В	С	D	-	_

Wiring Name	BRAKE1	BRAKE2
F	Α	В


When selecting the wire rod, please choose 600V PVC cable and the length should not longer than 30m. If the length exceeds 30m, please take the received voltage into consideration when selecting the wire size. Please refer to Section 3.1.6 for wire rod selection.



- 1) No polarity for brake coil, the wiring name is BRAKE1 & BRAKE2.
- 2) Power for brake is DC24 V. Never share it with the power of control signal VDD.
- 3) Box, (\triangle) in servo motor model represents encoder type. \triangle = 1: incremental, 20-bit; \triangle = 2: incremental, 17-bit; \triangle = 3: 33-bit; \triangle = A: absolute.
- 4) Box, (□) in servo motor model represents brake or keyway / oil seal.

3.1.5 Specification of Encoder Cable Connector


Encoder Connection (Diagram 1)






This diagram shows the connection between the servo drive and the motor encoder. It is not drawn by the practical scale and specification will be different according to the selected servo drive and motor model.

- Please refer to the Section of Specification and Definition of Encoder Connector.
- 2) Please refer to Section 3.5 CN2 Connector.




3-8 Revision February, 2017

Specification and Definition of Encoder Connector:



If not using housing and directly wire the cores, please follow the corresponding core number for wiring. For example, core number 1 from the servo drive CN2 should connect to core number 1 from the motor encoder; core number 2 from the servo drive CN2 should connect to core number 2 from the motor encoder and so on. Please number the cores from the servo drive in order and then connect it to the encoder.

Encoder Connection (Diagram 2):





This diagram shows the connection between the servo drive and the motor encoder. It is not drawn by the practical scale and specification will be different according to the selected servo drive and motor model.

Please refer to Section 3.5, CN2 Connector.

Motor Model	Connector of En	code	r Cable	
ECMA-G△1303□S (300W) ECMA-E△1305□S (500W) ECMA-F△1305□S (500W)		Dia	Tamainal	
ECMA-G△1306□S (600W) ECMA-F△1308□S (850W)	View from this side	Pin No.	Terminal Identification	Color
ECMA-G△1309□S (900W)	, this	Α	T+	Blue
ECMA-C△1010□S (1000W)		В	Т-	Blue& Black
ECMA-E△1310□S (1000W) ECMA-F△1313□S (1300W)	C A M C	S	DC+5V	Red/Red &White
ECMA-E△1315□S (1500W) ECMA-F△1318□S (1800W) ECMA-C△1020□S (2000W)	E S 9	R	GND	Black/ Black& White
ECMA-E△1320□S (2000W) ECMA-E△1820□S (2000W)	3106A-20-29S Military Connector	L	BRAID SHIELD	_
ECMA-C△1330□4 (3000W) ECMA-E△1830□S (3000W)				

3-10 Revision February, 2017

ECMA-F△1830□S (3000W)	
ECMA-E∆1835□S (3500W)	
ECMA-F△1845□S (4500W)	
ECMA-F△1855□3 (5500W)	
ECMA-F△1875□3 (7500W)	
ECMA-F1221B□3 (11kW)	
ECMA-F1221F□S (15kW)	

Please select shielded multi-core and the shielded cable should connect to the SHIELD end. Please refer to the description of Section 3.1.6.



- 1) Box, (\triangle) in servo motor model represents encoder type. \triangle = 1: incremental, 20-bit; \triangle = 2: incremental, 17-bit; \triangle = 3: 2500ppr; \triangle = A: absolute.
- 2) Box, (\square) in servo motor model represents brake or keyway / oil seal.

3.1.6 Selection of Wiring Rod

The recommended wire rods are shown as the following table.

Servo Drive and corresponding Servo Motor		Power Wiring - Wire Diameter mm ² (AWG)				
Servo Drive and Cor	responding Servo Motor	L1c, L2c	R, S, T	U, V, W	P⊕, C	
ASD-A2-0121-□	ECMA-C1040F□S					
A3D-A2-0121-L	ECMA-C∆0401□S					
ASD-A2-0221-□	ECMA-C∆0602□S					
	ECMA-C∆0604□S					
	ECMA-C∆0604□H					
ASD-A2-0421-□	ECMA-C∆0804□7	4.0				
	ECMA-E∆1305□S	1.3 (AWG16)	2.1 (AWG14)	0.82 (AWG18)	2.1 (AWG14)	
	ECMA-G∆1303□S	(AVVO10)	(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	(/ (// 0 10)	(/ (// 0 / 1)	
	ECMA-F∆1305□S					
	ECMA-C∆0807□S					
ASD-A2-0721-□	ECMA-C∆0807□H					
	ECMA-C∆0907□S					
	ECMA-G∆1306□S					
	ECMA-C∆0910□S			1.3 (AWG16)	2.1 (AWG14)	
	ECMA-C∆1010□S	1.3 (AWG16)	2.1 (AWG14)			
ASD-A2-1021-□	ECMA-E△1310□S					
	ECMA-F∆1308□S					
	ECMA-G∆1309□S					
ASD-A2-1521-□	ECMA-E∆1315□S					
	ECMA-C∆1020□S	1.3	2.1	2.1	2.1	
	ECMA-E∆1320□S	(AWG16)	(AWG14)	(AWG14)	(AWG14)	
ASD-A2-2023-□	ECMA-E∆1820□S					
	ECMA-F∆1313□S					
	ECMA-F∆1318□S	4.0				
	ECMA-C△1330□S	1.3 (AWG16)	2.1 (AWG14)	3.3 (AWG12)	2.1 (AWG14)	
ASD-A2-3023-□	ECMA-E∆1830□S	(7.000)	(((
A3D-A2-3023-L	ECMA-E∆1835□S					
	ECMA-F∆1830□S					
ASD-A2-4523-□	ECMA-F∆1845□S	1.3 (AWG16)	3.3 (AWG12)	8.4 (AWG8)	3.3 (AWG12)	
ASD-A2-5523-□	ECMA-F△1855□3	1.3 (AWG16)	3.3 (AWG12)	13.3 (AWG6)	3.3 (AWG12)	
ASD-A2-7523-□	ECMA-F△1875□3	1.3 (AWG16)	5.3 (AWG10)	13.3 (AWG6)	3.3 (AWG12)	

3-12 Revision February, 2017

ASD-A2-1B23-□	ECMA-F1221B□3	1.3 (AWG16)	8.4 (AWG8)	13.3 (AWG6)	8.4 (AWG8)
ASD-A2-1F23-□	ECMA-F1221F□S	1.3 (AWG16)	13.3 (AWG6)	21.2 (AWG4)	13.3 (AWG6)


Servo Drive Model	Encoder Wiring - Wire Diameter mm ² (AWG)					
Servo Drive Moder	Size	Number	Specification	Standard Length		
ASD-A2-0121-□						
ASD-A2-0221-□						
ASD-A2-0421-□						
ASD-A2-0721-□						
ASD-A2-1021-□						
ASD-A2-1521-□						
ASD-A2-2023-□	0.13 (AWG26)	10 core (4 pair)	UL2464	3m (9.84ft.)		
ASD-A2-3023-□						
ASD-A2-4523-□						
ASD-A2-5523-□						
ASD-A2-7523-□						
ASD-A2-1B23-□						
ASD-A2-1F23-□						

NOTE

- 1) Please use shielded twisted-pair cable for encoder wiring so as to reduce the interference of the noise.
- 2) The shield should connect to the \oplus phase of SHIELD.
- 3) Please follow the Selection of Wire Rod when wiring in order to avoid the danger it may occur.
- 4) Box, (\square) at the end of the servo drive model represents the model code of ASDA-A2. Please refer to the model information of the product you purchased.
- 5) (\triangle), in servo motor model represents encoder type. \triangle = 1: incremental type, 20-bit; \triangle = 2: incremental type, 17, bit; \triangle = 3: 2500 ppr; \triangle = A: absolute type.
- 6) Box, (\Box) in servo motor model represents brake or keyway / oil seal.

3.2 Connections - 400V series

3.2.1 Connecting to Peripheral Devices



3-14 Revision February, 2017

Installation Notes:

Check if the power and wiring among R, S, T and DC24V, DC0V are correct.
 Please refer to Chapter 11 for Specifications. Make sure the input voltage is correct, or it might damage the servo drive or danger may occur.

- 2. Check if the output terminal U, V, W of the servo motor is correctly wired. The incorrect wiring may disable the operation of the motor or cause the malfunction.
- 3. When applying to the external regenerative resistor, the contact between P⊕ and D should be opened and the external regenerative resistor should connect to terminal P⊕ and C. When applying to the internal regenerative resistor, the contact between P⊕ and D should be closed and the contact between P⊕ and C should be opened.
- 4. When an alarm occurs or the system is in emergency stop status, use ALARM or WARN to output and disconnect the power of magnetic contactor in order to disconnect the power of servo drive.

3.2.2 Connectors and Terminals of the Servo Drive

Terminal Signal	Name		Description	n		
DC24V, DC0V	Power input of the control circuit		ngle-phase AC age specification	power (select the		
R, S, T	Power input of the main circuit	Connect to th appropriate volt product)	ree-phase AC age specification			
		Connect to serve	o motor			
		Terminal Symbol	Wire Color	Description		
U, V, W		U	Red	Three-phase main		
FG (⊕)	Motor cable	V	White	power cable of the motor		
10(0)		W	Black			
			Green	Connect to the grounding of the servo drive.		
		Internal resistor		etween P⊕ and D end ed; contact between P⊕ ald be opened.		
		External resistor	Connect P ⊕, C ends to the and the contact between P end should be opened.			
P⊕, D, C, ⊖	Regenerative resistor terminal or braking unit	External braking unit	P⊕ and P⊕ of the brake unit sho connect to P⊕ and P⊕ respectiv The contact between P⊕ and D a P⊕ and C should be opened. (N terminal is built in L1C, L2C, ⊕ an R, S, T.) P⊕: Connect (+) terminal of V_BU voltage.			
			: Connect to (-) terminal ofV_BUS voltage.			
(Ground terminal	Connect to the gmotor.	round wire of th	ne power and the servo		
CN1	I/O connector (Option)	Connect to the I 3.4.	nost controller,	please refer to Section		
CN2	Connector (Option)	Connect to the encoder of the motor, please refer to Section 3.5.				
CN3	Connector (Option)	Connect to RS-4	85 or RS-232,	please refer to Section		
CN4	USB connector (Type B) (Option)	Connect to personal computer (PC or NOTEBOOK), please refer to Section 3.7				
CN5	Connector (Option)	Connect to linear scale or encoder for full-closed loop and motor feedback. Please refer to Section 3.8.				

3-16 Revision February, 2017

CN6	CANopen connector (Option)	RJ45 connector, please refer to Section 3.9
CN7	Extension DI connector (Option)	Extension DI connector. Please refer to 3.10.
CN8	Battery connector	Connector for absolute type of battery box


Pay special attention to the followings when wiring:

- 1. When the power is cutoff, do not touch R, S, T and U, V, W since the capacitance inside the servo drive still contains huge amount of electric charge. Wait until the charging light is off.
- 2. Separate R, S, T and U, V, W from the other wires. The interval should be at least 30 cm (11.8 inches).
- 3. If the wire of encoder CN2 or CN5 connecter is not long enough, please use shielded twisted-pair cable which cannot exceed 20 meters (65.62 inches). If it exceeds 20 meters, please choose the bigger wire diameter of signal cable to ensure it will not cause signal fading. As for the encoder wiring specification of 20-meter-long cable, please use AWG26 of wire size and metal braided shield twisted-pair cable which complies with the standard of UL 2464.
- 4. When using CANopen, please use the standard shielded twisted-pair cables to ensure the communication quality.
- 5. When selecting the wire rod, please refer to Section 3.2.6.
- 6. Do not install the plug-in capacitance in servo drive. It might burn out the soft-start resistance and danger will occur.

3.2.3 Wiring Method

The wiring method of 400V servo drive is divided into single-phase and three-phase. In the diagram below, Power On is contact **a**, Power Off and ALRM_RY are contact **b**. MC is the coil of magnetic contactor and self-remaining power and is the contact of main power circuit.

■ Wiring Method of Three-phase Power Supply (suitable for all series of 400 V servo drive)



3-18 Revision February, 2017

3.2.4 Specification of Motor Power Cable

Motor Model	U, V, W / Connector of Brake	Terminal Definition
ECMA-J△0604□S (400W) ECMA-J△0807□S (750W) ECMA-J△0907□S (750W) ECMA-J△0910□S (1000W)	24	А
ECMA-J△0604□S (400W) ECMA-J△0807□S (750W) ECMA-J△0907□S (750W) ECMA-J△0910□S (1000W) *□ : with brake	36 25 14	В
ECMA-K△1305□S (500W) ECMA-L△1305□S (500W) ECMA-L△1308□S (850W) ECMA-M△1309□S (900W) ECMA-J△1010□S (1000W) ECMA-K△1310□S (1000W) ECMA-L△1313□S (1300W) ECMA-K△1315□S (1500W) ECMA-J△1020□S (2000W) ECMA-K△1320□S (2000W) ECMA-J△1330□4 (3000W)	3106A-20-18S	С
ECMA-L△1830□S (3000W) ECMA-L△1845□S (4500W) ECMA-L△1855□3 (5500W) ECMA-L△1875□3 (7500W) ECMA-K△1820□S (2000W)	3106A-24-11S	D

Wiring Name	U (Red)	V (White)	W (Black)	CASE GROUND (Green)	BRAKE1 (Yellow)	BRAKE2 (Blue)
Α	1	2	3	4	-	-
В	1	2	4	5	3	6
С	F	I	В	E	G	Н
D	D	E	F	G	Α	В

When selecting the wire rod, please choose 600V PVC cable and the length should not longer than 30m. If the length exceeds 30m, please take the received voltage into consideration when selecting the wire size. Please refer to Section 3.1.6 for wire rod selection.




- 1) No polarity for brake coil, the wiring name is BRAKE1 & BRAKE2.
- 2) Power for brake is DC24 V. Never share it with the power of control signal VDD.
- 3) Box, (\triangle) in servo motor model represents encoder type. \triangle = 1: incremental, 20-bit; \triangle = 2: incremental, 17-bit; \triangle = 3: 2500 ppr; \triangle = A: absolute.
- 4) Box, (\Box) in servo motor model represents brake or keyway / oil seal.

3-20 Revision February, 2017

3.2.5 Specification of Encoder Connector


Encoder Connection (Diagram 1):






This diagram shows the connection between the servo drive and the motor encoder. It is not drawn by the practical scale and specification will be different according to the selected servo drive and motor model.

- 1) Please refer to the Section of Specification and Definition of Encoder Connector.
- 2) Please refer to Section 3.5 CN2 Connector.



Encoder Connection (Diagram 2):





This diagram shows the connection between the servo drive and the motor encoder. It is not drawn by the practical scale and specification will be different according to the selected servo drive and motor model.

Please refer to Section 3.5, CN2 Connector.

Motor Model	Connector of Encoder Cable			
ECMA-K△1305□S (500W) ECMA-L△1305□S (500W)	View from this side	Pin No.	Terminal Identification	Color
ECMA-L△1308□S (850W)		Α	T+	Blue
ECMA-M△1309□S (900W) ECMA-J△1010□S (1000W)	B A M	В	T -	Blue& Black
ECMA-K△1310□S (1000W) ECMA-L△1313□S (1300W)	C P N T C	S	DC+5V	Red/Red &White
ECMA-K△1315□S (1500W) ECMA-J△1020□S (2000W)	Ep 9	R	GND	Black/ Black& White
ECMA-K△1320□S (2000W) ECMA-J△1330□4 (3000W)	3106A-20-29S Military Connector	L	BRAID SHIELD	_

3-22 Revision February, 2017

Please select shielded multi-core and the shielded cable should connect to the SHIELD end. Please refer to the description of Section 3.1.6.



- 1) Box, (\triangle) in servo motor model represents encoder type. \triangle = 1: incremental, 20-bit; \triangle = 2: incremental, 17-bit; \triangle = 3: 2500 ppr; \triangle = A: absolute
- 2) Box, (\square) in servo motor model represents brake or keyway / oil seal.

3.2.6 Selection of Wiring Rod

Servo Drive and corresponding Servo		Power Wiring - Wire Diameter mm ² (AWG)			
М	otor	DC24V, DC0V	R, S, T	U, V, W	P⊕, C
	ECMA-J∆0604□S			0.82 (AWG18)	2.1 (AWG14)
	ECMA-J∆0807□S		0.82 (AWG18)		
ASD-A2-0743-□	ECMA-J∆0907□S	1.3 (AWG16)			
	ECMA-K∆1305□S	(71113)	(/ (// 0 10)	(/11/010)	(/ (// 3/1)
	ECMA-L∆1305□S				
	ECMA-J∆0910□S				
ASD-A2-1043-□	ECMA-K∆1310□S		0.82 (AWG18)	1.3 (AWG16)	2.1 (AWG14)
	ECMA-L∆1308□S	1.3 (AWG16)			
	ECMA-J△1010□S				
ASD-A2-1543-□	ECMA-K∆1315□S				
ASD-A2-1543-□	ECMA-M∆1309□S				
	ECMA-L∆1313□S				
	ECMA-J∆1020□S				
ASD-A2-2043-□	ECMA-K∆1320□S				
	ECMA-K∆1820□S				
ASD-A2-3043-□	ECMA-L∆1830□S	1.3	1.3	1.3 (AWG16)	2.1
ASD-A2-3043-L	ECMA-J∆1330□4	(AWG16)	(AWG16)		(AWG14)
ASD-A2-4543-□	ECMA-L∆1845□S	1.3	2.1	3.3	3.3
ASD-A2-5543-□	ECMA-L∆1855□3	(AWG16)	(AWG14)	(AWG12)	(AWG12)
ASD-A2-7543-□	ECMA-L∆1875□3	1.3 (AWG16)	3.3 (AWG12)	5.3 (AWG10)	3.3 (AWG12)

Servo Drive Model	Encoder Wiring - Wire Diameter mm ² (AWG)					
Servo Drive Moder	Size	Number	Specification	Standard Length		
ASD-A2-0743-□						
ASD-A2-1043-□) 10 core (4 pair)	UL2464			
ASD-A2-1543-□						
ASD-A2-2043-□	0.42 (A)M(C)(C)			2 (0.04#)		
ASD-A2-3043-□	0.13 (AWG26)			3m (9.84ft.)		
ASD-A2-4543-□						
ASD-A2-5543-□						
ASD-A2-7543-□						

NOTE


- 1) Box, (\square) at the end of the servo drive model represents the model code of ASDA-A2. Please refer to the model information of the product you purchased.
- 2) (\triangle), in servo motor model represents encoder type. \triangle = 1: incremental type, 20-bit; \triangle = 2: incremental type, 17, bit; \triangle = 3: 2500 ppr; \triangle = A: absolute type.
- 3) Box, (\Box) in servo motor model represents brake or keyway / oil seal.
- 4) Please use shielded twisted-pair cable for encoder wiring so as to reduce the interference of the noise.
- 5) The shield should connect to the
 phase of SHIELD.
- 6) Please follow the Selection of Wire Rod when wiring in order to avoid the danger it may occur.

3-24 Revision February, 2017


3.3 Basic Wiring

3.3.1 **220V** series

■ 200W (included) or models below (without built-in regenerative resistor)




■ 400W ~ 4.5 kW models (with built-in regenerative resistor)




3-26 Revision February, 2017

■ 5.5kW to 15kW models (with built-in fan but no regenerative resistor)




3.3.2 400V series

■ 750W to 1.5kW models (with built-in regenerative resistor and fan)



3-28 Revision February, 2017


■ 2kW to 7.5kW models (with built-in fan but no regenerative resistor)




3.4 I/O Signal (CN1) Connection


3.4.1 I/O Signal (CN1) Connector Terminal Layout

In order to have a more flexible communication with the master, 5 programmable Digital Outputs (DO) and 8 programmable Digital Inputs (DI) are provided. The setting of 8 digital inputs and 5 digital outputs of each axis are parameter P2-10~P2-17 and parameter P2-18~P2-22 respectively. In addition, the differential output encoder signal, A+, A-, B+, B-, Z+ and Z-, input of analog torque command, analog speed/position command and pulse position command are also provided. The followings are the pin diagrams.



CN1 Connector (female)





The rear wiring terminal of CN1 connector

3-30 Revision February, 2017

	ı		1	DO4+	Digital output		ı	,	26	DO4-	Digital output
2	DO3-	Digital output	3	DO3+	Digital output	27	DO5-	Digital output	28	DO5+	Digital autout
4	DO2-	Digital output	3	DO3+	Digital output	29	/HPULSE	High-speed	20	DO5+	Digital output
			5	DO2+	Digital output	•		position pulse (-)	30	DI8-	Digital input
6	DO1-	Digital output				31	DI7-	Digital input			
			7	DO1+	Digital output				32	DI6-	Digital input
8	DI4-	Digital input	9	DI1-	Digital input	33	DI5-	Digital input	24	DI3-	Digital input
10	DI2-	Digital input	9	-ווטן	Digital input	35	PULL	Pulse applied	34	טוט-	Digital input
	DIZ.	Digital ilipat	11	COM+	Power input (12~24V)		HI_S (SIGN)	power (SIGN)	36	SIGN	Position sign (+)
12	GND	Analog input				37	/SIGN	Position sign			,
		signal ground	13	GND	Analog input			(-)	38	HPULSE	High-speed
14	NC	No Connection			signal ground	39	PULL HI_P	Pulse applied Power			position pulse (+)
			15	MON2	Analog monitor		(PULSE)	(PULSE)	40	/HSIGN	High-speed
16	MON1	Analog monitor output 1			output 2	41	/PULSE	Pulse input (-)			position sign (-)
		1	17	VDD	+24V power				42	V_REF	Analog speed
18	T_REF	Analog torque Input			output (for external I/O)	43	PULSE	Pulse input (+)			input (+)
			19	GND	Analog input				44	GND	Analog input
20	VCC	+12V power output			signal ground	45	COM-	VDD(24V) power			signal ground
		(for analog command)	21	OA	A pulse			ground	46	HSIGN	High-speed position sign (+)
22	/OA	Encoder			output	47	COM-	VDD(24V)			()
		/A pulse output	23	/OB	Encoder /B pulse			power ground	48	OCZ	Encoder Z pulse open-
24	/OZ	Encoder /Z pulse			output	49	COM-	VDD(24V)			collector output
		output	25	ОВ	Encoder B pulse			power ground	50	OZ	Encoder Z pulse line- driver output
					output						unver output



NC means NO CONNECTION. This terminal is for internal use only. Do not connect it, or it may damage the servo drive.

3.4.2 Signals Explanation of Connector CN1

The following details the signals listed in previous section:

General Signals

Tierai Oigilais	•			
S	ignal	Pin No	Function	Wiring Method (Refer to 3.4.3)
Analog Command (input)	V_REF	42	 (1) The speed command of the motor is -10 V ~ +10 V which means the speed command is -3000 ~ +3000 r/min (default). It can change the corresponding range via parameters. (2) The position command of the motor is -10 V ~ +10 V which means the position command is -3 cycles ~ +3 cycles (default). 	C1
	T_REF	18	The torque command of the motor is -10 V \sim +10 V which means the rated torque command of -100 % \sim +100 %.	C1
Analog Monitor (output)	MON1 MON2	16 15	The operating state of the motor can be shown by analog voltage, such as speed and current. This drive provides two channel outputs. Users can select the desired monitoring data via parameter P0-03. This signal is based on the power ground.	C2
			Position pulse can be inputted by Line Driver	C3/C4
Position Pulse (input)	PULSE /PULSE SIGN /SIGN PULL HI_P PULL HI_S		(single phase max. frequency 500KHz) or open-collector (single phase max. frequency 200 KHz). Three kinds of command type can be selected via P1-00, CW pulse + CCW pulse, pulse + direction, A pulse + B pulse. When position pulse uses open-collector, the terminal should be connected to an external applied power in order to pull high.	C3/C4
High- speed Position Pulse (input)	HPULSE /HPULSE HSIGN /HSIGN	38 29 46 40	Position pulse can be inputted by Line Driver (single phase max. frequency 500KHz) or open-collector (single phase max. frequency 200 KHz). Three kinds of command type can be selected via P1-00, CW pulse + CCW pulse, pulse + direction, A pulse + B pulse. When position pulse uses open-collector, the terminal should be connected to an external applied power in order to pull high.	C4-2
	OA /OA	21 22		
Position Pulse	OB /OB	25 23	Encoder signal output A, B, Z (Line Drive output)	C13/C14
(output)	OZ /OZ	50 24		
	OCZ	48	Encoder signal output Z (Open-collector output)	-
			. , , , , , , , , , , , , , , , , , , ,	

3-32 Revision February, 2017

	VDD	17	VDD is the +24 V power provided by the drive and is for Digital Input (DI) and Digital Output (DO) signal. The maximum current is 500 mA.
Power	COM+ COM-	11 45 47 49	COM+ is the common input of Digital Input (DI) and Digital Output (DO) voltage. When using VDD, VDD should be connected to COM+. If not using, it needs to apply the external power (+12 V \sim + 24 V). Its positive end should connect to COM+ and the negative end should connect to COM
	VCC	20	VCC is the +12V power provided by the drive. It is used for providing the simple analog command (speed or torque command). The maximum current is 100 mA.
	GND	12, 13, 19, 44	
Other	NC	14	NO CONNECTION. This terminal is for internal use only. Do not connect it, or it may damage the servo drive.

There are numerous operation mode of this servo drive (please refer to Chapter 6.1). Each operation mode needs different I/O signal. In order to use the terminal in a more efficient way, the selection of I/O signal has to be programmable. That is to say, users can choose the desired DI/DO signal to meet the demand. Basically, the default setting of DI/DO signal has already have the appropriate function which can satisfy the demand of normal application.

Users have to select the operation mode based on the needs first (please refer to Chapter 6.1 for the introduction of each mode) and refer to the following DI/DO table to know the corresponding default setting of DI/DO signal and Pin No of the selected mode in order to conduct the wiring.

The table below lists the default setting of DI/DO signal function and pin No:

The explanation of DO signal default setting is as the followings.

DO Signal Name			in o.	Details	Wiring Method (Refer to 3.4.3)
SRDY	ALL	7	6	When the servo drive applies to the power and no alarm (ALRM) occurs in control circuit and motor power circuit, this DO is ON.	
SON	N/A	-	-	When the DI.SON is ON and the motor servo circuit can operate smoothly, this DO is ON.	C5/C6/C7/
ZSPD	ZSPD ALL 5 4 When		4	When the motor speed is slower than the setting value of parameter P1-38, this DO is ON.	C8
TSPD (except - PT, PR)			-	When the motor actual speed (r/min) is faster than the setting value of parameter P1-39, this DO is ON.	

DO Signal Name	Operation Mode		in o.	Details	Wiring Method (Refer to 3.4.3)
TPOS	PT, PR, PT-S, PT-T, PR-S, PR-T	1	26	When the deviation between the motor command and actual position (PULSE) is smaller than the setting value of parameter P1-54, this DO is ON.	
TQL N/A		-	-	When torque is limiting, this DO is ON.	
ALRM ALL		28	27	When the alarm occurs (except forward/reverse limit, emergency stop, communication error, under voltage), this DO is ON.	
BRKR	ALL	-	-	Control contact of brake.	
HOME	ALL	3	2	When homing is completed, this DO is ON.	
OLW	ALL	-	-	When the overload level is reached, this DO is ON.	
WARN	ALL	-	-	A warning occurs. When it is in the status of forward/reverse limit, emergency stop, communication error, under voltage, this DO is ON.	
OVF	PT, PR	-	-	Position command /feedback overflows	
SNL (SCWL)	PR	-	-	Reverse software limit	
SPL (SCCWL)	PR	-	-	Forward software limit	C5/C6/C7/
Cmd_OK	PR	-	-	The output of internal position command is completed.	C8
CAP_OK	PR	-	-	CAPTURE procedure is completed.	
MC_OK	PR	-	-	When DO.Cmd_OK and TPOS are ON, this DO is ON.	
CAM_AREA	PR	-	-	The master position of E-CAM is inside the setting area.	
S_CMP	S, Sz	-	-	When the deviation between the speed command and the feedback speed of the motor is smaller than the setting value of parameter P1-47, this DO is ON.	
SDO_0	ALL	-	-	Output the status of bit00 of P4-06	
SDO_1	ALL	-	-	Output the status of bit01 of P4-06	
SDO_2	ALL	-	-	Output the status of bit02 of P4-06	
SDO_3 ALL		-	-	Output the status of bit03 of P4-06	
SDO_4					
SDO_5	_				
SDO_6	ALL	-	-	Output the status of bit06 of P4-06	
SDO_7	ALL	-	-	Output the status of bit07 of P4-06	
SDO_8	ALL	-	-	Output the status of bit08 of P4-06	

3-34 Revision February, 2017

DO Signal Name	Operation Mode		in o.	Details	Wiring Method (Refer to 3.4.3)
SDO 9	ALL	ALL		Output the status of bit09 of P4-06	,
SDO A	ALL	_	_	Output the status of bit10 of P4-06	
SDO_B	ALL	_	_	Output the status of bit11 of P4-06	
SDO_C	ALL	-	-	Output the status of bit12 of P4-06	C5/C6/C7/
SDO_D	ALL	-	-	Output the status of bit13 of P4-06	C8
SDO_E	_		-	Output the status of bit14 of P4-06	+
_		-	Output the status of bit15 of P4-06		

NOTE

- 1) For example, if the user selects PR mode, pin 3 and 2 are HOME. If the user selects S mode, pin 3 and 2 are TSPD.
- 2) The unlisted Pin No means the signal is not the preset one. If users want to use it, parameters need to be changed and set as the desired ones. Please refer to Section 3.4.4 for further details.

The explanation of DI signal default setting is as the followings

DI Signal Name	Operation Mode	Pin No.	Function	Wiring Method (Refer to 3.4.3)
SON	ALL	9	When DI is ON, the servo circuit will be activated and the motor coil will generate current.	
ARST	ALL	33	When the alarm (ALRM) occurs, this signal is used to reset the servo drive and output the signal, Ready (SRDY) again.	
GAINUP	ALL	-	It is for switching the controller gain.	
CCLR	PT, PR	10	It is for clearing the deviation counter.	00/0/0/0
ZCLAMP	ALL	-	When this DI is ON and the motor speed is slower than the setting of P1-38, the motor position will be locked when the signal is triggered.	C9/C10/C 11 /C12
CMDINV	PR, T, S	-	When this DI is ON, the motor will operate in the opposite direction.	
CTRG	PR, PR-S, PR-T	10	In PR mode, the moment CTRG is ON (rising edge), save the position command selected by POS0~2 into the controller and then trigger the command.	
TRQLM	S, Sz	10	ON means the torque limit command is effective.	

DI Signal Name	Operation Mode	Pin No.					Fur	nctior	า			Wiring Method (Refer to 3.4.3)	
SPDLM	T, Tz	10	ON mea	ns the	spe	ed lin	nit co	omma	and is	effec	tive.		
POS0		34	In PR mo	ode, th	ne sc	urce	of p	ositio	n cor	nman	d:		
POS1		8	Position command		POS 4	POS 3	POS 2	POS 1	POS0	CTRG	Corresponding parameter		
POS2		_	P1	0	0	0	0	0	0	†	P6-00		
POS3					U	0	0	U	"	l	P6-01		
		-	P2	0	0	0	0	0	1	†	P6-02		
POS4	P, PR,	-		-						I	P6-03		
	PR-S, PR-T		~							•	P6-98		
		PR-T		P50	1	1	0	0	1	0	T	P6-99	
													P7-00
POS5		-	P51	1	1	0	0	1	1		P7-01		
				~								~	
			P64	1	1	1	1	1	1	†	P7-26		
				P7-27									
STOP	-	-	Stop										
SPD0		34	The sour	ce of	sele	cting	spee	ed co	mma	nd:			
	S, Sz,		SPD1	SPD0		Com	mand s	source				C9/C10/	
	PT-S,		0	0 S mode is analog input; Sz mode is 0									
SPD1	PR-S, S-T	8	0	1		P1-09							
			1 0			P1-10							
			1	1 1 P1-11								-	
TCM0		34	The sour	ce of	sele	cting	torqu	ie co	mma	nd:			
	PT, T, Tz,		TCM1	TCM0				source					
T0144	PT-T,	•	0	0				ınalog	input; T	z mode	is 0		
TCM1	PR-T, S-T	8	1	0		P1-12							
			1	1		P1-14							
S-P	PT-S, PR-S	31	Mode sw	ode switching. OFF: Speed; ON: Position								-	
S-T	S-T	31	Mode sw	ode switching. OFF: Speed; ON: Torque								-	
T-P	PT-T, PR-T	31	Mode sw	ode switching. OFF: Torque; ON: Position									
PT-PR	PT, PR	-	users ca	nen selecting PT-PR mode or the multi-mode, PT-PR-S, ers can select the source via this DI. When this DI is F, it is in PT mode. When this DI is ON, it is in PR ode.									

3-36 Revision February, 2017

DI Signal Name	Operation Mode	Pin No.	Function	Wiring Method (Refer to 3.4.3)
EMGS	ALL	30	It is contact B and has to be ON frequently; otherwise the alarm (ALRM) will occur.	
NL(CWL)	PT, PR, S, T, Sz, Tz	32	Reverse inhibit limit (contact B) and has to be ON frequently; or the alarm (ALRM) will occur.	
PL (CCWL)	PT, PR, S, T, Sz, Tz	31	Forward inhibit limit (contact B) and has to be ON frequently; or the alarm (ALRM) will occur.	
ORGP	PR	-	When DI is ON, the drive will start homing.	
SHOM	PR	-	In PR mode, it needs to search the origin. When this DI is ON, the origin searching function is activated. (Please refer to the setting of parameter P1-47.)	
CAM	PR	-	E-cam engaging control (please refer to the setting of value U and Z of P5-88.)	
JOGU	ALL	-	When this DI is ON, the motor JOG operates in forward direction.	C9/C10/C
JOGD	ALL	-	When this DI is ON, the motor JOG operates in reverse direction.	11 /C12
EV1	PR	-	Event trigger PR command	
EV2	PR	-	Event trigger PR command	
EV3	PR	-	Event trigger PR command	
EV4	PR	-	Event trigger PR command	
GNUM0 PT, PR, PT-S, - PR-S		-	Electronic gear ratio (numerator) selection 0 (Please refer to P2-60~P2-62 for gear ratio selection (numerator).)	
GNUM1	PT, PR, PT-S, PR-S - Electronic gear ratio (numerator) selection 1 (Please refer to P2-60~P2-62 for gear ratio selection (numerator).)			
INHP	INHP PT, PT-S - In position mode, when this DI is ON, the external pulse input command is not working.		•	

The default setting of DI and DO in each operation mode is shown as the followings. Please note that the following table neither detail the information as the previous one nor show the Pin number of each signal. However, each operation mode is separated in different columns in order to avoid the confusion.

Table 3.1 Default Value of DI Input Function

Symbol	DI Code	Input Function	PT	PR	S	Т	Sz	Tz	PT- S	PT- T	PR-S	PR- T	S-T
SON	0x01	Servo On	DI1	DI1	DI1	DI1	DI1	DI1	DI1	DI1	DI1	DI1	DI1
ARST	0x02	Alarm Reset	DI5	DI5	DI5	DI5	DI5	DI5					
GAINUP	0x03	Gain switch											
CCLR	0x04	Pulse clear	DI2						DI2	DI2			
ZCLAMP	0x05	Zero speed CLAMP											
CMDINV	0x06	The input command will be in reverse direction.											
Reserved	0x07	Reserved											
CTRG	0x08	Internal position command triggered		DI2							DI2	DI2	
TRQLM	0x09	Torque limit			DI2		DI2						
SPDLM	0x10	Speed limit				DI2		DI2					
POS0	0x11	Internal position command selection 0		DI3							DI3	DI3	
POS1	0x12	Internal position command selection 1		DI4							DI4	DI4	
POS2	0x13	Internal position command selection 2											
POS3	0x1A	Internal position command selection 3											
POS4	0x1B	Internal position command selection 4											
POS5	0x1C	Internal position command selection 5											
STOP	0x46	Motor stops											
SPD0	0x14	Speed command selection 0			DI3		DI3		DI3		DI5		DI3
SPD1	0x15	Speed command selection 1			DI4		DI4		DI4		DI6		DI4
ТСМ0	0x16	Torque command selection 0	DI3			DI3		DI3		DI3		DI5	DI5
TCM1	0x17	Torque command selection 1	DI4			DI4		DI4		DI4		DI6	DI6
S-P	0x18	Mode switch between speed and position command							DI7		DI7		
S-T	0x19	Mode switch between speed and torque command											DI7
T-P	0x20	Mode switch between								DI7		DI7	

3-38 Revision February, 2017

Symbol	DI Code	Input Function	PT	PR	S	Т	Sz	Tz	PT-S	PT- T	PR-S	PR- T	S-T
		torque and position command											
PT-PR	0x2B	Switch between PT and PR command											
EMGS	0x21	Emergency stop	DI8	DI8	DI8	DI8	DI8	DI8	DI8	DI8	DI8	DI8	DI8
NL(CWL)	0x22	Reverse inhibit limit	DI6	DI6	DI6	DI6	DI6	DI6					
PL(CCWL)	0x23	Forward inhibit limit	DI7	DI7	DI7	DI7	DI7	DI7					
ORGP	0x24	Original point of homing											
SHOM	0x27	Homing is activated											
CAM	0x36	E-Cam engaged											
JOGU	0x37	Forward JOG input											
JOGD	0x38	Reverse JOG input											
EV1	0x39	Event trigger PR command #1(refer to the setting of P5-98, P5-99)											
EV2	0x3A	Event trigger PR command #2 (refer to the setting of P5-98, P5-99)											
EV3	0x3B	Event trigger PR command #3 firmware V1.008 sub04 will be provided afterwards)											
EV4	0x3C	Event trigger PR command #4 (firmware V1.008 sub04 will be provided afterwards)											
GNUM0	0x43	Electronic gear ratio (numerator) selection 0											
GNUM1	0x44	Electronic gear ratio (numerator) selection 1											
INHP	0x45	Pulse input inhibit											




Table 3.2 Default Value of DO Output Function

		•											
Symbol	DO Code	Output Function	PT	PR	S	Т	Sz	Tz	PT- S	PT- T	PR- S	PR- T	S-T
SRDY	0x01	Servo is ready	DO1	DO1	DO1	DO1	DO1	DO1	DO1	DO1	DO1	DO1	DO1
SON	0x02	Servo is On.											
ZSPD	0x03	Zero-speed reached	DO2	DO2	DO2	DO2	DO2	DO2	DO2	DO2	DO2	DO2	DO2
TSPD	0x04	Reach the target speed			DO3	DO3	DO3	DO3	DO3	DO3	DO3	DO3	DO3
TPOS	0x05	Reach the target position	DO4	DO4					DO4	DO4	DO4	DO4	DO4
TQL	0x06	Torque limit											
ALRM	0x07	Servo alarm	DO5	DO5	DO5	DO5	DO5	DO5	DO5	DO5	DO5	DO5	DO5
BRKR	80x0	Brake			DO4	DO4	DO4	DO4					
HOME	0x09	Homing complete	DO3	DO3									
OLW	0x10	Early warning for overload											
WARN	0x11	Servo warning											
OVF	0x12	Position command /feedback overflows											
SNL (SCWL)	0x13	Reverse software limit											
SPL (SCCWL)	0x14	Forward software limit											
Cmd_OK	0x15	Internal position command is completed											
CAP_OK	0x16	Capture procedure is completed											
MC_OK	0x17	Servo procedure is completed											
CAM_AREA	0x18	Master position area of E-CAM											
SP_OK	0x19	Target speed reached											
SDO_0	0x30	Output the status of bit00 of P4-06											
SDO_1	0x31	Output the status of bit01 of P4-06											
SDO_2	0x32	Output the status of bit02 of P4-06											
SDO_3	0x33	Output the status of bit03 of P4-06											
SDO_4	0x34	Output the status of bit04 of P4-06											


3-40 Revision February, 2017


Symbol	DO Code	Output Function	PT	PR	S	Т	Sz	Tz	PT-S	PT- T	PR-S	PR- T	S-T
SDO_5	0x35	Output the status of bit05 of P4-06											
SDO_6	0x36	Output the status of bit06 of P4-06											
SDO_7	0x37	Output the status of bit07 of P4-06											
SDO_8	0x38	Output the status of bit08 of P4-06											
SDO_9	0x39	Output the status of bit09 of P4-06											
SDO_A	0x3A	Output the status of bit10 of P4-06											
SDO_B	0x3B	Output the status of bit11 of P4-06											
SDO_C	0x3C	Output the status of bit12 of P4-06											
SDO_D	0x3D	Output the status of bit13 of P4-06											
SDO_E	0x3E	Output the status of bit14 of P4-06											
SDO_F	0x3F	Output the status of bit15 of P4-06											



3.4.3 Wiring Diagrams (CN1)


The valid voltage of speed analog command and torque analog command is between -10V and +10V. The command value can be set via relevant parameters. The input impedance is $10K\Omega$.






3-42 Revision February, 2017

Pulse command can be input by the way of open-collector or Line driver. The maximum input pulse of Line driver is 500 kpps and 200 kpps for open-collector.






NOTE Resistor of $1K\Omega(1w)$ has to be connected.



> Caution: Do not apply to dual power or it may damage the servo drive.


C3-3: The source of pulse input is open-collector NPN equipment and applies the external power.





> Caution: Do not apply to dual power or it may damage the servo drive.

C3-4: The source of pulse input is open-collector PNP equipment and applies the external power.






NOTE Resistor of $1K\Omega(1w)$ has to be connected.

3-44 Revision February, 2017


C4-1: Pulse input (Line driver) can only apply to 5V power. Do not apply to 24V power.





> This opto-isolator is one-way input, please be ensured the direction of current of pulse input is correct.

C4-2: High-speed pulse input (Line driver) can only apply to 5V power. Do not apply to 24V power.







The high-speed pulse input interface of the servo drive is not the isolated interface. In order to reduce the interference of the noise, it is suggested that the terminal ground of the controller and the servo drive should be connected to each other.

When the drive connects to inductive load, the diode has to be installed. (The permissible current is under 40mA. The surge current is under 100mA.)


C5: Wiring of DO signal. The servo drive applies to the internal power and the resistor is general load.




C6: Wiring of DO signal. The servo drive applies to the internal power and the resistor is inductive load.



3-46 Revision February, 2017





Input signal via relay or open-collector transistor

NPN transistor, common emitter (E) mode (SINK mode)

C9: The wiring of DI. The servo drive applies to the internal power.


C10: The wiring of DI. The servo drive applies to the external power.

Servo Drive


COM+
Approx.
4.7KΩ
SON

PNP transistor, common emitter (E) mode (SOURCE mode)

C11: The wiring of DI. The servo drive applies to the internal power.




C12: The wiring of DI. The servo drive applies to the external power.







> Caution: Do not apply to dual power or it may damage the servo drive.

3-48 Revision February, 2017







3.4.4 DI and DO Signal Specified by Users

If the default setting of DI/DO signal cannot satisfy the need, self-set the DI/DO signal will do and easy. The signal function of DI1 \sim 8, DI9 \sim DI13 and DO1 \sim 5 is determined by parameter P2-10 \sim P2-17 and parameter P2-18 \sim P2-22 respectively. Please refer to Chapter 7.2, which shown as the following table. Enter DI or DO code in the corresponding parameter to setup DI/DO.


Signal Name		Pin No	Corresponding Parameter
	DI1-	CN1-9	P2-10
	DI2-	CN1-10	P2-11
	DI3-	CN1-34	P2-12
Standard	DI4-	CN1-8	P2-13
DI	DI5-	CN1-33	P2-14
	DI6-	CN1-32	P2-15
	DI7-	CN1-31	P2-16
	DI8-	CN1-30	P2-17
	EDI9	CN7-2	P2-36
	EDI10	CN7-3	P2-37
Extension DI (optional)	EDI11	CN7-4	P2-38
	EDI12	CN7-5	P2-39
	EDI13	CN7-6	P2-40
	EDI14	CN7-7	P2-41


Signal Name		Pin No	Corresponding Parameter
	DO1+	CN1-7	P2-18
	DO1-	CN1-6	P2-10
	DO2+	CN1-5	P2-19
	DO2-	CN1-4	P2-19
Standard	DO3+	CN1-3	P2-20
DO	DO3-	CN1-2	F Z-ZU
	DO4+	CN1-1	P2-21
	DO4-	CN1-26	PZ-Z I
	DO5+	CN1-28	P2-22
	DO5-	CN1-27	Γ ∠- Ζ ∠


3.4.5 Application: Using CN1 Quick Connector for Wiring

ASD-IF-SC5020 CN1 quick connector is designed for easy wiring. It is applicable to ASDA-A2 and ASDA-A2R series servo drive and can satisfy the demand of different DI/O application. It will be a good choice for those who do not want to self-weld the wiring rods. The vibration will not lose the leading wire due to the design of spring terminal blocks. It is rather convenient and fast when wiring and under construction. 5 digital inputs, 4 digital outputs, pulse command inputs and Z phase open-collector outputs are included.


Pin definition is as the following:








3-50 Revision February, 2017







	J2	J1		
PIN	Description	PIN	Description	
1	VDD	17	VDD	
2	COM+	11	COM+	
3	COM-	2,4,6,26,45,47	COM-	
4	DI1-	9	DI1-	
5	DI2-	10	DI2-	
6	DI3-	34	DI3-	
7	DI4-	8	DI4-	
8	DI7-	31	DI7-	
9	DO1+	7	DO1+	
10	DO2+	5	DO2+	
11	PULL_HI_PS	35	PULL_HI_PS	
12	/PULSE	41	/PULSE	
13	PULSE	43	PULSE	
14	/SIGN	37	/SIGN	
15	SIGN	36	SIGN	
16	OCZ	48	OCZ	
17	GND	12,13,19,44	GND	

J2		J1		
PIN	Description	PIN	Description	
18	DO4+	1	DO4+	
19	DO3+	3	DO3+	
20	CN_GND	51,52	CN_GND	

Example of wiring:






3-52 Revision February, 2017

Wiring and installation of CN1 quick connector:

Wiring:




Installation:




3.5 CN2 Connector


The terminal block of the connector and pin number are as follows:




(A) CN2 Connector



(B) Encoder Connector





3-54 Revision February, 2017

The definition of each signal is as follows:

	Drive Co	nnector	Encoder Connector		
PIN No.	Terminal Symbol	Function and Description	Military Connector	Quick Connector	Color
5	T+	Serial communication signal input / output (+)	Α	1	Blue
4	T-	Serial communication signal input / output (-)	В	4	Blue & Black
14,16	+5V	+5V power supply	S	7	Red / Red & White
13,15	13,15 GND Power ground		R	8	Black / Black & White
Shell	Shielding-	Shielding	L	9	_


About shielding and ground

The both sides of CN2 encoder cable are CN2 connector and encoder connector. Shielding and ground conductor should be correctly connected to the corresponding pins so as to effectively shield and ground.


The shielding procedures of CN2 encoder connector are as followings:




(1) Cut through the cable and expose the core wire which covers the metal core wires with shielding. The reserved core wire length should be 20~30mm. Then, cover a 45mm heat shrink tube on the cable.



(2) Spread the metal core wires with shielding and turn it upside down in downward direction. Ensure to follow the above table of CN2 Terminal Signal Identification to connect the pins one by one.



(3) Leave a length of 5~10mm metal core wires with shielding outside of the cable. The length is about the width of the metal saddle. The other unexposed wires of the cable should be protected by heat shrink tube for good ground contact.



(4) Install a metal saddle to fix the exposed metal core wires. The metal saddle must completely cover all the exposed metal core wires. The extended sheet metal should be connected to the metal part of the connector.



(5) Install the connector with shielding into the plastic case as shown in the figure.




(6) Tighten the screws to complete a shielded CN2 connector.

3-56 Revision February, 2017

3.6 Wiring of CN3 Connector

3.6.1 Layout of CN3 Connector

The servo drive connects to the personal computer via communication connector. The user can operate the servo drive via MODBUS, PLC or HMI. There are two common communication interfaces, RS-232 and RS-485. Both can be set via parameter P3-05. Among them, RS-232 is more common. Its communication distance is about 15 meter. If the user selects RS-485, its transmission distance is longer and supports more than one servo drives for connection.




PIN No.	Signal Name	Terminal Symbol	Function and Description
1	Grounding	GND	+ 5 V connects to the signal terminal
2	RS-232 data transmission	RS-232_TX	The drive transmits the data The connector connects to RS-232 of PC
3	-	-	Reserved
4	RS-232 data receiving	RS-232_RX	The drive receives the data The connector connects to RS-232 of PC
5	RS-485 data transmission	RS-485(+)	The drive transmits the date to differential terminal (+)
6	RS-485 data transmission	RS-485(-)	The drive transmits the date to differential terminal (-)



- 1) Please refer to Chapter 9, page 2 for the wiring of RS-485.
- 2) Two kinds of communication wire of IEEE1394 are commercially available. One of the internal ground terminals (Pin 1) will short circuit with the shielding and will damage the drive. Do not connect GND to the shielding.


3.6.2 Connection between PC and Connector CN3



3-58 Revision February, 2017

3.7 CN4 Serial Connector (USB)

CN4 is a serial connector which used to connect PC software and enhance the efficiency. The transmission speed of USB can up to 1MB, that is to say PC Data Scope can obtain the correct data in time.




CN4 Connector (female)

PIN No.	Signal Name	Function and Description
1	V bus	DC +5V (external power supply)
2	D-	Data-
3	D+	Data+
4	GND	Ground

3.8 CN5 Connector (Full-closed loop)

Connect to the external linear scale or encoder (A, B, Z) and form a full-closed loop with the servo. In position mode, the pulse position command issued by the controller is based on the control loop of the external linear scale. Please refer to Chapter 6.



CN5 Connector (female)

Pin No.	Signal Name	Terminal Symbol	Function and Description
1	/Z phase input	Opt_/Z	Linear scale /Z phase output
2	/B phase input	Opt_/B	Linear scale /B phase output
3	B phase input	Opt_B	Linear scale B phase output
4	A phase input	Opt_A	Linear scale A phase output
5	/A phase input	Opt_/A	Linear scale /A phase output
6	Encoder grounding	GND	Ground
7	Encoder grounding	GND	Ground
8	Encoder power	+5V	Linear scale 5V power
9	Z phase input	Opt_Z	Linear scale Z phase output




- 1) It only supports AB phase signal and the encoder with 5 V.
- 2) Application of full-closed loop: It supports the encoder with highest resolution, 1280000 pulse rev (Full-closed loop corresponds to the resolution of quadruple frequency when motor runs a cycle.).

3-60 Revision February, 2017

3.9 CN6 Connector (CANopen)

Based on the standard of CANopen DS301 and DS402, CN6 uses the standard CAN interface to implement position, torque and speed mode. It also can read or monitor the drive status.


The station number of CANopen is the same as RS-232/RS-485. All are set via parameter P3-00 and the transmission rate can up to 1 Mbps. It provides two sets of communication connectors, one is for receiving and another one is for transmission, in order to connect more than one drives. The last servo drive connects to termination resistor.



CN6 Connector (female)

PIN No.	Signal Name	Function and Description
1, 9	CAN_H	CAN_H bus line (dominant high)
2, 10	CAN_L	CAN_H bus line (dominant low)
3, 11	CAN_GND	Ground / 0 V / V -
4, 12	-	Reserved
5, 13	-	Reserved
6, 14	-	Reserved
7, 15	CAN_GND	Ground / 0 V / V -
8, 16	-	Reserved


Chapter 3 Wiring ASDA-A2



It can support up to 127 axes



- 1) The termination resistor is suggested to use 120 Ω (Ohm) 0.25W or above.
- 2) The wiring method of concatenate more than one drives is based on two terminals of CANopen. One is for receiving and another one is for transmission. And the servo drive connects to the termination resistor. The wiring diagram of the termination resistor is shown as the followings:




3-62 Revision February, 2017

ASDA-A2 Chapter 3 Wiring

3.10 Extension Digital Input Connector of CN7

A2 series servo drive provides additional extension DI on CN7 port. The function of this DI is similar to the one on CN1. Users can define and program it according to the demand.



CN7 Connector (female)

PIN No.	Signal Name	Terminal Symbol	Function Description
*1	VDD 24V power COM+		VDD (24V) power supply, same as Pin 11 of CN1
2	Extension DI9	EDI 9-	Digital input DI9-
3	Extension DI10	EDI 10-	Digital input DI10-
4	Extension DI11	EDI 11-	Digital input DI11-
5	Extension DI12	EDI 12-	Digital input DI12-
6	Extension DI13	EDI 13-	Digital input DI13-
7	Extension DI14	EDI 14-	Digital input DI14-




> *1 Caution: Do not use dual power supply or it might damage the servo drive.

Revision February, 2017 3-63

Chapter 3 Wiring ASDA-A2

3.11 CN8 Connector of Battery Box

CN8 connector on servo drive is the power supply for absolute battery box. Please refer to Chapter 12 for further information.



Pin Definition:

Pin No	Connector1	Connector2	
1	BAT+	BAT+	
2	BAT-	BAT-	




Due to the different design of servo drive model, CN8 might have one or two connectors, which however has the same pin definition.

3-64 Revision February, 2017

ASDA-A2 Chapter 3 Wiring

3.12 Standard Connection Example - 220V series


3.12.1 Position (PT) Control Mode



Revision February, 2017 3-65

Chapter 3 Wiring ASDA-A2


3.12.2 Position (PR) Control Mode



3-66 Revision February, 2017

ASDA-A2 Chapter 3 Wiring


3.12.3 Speed Control Mode



Revision February, 2017 3-67

Chapter 3 Wiring ASDA-A2


3.12.4 Torque Control Mode



3-68 Revision February, 2017

ASDA-A2 Chapter 3 Wiring

3.12.5 Communication Mode




Revision February, 2017 3-69

Chapter 3 Wiring ASDA-A2

3.13 Standard Connection Example - 400V series


3.13.1 Position (PT) Control Mode



3-70 Revision February, 2017

ASDA-A2 Chapter 3 Wiring


3.13.2 Position (PR) Control Mode



Revision February, 2017 3-71

Chapter 3 Wiring ASDA-A2


3.13.3 Speed Control Mode



3-72 Revision February, 2017

ASDA-A2 Chapter 3 Wiring


3.13.4 Torque Control Mode



Revision February, 2017 3-73

Chapter 3 Wiring ASDA-A2

3.13.5 Communication Mode




3-74 Revision February, 2017

Chapter 4 Panel Display and Operation

This chapter details the panel status and operation of ADSA-A2 series servo drive.

4.1 Panel Description




Name	Function
Display	Five-/Seven-segment display is for displaying the monitoring values, parameter values and setting values.
SHIFT Key	Pressing SHIFT key can scrolls through parameter groups. After a parameter is selected and its value displayed, pressing SHIFT key can move the cursor to the left and then change parameter settings by using arrow keys.
SET Key	Pressing the SET key can display and save the parameter groups, the various parameter settings. In monitor mode, pressing SET key can switch decimal or hexadecimal display. In parameter mode, pressing SET key can enter into parameter setting mode.
DOWN Key	Pressing the DOWN key can scroll through and change monitor codes, parameter groups and various parameter settings.
MODE Key	Pressing MODE key can enter or exit different parameter groups, and switch between Monitor mode and Parameter mode.
UP Key	Pressing the UP key can scroll through and change monitor codes, parameter groups and various parameter settings.
Charge LED	The Charge LED lights to indicate the power is applied to the circuit.

Revision February, 2017 4-1


4.2 Parameter Setting Procedure

Switch the mode:




Operate in each mode:

Monitoring mode




4-2 Revision February, 2017

Parameter Mode



Revision February, 2017 4-3

Edit Setting Mode



4-4 Revision February, 2017

4.3 Status Display

4.3.1 Save Setting Display

When finishing editing parameter, press the SET Key to save the setting. The panel will display the setting status according to the setting for a second.

Displayed Symbol	Description
SAUEU	The setting value is saved correctly. (Saved)
r-0LY	Read-only parameter. Write-protected. (Read-Only)
Locky	Enter the wrong password or no password has been entered. (Locked)
Out	Incorrect setting value or enter the reserved setting value. (Out of Range)
5 ^u -on	No entering is allowed when it is Servo ON. (Servo On)
Po-On	Parameter will be effective after the servo drive is re-powered on. (Power On)

4.3.2 Decimal Point

Display Symbol	Description
	High byte / low byte indication: When the data is displayed in decimal 32 bits, it is for indicating the current high or low byte. Negative sign: When the data is displayed in decimal format, the two decimal points in the left represents the negative sign, no matter it is showed in 16 or 32 bits. When it is showed in hexadecimal format, it only shows positive sign.

4.3.3 Alarm Message

Displayed Symbol	Description
8L,nnn	When there is an error of the drive, it will show 'AL' as the alarm sign and 'nnn' as the alarm code. For further explanation, please refer to Chapter 8, P0-01, parameter description, or Chapter 10, Troubleshooting.

4.3.4 Positive and Negative Sign Setting

Displayed Symbol	Description
02468	When entering into the Editing Setting Mode, pressing UP / DOWN Key can increase or decrease the displayed content. The SHIFT Key can change the desired adjusted carry value. (The carry value is blinking at the moment.)
2.4680	Pressing the SHIFT Key for two seconds can switch the positive (+) and negative (-) sign. If the parameter is over the range after switching the positive or negative sign, then it cannot be switched.

Revision February, 2017 4-5

4.3.5 Monitor Display

When the drive is applied to the power, the display will show the monitor displayed symbol for a second, and then enter into the Monitor Mode. In Monitor Mode, the UP / DOWN Key can change the desired monitor variable. Or, the user can directly change parameter P0-02 to set the monitor code. When applying to the power, the system will pre-set the monitor code according to the setting value of P0-02. For example, the setting value of P0-02 is 4. Every time when applying to the power, it will display C-PLS monitor sign first, and then shows the input pulse number of pulse command.

P0-02 Setting Value	Monitor Displayed Symbol	Description	Unit
0	FLPUU	Motor feedback pulse number (after the scaling of electronic gear ratio) (User unit)	[user unit]
1	[-PUU	Input pulse number of pulse command (after the scaling of electronic gear ratio) (User unit)	[user unit]
2	E-PUU	The difference of error pulse number between control command pulse and feedback pulse number (User unit)	[user unit]
3	FLPLS	Motor feedback pulse number (encoder unit) (1.28 millions Pulse/rev)	[pulse]
4	[-PL5	Input pulse number of pulse command (before the scaling of electronic gear ratio) (encoder unit)	[pulse]
5	E-PLS	Error pulse number (after the scaling of electronic gear ratio) (encoder unit)	[pulse]
6	[P-Fr	Input frequency of pulse command	[Kpps]
7	SPEEd	Motor speed	[r/min]
8	[584]	Speed input command	[Volt]
9	[5842]	Speed input command	[r/min]
10	[-64]	Torque input command	[Volt]
11	[-645]	Torque input command	[%]
12	RUG-L	Average torque	[%]
13	PE-L	Peak torque	[%]
14	U 6uS	Main circuit voltage	[Volt]
15]-[Load / Motor inertia ratio (Note: If it shows 13.0, it means the actual inertia is 13)	[1 times]
16	10657	IGBT temperature	[°C]

4-6 Revision February, 2017

P0-02 Setting Value	Monitor Displayed Symbol	Description	Unit
17	rSnFr	Resonance frequency (Low byte is the first resonance and high byte is the second one).	[Hz]
18	0 +5000 0 +5000 0 Z Z Z Z	The absolute pulse number of encoder Z phase equals to the homing value, 0. It will be +5000 or -5000 pulse when rotating in forward or reverse direction.	-
19	NAP I	Mapping parameter #1: shows the content of parameter P0-25 (specify the mapping target by P0-35)	-
20	NNRP2	Mapping parameter #2: shows the content of parameter P0-26 (specify the mapping target by P0-36)	-
21	NAP3	Mapping parameter #3: shows the content of parameter P0-27 (specify the mapping target by P0-37)	-
22		Mapping parameter #4: shows the content of parameter P0-28 (specify the mapping target by P0-38)	-
23	UAr- I	Monitor variable #1: shows the content of parameter P0-09 (specify the monitor variable code by P0-17)	-
24	UA2	Monitor variable #2: shows the content of parameter P0-10 (specify the monitor variable code by P0-18)	-
25	UA3	Monitor variable #3: shows the content of parameter P0-11 (specify the monitor variable code by P0-19)	-
26	UA4	Monitor variable #4: shows the content of parameters P0-12 (specify the monitor variable code by P0-20)	

Example of the displayed value	Status Description		
[] 234] (Dec)	16 bits	If the value is 1234, it displays 01234 (shows in decimal format).	
[234] (Hex)	TO DIES	If the value is 0x1234, it displays 1234 (shows in hexadecimal format; the first digit does not show any).	
12345 (Dec high) 67890 (Dec low)	32 bits	If the value is 1234567890, the display of the high byte is 1234.5 and displays 67890 as the low byte (shows in decimal format).	

Revision February, 2017 4-7

(Hex high)	If the value is 0x12345678, the display of the high byte h1234 and displays L5678 as the low byte (shows in hexadecimal format).
1.2.345	Negative display. If the value is -12345, it displays 1.2.345 (on shows in decimal format; there is no positive or negative sign for hexadecimal format display).




- 1) Dec means it is displayed in decimal format. Hex means it is displayed in hexadecimal format.
- 2) The above display methods can be applied in Monitor Mode and Editing Setting Mode.
- 3) When all monitor variables is 32 bits, high / low bit and the display (Dec/Hex) can be switched. According to the definition in Chapter 8, each parameter only supports one displaying method and cannot be switched.

4-8 Revision February, 2017

4.4 General Function

4.4.1 Operation of Fault Record Display

When it is in Parameter Mode, select P4-00~P4-04 and press the SET Key, the corresponding fault record will be shown.




Revision February, 2017 4-9

4.4.2 JOG Mode

When it is in Parameter Mode, select P4-05 and follow the setting method below for JOG operation.


- (1) Press the SET Key to display the speed value of JOG. The default value is 20r/min.
- (2) Press UP or DOWN Key to adjust the desired speed value of JOG. It is adjusted to 100r/min in the example.
- (3) Press the SET Key to display JOG and enter JOG mode.
- (4) When it is in JOG Mode, press UP or DOWN Key to enable the servo motor in forward or reverse direction. The servo motor stops running as soon as the user stops pressing the key. JOG operation is working only when it is Servo ON.



4-10 Revision February, 2017

4.4.3 Force DO Output

Enter into the Output Diagnosis Mode by the following settings. Set P2-08 to 406 and enable the function of force DO output. Then, set the force DO output by binary method via P4-06. When the setting value is 2, DO2 will be forced to enable. When the setting value is 5, DO1 and DO3 will be forced to enable. No data is retained in this mode. It returns to the normal DO mode when repower on the drive or set P2-08 to 400.






P4-06 is displayed in hexadecimal format. Therefore, it will not show the fifth 0.

Revision February, 2017 4-11

4.4.4 Digital Input Diagnosis Operation

Enter into the Digital Input Diagnosis Mode by the following setting methods. When the external output signal DI1~DI8 is ON, the corresponding signal will be shown on the panel. It is displayed by bit. When it shows bit, it means it is ON.


For example, if it shows **3FE1**, **E** is in hexadecimal format, it will be **1100** when it transfers to binary format. Then, DI6~DI8 is ON.



4.4.5 Digital Output Diagnosis Operation

Enter into the Digital Output Diagnosis Mode by the following setting methods. The output signal DO1~DO5 is ON and the corresponding signal will be shown on the panel. It is displayed by bit. When it shows bit, it means it is ON.

For example, if it shows **1F**, **F** is in hexadecimal format, it will be **1111** when it transfers to binary format. Then, DO1~DO4 is ON.



4-12 Revision February, 2017

Chapter 5 Trial Operation and Tuning

This chapter is divided into two parts to describe the trial operation. The first one is the inspection without load and another one is the inspection with load. For safety reasons, please conduct the first inspection.

5.1 Inspection without Load

Please remove the load of the servo motor, including coupling on the shaft and accessories so as to avoid any damage on servo drive or mechanism. This is aiming to avoid the falling off of the disassembled parts of the motor shaft and indirectly causing the personnel injury or equipment damage during operation. Running the motor without load, if the servo motor can run during normal operation, then it can connect to load for operation.

Caution: Please operate the servo motor without load first. If the servo motor runs normally, connect the load afterwards in order to avoid any danger.

Please check the following items before operation.

Inspection before operation (has not applied to the power yet)

- Check if there is any obvious damage shown on its appearance.
- The splicing parts of the wiring terminal should be isolated.
- Make sure the wiring is correct so as to avoid the damage or any abnormity.
- Check if the electric conductivity objects including sheetmetal (such as screws) or inflammable objects are not inside the servo drive.
- Check if the control switch is in OFF status.
- Do not place the servo drive or external regenerative resistor on inflammable objects.
- To avoid the electromagnetic brake losing efficacy, please check if stop function and circuit break function can work normally.
- If the peripheral devices are interfered by the electronic instruments, please reduce electromagnetic interference with devices.
- Please make sure the external voltage level of the servo drive is correct.

Inspection before running the servo drive (has already applied to the power)

■ The encoder cable should avoid excessive stress. When the motor is running, make sure the cable is not frayed or over extended.

Revision February, 2017 5-1

- Please contact with Delta if there is any vibration of the servo motor or unusual noise during the operation.
- Make sure the setting of the parameters is correct. Different machinery has different characteristic, please adjust the parameter according to the characteristic of each machinery.
- Please reset the parameter when the servo drive is in SERVO OFF status, or it may cause malfunction.
- When the relay is operating, make sure it can work properly.
- Check if the power indicator and LED display works normally.
- PWM is used to control 7.5 kW. Thus, when the temperature is lower than 40°C, the fan does not work.

5.2 Applying Power to the Servo Drive

Please follow the instructions below.

- **A.** Make sure the wiring between the motor and servo drive is correct.
 - 1) U, V, W and FG have to connect to cable red, white, black and green respectively. If the wiring is incorrect, the motor cannot work normally. The ground wire FG of the motor must be connected to the ground terminal of the servo drive. Please refer to Chapter 3.1 and 3.2 for wiring.
 - 2) The encoder cable of the motor has correctly connected to CN2: If users only desire to execute JOG function, it is unnecessary to connect CN1 and CN3 (Please refer to Chapter 5.3). Refer to Chapter 3.1 and 3.5 for the wiring of CN2.

Caution: Do not connect the power terminal (R, S, T) to the output terminal (U, V, W) of the servo drive. Or it might damage the servo drive.

B. Power circuit of the servo drive:

Caution: Wiring of 220 V servo drive is different from 400 V. Make sure the wiring is correct, or it might damage the servo drive.

220V Servo Drive: Apply power to the servo drive. Please refer to Chapter 3.1.3 for power wiring. **400V Servo Drive:** Apply power to the servo drive. Please refer to Chapter 3.2.3 for power wiring.

C. Power on:

220V Servo Drive: Power of the servo drive: including control circuit (L1c, L2c) and main circuit (R, S, T) power.

400V Servo Drive: Power of the servo drive: including control circuit (DC24V, DC0V) and main circuit (R, S, T) power.


When the power is on, the display of the servo drive will be:



The digital input (DI6~DI8) of the default value is the signal of reverse limit error (NL), forward limit error (PL) and emergency stop (EMGS), if not using the default setting of DI6~DI8, adjusting the setting of P2-15~P2-17 is a must. Parameters could be set to 0 (disable this DI

function) or modified to another function.

From the last setting, the servo drive status displays parameter P0-02 setting as the motor speed (07), then the screen display will be:



When the screen displays no text, please check if the power of control circuit is under voltage.

1) When the screen displays:



Warning of overvoltage:

It means the voltage input by the main circuit is higher than the rated voltage or power input error (incorrect power system).

Corrective action:

- Use the voltmeter to measure if the input voltage from the main circuit is within the range of rated voltage value.
- Use the voltmeter to measure if the power system complies with the specification.
- 2) When the screen displays:



Warning of encoder error:

Check if the motor encoder is securely connected or the wiring is correct.

Corrective action:

- Check if the wiring is the same as the instruction of the user manual.
- Check the encoder connector.
- Check if the wiring is loose.
- Encoder is damaged.

Revision February, 2017 5-3

3) When the screen displays:



Warning of emergency stop:

Please check if any of the digital input DI1~DI8 is set to emergency stop (EMGS).

Corrective action:

- If not desire to set emergency stop (EMGS) as one of the digital input, make sure no digital input is set to emergency stop (EMGS) among DI1~DI8. (That is to say none of the parameters, P2-10~P2-17 is set to 21.)
- If the function of emergency stop (EMGS) is needed and this DI is set as normally close (function code: 0x0021), please make sure this DI is always normally close. If not, please set this DI as normally open (function code: 0x0121).
- 4) When the screen displays:



Warning of negative limit error:

Please check if any of the digital input DI1~DI8 is set to negative limit (NL) and that DI is ON.

Corrective action:

- If not desire to set negative limit (NL) as one of the digital input, make sure no digital input is set to negative limit (NL) among DI1~DI8. (That is to say none of the parameters, P2-10~P2-17 is set to 22.)
- If the function of negative limit (NL) is needed and this DI is set as normally close (function code: 0x0022), please make sure this DI is always normally close. If not, please set this DI as normally open (function code: 0x0122).
- 5) When the screen displays:



Warning of positive limit error:

Please check if any of the digital input DI1~DI8 is set positive limit (PL) and that DI is ON.

Corrective action:

- If not desire to set positive limit (PL) as one of the digital input, make sure no digital input is set to positive limit (PL) among DI1~DI8. (That is to say none of the parameters, P2-10~P2-17 is set to 23.)
- If the function of positive limit (PL) is needed and this DI is set as normally close (function code: 0x0023), please make sure this DI is always normally close. If not, please set this DI as normally open (function code: 0x0123).

6) When the screen displays:



Warning of over current:

Corrective Action:

- Check the connection between the motor and servo drive.
- Check if the conducting wire is short circuited.

Exclude short circuit and avoid metal conductors being exposed.

7) When the screen displays:



Warning of under voltage:

Corrective action:

- Check if the wiring of main circuit input voltage is correct.
- Use voltmeter to measure if the main circuit voltage is normal.
- Use voltmeter to measure if the power system complies with the specification.




During the process of power on or servo on, if an alarm occurs or shows any abnormal display, please contact the distributors.

Revision February, 2017 5-5

5.3 JOG Trial Run without Load

It is very convenient to test the motor and servo drive with the method of JOG trial run without load since the extra wiring is unnecessary. For safety reasons, it is recommended to set JOG at low speed. Please see the following descriptions.

- **Step 1**: Use software setting to Servo ON. Set parameter P2-30 to 1. This setting is to force the servo ON through software.
- **Step 2**: Set P4-05 as JOG speed (Unit: r/min). After setting the desired JOG speed, press the **SET** Key, the servo drive will enter JOG mode.
- Step 3: Press the MODE Key to exist JOG mode.



If the motor does not run, please check if the wiring between UVW and encoder cable is correct. If the motor run abnormally, please check if the UVW phase sequence is correct.

5-6 Revision February, 2017

5.4 Trial Run without Load (Speed Mode)

Before the trial run without load, firmly secure the motor base so as to avoid the danger cause by the reaction of motor operation.

Step 1:

Set the control mode of the servo drive to speed mode. Set P1-01 to 2 as speed mode. Then, repower on the servo drive.

Step 2:

In speed control mode, the digital input settings of trial run are as follows:

-				
Digital Input	Parameter Setting Value	Symbol	Function Description	CN1 Pin No
DI1	P2-10 = 101	SON	Servo ON	DI1- = 9
DI2	P2-11 = 109	TRQLM	Torque limit	DI2- = 10
DI3	P2-12 = 114	SPD0	Speed command selection	DI3- = 34
DI4	P2-13 = 115	SPD1	Speed command selection	DI4- = 8
DI5	P2-14 = 102	ARST	Alarm reset	DI5- = 33
DI6	P2-15 = 0	Disabled	Invalid DI function	-
DI7	P2-16 = 0	Disabled	Invalid DI function	-
DI8	P2-17 = 0	Disabled	Invalid DI function	-
EDI9	P2-36 = 0	Disabled	Invalid DI function	CN7 = 2
EDI10	P2-37 = 0	Disabled	Invalid DI function	CN7 = 3
EDI11	P2-38 = 0	Disabled	Invalid DI function	CN7 = 4
EDI12	P2-39 = 0	Disabled	Invalid DI function	CN7 = 5
EDI13	P2-40 = 0	Disabled	Invalid DI function	CN7 = 6
EDI14	P2-41 = 0	Disabled	Invalid DI function	CN7 = 7

The above table disables the function of negative limit (DI6), positive limit (DI7) and emergency stop (DI8). Thus, the value of parameter P2-15 ~ P2-17 and P2-36 ~ P2-41 are set to 0 (Disabled). The digital input of Delta' s servo drive can be programmed by users. When programming digital input, please refer to the description of DI code.

The default setting includes the function of negative limit, positive limit and emergency stop, therefore, after the setting is completed, if there is any alarm occurs, please re-power on the servo drive or switch ON DI5 to clear the alarm. Please refer to Chapter 5.2.

Revision February, 2017 5-7

The speed command selection is determined by SPD0 and SPD1. See the table below.

Speed	DI signal of CN1				_	
Command No.	SPD1	SPD0	Command Source	Content	Range	
S1	0			Voltage deviation between V-REF and GND	-10V ~ +10V	
S2	0	1		P1-09	-60000 ~ 60000	
S3	1	0	Register parameter	P1-10	-60000 ~ 60000	
S4	1	1	paramote.	P1-11	-60000 ~ 60000	

0: means DI is OFF; 1: means DI is ON

Register parameter

The parameter setting range is from -60000 to 60000. Setting speed = Setting range x unit (0.1 r/min).

For example: P1-09 = +30000; Setting speed = $+30000 \times 0.1 \text{ r/min} = +3000 \text{ r/min}$

Command setting of speed register

Set parameter P1-09 to 30000.	Input command	Rotation direction
Set parameter P1-10 to 1000.	+	CW
Set parameter P1-11 to -30000.	-	CCW

Step 3:

- (1) Users switch ON DI1 and Servo ON.
- (2) Both DI3 (SPD0) and DI4 (SPD1), the speed command, are OFF, which means it currently executes S1 command. The motor rotates according to analog voltage command.
- (3) When DI3 (SPD0) is ON, it means it currently executes S2 command (3000 r/min). The rotation speed is 3000 r/min for rotary motor and 0.03 m/s for linear motor at the moment.
- (4) When DI4 (SPD1) is ON, it means it currently executes S3 command (100 r/min). The rotation speed is 100 r/min.
- (5) When both DI3 (SPD0) and DI4 (SPD1) are ON, it means S4 command (-3000 r/min) is executed at the moment. The rotation speed is -3000 r/min.
- (6) Step (3), (4) and (5) can be repeatedly executed.
- (7) If users desire to stop the motor, switch OFF DI1 (Servo OFF).

5-8 Revision February, 2017

5.5 Trial Run without Load (Position Mode)

Before the trial run without load, firmly secure the motor base so as to avoid the danger cause by the reaction of motor operation.

Step 1:

Set the control mode of the servo drive to position mode.

Set parameter P1-01 to 1, which is the position mode. Then, re-power on the servo drive.

Step 2: In position mode, the digital input settings of trial run are as follows:

Digital Input	Parameter Setting Value	Symbol	Function Description	CN1 Pin No
DI1	P2-10 = 101	SON	Servo ON	DI1- = 9
DI2	P2-11 = 108	CTRG	Command triggered	DI2- = 10
DI3	P2-12 = 111	POS0	Position command selection	DI3- = 34
DI4	P2-13 = 112	POS1	Position command selection	DI4- = 8
DI5	P2-14 = 102	ARST	Alarm reset	DI5- = 33
DI6	P2-15 = 0	Disabled	Invalid DI function	-
DI7	P2-16 = 0	Disabled	Invalid DI function	-
DI8	P2-17 = 0	Disabled	Invalid DI function	-
EDI9	P2-36 = 0	Disabled	Invalid DI function	CN7 = 2
EDI10	P2-37 = 0	Disabled	Invalid DI function	CN7 = 3
EDI11	P2-38 = 0	Disabled	Invalid DI function	CN7 = 4
EDI12	P2-39 = 0	Disabled	Invalid DI function	CN7 = 5
EDI13	P2-40 = 0	Disabled	Invalid DI function	CN7 = 6
EDI14	P2-41 = 0	Disabled	Invalid DI function	CN7 = 7

The above table disables the function of negative limit (DI6), positive limit (DI7) and emergency stop (DI8), thus, set P2-15 \sim P2-17 and P2-36 \sim P2-41 to 0 (Disabled). The digital input of Delta's servo drive can be programmed by users. When programming digital input, please refer to the description of DI code.

The default setting includes the function of negative limit, positive limit and emergency stop, therefore, after the setting is completed, if there is any alarm occurs, please re-power on the servo drive or switch ON DI5 to clear the alarm. Please refer to Chapter 5.2.

Please refer to Chapter 3.12.2, Position (PR) Mode Standard Wiring for wiring diagram. However, since POS2 is not the default digital input, set P2-14 to 113. Please refer to the table below for 64 sets of register command, POS0~POS5 and the relative parameters.

Revision February, 2017 5-9

Position Command	POS5	POS4	POS3	POS2	POS1	POS0	CTRG	Corresponding Parameter
PR0	0	0	0	0	0	0	†	P6-00
FRU	U	U	U	U	U	U		P6-01
PR1	0	0	0	0	0	1	†	P6-02
PRI	0	U	U	U	U	I	ļ	P6-03
~								~
DD50	4	1	0	0	1	0	1	P6-98
PR50	I	I	0	U	1	0		P6-99
PR51	1	1	0	0	1	1	1	P7-00
PRST	I	I	U	U	ı	I		P7-01
~								~
DD64	4	1 1 1 1 1 1	1	†	P7-26			
PR64	l	l	l	I	1	l		P7-27

0: means DI is OFF; 1: means DI is ON

Users can set the 64-set of command value (P6-00~P7-27). The value can be set as the absolute position command.

5-10 Revision February, 2017


5.6 Tuning Procedure

Estimate the inertia ratio: JOG Mode

	Tuning Procedure	Display			
1.	After completing wiring, when applying to the power, the servo drive will display:	RL0 13			
2.	Press the MODE Key to select the mode of parameter function.	PC-00			
3.	Press the SHIFT Key twice to select the mode of parameter group.	P2-00			
4.	Press the UP Key to select parameter P2-17.	P2- 17			
5.	Press the SET Key to display parameter value, which is shown as the content on the right.	[5]			
6.	Press the SHIFT Key twice, then press the UP Key and then press the SET Key.	[15]			
7.	Press the UP Key to select parameter P2-30.	P2-30			
8.	Press the SET Key to display the parameter value.				
9.	Press the UP Key and select the parameter value 1.				
10.	Then, the servo drive is ON and will show:				
11.	Press the MODE Key and then press the DOWN Key to select the value of inertia ratio.				
12.	The panel displays the current value of inertia ratio / total weight of movable section and load (kg) (default value).	5.0			
13.	Press the MODE Key to select the mode of parameter function.	P2-30			
14.	Press the SHIFT Key twice to select the mode of parameter group.	P4-00			
15.	Press the UP Key twice to select parameter P4-05.	P4-05			
16.	Press the SET Key to show the content, which is 20r/min at JOG speed. Press the UP or DOWN Key to increase or decrease the JOG speed. Press the SHIFT Key to move to the next digit of the left.	50			
17.	Set the desired JOG speed and press the SET Key which is shown as the figure on the right.	-J09-			
18.	Press the UP Key to rotate the motor in forward direction while press the DC motor will rotate in reverse direction.	OWN Key the			
19.	. Execute JOG operation at low speed first. With the constant speed, if the motor operates smoothly in forward and reverse direction, users can execute JOG operation at higher speed.				
20.	0. In P4-05, the servo drive cannot display inertia ratio. Please press the MODE Key twice to view the value of inertia ratio. If users desire to execute JOG operation again, press the MODE Key, and then press the SET Key twice. Observe the panel display to see if the load inertia ratio / total weight of movable section and load remain at the same value after acceleration and deceleration.				


Revision February, 2017 5-11

5.6.1 Flowchart of Tuning Procedure



5-12 Revision February, 2017

5.6.2 Inertia Estimation Flowchart (with Mechanism)



5.6.3 Flowchart of Auto Tuning

Set P2-32 to 1 (auto mode, continuous tuning)

Continue to estimate the system inertia. Automatically save the value in P1-37 every 30 minutes and refer the stiffness and bandwidth setting of P2-31.

P2-31 Stiffness setting in auto tuning mode (The default value is 80)

In auto and semi-auto mode, the bandwidth setting of speed circuit is:

1 ~ 50 Hz: low-stiffness, low-response


51 ~ 250 Hz: medium-stiffness, medium-response

251 ~ 850 Hz: high-stiffness, high-response

851 ~ 1000 Hz: extremely high-stiffness, extremely high-response

Stiffness setting in auto tuning mode: the bigger the value is, the stronger the stiffness will be.

Adjust the value of P2-31: Increase the value of P2-31 to increase stiffness or decrease to reduce the noise. Continue to tune until the performance is satisfied. Then, tuning is completed.



5-14 Revision February, 2017

5.6.4 Flowchart of Semi-Auto Tuning

Set P2-32 to 2 (semi-auto mode, non-continuous tuning)

After tuning for a while and wait until the system inertia is stable, it stops estimating. The estimated inertia ratio will be saved to P1-37. When switching mode from manual or auto to semi auto, the system starts tuning again. During the process of estimation, the system will refer the stiffness and bandwidth setting of P2-31.

P2-31 Response setting in auto mode (The default value is 80)

In auto and semi-auto mode, the bandwidth setting of speed circuit is:

1 ~ 50 Hz: low-stiffness, low-response


51 ~ 250 Hz: medium-stiffness, medium-response

251 ~ 850 Hz: high-stiffness, high-response

851 ~ 1000 Hz: extremely high-stiffness, extremely high-response

Response setting in semi-auto tuning mode: the bigger the value is, the better the response will be.

Adjust the value of P2-31: Increase the value of P2-31 to increase the response or decrease to reduce the noise. Continue to tune until the performance is satisfied. Then, tuning is completed.





- 1. If P2-33 bit 0 is set to 1, it means the inertia estimation in semi-auto mode is completed. The result can be accessed by P1-37.
- 2. If the value of P2-33 bit 0 is cleared to 0, the system will start to estimate again.

5.6.5 Limit of Inertia Ratio


Acceleration / Deceleration time of reaching 2000 r/min should be less than 1 second.

The speed in forward and reverse direction should be higher than 200 r/min.


The load inertia should be under 100 times of motor inertia.

The change of external force of inertia ratio cannot be too severe.

In auto mode, the inertia value will be saved to P1-37 every 30 minutes; while in semi-auto mode, the inertia value will be saved to P1-37 only until the system inertia is stable and stops the estimation of load inertia.



5-16 Revision February, 2017






- 1. Parameter P2-44 and P2-46 are the setting value of resonance suppression. If the value has been set to the maximum (32dB), and still cannot suppress the resonance, please reduce the speed bandwidth. After setting P2-47, users can check the value of P2-44 and P2-46. If the value of P2-44 is not 0, it means the resonance frequency exists in the system. Then, users can access P2-43 to see the resonance frequency (Hz). When there is another resonance frequency, the information will be shown in P2-45 and p2-46.
- 2. If resonance still exists, repeatedly set P2-47 to 1 for 3 times and manually adjust the setting of resonance.

5.6.6 Mechanical Resonance Suppression Method

Three groups of Notch filter are provided to suppress mechanical resonance. Two of them can be set to the auto resonance suppression and manual adjustment.

The procedure of manually suppress the resonance is as the followings:



5-18 Revision February, 2017

5.6.7 Tuning Mode and Parameters

Tuning mode	P2-32	Auto-set parameters	User-defined parameters	Inertia adjustment
Manual mode	0 (default setting)	N/A	P1-37 (Inertia ratio of the motor) P2-00 (Position control gain) P2-04 (Speed control gain) P2-06 (Speed integral compensation) P2-25 (Low-pass filter of resonance suppression) P2-26 (Anti-interference gain)	The value remains
Auto mode (continuous estimation)	1	P1-37 P2-00 P2-04 P2-06 P2-25 P2-26 P2-49	P2-31 Frequency response of speed loop setting in auto mode (response level)	Continuous tuning (update the inertia every 30 minutes)
Semi-auto mode (non-continuous estimation)	2	P1-37 P2-00 P2-04 P2-06 P2-25 P2-26 P2-49	P2-31 Frequency response of speed loop setting in semi-auto mode (response level)	Non-continuous tuning (stop updating the inertia after operating for a while)

When switching mode from auto mode 1 to manual mode 0, the value of P1-37, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the one in auto mode.

When switching mode from semi-auto mode 2 to manual mode 0, the value of P1-37, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the one in semi-auto mode.

5.6.8 Tuning in Manual Mode

The selection of position / speed response frequency should be determined by the machinary stiffness and application. General speaking, the high-frequency machinary or the one requries precise processing needs the higher response frequency. However, it might easily cause the resonance. And the stronger stiffness machinary is needed to avoid the resonance. When using the unknown resonse frequency machinary, users could gradually increase the gain setting value to increase the resonance frequency. Then, decrease the gain setting value until the resonance exists. The followings are the related descriptions of gain adjustment.

■ Position control gain (KPP, parameter P2-00)

This parameter determines the response of position loop. The bigger KPP value will cause the higher response frequency of position loop. And it will cause better following error, smaller position error, and shorter settling time. However, if the value is set too big, the machinery will vibrate or overshoot when positioning. The calculation of position loop frequency response is as the following:

Position Loop Frequency Response (Hz) =
$$\frac{\text{KPP}}{2\pi}$$

■ Speed control gain (KVP, parameter P2-04)

This parameter determines the response of speed loop. The bigger KVP value will cause the higher response frequency of speed loop and better following error. However, if the value is set too big, it would easily cause machinery resonance. The response frequency of speed loop must be 4~6 times higher than the response frequency of position loop. Otherwise, the machinery might vibrate or overshoot when positioning. The calculation of speed loop frequency response is as the following:

Speed Loop Frequency Response fv
$$=\left(\frac{KVP}{2\pi}\right) \times \left[\frac{(1+P1-37/10)}{(1+JL/JM)}\right]$$
 Hz

JM: Motor Inertia; JL: Load Inertia; P1-37: 0.1 times

When P1-37 (estimation or setting) equals the real inertia ratio (JL/JM), the real speed loop frequency response will be: $fv = \frac{KVP}{2\pi} Hz$

Speed integral compensation (KVI, parameter P2-06)

The higher the KVI value is, the better capability of eliminating the deviation will be. However, if the value is set too big, it might easily cause the vibration of machinery. It is suggested to set the value as the following:

KVI (P2 – 06)
$$\leq$$
 1.5 \times Speed Loop Frequency Response

5-20 Revision February, 2017

■ Low-pass filter of resonance suppression (NLP, parameter P2-25)

The high value of inertia ratio will reduce the frequency response of speed loop. Therefore, the KVP value must be increased to maintain the response frequency. During the process of increasing KVP value, it might cause machinary resonance. Please use this parameter to elimiate the noise of resonance. The bigger the value is, the better the capability of improving high-frequency noise will be. However, if the value is set too big, it would cause the unstability of speed loop and overshoot. It is suggested to set the value as the following:

NLP (P2
$$-$$
 25) $\leq \frac{1000}{6 \times \text{Speed Loop Frequency Response (Hz)}}$

■ Anti-interference gain (DST, parameter P2-26)

This parameter is used to strengthen the ability of resisting external force and gradually eliminate overshoot during acceleration / deceleration. Its default value is 0. It is suggested not to adjust the value in manual mode, unless it is for fine-tuning.

■ Position feed forward gain (PFG, parameter P2-02)

It can reduce the position error and shorten the settling time. However, if the value is set too big, it might cause overshoot. If the setting of e-gear ratio is bigger than 10, it might cause the noise as well.

(This page is intentionally left blank.)

5-22 Revision February, 2017

Chapter 6 Control Mode of Operation

6.1 Selection of Operation Mode

Three basic operation modes are provided in this servo drive, position, speed and torque. Users can use single mode (only in one-mode control) and dual mode to control. The following table lists all operation mode and description.

	Mode Name	Short Name	Setting Code	Description
	Position mode (Terminal input)			The servo drive receives position command and commands the motor to the target position. The position command is input via terminal block and receives pulse signal.
	Position mode (Register input)	PR	01	The servo drive receives position command and commands the motor to the target position. The position command is issued by register (64 sets of register in total) and uses DI signal to select the register.
	Speed Mode	S	02	The servo drive receives speed command and commands the motor to the target speed. The speed command can be issued by register (3 sets of registers in total) or the external analog voltage (-10V ~ +10V). DI signal is used to select the command source.
Single Mode	Speed mode (No analog input)	Sz	04	The servo drive receives speed command and commands the motor to the target speed. The speed command is issued by register (3 sets of registers in total) and cannot be issued by the external terminal block. DI signal is used to select the command source.
	Torque mode	Т	03	The servo drive receives torque command and commands the motor to the target torque. The torque command can be issued by register (3 sets of registers in total) or the external analog voltage (-10V ~ +10V). DI signal is used to select the command source.
	Torque mode (No analog input)	Tz	05	The servo drive receives torque command and commands the motor to the target torque. The torque command can be issued by register (3 sets of registers in total) and cannot be issued by the external terminal block. DI signal is used to select the command source.

Mode Name	Short Name	Setting Code	Description
	PT-S	06	Switch the mode of PT and S via DI signal.
	PT-T	07	Switch the mode of PT and T via DI signal.
	PR-S	08	Switch the mode of PR and S via DI signal.
Dual Mode	PR-T	09	Switch the mode of PR and T via DI signal.
Dual Mode	S-T	0A	Switch the mode of S and T via DI signal.
	CANopen	0B	Control by the master
	Reserved	0C	Reserved
	PT-PR	0D	Switch the mode of PT and PR via DI signal.
Multi Mode	PT-PR-S	0E	Switch the mode of PT, PR and S via DI signal.
iviuiti Mode	PT-PR-T	0F	Switch the mode of PT, PR and T via DI signal.

The steps of changing mode:

- (1) Switching the servo drive to Servo Off status. Turning SON signal of digit input to be off can complete this action.
- (2) Using parameter P1-01. (Refer to chapter 8).
- (3) After the setting is completed, cut the power off and restart the drive again.

The following sections describe the operation of each control mode, including control structure, command source and loop gain adjustment, etc.


6-2 Revision February, 2017

6.2 Position Mode

The followings describe the related information and settings of position mode.

6.2.1 Position Command in PT Mode

PT, position command is the pulse input from terminal block. There are three types of pulse and each type has positive/negative logic which can be set in parameter P1-00. See as the followings.



- Pulse Type
 - 0: AB phase pulse (4x)
 - 1: Clockwise (CW) and Counterclockwise (CCW) pulse
 - 2: Pulse + symbol

Other settings: reserved


Filter Width

If the received frequency is much higher than the setting, it will be regarded as the noise and filtered out.


Setting Value	Min. pulse width*note1 (Low-speed filter frequency)	Setting Value	Min. pulse width*note1 (High-speed filter frequency)
0	600 ns (0.83 Mpps)	0	150 ns (3.33 Mpps)
1	2.4 us (208 Kpps)	1	600 ns (0.83 Mpps)
2	4.8 us (104 Kpps)	2	1.2 us (416 Kpps)
3	9.6 us (52 Kpps)	3	2.4 us (208 Kpps)
4	No filter function	4	No filter function




NOTE 1) When the source of external pulse is from the high-speed differential signal and the setting value is 0 (the high-speed filter frequency is 3.33Mpps at the moment), then:



When this pulse width is shorter than 150 ns, it will be seen as low level. Two input pulse will be seen as one.



When this pulse width is shorter than 150 ns, it will be seen as high level. Two input pulse will be seen as one.




When High, Low duty of the pulse width are longer than 150 ns, it can ensure the pulse command will not be filtered.

If the user uses 2~4MHz input pulse, it is suggested to set the filter value to 4.

Note: When the signal is the high-speed pulse specification of 4 Mpps and the settings value of the filter is 4, then the pulse will not be filtered.

6-4 Revision February, 2017

Logic Type



Pulse Specification		Max. Input Frequency	Minimum time width					
		ricquericy	T1	T2	Т3	T4	T5	T6
High-speed pulse	Differential Signal	4 Mpps	62.5ns	125ns	250ns	200ns	125ns	125ns
Low-speed pulse	Differential Signal	500 Kpps	0.5µs	1µs	2µs	2µs	1µs	1µs
	Open-collector	200 Kpps	1.25µs	2.5µs	5µs	5µs	2.5µs	2.5µs

Pulse Specification		Max. Input Frequency	Voltage Specification	Forward Current
High-speed pulse	Differential Signal	4 Mpps	5V	< 25 mA
Low-speed pulse	pulse Differential 500 Kpps Signal		2.8V ~ 3.7V	< 25 mA
	Open-collector	200 Kpps	24V (Max.)	< 25 mA

The Source of External Pulse:

0: Low-speed optical coupler (CN1 Pin: PULSE, SIGN)

1: High-speed differential (CN1 Pin: HPULSE, HSIGN)

Position pulse can be input from CN1 terminal, PULSE (43), /PULSE (41), HPULSE (38), /HPULSE (29) and SIGN (36), /SIGN (37), HSIGN (46), /HSIGN (40). It could be open-collector or Line Driver. Please refer to Chapter 3.9.1 for wiring method.

6-6 Revision February, 2017

6.2.2 Position Command in PR Mode


PR position command source of each axis is from the 64-set of register which constituted by parameters (P6-00, P6-01) \sim (P7-26, P7-27). Through communication, one of the 99-set of register can be used as the position command. When going with the external DI/DO (CN1, POS0 \sim POS5 and CTRG), one of the previous 64 sets of register can be selected as the position command. See as the following table:

Position Command	POS5	POS4	POS3	POS2	POS1	POS0	CTRG	Parameters							
P1	ON	ON	ON	ON	ON	ON	†	P6-00							
F1	ON	ON	ON	ON	ON	ON		P6-01							
DO	ON	ON	ON	ON	ON	OFF	†	P6-02							
P2	ON	ON	ON	ON	ON	ON ON O	ON C	ON ON	UN	ON	ON	ON OF	OFF	ļ	P6-03
~								~							
P50	OFF	OFF	ON	ON	ON OFF	ON	†	P6-98							
P50	OFF	OFF	ON	ON	OFF	ON	ON	ļ	P6-99						
DE1	OFF	055	OFF	OFF	OFF	ON	ON	ON OFF	OFF	†	P7-00				
P51	OFF	OFF	ON			ON OFF C			UFF	OFF		ļ	P7-01		
~								~							
D64	OFF	OFF	OFF	OFF	OFF	OFF	- 055	†	P7-26						
P64	UFF	UFF	UFF	UFF	OFF	UFF	UFF		P7-27						

Status of POS0 ~ POS5: 0 means the DI is OFF; 1 means the DI is ON.


CTRG[†]: the moment DI is OFF to ON.

The application of absolute type and incremental type register is rather extensive. It is more like a simple procedure control. Users can complete the cyclic operation by referring to the above table. For example, position command P1 is 10 turns and P2 is 20 turns. P1 is issued first and P2 comes after. The following diagram shows the difference of both.




6.2.3 Control Structure of Position Mode

The basic control structure is as the following diagram:



For a better control, the pulse signal should be processed and modified through position command unit. Structure is shown as the diagram below.




The upper path of the above diagram is PR mode and the lower one is PT mode which could be selected via P1-01. Both modes can set E-gear ratio for the proper position resolution. Moreover, either S-curve filter or low-pass filter can be used to smooth the command. See the description in later parts.

6-8 Revision February, 2017


Pulse Command Inhibit Input Function (INHP)

Use DI to select INHP (Refer to P2-10~17 and table 8.1 INHP (45)) before using this function. If not, this function will be unable to use. When DI (INHP) is ON, the pulse command will be cleared in position control mode and the motor will stop running. (Only DI 8 supports this function.)




6.2.4 S-curve Filter (Position)

S-curve filter smoothes the motion command. With S-curve filter, the process of acceleration becomes more continuous and the jerk will be smaller. It not only improves the performance when motor accelerates / decelerates, but also smoothes the operation of mechanical structure. When the load inertia increases, the operation of the motor will be influenced by friction and inertia during the time of activation and stop. However, the situation can be improved by increasing the value of Acceleration / Deceleration Constant of S-Curve (TSL), Acceleration Constant of S-Curve (TACC) and Deceleration Constant of S-Curve (TDEC). When the position command source is pulse, its speed and angular acceleration is continuous, thus, S-curve filter is not a must.



Position and speed S-curve and time setting (acceleration for position command)



Position and speed S-curve and time setting (deceleration for position command)

Relevant Parameters:

aic	iameters.						
	TACC	Ac	celeration Constant	Address: 0144H 0145H			
	Operatio Interface		Panel / Software	Communication	Related Section: 6.3.3		
	Defaul	lt :	200				
	Con Mode		S				
	Uni	it :	ms				
	Range	e :	1 ~ 65500				
	Data Size	e :	16-bit				
	Forma	ıt :	Decimal				

Settings: Acceleration Constant of Rotary Motor:

The time that speed command accelerates from 0 to the rated speed.

Acceleration Constant of Linear Motor

The time that speed command accelerates from 0 to 5m/s.

P1-34, P1-35 and P1-36, the acceleration time of speed command from zero to the rated speed, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.



- **NOTE** 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-34 will be set within 20000 automatically.

6-10 Revision February, 2017

P1-35

TDEC De	celeration Constant	Address: 0146H 0147H			
Operational Interface :	Danal / Caffurara Communication		Related Section: 6.3.3		
Default:	200				
Control Mode :	S				
Unit:	ms	ms			
Range :	1 ~ 65500				
Data Size :	16-bit				
Format :	Decimal				

Settings: Deceleration Constant of Rotary Motor:

The time that speed command decelerates from the rated speed to 0.

Deceleration Constant of Linear Motor:

The time that speed command decelerates from 5m/s to 0.

P1-34, P1-35 and P1-36, the deceleration time of speed command from the rated speed to zero, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.




- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-35 will be set within 20000 automatically.

P1-36	I ISI L	cceleration / Deceler urve	ration Constant of S-	Address: 0148H 0149H	
	Operational Interface	DI/O-#	Communication	Related Section: 6.3.3	
	Default	: 0			
	Contro Mode	C DD			
	Unit	; ms			
	Range	: 0 ~ 65500 (0: disabl	e this function)		
	Data Size	; 16-bit			
	Format	: Decimal			

6-11 Revision February, 2017

Settings: Acceleration / Deceleration Constant of S-Curve:



- P1-34: Set the acceleration time of acceleration / deceleration of trapezoid-curve
- P1-35: Set the deceleration time of acceleration / deceleration of trapezoid-curve
- P1-36: Set the smoothing time of S-curve acceleration and deceleration
- P1-34, P1-35 and P1-36 can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.



- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-36 will be set within 10000 automatically.

6.2.5 Electronic Gear Ratio

Related parameters:

P1-44 ▲		·	ar Ratio (Numerator) (N1)			
	Operational Interface	Panel / Software	Communication	Related Section: 6.2.5		
	Default :	1				
	Contro Mode :	PT / PR				
	Unit :	Pulse				
	Range :	1 ~ (2 ²⁹ -1)				
	Data Size :	: 32-bit				
	Format :	Decimal				

Settings: Please refer to P2-60~P2-62 for the setting of multiple gear ratio (numerator).



- 1. In PT mode, the setting value can be changed when Servo ON.
- 2. In PR mode, the setting value can be changed when Servo OFF.


6-12 Revision February, 2017 P1-45

GR2 Ge	ar Ratio (Denominato	Address: 015AH 015BH	
Operational Interface :	Panel / Software	Communication	Related Section: 6.2.5
Default :	1		
Control Mode :	PT / PR		
Unit :	Pulse		
Range :	1 ~ (2 ³¹ -1)		
Data Size :	32-bit		
Format :	Decimal		

Settings: If the setting is wrong, the servo motor will easily have sudden unintended acceleration.

Please follow the rules for setting:

The setting of pulse input:



Range of command pulse input: 1 / 50 < Nx / M < 25600


NOTE 1) The setting value cannot be changed when Servo ON neither in PT nor in PR mode.

E-Gear ratio =
$$(\frac{N}{M}) = \frac{P1-44}{P1-45}$$
, has to match $\frac{1}{50} \le (\frac{N}{M}) \le 5000$

Electronic gear provides simple ratio change of travel distance. The high electronic gear ratio would cause the position command to be the stepped command. S-curve or low-pass filter can be used to improve the situation. When electronic gear ratio is set to 1, the motor will turn one cycle for every 10000PUU. When electronic gear ratio is changed to 0.5, then every two pulses from the command will be refer to one PUU of motor encoder.

6-13 Revision February, 2017

For example (rotary motor): after setting the electronic gear ratio properly, the moving distance of the object is $1\mu m/pulse$, which is easier to use.



Motor (Encoder resolution: A/B, Z)

	Gear Ratio	Moving distance of each pulse command
Electronic gear is unapplied.	$=\frac{1}{1}$	$=\frac{3\times1000}{4\times2500}=\frac{3000}{10000}=\mu\text{m}$
Electronic gear is applied.	$=\frac{10000}{3000}$	$=1\mu m$

6-14 Revision February, 2017


6.2.6 Low-pass Filter

Related parameters:

P1-08


PFLT		ooth Constant of P ss Filter)	Address: 0110H 0111H	
Operation Interfac		Panel / Software	Communication	Related Section: 6.2.6
Defau	lt:	0		
Con Mod		PT / PR		
Un	it:	10 ms		
Rang	e :	0 ~ 1000		
Data Siz	e :	16-bit		
Forma	at:	Decimal		
Exampl	e :	11 = 110 ms		
0 11:		O. Disabled		

Settings: 0: Disabled



6.2.7 Timing Diagram in Position Mode (PR)

In PR mode, the position command is selected by either DI signal (POS0~POS5 and CTRG) of CN1 or communication. Please refer to Section 6.2.2 for the information about DI signal and its selected register. Followings are the timing diagrams.



 CMD_OK : CMD_OK is activated when the servo drive has detected that Pr command has been completed

TPOS: TPOS will be activated when the drive detects that the position of the motor is in a -P1-54 to +P1-54 band of the target position.

MC_OK: MC_OK is activated when CMD_OK and TPOS are both ON.

6-16 Revision February, 2017

6.2.8 Gain Adjustment of Position Loop

Before setting the position control unit, users have to manually (P2-32) complete the setting of speed control unit since the speed loop is included in position loop. Then, set the proportional gain (parameter P2-00) and feed forward gain (parameter P2-02) of position loop. Users also can use the auto mode to set the gain of speed and position control unit automatically.

- 1) Proportional gain: Increase the gain so as to enhance the response bandwidth of position loop.
- 2) Feed forward gain: Minimize the deviation of phase delay

The position loop bandwidth cannot exceed the speed loop bandwidth. It is suggested that $fp \le \frac{fv}{4}$.

fv: response bandwidth of speed loop (Hz).

KPP = $2 \times \pi \times \text{fp.}$ fp: response bandwidth of position loop (Hz).

For example, the desired position bandwidth is 20 Hz \rightarrow KPP = $2 \times \pi \times 20 = 125$.

Related parameters:

P2-00	KPP Po	osition Loop Gain	sition Loop Gain			
	Operationa Interface :	al Panel / Software	Communication	Related Section: 6.2.8		
	Default :	35				
	Contro Mode :	DT / DD				
	Unit :	rad/s				
	Range :	0 ~ 2047				
	Data Size :	16-bit				
	Format :	Decimal				


Settings: When the value of position loop gain is increased, the position response can be enhanced and the position error can be reduced. If the value is set too big, it may easily cause vibration and noise.

P2-02	PFG	Position Feed Forwar	Address: 0204H 0205H	
		onal Panel / Software e:	Communication	Related Section: 6.2.8
	Default: 50			
	Con Mode	trol e:PT / PR		
	Un	it : %		


Range :	0 ~ 100
Data Size :	16-bit
Format :	Decimal

Settings: If the position command is changed smoothly, increasing the gain value can reduce the position error.

If the position command is not changed smoothly, decreasing the gain value can tackle the problem of mechanical vibration.



When the value of proportional gain, KPP is set too big, the response bandwidth of position loop will be increased and diminish the phase margin. And the motor rotor rotates vibrantly in forward and reverse direction at the moment. Thus, KPP has to be decreased until the rotor stops vibrating. When the external torque interrupts, the over-low KPP cannot meet the demand of position deviation. In this situation, parameter P2-02 can effectively reduce the position error.



6-18 Revision February, 2017


6.2.9 Low-frequency Vibration Suppression in Position Mode

If the stiffness is not enough, the mechanical transmission will continue to vibrate even when the motor stops after completing the positioning command. The function of low-frequency vibration suppression can eliminate the vibration of mechanical transmission. The range is between 1.0Hz and 100.0HZ. Both manual setting and auto setting are provided.

Auto setting:

If the frequency is hard to find, it can enable the function of auto low-frequency vibration suppression. This function automatically searches the frequency of low-frequency vibration. If P1-29 is set to 1, the system will disable the function of low-frequency vibration suppression automatically and starts to search the vibration frequency. When the detected frequency remains at the same level, P1-29 will be set to 0 automatically and set the first frequency in P1-25 and set P1-26 to 1. The second frequency will be set in P1-27 and then set P1-28 to 1. If P1-29 is automatically set back to 0 and still has low-frequency vibration, please check if the function of P1-26 or P1-28 is enabled. If the value of P1-26 and P1-28 is 0, it means no frequency has been detected. Please decrease the value of P1-30 and set P1-29 to 1 so as to search the vibration frequency again. Please note that when the detection level is set too small, the noise will be regarded as the low-frequency.

Flowchart of auto low-frequency vibration suppression:



Note 1: When the value of P1-26 and P1-28 is 0, it means it is unable to search the frequency. It is probably because the detection level is set too high and is unable to detect the low-frequency vibration.

Note 2: When the value of P1-26 or P1-28 is not set to 0 and still cannot eliminate the vibration, it is probably because the detection level is set too low, the system regards the noise or other non-primary frequency as the low-frequency vibration.

Note 3: When the process of auto vibration suppression is completed and the vibration still cannot be diminished, P1-25 or P1-27 can be manually set to suppress the vibration if the frequency (Hz) of the low-frequency is identified.

Related parameters:

ed parar	meters:			
P1-29	77 1/ 2 IVI	Auto Low-frequency \ Setting	/ibration Supression	Address: 013AH 013BH
	Operatior Interface	Danal / Coffware	Communication	Related Section: 6.2.9
	Default	: 0		
	Cont Mode	PT / PR		
	Unit	t:-		
	Range	: 0 ~ 1		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: 0: The function is disabled.

1: The value will set back to 0 after vibration suppression.

Description of Auto Mode Setting:

When the parameter is set to 1, it is in auto suppression. When the vibration frequency is not being detected or the value of searched frequency is stable, the parameter will set to 0 and save the low-frequency vibration suppression to P1-25 automatically.

P1-30			Low-frequency Vibration Detection			
		onal Panel / Software e:	Communication	Related Section: 6.2.9		
		lt : 500				
mode .		e: PT/PR	PT / PR			

6-20 Revision February, 2017

Unit :	Pulse
Range :	1 ~ 8000
Data Size :	16-bit
Format :	Decimal

Settings: When enabling the auto suppression (P1-29 = 1), it will automatically search the detection level. The lower the value is, the more sensitive the detection will be. However, it is easy to misjudge the noise or regard the other low-frequency vibration as the suppression frequency. If the value is bigger, it will make more precise judgment. However, if the vibration of the mechanism is smaller, it might not detect the

frequency of low-frequency vibration.

P1-30 is to set the range to detect the magnitude of low-frequency vibration. When the frequency is not being detected, it is probably because the value of P1-30 is set too big which exceeds the range of vibration. It is suggested to decrease the value of P1-30. Please note that if the value is too small, the system might regard the noise as the vibration frequency. If the SCOPE is available, it can be used to observe the range of position error (pulse) between upper and lower magnitude of the curve and set up the appropriate value of P1-30.

Manual Setting:

There are two sets of low-frequency vibration suppression. One is parameter P1-25~P1-26 and another one is parameter P1-27~P1-28. These two sets of low-frequency vibration suppression can be used to eliminate two different frequency vibrations. Parameter P1-25 and P1-27 are used to suppress the low-frequency vibration. The function is working only when the parameter setting value of low-frequency vibration close to the real vibration frequency. Parameter P1-26 and P1-28 are used to set the response after filter. The bigger the setting value of P1-26 and P1-28 is, the better response will be. However, if the value is set too big, the motor might not operate smoothly. The default value of parameter P1-26 and P1-28 is 0, which means the function is disabled. Followings are the related parameters:

P1-25	VSF1	Low-frequency Vibrat	Address: 0132H 0133H	
	Operation	nal Papal / Software	Communication	Related Section:
	Operational Panel / Software		Communication	6.2.9
	Default: 1000			
		rol PT / PR		

Unit: 0.1 Hz

Range: 10 ~ 1000

Data Size: 16-bit

Format: Decimal

Example: 150= 15 Hz

Settings: The setting value of the first low-frequency vibration suppression. If P1-26 is set to 0, then it will disable the first low-frequency filter.

Low-frequency Vibration Suppression Gain Address: 0134H VSG1 P1-26 0135H Operational Related Section: Panel / Software Communication 6.2.9 Interface: Default: 0 Control PT / PR Mode: Unit: -Range: $0 \sim 9$ (0: Disable the first low-frequency filter) Data Size: 16-bit Format : Decimal

Settings: The first low-frequency vibration suppression gain. The bigger value it is, the better the position response will be. However, if the value is set

too big, the motor will not be able to smoothly operate. It is suggested

to set the value to 1.

VSF2 Lo	ow-frequency Vibrat	Address: 0136H 0137H	
Operationa Interface :	ıl Panel / Software	Communication	Related Section: 6.2.9
Default :	1000		
Contro Mode :	PT / PR		
Unit:	0.1 Hz		
Range :	10 ~ 1000		
Data Size :	16-bit		
Format :	Decimal		
Example :	150 = 15 Hz		

6-22 Revision February, 2017

Settings: The setting value of the second low-frequency vibration suppression. If P1-28 is set to 0, then it will disable the second low-frequency filter.

P1-28	VSG2 L	.ow-frequency Vibra	w-frequency Vibration Suppression Gain (2)		
	Operational Interface	D 1 / O-ft	Communication	Related Section: 6.2.9	
	Default	: 0			
	Control Mode :				
	Unit	-			
Range: 0~9 filter		. 0 ~ 9 (0: Disable th	0 ~ 9 (0: Disable the second low-frequency filter)		
	Data Size: 16-bit Format: Decimal				

Settings: The second low-frequency vibration suppression gain. The bigger value it is, the better the position response will be. However, if the value is set too big, the motor will not be able to smoothly operate. It is suggested to set the value to 1.

6.3 Speed Mode

Speed control mode (S or Sz) is applicable in precision speed control, such as CNC machine tools. This servo drive includes two types of command input, analog and register. Analog command input can use external voltage to control the motor speed. There are two methods in register input. One is used before operation. Users set different value of speed command in three registers, and then use SP0, SP1 of CN1 DI signal for switching. Another method is to change the value of register by communication. In order to deal with the problem of non-continuous speed command when switching register, a complete S-curve program is provided. In close-loop system, this servo drive adopts gain adjustment and integrated PI controller and two modes (manual and auto) for selection. Users can set all parameters and all auto or auxiliary function will be disabled in manual mode. While in auto mode, it provides the function of load inertia estimation and parameter adjustment. In auto mode, parameters which set by users will be regarded as the default value.

6.3.1 Selection of Speed Mode

There are two types of speed command source, analog voltage and internal parameters. The selection is determined by CN1 DI signal. See as the followings.

Speed	CN1 D	N1 DI signal		Command Source		Content	Dongo	
Command	SPD1	SPD0	Command Source		iliu Source	Content	Range	
S1	0	0	Mode	S	External analog signal	Voltage between V- REF-GND	-10 V ~ +10V	
					Sz	N/A	Speed command is 0	0
S2	0	1		Register parameters		P1-09		
S3	1	0	Regist			P1-10	-60000 ~ 60000	
S4	1	1				P1-11		

- Status of SPD0 ~ SPD1: 0 means DI OFF, 1 means DI ON.
- When both SPD0 and SPD1 are 0, if it is in Sz mode, the command will be 0. Thus, if there is no need to use analog voltage as the speed command, Sz mode can be applied to tackle the problem of zero-drift. If it is in S mode, the command will be the voltage deviation between V-REF and GND. The range of input voltage is between -10V and +10V and its corresponding speed is adjustable (P1-40).
- When one of SPD0 and SPD1 is not 0, the speed command is from the internal parameter. The command is activated after changing the status of SPD0~SPD1. There is no need to use CTRG for triggering.

6-24 Revision February, 2017


■ The setting range of internal parameters is between -60000 and 60000. Setting value = setting range x unit (0.1r/min).

For example: P1-09 = +30000, setting value = $+30000 \times 0.1$ r/min = +3000r/min

The speed command not only can be issued in speed mode (S or Sz), but also in torque mode (T or Tz) as the speed limit.


6.3.2 Control Structure of Speed Mode

The basic control structure is shown as the following diagram:



The speed command unit is to select speed command source according to Section 6.3.1, including the scaling (P1-40) setting and S-curve setting. The speed control unit manages the gain parameters of the servo drive and calculates the current command for servo motor in time. The resonance suppression unit is to suppress the resonance of mechanism. Detailed descriptions are shown as the following:

Here firstly introduces the function of speed command unit. Its structure is as the following diagram.




The upper path is the command from register while the lower one is external analog command. The command is selected according to the status of SPD0, SPD1 and P1-01(S or Sz). Usually, Scurve and low-pass filter are applied for having a smooth resonance of command.

6.3.3 Smooth Speed Command

S-curve Filter

During the process of acceleration or deceleration, S-curve filter applies the program of three-stage acceleration curve for smoothing the motion command, which generates the continuous acceleration. It is for avoiding the jerk (the differentiation of acceleration) came from the sudden command change and indirectly causes the resonance and noise. Users can use acceleration constant of S-curve (TACC) to adjust the slope changed by acceleration, deceleration constant of S-curve (TDEC) to adjust the slope changed by deceleration and acceleration / deceleration constant of S-curve (TSL) to improve the status of motor activation and stop. The calculation of the time to complete the command is provided.



S-curve characteristics and Time relationship

Related parameters:

P1-34	TACC	Acceleration Constan	celeration Constant of S-Curve		
	Operation Interface	al Panel / Software	Communication	Related Section: 6.3.3	
	Default	: 200	00		
	Contr Mode	S			
	Unit	; ms			
	Range	: 1 ~ 65500			
	Data Size	: 16-bit			
	Format	: Decimal			

6-26 Revision February, 2017

Settings: Acceleration Constant of Rotary Motor:

The time that speed command accelerates from 0 to the rated speed.

Acceleration Constant of Linear Motor

The time that speed command accelerates from 0 to 5m/s.

P1-34, P1-35 and P1-36, the acceleration time of speed command from zero to the rated speed, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.



- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-34 will be set within 20000 automatically.

P1-35	TDEC	Deceleration Constant	Deceleration Constant of S-Curve		
	Operation Interfac	onal e : Panel / Software	Communication	Related Section: 6.3.3	
	Defau	lt: 200			

Mode: Unit: ms

Control

Range: 1 ~ 65500

Data Size: 16-bit

Format: Decimal

Settings: Deceleration Constant of Rotary Motor:

The time that speed command decelerates from the rated speed to 0.

Deceleration Constant of Linear Motor:

The time that speed command decelerates from 5m/s to 0.

P1-34, P1-35 and P1-36, the deceleration time of speed command from the rated speed to zero, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.



- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-35 will be set within 20000 automatically.


6-27 Revision February, 2017

P1-36

I ISI L	celeration / Decelerati	Address: 0148H 0149H	
Operational Interface :	Panel / Software	Related Section: 6.3.3	
Default :	0		
Control Mode :	S, PR		
Unit:	ms		
Range :	0 ~ 65500 (0: disable t	his function)	
Data Size :	16-bit		
Format :	Decimal		

Settings

Acceleration / Deceleration Constant of S-Curve:



- P1-34: Set the acceleration time of acceleration / deceleration of trapezoid-curve
- P1-35: Set the deceleration time of acceleration / deceleration of trapezoid-curve
- P1-36: Set the smoothing time of S-curve acceleration and deceleration

P1-34, P1-35 and P1-36 can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.




- **NOTE** 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-36 will be set within 10000 automatically.

Analog Speed Command Filter

Analog speed command filter is provided especially for ASDA-A2 series users. It mainly helps with buffer when the analog input signal changes too fast.

6-28 Revision February, 2017



Analog speed command filter smooth the analog input command. Its time program is the same as S-curve filter in normal speed. Also, the speed curve and the acceleration curve are both continuous. The above is the diagram of analog speed command filter. The slope of speed command in acceleration and deceleration is different. Users could adjust the time setting (P1-34, P1-35 and P1-36) according to the actual situation to improve the performance.


Command End Low-pass Filter

It is usually used to eliminate the unwanted high-frequency response or noise. It also can smooth the command.

Related parameters:


-06 SF	LT A	nalog Speed Comma	and (Low-pass Filter)	Address: 010CH 010DH
Op Int	erationa erface :	ll Panel / Software	Communication	Related Section: 6.3.3
	Default :	0	0	
	Contro Mode :	ms 0 ~ 1000 (0: disable this function)		
	Unit :			
1	Range :			
Dat	a Size :			
F	ormat :	Decimal		
i		0. Dia abla d		

Settings: 0: Disabled



6.3.4 The Scaling of Analog Command

The motor speed command is controlled by the analog voltage deviation between V_REF and VGND. Use parameter P1-40 to adjust the speed-control slope and its range.



Related parameters:

D4	-40 A
	-4U A

VCM	Maximum Speed of Analo	aximum Speed of Analog Speed Command				
Operation Interface	nal	Communication	0151H Related Section: 6.3.4			
Defau	t:Same as the rated spec	Same as the rated speed of each model				
Con Mode	C/T					
Un	t : r/min					
Range	e: 0 ~ 5000	0 ~ 5000				
Data Size	e:16-bit	16-bit				
Forma	t : Decimal					

Settings: Maximum Speed of Analog Speed Command:

In speed mode, the analog speed command inputs the swing speed setting of the max. voltage (10V).

For example, if the setting is 3000, when the external voltage input is 10V, it means the speed control command is 3000r/min. If the external voltage input is 5V, then the speed control command is 1500r/min.


Speed control command = input voltage value x setting value / 10

In position or torque (force) mode, analog speed limit inputs the swing speed limit setting of the max. voltage (10V).

Speed limit command = input voltage value x setting value / 10

6-30 Revision February, 2017

6.3.5 Timing Diagram in Speed Mode






- 1) OFF means the contact point is open while ON means the contact point is close.
- 2) When it is in Sz mode, the speed command S1 = 0; When it is in S mode, the speed command S1 is the external analog voltage input.
- 3) When the servo drive is On, please select the command according to SPD0~SPD1 status.

6.3.6 Gain Adjustment of Speed Loop

Here introduces the function of speed control unit. The following shows its structure.



Many kinds of gain in speed control unit are adjustable. Two ways, manual and auto, are provided for selection.

Manual: All parameters are set by users and the auto or auxiliary function will be disabled in this mode.

Auto: General load inertia estimation is provided. It adjusts the parameter automatically. Its framework is divided into PI auto gain adjustment and PDFF auto gain adjustment.

Parameter P2-32 can be used to adjust the gain.

P2-32 ▲	AUT2 Tu	ning Mode Selectio	n	Address: 0240H 0241H
	Operational Interface :	Panel / Software	Communication	Related Section: 5.6 and 6.3.6
	Default :	0		
-	Control Mode :	ALL		
_	Unit :	:- :-		
-	Range :	0 ~ 0x2		 : :
-	Data Size :	16-bit		:
-	Format :	Hexadecimal		

Settings: 0: Manual Mode

1: Auto Mode (continuous adjustment)

2: Semi-auto Mode (non- continuous adjustment)

Relevant description of manual mode setting:

When P2-32 is set to 0, parameters related to gain control, such as P2-00, P2-02, P2-04, P2-06, P2-07, P2-25 and P2-26, all can be set by the user.

When switching mode from auto or semi-auto to manual, parameters about gain will be updated automatically.

Relevant description of auto mode setting:

Continue to estimate the system inertia, save the inertia ratio to P1-37 every 30 minutes automatically and refer to the stiffness and bandwidth setting of P2-31.

- 1. Set the system to manual mode 0 from auto 1 or semi-auto 2, the system will save the estimated inertia value to P1-37 automatically and set the corresponding parameters.
- 2. Set the system to auto mode 1 or semi-auto mode 2 from manual mode 0, please set P1-37 to the appropriate value.
- 3. Set the system to manual mode 0 from auto mode 1, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the corresponding parameters of auto mode.
- 4. Set the system to manual mode 0 from semi-auto mode 2, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the corresponding parameters of semi-auto mode.

Relevant description of semi-auto mode setting:

6-32 Revision February, 2017

Relevant description of semi-auto mode setting:

- 1. When the system inertia is stable, the value of P2-33 will be 1 and the system stops estimating. The inertia value will be saved to P1-37 automatically. When switching mode to semi-auto mode (from manual or auto mode), the system starts to estimate again.
- 2. When the system inertia is over the range, the value of P2-33 will be 0 and the system starts to estimate and adjust again.

Manual Mode

When P2-32 is set to 0, users can define Speed Loop Gain (P2-04), Speed Integral Compensation (P2-06) and Speed Feed Forward Gain (P2-07). Influence of each parameter is as the followings.

Proportional gain: To increase proportional gain can enhance the response frequency of speed loop.

Integral gain: To increase the integral gain could increase the low-frequency stiffness of speed loop, reduce the steady-state error and sacrifice the phase margin. The over high integral gain will cause the instability of the system.

Feed forward gain: Diminish the deviation of phase delay.

Relevant parameters:

P2-04	KVP Sp	peed Loop Gain		Address: 0208H 0209H
	Operationa Interface :	ll Panel / Software	Communication	Related Section: 6.3.6
	Default: 500			
	Control Mode:			
	Unit :	rad/s		
	Range :	0 ~ 8191		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: Increase the value of speed loop gain can enhance the speed response. However, if the value is set too big, it would easily cause

resonance and noise.

P2-06	KVI	Speed Integral Compe	Speed Integral Compensation		
	Operation Interfact	onal Panel / Software e :	Communication	Related Section: 6.3.6	
	Defau	ılt : 100			

Control Mode:

Unit: rad/s

Range: 0 ~ 1023

Data Size: 16-bit

Format: Decimal

Settings: Increasing the value of speed integral compensation can enhance speed response and diminish the deviation of speed control. However,

if the value is set too big, it would easily cause resonance and noise.

P2-07	KVF Sp	peed Feed Forward (Address: 020EH 020FH	
	Operationa Interface:	l Panel / Software	Communication	Related Section: 6.3.6
	Default :	0		
	Contro Mode :	ALI		
	Unit :	%		
	Range :	0 ~ 100		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: When the speed control command runs smoothly, increasing the gain value can reduce the speed command error. If the command does not

run smoothly, decreasing the gain value can reduce the mechanical


vibration during operation.

Theoretically, stepping response can be used to explain proportional gain (KVP), integral gain (KVI) and feed forward gain (KVF). Here, the frequency domain and time domain are used to illustrate the basic principle.


6-34 Revision February, 2017

Frequency Domain


STEP 1: Set the value of KVI=0, the value of KVF=0 and adjust the value of KVP.



STEP 2: Fix the value of KVP and adjust the value of KVI.




STEP 3: Select the value of KVI, if the value of phase margin is too small, re-adjust the value of KVP again to obtain the value, 45deg of phase margin.



Time Domain

Speed



The bigger KVP value cause higher bandwidth and shorten the rising time. However, if the value is set too big, the phase margin will be too small.

To steady-state error, the result is not as good as KVI. But it helps to reduce the dynamic following error.



The bigger KVI value cause greater lowfrequency gain and shorten the time the steady-state error returns to zero. However, the phase margin will dramatically decrease as well.

To steady-state error, it is very helpful but shows no benefit to dynamic following error.

KVF

If the KVF value closes to 1, the feed forward compensation will be more complete and the dynamic following error will become smaller. However, if the KVF value is set too big, it would cause vibration.

Generally, instrument is needed when applying frequency domain for measurement. Users are required to adopt the measurement techniques; while time domain only needs a scope and goes with the analog input / output terminal provided by the servo drive. Thus, time domain is frequently

▶ Time

► Time


6-36 Revision February, 2017

used to adjust PI controller. The abilities of PI controller to deal with the resistance of torque load and the following command are the same.

That is to say, the following command and resistance of torque load have the same performance in frequency domain and time domain. Users can reduce the bandwidth by setting the low-pass filter in command end.

Auto Mode

Auto mode adopts adaptive principle. The servo drive automatically adjusts the parameters according to the external load. Since the adaptive principle takes longer time, it will be unsuitable if the load changes too fast. It would be better to wait until the load inertia is steady or changes slowly. Depending on the speed of signal input, the adaptive time will be different from one another.



6.3.7 Resonance Suppression

When resonance occurs, it is probably because the stiffness of the control system is too strong or the response is too fast. Eliminating these two factors might improve the situation. In addition, low-pass filter (parameter P2-25) and notch filter (parameter P2-23 and P2-24) are provided to suppress the resonance if not changing the control parameters.

Related parameters:

P2-23	NCF1	Resonance Suppress	ion (Notch filter) (1)	Address: 022EH 022FH
	Operation Interface	nal Panel / Software	Communication	Related Section: 6.3.7
	Defaul	t : 1000	ALL Hz	
	Cont Mode	: А І І		
	Uni	t : Hz		
	Range	e: 50 ~ 1000		
-	Data Size	e: 16-bit	16-bit	
	Forma	t : Decimal		

Settings: The first setting value of resonance frequency. If P2-24 is set to 0, this function is disabled. P2-43 and P2-44 are the second Notch filter.

P2-24		esonance Suppressic ttenuation Rate (1)	sonance Suppression (Notch filter) enuation Rate (1)		
	Operational Interface:	al Panel / Software	Communication	Related Section: 6.3.7	
	Default :	0	0		
	Control Mode :				
	Unit : dB				
	Range: 0 ~ 32 (0: disable the function of Notch filter) Data Size: 16-bit		function of Notch filter)		
	Format :	Decimal			

Settings: The first resonance suppression (notch filter) attenuation rate. When this parameter is set to 0, the function of Notch filter is disabled.

NOTE If the value of attenuation rate is set to 5, then, it would be -5dB.

6-38 Revision February, 2017

P2-43	NCF2 Re	esonance Suppress	ion (Notch filter) (2)	Address: 0256H 0257H
	Operationa Interface:	Danal/Caffurana	Communication	Related Section: 6.3.7
	Default:	1000		
	Contro Mode :	ΛII		
	Unit :	Hz		
	Range :	50 ~ 2000		
	Data Size :	16-bit		
	Format :	Decimal		
	Settings:	The second setting	value of resonance freque	ency. If P2-44 is set to 0,

Address: 0258H **Resonance Suppression (Notch filter)** P2-44 DPH2 Attenuation Rate (2) 0259H Related Section: Operational Panel / Software Communication 6.3.7 Interface: Default: 0 Control Mode: Unit: dB Range: 0 ~ 32 (0: disable Notch filter) Data Size: 16-bit Format: Decimal

Settings: The second resonance suppression (notch filter) attenuation rate. When this parameter is set to 0, the function of Notch filter is disabled.

this function is disabled. P2-23 and P2-24 are the first Notch filter.

NOTE If the value of attenuation rate is set to 5, then it would be -5dB.

P2-46	рыз	Resonance Suppressi Attenuation Rate (3)	on (Notch filter)	Address: 025CH 025DH
	Operation Interfac	onal Panel / Software e :	Communication	Related Section: 6.3.7
	Defau	ılt : O		
	Cor Mod	ntrol e :		

Unit: dB

Range: 0 ~ 32

Data Size: 16-bit


Format: Decimal

Settings: The third group of resonance suppression (Notch filter) attenuation

rate. Set the value to 0 to disable the function of Notch filter.

P2-25	NLP Lo	w-pass Filter of Reso	onance Suppression	Address: 0232H 0233H
	Operational Interface :	Panel / Software	Communication	Related Section: 6.3.7
	Default :	0.2 (under 1kW) or 0.5 (other model)	2 (under 1kW) or 0.5 (other model)	
	Control Mode :	ALL		
	Unit :	1 ms	0.1 ms	
	Range :	0.0 ~ 100.0	0 ~ 1000	
	Data Size :	16-bit		
	Format :	One decimal	Decimal	
	Example :	1.5 = 1.5 ms	15 = 1.5 ms	

Settings: Set the low-pass filter of resonance suppression. When the value is set to 0, the function of low-pass filter is disabled.



6-40 Revision February, 2017


There are two sets of auto resonance suppression, one is P2-43 and P2-44 and another one is P2-45 and P2-46. When the resonance occurs, set P2-47 to 1 or 2 (enable the function of resonance suppression), the servo drive searches the point of resonance frequency and suppresses the resonance automatically. Write the point of frequency into P2-43 and P2-45 and write the attenuation rate into P2-44 and P2-46. When P2-47 is set to 1, the system will set P2-47 to 0 (disable the function of auto suppression) automatically after completing resonance suppression and the system is stable for 20 minutes. When P2-47 is set to 2, the system will keep searching the point of resonance.

When P2-47 is set to 1 or 2, but resonance still exists, please confirm the value of parameter P2-44 and P2-46. If one of them is 32, it is suggested to reduce the speed bandwidth first and then start to estimate again. If the value of both is smaller than 32 and resonance still exists, please set P2-47 to 0 first and then manually increase the value of P2-44 and P2-46. It is suggested to reduce the bandwidth if the resonance has not been improved. Then use the function of auto resonance suppression.

When manually increase the value of P2-44 and P2-46, please check if the value of both is bigger than 0. If yes, it means the frequency point of P2-43 and P2-45 is the one searched by auto resonance suppression. If the value of both is 0, it means the default, 1000 of P2-43 and P2-45 is not the one searched by auto resonance suppression. Deepen the resonance suppression attenuation rate might worsen the situation.


	Settings of P2-47		
Current Value	Desired Value	Function	
0	1	Clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function.	
0	2	Clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function.	
1	0	Save the setting value of P2-43 ~ P2-46 and disable auto resonance suppression function.	
1	1	Clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function.	
1	2	Do not clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function continuously.	
2	0	Save the setting value of P2-43 ~ P2-46 and disable auto resonance suppression function.	
2	1	Clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function.	
2	2	Do not clear the setting value of P2-43 ~ P2-46 and enable auto resonance suppression function continuously.	

Flowchart of Auto Resonance Suppression:




6-42 Revision February, 2017

Here illustrates the effect via low-pass filter (parameter P2-25). The following diagram is the system open-loop gain with resonance.




When the value of P2-25 is increased from 0, BW becomes smaller (See as the following diagram). Although it solves the problem of resonance frequency, the response bandwidth and phase margin is reduced.




If users know the resonance frequency, notch filter (parameter P2-23 and P2-24) can directly eliminate the resonance. The frequency setting range of notch filter is merely from 50 to 1000Hz. The suppression strength is from 0 to 32dB. If the resonance frequency is not within the range, it is suggested to use low-pass filter (parameter P2-25).

Here firstly illustrates the influence brought by notch filter (P2-23 and P2-24) and low-pass filter (P2-25). The following diagrams are the system of open-loop gain with resonance.

Resonance suppression with notch filter



Resonance suppression with low-pass filter



When the value of P2-25 is increased from 0, BW becomes smaller. Although it solves the problem of resonance frequency, the response bandwidth and phase margin is reduced. Also, the system becomes unstable.

If users know the resonance frequency, notch filter (parameter P2-23 and P2-24) can directly eliminate the resonance. In this case, notch filter will be more helpful than low-pass filter. However, if the resonance frequency drifts because of time or other factors, notch filter will not do.

6-44 Revision February, 2017

6.4 Torque Mode

Torque control mode (T or Tz) is appropriate in torque control application, such as printing machine, winding machine, etc. There are two kinds of command source, analog input and register. Analog command input uses external voltage to control the torque of the motor while register uses the internal parameters (P1-12~P1-14) as the torque command.

6.4.1 Selection of Torque Command

Torque command source are external analog voltage and parameters. It uses CN1 DI signal for selection. See as below.


Torque Command	DI signal of CN1 TCM1 TCM0		Command Source		Content	Range	
	TOMI	I CIVIU					
T1	0	0	Mode	Т	External analog command	Voltage between T-REF-GND	-10V ~ +10V
	0	U	Mode	Tz	None	Torque command is 0	0
T2	0	1				P1-12	/
Т3	1	0		P	arameters	P1-13	-300% ~ 300%
T4	1	1				P1-14	30070

- The status of TCM0 ~ TCM1: 0 means DI OFF and 1 means DI ON.
- When TCM0 = TCM1 = 0, if it is in Tz mode, then the command is 0. Thus, if there is no need to use analog voltage as torque command, Tz mode is applicable and can avoid the problem of zero drift. If it is in T mode, the command will be the voltage deviation between T-REF and GND. Its input voltage range is -10V ~ +10V, which mean the corresponding torque is adjustable (P1-41).
- When neither TCM0 nor TCM1 is 0, parameters become the source of torque command. The command will be executed after TCM0 ~ TCM1 are changed. There is no need to use CTRG for triggering.

The torque command can be used in torque mode (T or Tz) and speed mode (S or Sz). When it is in speed mode, it can be regarded as the command input of torque limit.


6.4.2 Control Structure of Torque Mode

The basic control structure is as the following diagram:



The torque command unit is to select torque command source according to Section 6.4.1, including the scaling (P1-41) setting and S-curve setting. The current control unit manages the gain parameters of the servo drive and calculates the current for servo motor in time. Since the current control unit is very complicated, and is not relevant to the application. There is no need to adjust parameters. Only command end setting is provided.

The structure of torque command unit is as the following diagram.



The upper path is the command from register while the lower one is external analog command. The command is selected according to the status of TCM0, TCM1 and P1-01 (T or Tz). The torque represented by analog voltage command can be adjusted via the scaling and can obtain a smoother response via low-pass filter.


6-46 Revision February, 2017

6.4.3 Smooth Torque Command

Related parameters:


P1-07	TFLT	Analog Torque Comm	and (Low-pass Filter)	Address: 010EH 010FH
	Operation Interface		Communication	Related Section: 6.4.3
	Defaul	t : 0		
	Cont Mode	T		
	Uni	t : ms		
	Range	e: 0 ~ 1000 (0: disable	this function)	
	Data Size	e: 16-bit		
	Forma	t : Decimal		

Settings: 0: Disabled



6.4.4 The Scaling of Analog Command

The motor torque command is controlled by the analog voltage deviation between T_REF and GND and goes with parameter P1-41 to adjust the torque slope and its range.



Related parameters:

P1-	41	Λ

TCM N	laximum Output of A	nalog Torque Command	Address: 0152H 0153H
Operation Interface	al Panel / Software :	Communication	Related Section: 6.4.4
Default	: 100		
Contr Mode	ol : ALL		
Unit	: %		
Range	: 0 ~ 1000		
Data Size	: 16-bit		
Format	: Decimal		

Settings: Maximum Output of Analog Torque Command:


In torque mode, the analog torque command inputs the torque setting of the max. voltage (10V). When the default setting is 100, if the external voltage inputs 10V, it means the torque control command is 100% rated torque. If the external voltage inputs 5V, then the torque control command is 50% rated torque.

Torque control command = input voltage value x setting value / 10 (%)

In speed, PT and PR mode, the analog torque limit inputs the torque limit setting of the max. voltage (10V).

Torque limit command = input voltage value x setting value / 10 (%)

6.4.5 Timing Diagram in Torque Mode



- NOTE 1. OFF means the contact point is open while ON means the contact point is close.
 - 2. When it is in Tz mode, the torque command T1 = 0; When it is in T mode, the torque command T1 is the external analog voltage input.
 - 3. When it is Servo On, please select the command according to TCM0~TCM1 status.

6-48 Revision February, 2017

6.5 Dual Mode

Apart from single mode, dual mode is also provided for operation. According to Section 6.1, dual modes are as followings:

- 1. Speed/position dual mode (PT-S, PR-S, PT-PR)
- 2. Speed/torque dual mode (S-T)
- 3. Torque/position dual mode (PT-T, PR-T)
- 4. Position speed multi mode (PT-PR-S)
- 5. Position torque multi mode (PT-PR-T)

Mode Name	Short Name	Setting Code	Description
	PT-S	06	PT and S can be switched via DI signal, S_P.
	PT-T	07	PT and T can be switched via DI signal, T_P.
Dual Mada	PR-S	08	PR and S can be switched via DI signal, S_P.
Dual Mode	PR-T	09	PR and T can be switched via DI signal, T_P.
	S-T	0A	S and T can be switched via DI signal, S_T.
	PT-PR	0D	PT and PR can be switched via DI signal, PT_PR.
Multiple Mede	PT-PR-S	0E	PT , PR and S can be switched via DI signal, S_P and PT_PR.
Multiple Mode	PT-PR-T	0F	PT , PR and T can be switched via DI signal, T_P and PT_PR.

Sz and Tz dual mode is not provided here. For avoiding occupying too many digital inputs in dual mode, speed and torque mode can use external analog voltage as the command source so as to reduce digital input (SPD0, SPD1 or TCM0, TCM1). Please refer to Chapter 3.3.2, table 3.1, Default Value of DI Input Function and table 3.2, Default Value of DO Output Function for the default DI/DO of each mode.

The relationship between DI/DO signals and PIN define are set after the mode is selected. If users desire to change the setting, please refer to Chapter 3.3.4.

6.5.1 Speed / Position Dual Mode

There are PT-S and PR-S in speed/position dual mode. The command source of the former one comes from external pulse while the latter one comes from internal parameters (P6-00~P7-27). Speed command could be issued by external analog voltage or internal parameters (P1-09~P1-11). The switch of speed/position mode is controlled by S-P signal and the switch of PR-S mode is controlled by DI signal, which is more complicated. The timing diagram is shown as below.




Figure 1.: Speed / Position Control Mode Selection

In speed mode (S-P is ON), the speed command is selected via SPD0 and SPD1. CTRG is not working at the moment. When switching to position mode (S-P is OFF), since position command has not been issued (needs to wait the rising edge of CTRG), the motor stops. The position command is determined by POS0~POS5 and triggered by rising edge of CTRG. When S-P is ON, it goes back to speed mode again. Please refer to the introduction of single mode for DI signal and the selected command of each mode.

6.5.2 Speed / Torque Dual Mode

S-T is the only mode. The speed command comes from the external analog voltage and internal parameters (P1-09 ~P1-11), which is selected via SPD0~SPD1. Similarly, the source of torque command could be external analog voltage and internal parameters (P1-12 ~ P1-14) and is selected via TCM0~TCM1. The switch of speed/torque mode is controlled by S-T signal. The timing diagram is shown as below.




Figure 2.: Speed / Torque Control Mode Selection

In torque mode (S-T is ON), the torque command is selected via TCM0 and TCM1. When switching to speed mode (S-T is OFF), the torque command is selected via SPD0 and SPD 1. The

6-50 Revision February, 2017

motor operates according to the speed command. When S-T is ON, it goes back to the torque mode again. Please refer to the introduction of single mode for DI signal and the selected command of each mode.

6.5.3 Torque / Position Dual Mode

There are PT-T and PR-T in speed/position dual mode. The command source of the former one comes from external pulse while the latter one comes from internal parameters (P6-00~P7-27). Torque command could be issued by external analog voltage or internal parameters (P1-12~P1-14). The switch of torque/position mode is controlled by T-P signal and the switch of PR-T mode is controlled by DI signal, which is more complicated. The timing diagram is shown as below.




Figure 3.: Torque / Position Control Mode Selection

In torque mode (T-P is ON), the torque command is selected via TCM0 and TCM1. CTRG is not working at the moment. When switching to position mode (T-P is OFF), since position command has not been issued (needs to wait the rising edge of CTRG), the motor stops. The position command is determined by POS0~POS5 and triggered by rising edge of CTRG. When T-P is ON, it goes back to torque mode again. Please refer to the introduction of single mode for DI signal and the selected command of each mode.


6.6 Others

6.6.1 The Use of Speed Limit

The maximum speed in each mode is limited by internal parameters (P1-55), not matter it is in position, speed or torque mode.

The issuing method of speed limit command and speed command is the same. The command source could be external analog voltage or internal parameter (P1-09 \sim P1-11). Please refer to Section 6.3.1 for descriptions.


Speed limit can be used in torque mode (T) only. It is used for limiting the motor speed. When the command in torque mode is issued by external analog voltage, DI signal is enough and can be regarded as SPD0~SPD1 which is used to determine the speed limit command (internal parameters). If the DI signal is not enough, speed limit command can be issued by analog voltage. When the function of disable/enable limit function in P1-02 is set to 1, the speed limit function is enabled. See the timing diagram as below.



6.6.2 The Use of Torque Limit

The issuing method of torque limit command and torque command is the same. The command source could be external analog voltage or internal parameter (P1-12 \sim P1-14). Please refer to Chapter 6.4.1 for descriptions.

Torque limit can be used in position mode (PT, PR) or speed mode (S). It is used for limiting the motor torque output. When the command in position mode is issued by external analog voltage, DI signal is enough and can be regarded as TCM0~TCM1, which is used to determine torque limit command (internal parameters). If the DI signal is not enough, torque limit command can be issued by analog voltage. When the function of disable/enable torque limit function in P1-02 is set to 1, the torque limit function is enabled. See the timing diagram as below.



6-52 Revision February, 2017

6.6.3 Analog Monitor

Users could observe the needed voltage signal via analog monitor. Two analog channels are provided by the servo drive and locate in terminal 15 and 16 of CN1. The related parameter settings are as the followings.

P0-03

MON	Analo	og Output Monito	or	Address: 0006H 0007H
Operation Interfac		inel / Software	Communication	Related Section: 6.6.4
Defau	It: 00			
Control Mod	e: AL			2 2 4 4
Un	it : -			
Rang	e: 00	~ 0x77		
Data Siz	e: 16	-bit		
Forma	at : He	ecimal		
Settings	s:		➤ MON2 ➤ MON1 ► Not used	•

MON1, MON2 Setting Value	Description
0	Motor speed (+/-8 Volts/Max. speed)
1	Motor torque (force) (+/-8 Volts/Max. torque (force))
2	Pulse command frequency (+8 Volts / 4.5Mpps)
3	Speed command (+/-8 Volts/ Max. speed command)
4	Torque (force) command (+/-8 Volts/Max. torque (force) command)
5	VBUS voltage (+/-8 Volts / 450V)
6	Reserved
7	Reserved



Please refer to parameter P1-04, P1-05 for proportional setting of analog output voltage.

For example: P0-03 = 01 (MON1 is the analog output of motor speed; MON2 is the analog output of motor torque (force))

MON1 output voltage =
$$8 \times \frac{\text{Motor speed}}{(\text{Max. speed} \times \frac{P1-04}{100})}$$
 (unit : Volts)
MON2 output voltage = $8 \times \frac{\text{Motor torque}}{(\text{Max. torque (force)} \times \frac{P1-05}{100})}$ (unit: Volts)

-03	AOUT Po	larity Setting of Encode	er Pulse Output	Address: 0106H 0107H
	Operationa Interface :	Panel / Software (Communication	Related Section: 3.3.3
	Default :	0		
	Contro Mode :	ALL		
	Unit :	-		
	Range :	0 ~ 0x13		
	Data Size :	16-bit		
	Format :	Hecimal		
	Settings:	Pc	plarity of monitor analog output plarity of encoder pulse output ot in use	
		Polarity of monitor a	analog output	
		0: MON1(+), MON2		
		1: MON1(+), MON2 2: MON1(-), MON2(

- 2: MON1(-), MON2(+)
- 3: MON1(-), MON2(-)
- Polarity of encoder pulse output
 - 0: Forward output
 - 1: Reverse output

6-54

DИ		М
	┗'	

MON1 MC	ON1 Analog Monitor	Output Proportion	Address: 0108H 0109H
Operational Interface :	Panel / Software	Communication	Related Section: 6.4.4
Default :	100		
Control Mode :	ALL		-
Unit:	% (full scale)		
Range :	0 ~ 100		
Data Size :	16-bit		
Format :	Decimal		-
	D. ()	notor DO O2 for the cotting	···

Settings: Please refer to parameter P0-03 for the setting of analog output

selection.

For example:

P0-03 = 0x00 (MON1 is the speed analog output) When the output voltage value of MON1 is V1: Motor speed = (Max. speed ×V1/8) ×P1-04/100

Ρ1	Н	n	5
----	---	---	---

MON2	MON2 Analog Monitor	ON2 Analog Monitor Output Proportion		
Operational Panel / Software Communication			Related Section: 6.4.4	
Defaul	t : 100	100		
Con Mode	ΔΙΙ	ΔΙΙ		
Uni	it: % (full scale)	% (full scale)		
Range	e: 0 ~ 100	0 ~ 100		
Data Size	16-bit			
Forma	t : Decimal	Decimal		

Settings: Please refer to parameter P0-03 for the setting of analog output

selection.

For example:

P0-03 = 0x00 (MON2 is the speed analog output) When the output voltage value of MON2 is V2:

Motor speed = $(Max. \times V2/8) \times P1-05/100$

P4-20		set Adjustment Value of Analog Monitor tput (Ch1)		Address: 0428H 0429H
	Operational Interface :	Panel / Software	Communication	Related Section: 6.4.4
	Default :	0		
	Control Mode :	ALL		
	Unit :	mV		
	Range :	-800 ~ 800		
	Data Size :	16-bit		
	Format :	Decimal		
	Settings:	Offset adjustment v	alue (cannot reset)	


P4-21		Offset Adjustment Va Output (Ch2)	set Adjustment Value of Analog Monitor tput (Ch2)	
	Operatio Interface	Danal / Software	Communication	Related Section: 6.4.4
	Defaul	t : 0		
	Con Mode	ΔΙΙ		
	Uni	t : mV		
	Range	e: -800 ~ 800		
	Data Size	e : 16-bit		
	Forma	t : Decimal		
	Settings	S : Offset adjustment v	alue (cannot reset)	-

For example, if users desire to observe the voltage signal in channel 1 and set this channel for observing the pulse command frequency, when the pulse command frequency 2.25M corresponds to 8V output voltage, users need to adjust the monitor output proportion of P1-04 to 50 (= 2.25M/ Max. input frequency). Other related settings include P0-03 (X= 3) and P1-03 (The polarity setting range of monitor analog output is between 0 and 3, and it can set positive/negative polarity output). Generally speaking, the output voltage of Ch1 is V₁; the pulse command frequency is (Max. input frequency $\times V_1/8$) $\times P1-04/100$.

Because of the offset value, the zero voltage level of analog monitor output does not match to the zero point of the setting. This can be improved via the setting of offset adjustment value of analog

6-56 Revision February, 2017

monitor output, DOF1 (4-20) and DOF2 (P4-21). The voltage level of analog monitor output is ±8V, if the output voltage exceeds the range, it will be limited within ±8V. The provided resolution is about 10bits, which equals to 13mV/LSB.




6.6.4 The Use of Brake

When operating brake via servo drive, if the DO signal, BRKR is set to OFF, it means the brake is not working and the motor will be locked. If BRKR is set to ON, it means the brake is working and the motor can operate. The operation of brake has two kinds. Users can set the relevant dealy via regiser MBT1 (P1-42) and MBT2 (P1-43). It is usually applied in Z axis in order to reduce the heat generated when servo motor puts up resistance and shorten its lifetime. In order to avoid the error of brake, it must be worked when the servo drive is off. To operate the brake, the brake has to be activated before the motor stops running (Servo OFF). The brake has to be released after Servo ON. Otherwise, it would become the loading of the motor and might damage the brake.

If it works during the process of acceleration or constant speed, the servo drive needs to generate more current to resist the brakeforce of brake and it might cause the alarm of overload warning.

Timing diagram of brake control:




The output timing of BRKR:

1. When Servo OFF, go through the time set by P1-43 and the motor speed is faster than the setting in P1-38, DO.BRKR is OFF (the brake is locked).

2. When Servo Off, has not reached the time set by P1-43 but the motor speed is slower than the setting in P1-38, DO.BRKR is OFF (the brake is locked.).


The wiring diagram of using mechanical brake:





- 1) Please refer to Chapter 3, Wiring.
- 2) The brake signal controls the solenoid valve, provides power to the brake and enables the brake.
- 3) Please note that there is no polarity in coil brake.
- 4) Do not use brake power and control power (VDD) at the same time.

Timing diagram of control power and main power:



6-58 Revision February, 2017

Chapter 7 Motion Control

7.1 Motion Control Functions of ASDA-A2

- 1) Single-axis motion controller of PR (Procedure) control
- 2) Function of Capture (data capture) / Compare (data compare)
- 3) Electronic Cam (E-Cam) function (ASDA-A2 series L type models do not provide this function.)

7.2 System Information

The information of the servo drive can be divided into three parts: System parameters, Monitoring variables and Data array.

Descriptions are as follows:

	System Parameters	Monitoring variables
Functional Description	It is used to be the reference mode, important data or operation condition when the servo drive is operating, e.g. Control Mode, Servo Loop Gain, etc.	The status of the servo drive or motor, e.g. motor position, speed, electric current, etc.
Display Format	Panel displays PX-XX. Pressing the SET Key to display parameters and start setting. Please refer to Chapter 4 for Panel Display and Operation.	Set P0-02 to Monitoring variables code and enter into Monitor Mode. The panel will display the value of the variable. Or pressing the MODE Key on the panel to switch to Monitor Mode. Please refer to Chapter 4 for Panel Display and Operation.
Access Method	Readable and writable (depends on parameters)	Read-only
Data Size	16-bit or 32-bit (depends on parameters)	32-bit integers only
Communication	Access via MODBUS / CANopen / USB Each parameter occupies two MODBUS addresses	 It only can be monitored via PC software by connecting USB It does not directly support MODBUS / CANopen access, unless mapping is for corresponding the specified monitoring variables to system parameters.
Mapping Support	8 groups of parameter, P0-25 ~ P0-32 (set by P0-35 ~ P0-42)	5 groups of parameter, P0-09 ~ P0-13 (set by P0-17 ~ P0-21)
Note		In Monitor Mode, pressing UP/DOWN Key on the panel to switch the commonly used monitoring variables

ASDA-A2 Chapter 7 Motion Control

	(code 0~26); however, it cannot display
	all (about 150 in total)

7.2.1 Description of Monitoring Variables

Description of monitoring variables:

Item	Descriptions		
Variable Code	Each monitoring variable has a code. Set the code via P0-02 so that the users can monitor the variable.		
Format	Every monitoring variable is saved with the format of 32-bit (long integer) in the servo drive.		
Classification	 It is divided into basic variables and extension variables: Basic variables: Use the Monitor Mode on the panel to find the variable (variables in the cycle) by pressing UP/ DOWN Key (P0-02 = 0~26) Extension variables: Variables other than the basic ones (P0-02 = 27~127) 		
Monitor Method	Two methods, Panel display and Mapping: 1. Panel display: View through the panel directly 2. Mapping: Correspond the variables to the system parameters and view the variables via parameters.		
Panel Display	 Switch to the Monitor Mode by pressing the MODE Key and select the desired monitoring variables via UP/DOWN Key. Directly enter the desired monitoring code via P0-02 for viewing. Pressing the SHF Key on the panel can switch the display of high / low word; Pressing the SET Key on the panel can switch the display of decimal / hexadecimal format. 		
Mapping	 decimal / hexadecimal format. Mapping parameters that support monitoring variable are P0-09 ~ P0-13 Please refer to Chapter 8.3 for parameter description. Monitoring variables can be read via communication by mapping parameters. The value of mapping parameters (P0-09~P0-13) is the content of basic variables (17h, 18h, 19h, 1Ah). The setting value which is set by P0-17 should be monitored via p0-09 (refer to p0-02). When accessing data via communication, the value of P0-17 can be read or monitored via panel (Set P0-02 to 23). When the panel shows 「VAR-1」, it means it is the value of P0-09. 		

The descriptions of monitoring variables attribute are as the following.

Attribute	Descriptions
В	BASE: basic variables. Variables that can be viewed by UP/DOWN Key on the panel.
Dn	When the panel displays, the position of the decimal point will be D1 which means it only shows one decimal point; D2 means it shows two decimal points.
Dec	When the panel displays, the information only can be shown in decimal format. Pressing the SET Key on the panel cannot switch it to hexadecimal format.
Hex	When the panel displays, the information only can be shown in hexadecimal format. Pressing the SET Key on the panel cannot switch it to decimal format.

7-2 Revision February, 2017

Chapter 7 Motion Control ASDA-A2

Explanation of monitoring variables:

Code	Name of Variables / Attribute	Descriptions
000 (00h)	Feedback position (PUU)	The current feedback position of the motor encoder. The unit is PUU (user unit).
001 (01h)	Position command (PUU)	The current coordinate of position command. The unit is PUU (user unit). PT mode: it represents the pulse number the servo drive received. PR mode: the value of absolute coordinate from position command Equals to the pulse number sent by the controller.
002 (02h)	Position deviation (PUU)	The deviation between the position command and feedback position. The unit is PUU (user unit).
003 (03h)	Feedback position (pulse)	Current feedback position of the motor encoder. The unit is pulse (encoder unit).
004 (04h)	Position command (pulse)	The current coordinate of the position command. The unit is pulse (encoder unit). The command that had gone through E-gear.
005 (05h)	Position deviation (pulse)	The deviation between the position command and feedback position. The unit is pulse (encoder unit).
006 (06h)	Pulse command frequency B	Frequency of pulse command received by the servo drive. The unit is Kpps. It is suitable in PT/PR mode.
007 (07h)	Speed feedback B D1 Dec	Current speed of the motor. The unit of rotary motor is 0.1 r/min. The value is more stable since it has been though low-pass filter.
008 (08h)	Speed command (analog) B D2 Dec	The speed command is issued by analog. The unit is 0.01 Volt.
009 (09h)	Speed command (processed)	The processed speed command. The source might be analog, register or position loop.
010 (0Ah)	Torque command (analog) B D2 Dec	The torque command is issued by analog. The unit is 0.01 Volt.
011 (0Bh)	Torque command (processed)	The processed torque command. The unit is percentage (%). The source might be analog, register or speed loop.
012 (0Ch)	Average load B	Average load output by the servo drive. The unit is percentage (%).
013 (0Dh)	Peak load B	The maximum load output by the servo drive. The unit is percentage (%).
014 (0Eh)	DC Bus voltage B	Capacitor voltage after rectification. The unit is Volt.

Code	Monitoring Variables / Attribute	Explanation
015 (0Fh)	Inertia ratio B D1 Dec	Ratio of load inertia and motor inertia. The unit is 0.1 times.
016 (10h)	IGBT temperature B	IGBT temperature. Unit is °C.
017 (11h)	Resonance frequency B Dec	Resonance frequency of the system, including 2 groups of frequency, F1 and F2. When monitoring via panel, pressing SHF can switch the display of both: F2 shows no decimal point while F1 shows one. When reading through communication (mapping parameter): Low-16 Bit (Low WORD) returns frequency F2. High-16 Bit (High WORD) returns frequency F1.
018 (12h)	Z phase offset B Dec	The offset between the motor position and Z phase. The range is from -5000 to +5000. If the position is the same as Z phase, its value is 0. The bigger the value is, the more the offset will be.
019 (13h)	Mapping parameter #1 B	Return the value of parameter P0-25 which is mapped by P0-35.
020 (14h)	Mapping parameter #2 B	Return the value of parameter P0-26 which is mapped by P0-36.
021 (15h)	Mapping parameter #3 B	Return the value of parameter P0-27 which is mapped by P0-37.
022 (16h)	Mapping parameter # 4 B	Return the value of parameter P0-28 which is mapped by P0-38.
023 (17h)	Mapping monitoring variable #1 B	Return the value of parameter P0-09 which is the monitoring variables mapped by P0-17.
024 (18h)	Mapping monitoring variable #2 B	Return the value of parameter P0-20 which is the monitoring variables mapped by P0-18.
025 (19h)	Mapping monitoring variable #3 B	Return the value of parameter P0-11 which is the monitoring variables mapped by P0-19
026 (1Ah)	Mapping monitoring variable #4B	Return the value of parameter P0-12 which is the monitoring variables mapped by P0-20.
028 (1Ch)	Alarm codes	Alarm codes of DMCNET mode (It is applicable to A2-F, A2-N, A2-M/U/L)
029 (1Dh)	Feedback of auxiliary encoder (PUU)	The position feedback from auxiliary encoder (CN5) (It is applicable to A2-F)
030 (1Eh)	Position error of auxiliary encoder (PUU)	Position deviation between position feedback (from CN5) and command (It is applicable to A2-F)
031 (1Fh)	Position error or main/auxiliary encoder (PUU)	Feedback position deviation between main encoder and auxiliary encoder (It is applicable to A2-F)

7-4 Revision February, 2017

Code	Name of Variables / Attribute	Description
035 (23h)	Indexing coordinate command	The current command of the indexing coordinates. The unit is PUU (user unit).
037 (25h)	Compare data of COMPARE	Display the compare data. This actual compare data is a compare value plus an offset value via P1-23 and P1-24. CMP_DATA = DATA_ARRAY[*] + P1-23 + P1-24
038 (26h)	Voltage level of battery	The voltage level of battery for an absolute encoder.
039 (27h)	DI status (Integrated) Hex	The processed DI status of the servo drive. Each bit corresponds to one DI channel. The source includes hardware channel / software P4-07 which is determined by P3-06.
040 (28h)	DO status (Hardware) Hex	The real status of Digital Output hardware. Each bit corresponds to one DI channel.
041 (29h)	Drive Status	Return the value of P0-46. Please refer to the description of the parameter.
043 (2Bh)	CAP, data capturing	The Data captured by CAP hardware from the latest time Note: CAP could continuously capture many points.
048 (30h)	Auxiliary encoder CNT	The value of pulse counter from auxiliary encoder (CN5)
049 (31h)	Pulse command CNT	The value of pulse counter from pulse command (CN1)
050 (32h)	Speed command (processed) D1 Dec	The processed speed command. The unit is 0.1 r/min. The source might be analog, register or position loop.
051 (33h)	Speed feedback (immediate) D1 Dec	Current actual speed of the motor. The unit is 0.1 r/min.
052 (34h)	Speed feedback (filter) D1 Dec	Current actual speed of the motor. The unit is 0.1 r/min.
053 (35h)	Torque command (processed) D1 Dec	The processed torque command. The unit is 0.1 percent (%). The source might be analog, register or speed loop.
054 (36h)	Torque feedback D1 Dec	Current actual torque (force) of the motor. The unit is 0.1 percent (%).
055 (37h)	Electric current feedback D2 Dec	Current actual electric current of the motor. The unit is 0.01 ampere (Amp).
056 (38h)	DC Bus voltage D1 Dec	Capacitor voltage after rectification. The unit is 0.1 volt.
059 (3Bh)	Pulse from E-Cam master axis (accumulation)	The accumulative pulse number of E-Cam master axis. It is the same as P5-86. A2L does not support this function.

Code	Monitoring Variables / Attribute	Explanation
060 (3Ch)	Pulse from E-Cam master axis (increment)	The incremental pulse number from master axis. The unit is pulse number per msec. A2L does not support this function.
061 (3Dh)	Pulse from E-Cam mast axis (lead pulse)	The lead pulse of E-Cam master axis which is used to judge the engaging condition. When it is disengaged: lead pulse = P5-87 or P5-92. When it is engaged: lead pulse = P5-89. When the value is 0, it will be disengaged. A2L does not support this function.
062 (3Eh)	The position of E-Cam axis	The position of E-Cam axis. Unit: The pulse is from the master axis. When the incremental pulse from master axis is P, the axis rotates M cycle (P5-83 = M, P5-84 = P). A2L does not support this function.
063 (3Fh)	Position of E-Cam slave axis	The position of E-Cam slave axis. Unit: PUU A2L does not support this function.
064 (40h)	Terminal register of PR command	In PR mode, the termination of position command (Cmd_E)
065 (41h)	Output register of PR command	In PR mode, the accumulative output of position command
067 (43h)	PR target speed	The target speed of path command in PR mode. The unit is PPS (Pulse Per Second)
068 (44h)	S-curve filter (input)	The input commands of S-curve filter which is used to smooth the input command. It is effective in PR mode, E-Cam and speed command. A2L does not support this function.
069 (45h)	S-curve filter (output)	The output commands of S-curve filter which is used to smooth the output command. It is effective in PR mode, E-Cam and speed command. A2L does not support this function.
072 (48h)	Speed command (analog) B D1 Dec	The speed command is issued via analog. The unit is 0.1 r/min. This function is supported by A2-M/U/L.
076 (4Ch)	Speed command of PR contour	In PR mode, the programmed trapezoid speed curve is determined by the target speed, acceleration, deceleration and moving distance (before S-curve filter). The unit is PPS (Pulse Per Second).
081 (51h)	Synchronous capture axis Incremental input pulse	When synchronous capture axis is enabled, the received pulse number between two captures can be used to measure the real distance of Mark.
082 (52h)	PR number that is currently executed	To inform HMC the PR number that is being executed (It is applicable to A2-F)
084 (54h)	Synchronous capture axis Deviation pulse number	The deviation between the real output pulse and the target pulse when synchronous capture axis is enabled. If it reaches the synchronization, the value will close to 0.

7-6 Revision February, 2017

Code	Name of Variables / Attribute	Description
091 (5Bh)	The feedback of indexing coordinate	The immediate feedback position of indexing coordinates. The unit is PUU (user unit).
096 (60h)	Firmware version Dec	It includes two versions, DSP and CPLD. When monitoring via panel, pressing the SHF Key can switch the display of both: DSP shows no decimal point while CPLD shows one. When reading through communication (parameter mapping): Low-16 Bit (Low WORD) returns DSP version number. High-16 Bit (High WORD) returns CPLD version number.
098 (62h)	PLC scan time	The update time of DI/DO. The unit is 0.5 msec.
109 (6Dh)	The amount of data array	Returns the amount of data array. The unit is DWORD (32 Bits)
111 (6Fh)	Error code of the servo drive	Error code of the servo drive: only for the control loop, not including the motion controller.
112 (70h)	CANopen SYNC TS (hasn't been through the filter)	The time the servo drive receives SYNC signal (TimeStamp) The unit is usec.
113 (71h)	CANopen SYNC TS (has been through the filter)	The time the servo drive receives SYNC signal and has been through the filter. The unit is usec.
114 (72h)	CANopen timing synchronization	To synchronize the device timing with the controller during the operation. The unit is usec.
116 (74h)	The differential between position and Z phase of auxiliary encoder (pulse)	The differential between the current position and Z phase position of auxiliary encoder (It is applicable to A2-F)
120 (78h)	DMCNET connection status	DMCNET connection status (It is applicable to A2-F, A2-N)
121 (79h)	The PDO packet of DMCNET is lost during transmission	Accumulative number of the lost DMCNET PDO packet (It is applicable to A2-F, A2-N) Format: $chAchB \mid chB \mid chA$ For example, $459010 = 0x070102$ $chAchB_{error} = 7$, $chB_{error} = 1$, $chA_{error} = 2$
123 (7Bh)	The returned value when monitoring via panel	The returned value when monitoring via panel

7.2.2 Description of Data Array

Many functions of motion control, such as CAPTURE, COMPARE and E-Cam (A2L does not support E-Cam function) are the data that needs to be saved in large amount of memory space, therefore, the servo drive reserves a continuous internal space to satisfy the need. The main feature of the data array is as the followings:

Feature Introduction of Data Array				
	 Save the captured data of CAPTURE Save the compared value of COMPARE Save the contour table of E-Cam 			
	Note:			
Usage	1. The system does not partition off the data array into the individual space of CAP, CMP and E-Cam. The user could program it according to the demand. Therefore, the space might be overlapped. Please pay close attention to it when using.			
	2. A2L does not support E-Cam function.			
Size of Data Array	 32-bit integer x 800 (refer to P5-10) Each data has its corresponding address. Specify the address is a must when reading or writing the data. The 800 data is from 0 to 799. 			
Data Retained	 Manually set up the saving (P2-08 = 30, 35) is a must and the data should be saved in EEPROM of the servo drive. Save the data when it is Servo Off. The data will be loaded into data array automatically when it is Servo On. 			
Accessing Window	● Should be access via parameter P5-10 ~ P5-13.			

The content of the data array cannot be read or wrote directly, reading or writing the data must via parameter P5-10 \sim P5-13. The description of the parameters is as the followings:

	Description of Related Parameter about Data Array					
Parameter	Name	Description				
P5-10	Size of data array	Return the size of data array (read-only)				
P5-11	Reading / writing address	Set the desired address of reading and writing				
P5-12 writin	Reading /	Read via panel: After reading the content of P5-11, the value of P5-11 will not change. Write via panel: After writing the content of P5-11, the value of P5-11 will increase 1 automatically.				
	writing window #1	Read via communication: After reading the content of P5-11, the value of P5-11 will increase 1 automatically.				
		Write via communication: After writing the content of P5-11, the value of P5-11 will increase 1 automatically.				

7-8 Revision February, 2017

		Read via panel: After reading the content of P5-11, the value of P5-11 will increase 1 automatically. Write via panel: It cannot be written via panel.			
P5-13	Reading / writing window #2	Read via communication: After reading the content of P5-11, the value of P5-11 will increase 1 automatically.			
		Write via communication: After writing the content of P5-11, the value of P5-11 will increase 1 automatically.			

Set the desired reading / writing address via P5-11 first. Then, read / write P5-12 or P5-13 in order to access the content of data array. If users desire to continuously write 3 data, 100, 200, 300 into the address of data array, 11, 12 and 13, the operation step is as follows:

A. Write via panel: Use P5-12 (reading / writing window #1), since P5-13 does not support writing via panel:

- 1. Set address: Set P5-11 to 11 (The first written address)
- 2. Write into data: Set P5-12 to 100 (After writing 100 into address 11 in data array, the value of P5-11 will increase 1 automatically.)

Set P5-12 to 200 (After writing 200 into address 12 in data array, the value of P5-11 will increase 1 automatically.)

Set P5-12 to 300 (After writing 300 into address 13 in data array, the value of P5-11 will increase 1 automatically.)

The last step is to read address 11, 12 and 13 and check if the content is the value that just wrote into.

- **B**. Read via panel: Use P5-13 (reading / writing window #2) so as to continuously read the content.
 - 1. Set address: Set P5-11 to 11 (The first read address)
 - 2. Read the data: When the panel displays P5-13,

Press the **SET** Key for the first time and show the content of address 11. Then, press the **MODE** Key to exit.

Press the **SE**T Key for the second time and show the content of address 12. Then, press the **MODE** Key to exit.

Press the **SET** Key for the second time and show the content of address 13. Then, press the **MODE** Key to exit.

Note: Every time when reading the data via P5-13, the value of P5-11 will increase 1 automatically. Thus the user could continuously read the data.

If reading the data via P5-12, then the value of P5-11 will not change. The user is unable to read the next data automatically.

If users desire to read / write the data array via communication, the operation procedure is similar to panel. Moreover, the function of P5-12 and P5-13 is the same. If users desire to write 6 data, 100, 200, 300, 400, 500 and 600 into the address of data array via Modbus communication command 0x10 (continuous writing), the content of the issued command is as the followings:

	Content of Communication Command: Write into Data Array								
		C4 =4	Written	P5-11		P5-12		P5-13	
No.	Command	Start Add.	Amount	Low Word	High Word	Low Word	High Word	Low Word	High Word
			6	11	0	100	0	200	0
1	0x10	P5-11	(Word)	The first address		The first data		The second data	
	0.40	DE 44	6	13	0	300	0	400	0
2	0x10	P5-11	(Word)	The third	address	The thi	rd data	The four	th data
2	3 0x10)x10 P5-11 (\	6	15	0	500	0	600	0
3			(Word)	The fifth	address	The fif	th data	The sixt	h data

If users desire to read the value of data array in order to check the previous written content, users can write the desired reading start address into P5-11 via MODBUS communication command 0x06 (write 1 data). The issuing communication command is as the following:

Content of Communication Command: Set the Reading Address of Data Array						
No.	No. Command Start Add. Written Data					
4	0x06	P5-11	11			

Then, read the content of specified address by communication command 0x03 (continuous reading). The issuing communication command is as follows:

Content of Communication Command: Read Data Array			Return Data						
		Ctort	Dood	P5-	11	P5	-12	P5	-13
No.	Command	Start Add.	Read Amount	Low Word	High Word	Low Word	High Word	Low Word	High Word
			6	11	0	100	0	200	0
5	0x03	P5-11	(Word)	Read a	ddress		a of ess 11		a of ess 12
			6	13	0	300	0	400	0
6	0x03	P5-11	(Word)	Read a	ddress		a of ess 13		a of ess 14
			6	15	0	500	0	600	0
7	0x03	P5-11	P5-11 6 (Word)		ddress		a of ess 15		a of ess 16

The return value on the right-hand side of the above table represents the read parameter, P5-11, P5-12 and P5-13, which is also the content of address 11~16 in data array.

7-10 Revision February, 2017

7.3 Description of Motion Axes

The motion axis is an internal counter of the servo drive. It is used for counting the absolute position of the axis (32-bit integer). The following motion axes are included in this servo drive:

N	ame of the Axis	Description	Access	Attribute
1.	Main Encoder (P5-16)	It represents the absolute feedback position of the motor. The unit is PUU (user unit).	R	Physical Axis
2.	Auxiliary Encoder (P5-17)	It is counted by the pulse signal from CN5 and usually connects to the second encoder or linear scale. Its pulse is A/B type.	R/W	Physical Axis
3.	Pulse Command (P5-18)	It is counted by the pulse signal from CN1 and usually connects to the pulse command of the controller. The pulse type could be set by P1-00.	R/W	Physical Axis
4.	Capture Axis (P5-37)	It is the axis which has CAP function. Its command source could be the above mentioned axis 1~3, which can write the new value into it and has an offset from the physical axis. Moreover, after capturing the first point, the axis position can be redefined.	R/W	Functional Axis
5.	Compare Axis (P5-57)	It is the axis which has CMP function. Its command source could be the above mentioned axis 1~4, which can write the new value into it and has an offset from the physical axis.	R/W	Functional Axis
6.	Master Axis (P5-86)	It is the master axis of E-Cam. Its command source could be the above mentioned axis 2, 3, 4 and 7, which can write the new value into it and has an offset from the physical axis.	R/W	Functional Axis
7.	Command Axis in PR Mode	The command position is from the path generator in PR mode.	R	Virtual Axis
8.	Internal Time Axis	It is the internal accumulative time counter of the servo drive. The value increases 1 every 1ms.	R	Virtual Axis
9.	Synchronous Capture Axis (P5-77)	It is similar to Capture Axis (P5-37); however, it automatically adjusts the incremental pulse between two CAPs to the setting value of P5-78.	R/W	Virtual Axis

Note: Physical Axis: The position value is counted from the actual hardware signal.

Functional Axis: It is the virtual axis which has been processed by the physical. The value might not be the same as the source of physical axis. However, the incremental value is the same as the one in physical axis.

Virtual Axis: The axis position comes from the internal firmware of the servo drive. The command axis of PR mode is not instantaneous; therefore, it cannot be the command source axis of CAP and CMP function. However, it could be the command source of master axis of E-Cam.

7.4 Description of PR Mode

PR Procedure: It is the smallest unit of command. Command could be one or many procedures to constitute.

Procedure is triggered by DI.CTRG. POS0~POS5 is used to specify the triggered procedure number.

The triggered procedure is completed and will trigger the next one automatically. The procedure number can be set and the delay time between procedures as well.

The E-Cam function is provided in PR mode. It can be enabled via PR procedure. After it is disabled, it can return to the specified PR procedure.

7.5 The Difference between General PR Mode and the One in ASDA-A2

	General PR Mode	PR Mode in A2R
Command Number	8	64
Command Type	Positioning Command	Positioning / Constant speed Command PR jump, write in parameters
Position Command Parameter	 Absolute or incremental Acceleration/Deceleration time x 1 set Motion speed x 8 sets Delay time x 8 sets 	 Absolute / incremental can be set individually Acceleration/Deceleration time x 16 sets Motion speed x 16 sets Delay time x 16 sets
Command Triggering Time	It has to wait until DO.ZSPD is ON	Anytime will do. It could specify the next command issuing method (in sequence / interrupt / overlap)
Command Triggering Method	● Use DI.CTRG + POSn	 Use DI.CTRG + POSn Event trigger: DI.Event + CAP complete P5-07, fill in PR number to trigger.
Position Command PROFILE	 Trapezoid curve with S- curve filter (If S-curve is not enabled, then it has no function of acceleration / deceleration) 	Trapezoid curve with S-curve filter (Trapezoid curve and S-curve can be set individually.
Format of Position Command	 Two register for turns and pulse within one turn respectively. 	PUU (32bit)
Homing Function	 The function is enabled automatically when the power is On. (Servo ON for the first time) Use DI.SHOM to trigger 	 The function is enabled automatically when the power is On. (Servo ON for the first time) Use DI.SHOM to trigger PR 0 = Homing After homing is completed, the specified PR will be executed automatically.
Software limit protection	No	Yes

7-12 Revision February, 2017

7.6 The Position Unit of PR Mode

The position data of PR mode is represented by PUU (Pulse of User Unit). It is also the proportion between the controller position unit and the internal position unit of the servo drive, which is the so-called electronic gear ratio of the servo drive.

- 1. The position unit of the servo drive (pulse): Encoder unit: 1280000 (pulse/rev), which will not change.
- 2. User unit (PUU): The unit of the controller.
 - P pulse per revolution (PUU/rev), the gear ratio should set as:
 - GEAR_NUM (P1-44) / GEAR_DEN (P1-45) = 1280000 / P

7.7 Description of Register in PR Mode

- 1. Position register of PR mode: All is represented in PUU (Pulse of User Unit).
- 2. Command register (monitoring variable 064): Command termination register Cmd_E. It represents the absolute terminal coordinate of position command.
- 3. Command output register (monitoring variable001): Cmd_O; it represents the absolute coordinate from the current output command.
- 4. Feedback register (monitoring variable 000): Fb_PUU; it shows the absolute feedback position of the motor.
- 5. Deviation register (monitoring variable 002): Err_PUU; it is the deviation between the register from command output and feedback register.
- 6. In PR mode, either in operation or stop status, it satisfies the condition of Err_PUU = Cmd_O Fb PUU.

Influence brought by position command:

Type of Command	When issuing the command = >	= > When command is executing = >	= > Command is completed					
Absolute Positioning Command	Cmd_E = command data (absolute) Cmd_O does not change. DO.CMD_OK is OFF	Cmd_E does not change. Cmd_O continuously output	Cmd_E does not change. Cmd_O = Cmd_E DO.CMD_OK is ON					
Incremental Positioning Command	Cmd_E+= command data (incremental) Cmd_O does not change. DO.CMD_OK is OFF	Cmd_E does not change. Cmd_O continuously output	Cmd_E does not change. Cmd_O = Cmd_E DO.CMD_OK is ON					
Issue the command of DI: STP to stop the command	Cmd_E does not change. Cmd_O continuously output DO.CMD_OK is unchangeable	Cmd_E does not change. Cmd_O stops according to the deceleration curve	Cmd_E does not change. Cmd_O = position after stop DO.CMD_OK is ON					

Type of Command	When issuing the command = >	= > When command is executing = >	= > Command is completed				
anytime							
	Cmd_E does not change.	Cmd_E continuously output	Cmd_E = the absolute position of Z				
Homing Command	Cmd_O does not change. DO.CMD OK is OFF	Cmd_O continuously output	Cmd_O = position after stop				
	DO.HOME is OFF		DO.CMD_OK is ON				
			DO.HOME is ON				
	Cmd_E continuously output.	nd_E continuously output.					
Speed Command	Cmd_O continuously output. Very the speed reaches the setting DO.CMD_OK is OFF	•	d is completed, it means				
Enter PR (Ser and enter into I	vo Off->On or switch the mod	Cmd_O = Cmd_E = c	current feedback position				

Note: The incremental positioning command is accumulated by command termination Cmd_E. It is neither related to the current position of the motor nor the command time.

7-14 Revision February, 2017

7.8 Homing Description of PR Mode

The purpose of homing is to connect the Z pulse position of motor encoder to the internal coordinate of the servo drive. The coordinate value corresponded by Z pulse can be specified.

After homing is completed, the stopped position will not be the Z pulse. It is because it has to decelerate to stop when finding the Z pulse. It might therefore exceed a bit. However, since the position of Z pulse has correctly setup, it would not influence the accuracy of positioning. For example, when specifying the coordinate value corresponded by Z pulse is 100 and it is $Cmd_O = 300$ after homing, it means the deceleration distance is 300 - 100 = 200 (PUU). Since $Cmd_E = 100$ (Z's absolute coordinate), if desire to return to Z pulse position, issuing the positioning command will do, absolute 100 command or incremental 0 command.

After homing is completed, it will execute the specified PR automatically, which can move a distance of offset after homing.

When it is executing homing, software limit is disabled.

7.9 DI / DO Provided by PR Mode and Diagrams


DI signal:

CTRG, SHOM, STP, POS 0~5, ORG, PL (CCWL), NL (CWL), EV1~4

DO signal:

CMD OK, MC_OK, TPOS, ALM, CAP_OK, CAM_AREA

System frame:



Description of command triggered method in PR mode:

64 command procedures are in each axis of PR mode. Procedure #0 is homing and the others (#1~#63) are the procedures that users can self-define. The command triggered method is concluded as the followings:

	Command Source	Description
Standard trigger	DI.CTRG + POS0 ~ 5	Use DI.POS0 ~ 5 to trigger the desired procedure number. Then, use the rising edge of DI.CTRG to trigger PR command. Application: PC or PLC that issues command via DI
Functional trigger	DI.STP, SHM	When DI.STP is from OFF → ON, the command stops in half way. When DI.SHOM is from OFF → ON, it starts homing.
Event trigger	DI.EV1~4	The change status of DI.EV1 ~ 4 can be the triggered event. Set the triggered procedure number from OFF → ON by parameter P5-98. Set the triggered procedure number from ON → OFF by parameter P5-99. Application: connect to the sensor and trigger the preset procedure.
Software trigger	P5-07	Directly write the procedure number into P5-07 and trigger command. Both panel and communication (RS-232/485 / CANopen) can do. Application: PC or PLC that issues command via

7-16 Revision February, 2017

		communication.
Other	CAP trigger E-CAM disengage trigger	After the capture is completed, procedure #50 can be triggered and activated by the setting value Bit3 of P5-39 X. When E-cam is disengaged and returns to PR mode, the procedure specified by P5-88 BA setting value can be triggered. A2L does not support E-Cam function.

7.10 Parameter Settings

1) Target speed: P5-60 ~ P5-75, 16 PR in total

Bit	15 ~ 0-bit
W0	TARGET_SPEED: 0.1 ~ 6000.0(r/min)

2) Accel / Decel time: P5-20 ~ P5-35, 16 PR in total

Bit	15 ~ 0
W0	T_ACC / T_DEC: 1 ~ 65500 (msec)

Note: The deceleration time used by DI: STP/EMS/NL(CWL)PL(CCWL) is defined via P5-07.

3) Pause time: P5-40 ~ P5-55, total 16 PR in total

Bit	15 ~ 0
W0	IDLE: 0 ~ 32767(msec)

4) PR parameters: P5-00 ~ P5-09, P6-00 ~ P6-01, 12 DWORD in total

	32-bit			
P5-00	Reserved			
P5-01	Reserved (It is for testing only, do not use)			
P5-02	Reserved (It is for testing only, do not use)			
P5-03	Deceleration time of auto protection			
P5-04	Homing mode			
P5-05	1 st Speed setting of high speed homing			
P5-06	2 nd Speed setting of low speed homing			
P5-07	PR command register			
P5-08	Forward software limit			
P5-09	Reverse software limit			
P6-00	Homing setting			
P6-01	Origin definition			

Note: Path (procedure)

5) PR Definition: P6-02 ~ P7-27, (64-bit), 63 sets of PR in total (2N)

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0								TYPE
DW1	DATA (32-bit)							

Each PR has two parameters; the PR function is determined by TYPE. DATA represents position or speed data while the others are the additional information.

7-18 Revision February, 2017

6) SPEED, Constant speed control: TYPE = 1

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	-	-	DLY	-	DEC	ACC	OPT	1
DW1	DATA (32 bit): Target speed. Unit: Defined by OPT.UNIT							

When this command is executing, the motor accelerates or decelerates from the current speed until it reaches the target speed. After the command is completed, the motor will remain at the same speed and never stop.

OPT:

OPT							
Bit 7	Bit 7 Bit 6 Bit 5 Bit 4						
-	UNIT	AUTO	INS				

XDI.STP stop and software limit are acceptable.

INS: When this PR is executing, it will interrupt the previous PR.

AUTO: When the speed reaches the constant speed area, the next PR will be loaded automatically.

UNIT: 0 unit is $0.1r/min (10^{-6} \text{ m/s} \text{ for linear motor})$; 1 unit is PPS (Pulse Per Second)

ACC / DEC: 0 ~ F, Accel / Decel number



SPD: 0 ~ F, target speed number

DLY: 0 ~ F, delay time number. The delay after executing this PR. The external INS is invalid.



7) POSITION, Positioning control: (TYPE = 2, PR is completed and stopped), (TYPE = 3, the next PR is executed automatically after the PR is completed)

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	-	-	DLY	SPD	DEC	ACC	OPT	2 or 3
DW1	DATA (32 bit): Target position, Unit: Pulse of User Unit							

OPT:

	OPT							
Bit 7	Bit 6	Bit 5	Bit 4	Evalenation				
CN	ИD	OVLP	INS	Explanation				
0	0			Absolute position command: Cmd_E = DATA (Note 1)				
1	0			Incremental position command: Cmd_E = Cmd_E + DATA (Note 2)				
0	1	-	-	-	Relative position command: Cmd_E = Current feedback position + DATA (Note 3)			
1	1			Capture position command: Cmd_E = Capture position + DATA (Note 4)				

XDI.STP stop and software limit are acceptable.

INS: When this PR is executing, it will interrupt the previous PR

OVLP: It is allowed to overlap the next PR. When overlapping, please set DLY to 0.

CMD: The calculation of the position terminal command (Cmd_E) is as the followings:

Note 1: Position terminal command is determined by DATA.

Note 2: Position terminal command is determined by the previous terminal command (Monitoring variable 40h) plus DATA.

Note 3: Position terminal command is determined by the current feedback position (Monitoring variable 00h) plus DATA.

Note 4: Position terminal command is determined by the position latched by CAP (Monitoring variable 2Bh) plus DATA.

8) Special code: TYPE = 7, jump to the specified PR.

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	-	-	DLY	-	FUNC_CODE	-	OPT	7
DW1		PR Number (0 ~ 63)						

OPT:

OPT								
Bit 7	Bit 7 Bit 6 Bit 5 Bit 4							
-	INS							

PATH_NO: The jump target procedure number

FUNC_CODE: Reserved

DLY: The delay time after jump

9) Special code: TYPE = 8, write the specified parameter.

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	0	S_D	DLY	DI	ESTINATIO	N	OPT	8
DW1		SOURCE						

7-20 Revision February, 2017

DLY: Delay time after writing the parameters

Bit28 ~ Bit31are not 0x0, then AL213 occurs.

S_D: Specified data source and written target.

				S_D			
Bit 27	Bit 26	Bit 25	Bit 24	Explanation			
SO	UR	Rsvd	DEST	Data Source	Write Destination		
0	0		0	Constant	Parameter Px-xx		
0	1		0	Parameter Px-xx	Parameter Px-xx		
1	0		0	Data Array	Parameter Px-xx		
1	1	0	0	Monitoring variable	Parameter Px-xx		
0	0	0	1	Constant	Data Array		
0	1		1	Parameter Px-xx	Data Array		
1	0		1	Data Array	Data Array		
1	1		1	Monitoring variable	Data Array		

Rsvd is not 0, then AL213 occurs.

OPT:

OPT								
Bit 7	Bit 7 Bit 6 Bit 5 Bit 4							
-	AUTO INS							

Para_Data: the written data

INS: When executing this PR, it interrupts the previous one.

AUTO: When this PR is completed, it will execute the next PR automatically.

ROM: 1 means to write into EEPROM at the same time. (The supported written target is parameter, if the target is data array, then it will not be written into EEPROM.)

DESTINATION: Setting of the written target

	DESTINATION				
	Bit 19 ~ 16	Bit 15 ~ 12	Bit 11 ~ 8		
When DEST = 0, it represents parameter, Px-xx	P_Grp	P_	ldx		
When DEST = 1, it represents data array.		Array_Addr			

P_Grp, P_Idx: Specified parameter group and number

Array_Addr: Position of the specified data array.

SOURCE: Settings of data source

	SOURCE							
Bit	31 ~ 28	31 ~ 28 27 ~ 24 23 ~ 20 19 ~ 16 15 ~ 12					7 ~ 4	3 ~ 0
SOUR = 00 means constant		Para_Data						
SOUR = 01 means parameter Px-xx		Rsvd (0x0000 0) P_Grp P_Idx						ldx
SOUR = 10 means data array		Rsvd (0x0000 0) Array_Addr						r
SOUR = 11 means monitoring variable	Rsvd (0x0000 00) Sys_Var						_Var	

P_Grp, P_Idx: specified parameter group and number

Array_Addr: specified the position of data array

Para Data: the written constant

Sys_Var: monitor parameter code. Refer to P0-02 for its setting.

When Rsvd is not 0, it will display AL.213. When P_Grp exceeds the range, it will display AL.207. When displaying AL.209, it means P_Idx exceeds the range.

When Array_Addr exceeds the range, it will display AL.213. And AL.231 is for Sys_Var exceeding the range.

Note: 1. Even when the written parameter is retained, the new value will not be written into EEPROM. Too frequent written will not shorten the lifetime of EEPROM.


Note: The aim of writing parameters via PR procedure is for turning ON/OFF or adjusting some functions. (E.g. according to different positioning command to adjust P2-00, Position Loop Gain.) This procedure will continuously repeat during the operation. If the data is all written into EEPROM, it will shorten the lifetime of EEPROM. In addition, if P2-30 is set to 5, the modified parameters (either from panel or communication) will not be saved and is inconvenient to use. Thus, this new function is added.

- 3. If writing parameters fails, alarm AL.213~219 will occur (Refer to Chapter 11 of the manual) and the next PR which is enabled by AUTO function will not be executed.
- 10) Special Function: TYPE = 0xA, Indexing command.

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	-	OPT2	DLY	SPD	DEC	ACC	OPT	0xA
DW1		DATA (32-bit): Indexing Coordinate Command, Unit: PUU						

7-22 Revision February, 2017

OPT:



INS: When this PR is executing, it interrupts the previous one.

OVLP: It is allowed to overlap the next PR. When overlapping, please set DLY to 0.

OPT2:

OPT2								
Bit 27	Bit 27 Bit 26 Bit 25 Bit 24							
-	- AUTO - S_LOW							

AUTO: Position reached and the next PR is loaded automatically.

S LOW: Selection of speed unit. 0 means the unit is 0.1r/min; while 1 means 0.01r/min

DATA (DW1): Data format

DW1: DATA (32 bits)
PUU: 0~ (P2-52-1)

P2-52: Size of indexing coordinates

11) Homing Definition: P6-00 ~ P6-01, (64 bits) one set of PR.

Bit	31 ~ 28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DW0	BOOT	-	DLY	DEC2	DEC1	ACC	PA	TH
DW1		ORG_DEF (32-bit)						

PATH (PR): 0 ~ 3F. (6 bits)

00 (Stop): Homing completed and stops

01 ~ 3F (Auto): Homing completed and executes the specified PR: 1 ~ 63.

Note: PATH (procedure) ACC: Acceleration time

DEC1/DEC2: The first / second deceleration time

DLY: Delay time


BOOT: Activation mode. When the POWER is ON:

0: will not do homing

1: start homing (Servo ON for the first time)

ORG_DEF: the coordinate value of the origin definition which might not be 0

1) After finding the origin (Sensor or Z), the motor has to decelerate to stop. The stop position will slightly exceed the origin. After the positioning is completed, users can determine and setup the motor position:



If not returning to the original point, set PATH to 0.

If desire to return to the original point, set PATH to non-zero value and setup that PR: absolute positioning command = ORG_DEF.

CMD_O: Command Output Position

CMD_E: Command End Position

2) Homing does not define the offset value but uses PATH to specify a path as the offset value.

After finding the origin, if the user desires to move a short distance of offset S (the related home Sensor or Z) and set the coordinate to P after moving: (incremental positioning command = S will do)

7-24 Revision February, 2017

7.10.1 The Relation between the Previous Path and the Next Path

1) Interrupt (the previous path) and overlap (the next path) can be set in every path



Note: Path (procedure)

2) The priority of interrupt command is higher than overlap

PATH 1	PATH 2	Relation	Output	Note
OVLP = 0	INS = 0	In sequence	DLY 1	PATH 1/2 which could be the combination of speed/position
OVLP = 1	INS = 0	Overlap	NO DLY	PATH 2 is SPEED and does not support overlap
OVLP = 0	INS = 1	Interrupt	N/A	PATH 1/2 which could be the
OVLP = 1	1110 - 1	interrupt	IN/A	combination of speed/position

7.10.2 Programming the Path in PR Mode


1) Sequence command

Speed Path 1 Path 2 Time DLY 1

Path 1: is AUTO and has set DLY Path 2: does not set INS

(DLY starts to count after completing the command)

Speed




Path 1: speed command and has set DLY

Path 2: position command (DLY starts to count after completing

2) Overlap

Speed




Path 1: has set OVLP but cannot set DLY

Path 2: does not set INS

the command)

3) Internal Interrupt

Speed



Path 1: AUTO and has set DLY


Path 2: has set INS

(DLY is effective to the internal interrupt)

It can be used to pre-constitute complicated Profile

4) External Interrupt

Speed



Path 1: AUTO or SINGLE

Regardless the setting of DLY

Path 2: has set INS


(DLY is ineffective to the external interrupt)

Profile can be changed from external any time

7-26 Revision February, 2017

7.11 The Description of E-Cam Function

E-Cam is a virtual cam which is implemented by software. It includes Master axis and Slave axis. The illustration is as the following:



In PT mode, the position command (slave) is issued by the external pulse input (master). The two is merely the linear scaling relation (its scaling equals to e-gear ratio). However, instead of linear scaling, E-Cam is defined by cyclic curve profile, just like the cam shape. In physical machine cam, slave axis can operate as variable speed motion, alternating motion, intermittent motion, etc by master axis with the constant speed motion. It is very extensive in application. Using E-Cam could have similar effect. The following table describes the differences between E-Cam and Machine Cam.


	Machine Cam	E-Cam			
Structure	Return to the original position after rotating a cycle.	It might not return to the original position after rotating a cycle. The structure could be in spiral shape like mosquito coil incense.			
Smooth Performance	It is determined by the fineness of the real process.	It is interpolated by cubic curve via software			
Position Accuracy	sition Very precise (when it has no actual position might have				
Long Distance Motion	The longer the slave axis is, the bigger the cam will be. It is not easy to make.	Change the value of the table will do. It is easy to realize.			
The Necessity of Master Axis	The master axis is necessary.	The master axis is unnecessary when it is applied to constant speed motion. It will do by using the internal signal of the servo drive.			
Flexibility	It is inconvenient to change and modify and it is expensive as well.	It will do by re-setting the parameter.			
Maintenance	Machine will wear and the maintenance is necessary.	No need to maintain.			
Others	The master axis needs space and it consumes energy as well.	Save the space and energy which protects the environment.			

The main feature of E-Cam is as the followings:

Features of E-Cam						
Operation	Operate the E-cam in PR mode only.					
Active the E-Cam Function P5-88.X	0: disable E-cam function and force to disengage (default). 1: enable E-cam function and starts to judge the engaged condition.					
E-Cam Status	Stop / Pre-engage / Engage					
Source of Master Axis	 Auxiliary encoder (linear scale) Pulse command CAP axis (defined by CAP function) PR command Time axis Synchronous capture axis 					
Motion Command of the Servo Drive	The overlap motion command issued by PR and E-Cam Command of the Servo Drive = E-Cam command + PR command The command will be issued only in Engaged status PR command is effective regardless to the E-Cam status. Except when E-cam is engaging and the source of master axis is PR command, PR command is 0. When E-Cam is operating, its position still can be adjusted by PR command (incremental command in general).					
Data Storage Address of E-Cam table	It is stored in Data array and the start address is set by P5-81.					
Data Size of E-Cam table	• It is set by P5-82. 720 points is the maximum and 5 points is the minimum.					
Data Format of E-Cam table	32-bit signed value.					
Data Content of E-Cam table	Save the position of slave axis (User unit, PUU)					
The operation of E-Cam position	 The master axis operates by incremental command input. The slave axis issues position command incrementally. The start and the end of E-Cam curve profile could not always be the same. It depends on the value of E-Cam table. The command is interpolated by cubic curve. The torque on each point will be smoothly connected because of quadratic differential operation. 					

7-28 Revision February, 2017

E-Cam provided by this servo drive and below is its functional diagram:




Master Axis, the description is as follows:

Function	The moving distance of the master axis is the source which could drive the E-Cam
Source of Master Axis The Setting Value of P5-88 Y	Source selected by P5-88.Y: Auxiliary encoder (linear scale) Pulse command PR command Time axis Synchronous capture axis CAP axis (defined by CAP function)
Position of Master Axis P5-86	The position of master axis can be monitored via P5-86. It also can be written before the E-cam engaged. To change this parameter will not influence the position of the slave. It is because the moving distance of master axis remains.

■ Clutch, the description is as follows:

Function	It is used to determine the status of engaged / disengaged between the master axis and gear box # 1. The moving distance of the master axis can drive the E-Cam not until the cam is engaged.
Activate E-cam function P5-88.X	O: disable E-cam function (default value). If the cam is engaged, the cam will be forced to disengage. 1: enable E-cam function and starts to judge the engaged condition
E-Cam Status	Status can be known via parameter P5-88.S: 0 – Stop; 1 – Engage; 2 – Pre-engage



Status Description:

- Stop: It is the initial status of the cam. The E-cam will not operate
 with the master pulse. When E-cam function is disabled (P588.X=0), it returns to this status.
- Pre-engage: When the engaged condition (path 1) is established, it enters this status. The E-cam still will not operate with the master pulse.
- Engage: When it reaches pre-engaged status (path 3), it enters this status. The E-cam starts to operate with the master pulse.

Path Description:

- Path 1 : When the engaged condition is established (P5-88.Z), the status is Stop → Pre-engaged.
 - The lead pulse is determined by P5-87.
- Path 2: When the E-cam function is disabled (P5-88.X=0), it returns to Stop status.
- Path 3: When it is in pre-engaged status, the status is Preengaged → Engaged.
- Path 4: When the disengaged condition is established (P5-88.U = 4), the status is Engaged → Pre-engaged. The lead pulse is determined by P5-92. (It is available after firmware version V1.006sub04)
- Path 5: When the disengaged condition is established (P5-88.U = 1,2,6), or the E-cam function is disabled (P5-88.X = 0), the status is Engaged → Stop.

Engage Condition P5-88.Z

When the E-cam is in Stop status, the method of determine engaged (path 1) is as the following:

- 0: Engaged immediately. If P5-88.X is set to 1, the engaged condition is established.
- 1: When DI.CAM is ON, E-cam is engaged.
- 2: From CAP to engaged: E-cam is engaged when CAP function is enabled. After engaged, it starts to count the moving distance. Since the CAP position is captured by hardware, it has good instantaneity and no software delay, which is suitable for the operating master axis before engaged.

7-30 Revision February, 2017

Lead Pulse Monitoring Variables (061)	 In pre-engaged status, the lead pulse is the moving distance of master axis before the E-cam is engaged (path 3). Its value decreases when input the master pulse. When the value is 0, it enters Engaged status. Enter Pre-engaged status via path 1, the lead pulse is determined by the value of P5-87. Enter Pre-engaged status via path 4, the lead pulse is determined by the value of P5-92. If the setting is 0, it means no lead pulse and will enter Engaged status immediately. Symbol +/ - represents the direction of lead pulse. Please note that the E-cam will be unable to engage if setting the wrong direction. If setting the wrong direction, the value of monitoring variable (061) will increase, which is far from 0 and causes overflow at the end. If it overflows, the E-cam function will be disabled (P5-88.X=0) and the E-cam will be forced to return to Stop status. 						
	disenga	he E-cam is in Engaged status, the methaged is as the following: , 4 and 6 cannot be selected at the same					
	U	Disengage Condition	After Disengaged				
	0	Never disengaged. It will be forced to disengage until P5-88.X is set to 0.	(Path 5) Enter Stop Status				
	1 DI.CAM is OFF		(Path 5) Enter Stop Status				
Disengage Condition P5-88.U	2	Master axis receives the pulse number which is set by P5-89 and stops immediately. (The symbol represents the direction)	(Path 5)				
	6	Same as 2, the E-cam starts to decelerate when disengaging. It is suitable for the application of calling the next PR position command right after disengaged.	Enter Stop Status				
	4	Master axis receives the pulse number which is set by P5-89 and stops immediately. (The symbol represents the direction)	(Path 4) Returns to Pre- engage Status The lead pulse is P5-92				
	8	Disable the E-cam after disengaging	Set P5-88.X = 0				
Auxiliary Selection P5-88.BA	When the E-cam disengaged, if it is in the setting distance (P5-88.U=2), it returns to Stop status and can determine the execution PR number.						


■ Gear # 1, the description is as follows:

Function	Set the relativity of master axis and E-cam axis.
	E.g. The master axis operates one cycle; the E-cam axis is no need to operate one cycle.
Description	E-cam axis is a virtual axis.
·	 The E-cam axis operates one cycle (360 degrees) means the cam operates one cycle and the slave axis operates one cycle.
	The pulse number is the unit of moving distance of the master axis. Its resolution is determined by the source.
Setting Method	If the pulse number of master axis is P, the E-cam axis
P5-83: M	operates M cycle.
P5-84: P	Then, the setting of gear ratio is P5-83 = M, P5-84 = P

■ Cam, the description is as follows:

Function	 Set the relation between E-cam axis and slave axis and define it in the E-cam table. 				
Function	E-cam axis operates one cycle and the slave axis operates one cycle.				
Data Storage Address of E- Cam table	Data array, the start address is set by P5-81				
Data Format	32-bit (It has positive and negative, user unit: PUU)				
E-Cam Curve	 It is used to magnify (minify) the E-cam shape. It equals to the value of data multiplies P5-19. 				
Scaling	Switch the symbol, + / - will change the operation direction of				
P5-19	slave axis.				
0 ~ +/- 32.700	• If P5-19 is set to 0, the E-cam command will not be outputted. (The				
	setting will be 0 for good).				
Data Size	 It is divided into N parts via P5-82 (> = 5) and does not exceed the limit of data array. It means 360 degrees a cycle of E-cam are divided into N areas. Each area is (360/N) degrees. 				
	 The position data of slave axis is saved in E-cam table. (User unit: PUU). 				
	If E-cam is divided into N areas, the position of each area must be				
	included in the table. It must set N + 1 points in total. It is because				
	the position of the first point (0 degree) and the final point (360 degree) might not be the same.				
	The data of The data of				
Data Content	1.0° and 360° 2.0° and 360° is identical is different				
	is identical is different				
	: 0° & 360° : 360°				

7-32 Revision February, 2017



■ Gear # 2, the description is as follows:

Function	•	Set the relation between slave axis and pulse command The slave axis operates a cycle, but the pulse command might not operate a cycle.
	•	The slave axis is a virtual axis and the unit of slave position is PUU.
Description	•	The pulse command is the encoder unit (pulse). The resolution is 1280000 pulse/rev.
	•	For one cycle of the chart, the slave axis operates a cycle.

Setting Method P1-44: numerator	•	If the pulse number of slave axis is L, the motor axis operates R cycle.
P1-45: denominator		Then, the setting of gear ratio is P1-44/P1-45 = 1280000 x R / L
	•	The gear ratio of PT and PR is the same.

Digital Output of E-cam, the description is as follows:

DO Name and Number	• DO.CAM_AREA (DO no.= 0x18)
Function	 If DO.CAM_AREA is ON, it means the position of E-cam axis is in the setting range.
When the E-cam is engaging	 Set the angle range of DO ON by P5-90 and P5-91. Please refer to table 1 and 2 below
When the E-cam is disengaging	DO.CAM_AREA is OFF.

Table 1 P5-90 <= P5-91:

E-Cam angle	0°	~	P5-90	~	P5-91	~	360°
DO:CAM_AREA	OFF	OFF	ON	ON	ON	OFF	OFF

Table 2 P5-90 > P5-91:

E-Cam angle	0°	~	P5-91	~	P5-90	~	360°
DO:CAM_AREA	ON	ON	OFF	OFF	OFF	ON	ON

7.11.1 Function Description of CAPTURE (Data Capture)

The concept of CAPTURE is to capture the position of motion axis instantaneously by using the external trigger signal DI7. Then save it in data array so as to be used for motion control afterwards. Since CAPTURE is finished by hardware, there is no problem of software delay. It also can accurately capture the high-speed motion axis. The CAPTURE features provided by this servo drive is as follows.

CAPTURE Features		
Pulse Source	 Main encoder of the motor Auxiliary encoder (linear scale) Pulse command 	
	The selected axis will be displayed in P5-37, the default value can be written in before capture.	
	Note: When the source of COMPARE is CAP axis, the CAP source cannot be changed.	
Trigger signal	Triggered by DI7, the response time is 5 usec. Note: DI7 directly connects to CAPTURE hardware. Thus, regardless the setting value of P2-16 (DI Code), CAPTURE can work. When using CAPTURE, in order to avoid DI error, system will force to disable DI function, which means the setting will be P2-16 = 0x0100 automatically. Since the value is not written into EEPROM, P2-16 will return to the default value after re-power on.	

7-34 Revision February, 2017


CAPTURE Features		
Trigger method	 Edge trigger can select contact A/B It is capable to continuously capture more than one point. It can set the trigger interval. (The interval between this trigger and the next one.) 	
Data storage position	Data array. The start address is set by P5-36.	
Capture number	It is set via P5-38 and will not exceed the limit of data array.	
Capture format	32-bit (It has positive and negative.)	
Auxiliary selection	 After capturing the first data, the CAP axis coordinate system will be set to the value the same as P5-76. After capturing the first data, the COMPARE function is enabled automatically. After capturing all points, PR procedure # 50 is triggered automatically. 	
DO.CAP_OK	 The default value is OFF. After capturing the last point, this DO is ON. Set P5-39.X0 to 1 so as to activate CAPTURE function and this DO is OFF. 	
Note	 If P5-38=0, set the value of P5-39 X, Bit0 to 1 will disable the CAPTURE function. Clear the setting value of P5-39 X, Bit0 to 0 and set DO.CAP_OK to OFF. Since the capture axis is 32-bit wide, the accumulation will cause overflow. Please avoid this. 	

The CAP data is saved in data array and the first CAP data locates in P5-36. The CAP number has no limit, thus it can be set via P5-38. The last CAP data is saved in P5-36 + P5-38 - 1. Set the value of P5-39 X, Bit0 to 1 so as to activate CAP function. Every time when DI7 is triggered, one data will be captured and saved in data array. Then, the value of P5-38 will decrease one automatically until the CAP number reaches the setting value (P5-38 = 0). The CAP procedure is completed, the setting value of P5-39 X, Bit0 will be cleared to 0 and DO.CAP OK is ON.

When capturing the first data, the position of CAP axis can be reset. The first CAP value will be the value set by P5-76. And the value of the second CAP data will be the incremental value from the first data. This method is called Relative Capture. If not selecting the first data reset, it is called Absolute Capture.

When capturing the first data, it automatically activates COMPARE function, which means the COMPARE function, is activated via DI5.

The diagram of CAP:



7.11.2 Function Description of COMPARE (Data Compare)

The concept of COMPARE is to compare the instant position of motion axis with the value which is saved in data array. Then output DO3 after the COMPARE condition is established for motion control. Since COMPARE is finished by hardware, there is no problem of software delay. It also can accurately compare the high-speed motion axis. The COMPARE features provided by this servo drive is as follows.

COMPARE Features		
Pulse Source	 Main Encoder of the Motor Auxiliary Encoder (linear scale) Pulse Command CAP Axis (set by CAPTURE). When selecting this axis, CAP source cannot be changed. The selected axis is displayed in P5-57. Before compare, the default value can be written in. 	
Output Signal	Output by DO4 and the response time is 5 usec. Note: DO3 directly connects to COMPARE hardware, thus, regardless the setting value of P2-20 (DO Code), the function can work. When using COMPARE, in order to avoid DO error, the system will force to disable DO function, which means the setting will be P2-21 = 0x0100 automatically. Since the value is not written into EEPROM, P2-21 will return to the default value after re-power on.	
Output Method	 Pulse output can select contact A/B. It is capable to continuously output more than one point. It can set the pulse output time. 	


7-36 Revision February, 2017

Data Storage Position	 Data array. The start address is set by P5-56.
Compare Number	It is set via P5-58 and will not exceed the limit of data array.
Compare Format	32-bit (It has positive and negative.)
Compare Condition	 It will be triggered when the source of compare axis pass through the compare value.
Auxiliary Selection	 Cycle mode: When comparing to the last point, it automatically returns to the first point and starts to compare. When the last compare is completed, the CAPTURE function is activated automatically.
Note	 If P5-58 is set to 0, set the value of P5-59 X, Bit0 to1 will be unable to compare. Set the value of P5-59 X, Bit0 to 0. Since the capture axis is 32-bit wide, the accumulation will cause overflow. Please avoid this.

The value of COMPARE is saved in data array and the first compare data locates in P5-56. The CMP number has no limit, thus it can be set via P5-58. The last CMP data is saved in P5-56 + P5-58 - 1. Set the value of P5-59 X, Bit0 to 1 so as to activate CMP function and start to compare the first data of data array. Every time when a position saved in data array is compared, the compare DO will be outputted. Then, the value of P5-58 will decrease one automatically and compare the next value until the CMP number reaches the setting value (P5-58 = 0). When the CMP procedure is completed, the setting value of P5-59 X, Bit0 will be cleared to 0.

When comparing to the last point, it can select if it returns to the first data for comparing. This is called cycle mode. Or it can activate CAPTURE function and wait DI7 for triggering CAP/CMP procedure.

The diagram of COMPARE:



(This page is intentionally left blank.)

7-38 Revision February, 2017

Chapter 8 Parameters

8.1 Parameter Definition

Parameters are divided into eight groups which are shown as follows. The first character after the start code P is the group character and the second character is the parameter character.

As for the communication address, it is the combination of group number along with two digit number in hexadecimal. The definition of parameter groups is as the followings:

Group 0: Monitor parameters (example: P0-xx)

Group 1: Basic parameters (example: P1-xx)

Group 2: Extension parameters (example: P2-xx)

Group 3: Communication parameters (example: P3-xx)

Group 4: Diagnosis parameters (example: P4-xx)

Group 5: Motion control parameters (example: P5-xx)

Group 6: PR parameters (example: P6-xx)

Group 7: PR parameters (example: P7-xx)

Control Mode Description:

PT: Position control mode (Input the position command via the terminal block)
PR: Position control mode (The internal register issues the position command)

S : Speed control mode

T : Torque control mode

DMC : DMCNET control mode

Special Symbol Description

(★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.

(▲) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.

(●) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.

(**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

8.2 List of Parameters

	Monitor and General Output Parameter									
Parameter	Abbr.	Function	Default	Unit	Co	ontro	l Mo	de	Related	
i arameter	Abbi.	1 dilotion	Delauit	Offic	PT	PR	S	Т	Section	
P0-00 ★	VER	Firmware Version	Factory Setting	N/A	0	0	0	0	-	
P0-01 ■	ALE	Alarm Code Display of Drive (Seven-segment Display)	N/A	N/A	0	0	0	0	11.1 11.2 11.3	
P0-02	STS	Drive Status	00	N/A	0	0	0	0	7.2	
P0-03	MON	Analog Output Monitor	01	N/A	0	0	0	0	4.3.5	
P0-08 ★	TSON	Servo On Time	0	Hour					-	
P0-09 ★	CM1	Status Monitor Register 1	N/A	N/A	0	0	0	0	4.3.5	
P0-10 ★	CM2	Status Monitor Register 2	N/A	N/A	0	0	0	0	4.3.5	
P0-11★	СМЗ	Status Monitor Register 3	N/A	N/A	0	0	0	0	4.3.5	
P0-12 ★	CM4	Status Monitor Register 4	N/A	N/A	0	0	0	0	4.3.5	
P0-13 ★	CM5	Status Monitor Register 5	N/A	N/A	0	0	0	0	4.3.5	
P0-17	CM1A	Status Monitor Register 1 Selection	0	N/A					-	
P0-18	CM2A	Status Monitor Register 2 Selection	0	N/A					-	
P0-19	СМЗА	Status Monitor Register 3 Selection	0	N/A					-	
P0-20	CM4A	Status Monitor Register 4 Selection	0	N/A					-	
P0-21	CM5A	Status Monitor Register 5 Selection	0	N/A					-	
P0-25	MAP1	Mapping Parameter # 1	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-26	MAP2	Mapping Parameter # 2	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-27	MAP3	Mapping Parameter # 3	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-28	MAP4	Mapping Parameter # 4	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-29	MAP5	Mapping Parameter # 5	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-30	MAP6	Mapping Parameter # 6	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-31	MAP7	Mapping Parameter # 7	No need to initialize	N/A	0	0	0	0	4.3.5	
P0-32	MAP8	Mapping Parameter # 8	No need to initialize	N/A	0	0	0	0	4.3.5	

8-2 Revision February, 2017

Monitor and General Output Parameter										
Doromotor	Abbr.	Function	Default	Unit	Co	ontro	I Мо	de	Related	
Parameter	ADDI.	FUNCTION	Delault	Offic	РТ	PR	S	Т	Section	
P0-35	MAP1A	Target Setting of Mapping Parameter P0-25	0x0	N/A	0	0	0	0	4.3.5	
P0-36	MAP2A	Target Setting of Mapping Parameter P0-26	0x0	N/A	0	О	0	0	4.3.5	
P0-37	MAP3A	Target Setting of Mapping Parameter P0-27	0x0	N/A	0	0	0	0	4.3.5	
P0-38	MAP4A	Target Setting of Mapping Parameter P0-28	0x0	N/A	0	0	0	0	4.3.5	
P0-39	MAP5A	Target Setting of Mapping Parameter P0-29	0x0	N/A	0	0	0	0	4.3.5	
P0-40	MAP6A	Target Setting of Mapping Parameter P0-30	0x0	N/A	0	0	0	0	4.3.5	
P0-41	MAP7A	Target Setting of Mapping Parameter P0-31	0x0	N/A	0	0	0	0	4.3.5	
P0-42	MAP8A	Target Setting of Mapping Parameter P0-32	0x0	N/A	0	0	0	0	4.3.5	
P0-46 ★	SVSTS	Servo Digital Output Status Display	0	N/A	0	0	0	0	-	
P1-04	MON1	MON1 Analog Monitor Output Proportion	100	%(full scale)	0	0	0	0	6.4.4	
P1-05	MON2	MON2 Analog Monitor Output Proportion	100	%(full scale)	0	0	0	0	6.4.4	

^(★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.

⁽**A**) Setting is invalid when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.

^(●) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.

⁽**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

Filter and Resonance Suppression Parameter												
			_		Co	ontro	I Mo	de	Related			
Parameter	Abbr.	Function	Default	Unit	РТ	PR	S	Т	Section			
P1-06	SFLT	Analog Speed Command (Low-pass Filter)	0	ms			0		6.3.3			
P1-07	TFLT	Analog Torque Command (Low-pass Filter)	0	ms				0	6.4.3			
P1-08	PFLT	Smooth Constant of Position Command (Low-pass Filter)	0	10 ms	0	0			6.2.6			
P1-25	VSF1	Low-frequency Vibration Suppression (1)	100.0	0.1Hz	0	0			6.2.9			
P1-26	VSG1	Low-frequency Vibration Suppression Gain (1)	0	N/A	0	0			6.2.9			
P1-27	VSF2	Low-frequency Vibration Suppression (2)	100.0	0.1Hz	0	0			6.2.9			
P1-28	VSG2	Low-frequency Vibration Suppression Gain (2)	0	N/A	0	0			6.2.9			
P1-29	AVSM	Auto Low-frequency Vibration Supression Setting	0	N/A	0	0			6.2.9			
P1-30	VCL	Low-frequency Vibration Detection	500	pulse	0	0			6.2.9			
P1-34	TACC	Acceleration Constant of S- Curve	200	ms		0	0		6.3.3			
P1-35	TDEC	Deceleration Constant of S- Curve	200	ms		0	0		6.3.3			
P1-36	TSL	Acceleration / Deceleration Constant of S-Curve	0	ms		0	0		6.3.3			
P1-59	MFLT	Analog Speed Command	0	0.1ms			0		-			
P1-62	FRCL	Friction Compensation	0	%	0	0	0	0	-			
P1-63	FRCT	Friction Compensation	0	ms	О	0	0	0	-			
P1-68	PFLT2	Position Command Moving Filter	0	ms	0	0			-			
P1-75	FELP	Low-pass Filter Time Constant of Full-closed Loop control	100	ms	0	0			-			
P2-23	NCF1	Resonance suppression (Notch filter) (1)	1000	Hz	0	0	0	0	6.3.7			
P2-24	DPH1	Resonance Suppression (Notch filter) Attenuation Rate (1)	0	dB	0	0	0	0	6.3.7			
P2-43	NCF2	Resonance suppression (Notch filter) (2)	1000	Hz	0	0	0	0	6.3.7			
P2-44	DPH2	Resonance Suppression (Notch filter) Attenuation Rate (2)	0	dB	0	0	0	0	6.3.7			
P2-45	NCF3	Resonance suppression (Notch filter) (3)	1000	Hz	0	0	0	0	6.3.7			

8-4 Revision February, 2017

P2-46	DPH3	Resonance Suppression (Notch filter) Attenuation Rate (3)	0	dB	0	0	0	0	6.3.7
P2-47	ANCF	Auto Resonance Suppression Mode Setting	1	N/A	0	0	0	0	-
P2-48	ANCL	Resonance Suppression Detection Level	100	N/A	0	0	0	0	-
P2-25	NLP	Low-pass Filter of Resonance Suppression	2 or 5	0.1ms	0	0	0	0	6.3.7
P2-33 ▲	INF	Semi-auto Inertia Adjustment	0	N/A	0	0	0	0	6.3.6
P2-49	SJIT	Speed Detection Filter	0	-	0	0	0	0	-

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (**A**) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

	Gain and Switch Parameter										
Davamatar	م ا ما ۸	Function	Default	Lloit	С	ontro	I Мо	de	Related		
Parameter	Abbr.	Function	Default	Unit	PT	PR	S	Т	Section		
P2-00	KPP	Position Loop Gain	35	rad/s	0	0			6.2.8		
P2-01	PPR	Switching Rate of Position Loop Gain	100	%	0	0			6.2.8		
P2-02	PFG	Position Feed Forward Gain	50	%	0	0			6.2.8		
P2-03	PFF	Smooth Constant of Position Feed Forward Gain	5	ms	0	0			-		
P2-04	KVP	Speed Loop Gain	500	rad/s	О	0	0	О	6.3.6		
P2-05	SPR	Switching Rate of Speed Loop Gain	100	%	0	0	0	0	-		
P2-06	KVI	Speed Integral Compensation	100	rad/s	0	0	0	0	6.3.6		
P2-07	KVF	Speed Feed Forward Gain	0	%	0	0	0	0	6.3.6		
P2-26	DST	Anti-interference Gain	0	0.001	0	0	0	0	-		
P2-27	GCC	Gain Switching and Switching Selection	0	N/A	0	0	0	0	-		
P2-28	GUT	Gain Switching Time Constant	10	10 ms	0	0	0	0	-		
P2-29	GPE	Gain Switching	1280000	pulse Kpps r/min (rotary motor) 10 ⁻³ m/s (linear motor)	0	0	0	0	-		
P2-31 ■	AUT1	Speed Loop Frequency	80	Hz	0	0	0	0	5.6		
PZ-31 1	AUTI	Response Setting in Auto and Semi-auto Mode	ου	П∠	U		U	U	6.3.6		

D2 22 A	ALITO	Tuning Made Coloction	0	NI/A			_	5.6
P2-32 ▲	AUT2	Tuning Mode Selection	U	N/A	U	U	U	6.3.6

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (▲) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

	Position Control Parameter										
		Position Contro	oi Paramete	ər							
Parameter	Abbr.	Function	Default	Unit	Cc	ntrol	Mod	de	Related		
					PT	PR	S	Т	Section		
P1-01●	CTL	Input Setting of Control Mode and Control Command	0	pulse r/min N-M	0	0	0	0	6.1		
P1-02▲	PSTL	Speed and Torque Limit Setting	0	N/A	0	0	0	0	6.6		
P1-12 ~ P1-14	TQ1 ~ 3	Internal Torque Limit 1 ~ 3	100	%	0	0	0	0	6.4.1		
P1-46 ▲	GR3	Pulse Number of Encoder Output	2500	pulse	0	0	0	0	-		
P1-55	MSPD	Maximum Speed Setting	rated	r/min	0	0	0	0	-		
P1-72	FRES	Resolution of Linear Scale for full-closed loop control	5000	Pulse/ rev	0	0			-		
P1-73	FERR	Error Protection Range for Full-closed Loop Control	30000	pulse	0	0			-		
P1-74	FCON	Full-closed Loop Control of Linear Scale	000h	-	0	0			-		
P2-50	DCLR	Pulse Clear Mode	0	N/A	0	0			-		
		External Pulse Com	mand (PT n	node)		·					
P1-00▲	PTT	External Pulse Input Type	0x2	N/A	О				6.2.1		
P1-44 ▲	GR1	Gear Ratio (Numerator) (N1)	1	pulse	0	0			6.2.5		
P1-45▲	GR2	Gear Ratio (Denominator) (M)	1	pulse	О	О			6.2.5		
P2-60	GR4	Gear Ratio (Numerator) (N2)	1	pulse	0				-		
P2-61	GR5	Gear Ratio (Numerator) (N3)	1	pulse	0				-		
P2-62	GR6	Gear Ratio (Numerator) (N4)	1	pulse	О				-		
		Register Control Con	nmand (PR	mode)	I				I		
P6-02 ~ P7-27	PO1 ~ PO63	Internal Position Command 1 ~ 63	0	N/A		0			7.10		
P5-60 ~ P5-75	POV1 ~ POV15	Target Speed Setting#0 ~ 15	20 ~ 3000	0.1r/min		0			7.10		
P5-03	PDEC	Deceleration Time of Auto Protection	0XF00FF FFF	N/A	0	0	0	0	-		

8-6 Revision February, 2017

Position Control Parameter										
Parameter	Abbr.	Function	Default	Unit	Со	ntrol	Мос	de	Related	
raiametei	Abbi.	1 diletion	Delault	Offic	PT	PR	S	Т	Section	
P5-04	HMOV	Homing Mode	0	N/A	0	0			-	
P5-05	HSPD1	1 st Speed Setting of High Speed Homing	100	0.1r/min	0	0	0	0	-	
P5-06	HSPD2	2 nd Speed Setting of Low Speed Homing	20	0.1r/min	0	0	0	0	-	
P5-07	PRCM	Trigger Position Command (PR mode only)	0	N/A		0			-	
P5-20 ~ P5-35	AC0 ~ AC15	Acceleration/Deceleration Time	200 ~ 30	ms		0			7.10	
P5-40 ~ P5-55	DLY0 ~ DLY15	Delay Time after Position Completed	0 ~ 5500	ms		0			7.10	
P5-98	EVON	Position Command of Event Rising-edge Trigger	0	N/A		0			-	
P5-99	EVOF	Position Command of Event Falling-edge Trigger	0	N/A		0			-	
P5-15	PMEM	PATH#1 ~ PATH#2 No Data Retained Setting	0x0	N/A	0	0	0	0	-	
P5-16	AXEN	Axis Position - Motor Encoder	N/A	N/A	0	0	0	0	7.3	
P5-17	AXAU	Axis Position - Auxiliary Encoder	N/A	N/A	0	0	0	0	7.3	
P5-18	AXPC	Axis Position - Pulse Command	N/A	N/A	0	0	0	0	7.3	
P5-08	SWLP	Forward Software Limit	+2 ³¹	PUU		0			-	
P5-09	SWLN	Reverse Software Limit	-2 ³¹	PUU		0			-	

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (▲) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

Speed Control Parameter											
Parameter	Abbr.	Function	Default	Unit	C	ontro	l Mo	de	Related		
raiailletei	AUUI.	FullClion	Delault	Offic	PT	PR	S	Т	Section		
P1-01●	CTL	Input Setting of Control Mode and Control Command	0	pulse r/min N-M	0	0	0	0	6.1		
P1-02▲	PSTL	Speed and Torque Limit Setting	0	N/A	0	0	0	0	6.6		
P1-46 ▲	GR3	Output Pulse Counts Per One Motor Revolution	1	pulse	0	0	0	0	-		
P1-55	MSPD	Maximum Speed Limit	rated	r/min	0	0	0	0	-		

P1-09 ~ P1-11	SP1 ~ 3	Internal Speed Command 1 ~ 3	1000 ~ 3000	0.1 r/min			0	О	6.3.1
P1-12 ~ P1-14	TQ1 ~ 3	Internal Torque Limit 1 ~ 3	100	%	0	0	0	0	6.6.2
P1-40 ▲	VCM	Maximum Speed of Analog Speed Command	rated	r/min			0	0	6.3.4
P1-41 ▲	TCM	Maximum Output of Analog Torque Speed	100	%	0	0	0	0	-
P1-76	AMSPD	Maximum Rotation Setting of Encoder Setting (OA, OB)	5500	r/min	0	0	0	0	-

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (**A**) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

	Torque Control Parameter									
Daramatar	A b b s	Function	Default	Unit	Co	ontro	I Mo	de	Related	
Parameter	Abbr.	Function	Default	Unit	РТ	PR	S	Т	Section	
P1-01●	CTL	Input Setting of Control Mode and Control Command	0	pulse r/min N-M	0	0	0	0	6.1	
P1-02▲	PSTL	Speed and Torque Limit Setting	0	N/A	0	0	0	0	6.6	
P1-46▲	GR3	Output Pulse Counts Per One Motor Revolution	1	pulse	0	0	0	0	-	
P1-55	MSPD	Maximum Speed Limit	rated	r/min	0	0	0	0	-	
P1-09 ~ P1-11	SP1~3	Internal Speed Limit 1~3	100 ~ 300	0.1 r/min			0	0	6.6.1	
P1-12 ~ P1-14	TQ1~3	Internal Torque Command 1~3	100	%	0	0	0	0	6.4.1	
P1-40 ▲	VCM	Maximum Speed of Analog Speed Command	rated	r/min			0	0	-	
P1-41▲	TCM	Maximum Output of Analog Torque Limit	100	%	0	0	0	0	6.4.4	

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (▲) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

8-8 Revision February, 2017

	Plannin	g of Digital Input / Output Pin an	d Outpu	t Settir	ng P	aran	nete	r	
Parameter	Abbr.	Function	Default	Unit	С	ontro	І Мо	de	Related
raiametei	AUUI.	Function	Delault	Offic	PT	PR	S	Т	Section
P2-09	DRT	DI Debouncing Time	2	ms	0	0	0	0	-
P2-10	DI1	DI1 Functional Planning	101	N/A	0	0	0	0	Table 8.1
P2-11	DI2	DI2 Functional Planning	104	N/A	0	0	0	0	Table 8.1
P2-12	DI3	DI3 Functional Planning	116	N/A	0	0	0	0	Table 8.1
P2-13	DI4	DI4 Functional Planning	117	N/A	0	0	0	0	Table 8.1
P2-14	DI5	DI5 Functional Planning	102	N/A	0	0	0	0	Table 8.1
P2-15	DI6	DI6 Functional Planning	22	N/A	0	0	0	0	Table 8.1
P2-16	DI7	DI7 Functional Planning	23	N/A	0	0	0	0	Table 8.1
P2-17	DI8	DI8 Functional Planning	21	N/A	0	0	0	0	Table 8.1
P2-36	EDI9	DI9 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-37	EDI10	DI10 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-38	EDI11	DI11 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-39	EDI12	DI12 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-40	EDI13	DI13 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-41	EDI14	DI14 Functional Planning	0	N/A	0	0	0	0	Table 8.1
P2-18	DO1	DO1 Functional Planning	101	N/A	0	0	0	0	Table 8.2
P2-19	DO2	DO2 Functional Planning	103	N/A	0	0	0	0	Table 8.2
P2-20	DO3	DO3 Functional Planning	109	N/A	0	0	0	0	Table 8.2
P2-21	DO4	DO4 Functional Planning	105	N/A	0	0	0	0	Table 8.2
P2-22	DO5	DO5 Functional Planning	7	N/A	0	0	0	0	Table 8.2
P1-38	ZSPD	Zero Speed Range Setting	100	0.1 r/min	0	0	0	0	Table 8.2
P1-39	SSPD	Target Motor Detection Level	3000	r/min	0	0	0	0	Table 8.2
P1-42	MBT1	Enable Delay Time of Brake	0	ms	0	0	0	0	6.5.5

P1-43	MBT2	Disable Delay Time of Brake	0	ms	0	0	0	0	6.5.5
P1-47	SCPD	Speed Reached (DO : SP_OK) Range	10	r/min			0		Table 8.2
P1-54	PER	Position Completed Range	12800	pulse	0	0			Table 8.2
P1-56	OVW	Output Overload Warning Level	120	%	0	0	0	0	Table 8.2

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (**A**) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

Communication Parameter											
Davamatar	A b b s	Function	Default	l lmi4	Control Mode				Related		
Parameter	Abbr.	Function	Default	Unit	РТ	PR	S	Т	Section		
P3-00●	ADR	Address Setting	0x01	N/A	0	0	0	0	9.2		
P3-01	BRT	Transmission Speed	0x3203	bps	0	0	0	0	9.2		
P3-02	PTL	Communication Protocol	6	N/A	0	Ο	0	0	9.2		
P3-03	FLT	Communication Error Disposal	0	N/A	0	0	0	0	9.2		
P3-04	CWD	Communication Timeout	0	sec	0	0	0	0	9.2		
P3-05	CMM	Communication Mechanism	0	N/A	0	Ο	0	0	9.2		
P3-06∎	SDI	Control Switch of Digital Input (DI)	0	N/A	0	0	0	0	9.2		
P3-07	CDT	Communication Response Delay Time	0	1ms	0	0	0	0	9.2		
P3-08	MNS	Monitor Mode	0000	N/A	0	0	0	0	9.2		
P3-09	SYC	CANopen Synchronize Setting	0x57A1	N/A							
P3-09	310	DMCNET Synchornize Setting	0x3511	IN/A							
P3-10	CANEN	CANopen Protocol Setting	0x0000	N/A							
P3-10	CAINEIN	DMCNET Protocol Setting	1	IN/A							
P3-11	CANOP	CANopen Selection	0	N/A							
F 3-11	CANOP	DMCNET Selection	0	IN/ <i>P</i> 4							
D2 12	OSTDO	CANopen Support Setting	0	N/A							
P3-12	QSTPO	DMCNET Support Setting	0	IN/ <i>F</i> A							

- (★) Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.
- (**A**) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.
- (•) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.
- (**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

8-10 Revision February, 2017

Diagnosis Parameter											
Parameter	Abbr.	Function	Default	Unit	Co	ontro	I Мо	de	Related		
Parameter	ADDI.	Function	Delault	Offic	PT	PR	S	Т	Section		
P4-00★	ASH1	Fault Record (N)	0	N/A	0	Ο	0	0	4.4.1		
P4-01★	ASH2	Fault Record (N-1)	0	N/A	0	0	0	0	4.4.1		
P4-02★	ASH3	Fault Record (N-2)	0	N/A	0	0	0	0	4.4.1		
P4-03★	ASH4	Fault Record (N-3)	0	N/A	0	0	0	0	4.4.1		
P4-04★	ASH5	Fault Record (N-4)	0	N/A	0	О	0	0	4.4.1		
P4-05	JOG	Servo Motor Jog Control	20	r/min	0	0	0	0	4.4.2		
P4-06▲■	FOT	Digital Output Register (Readable and Writable)	0	N/A	0	О	0	0	4.4.4		
P4-07	ITST	Multi-function of Digital Input	0	N/A	0	О	0	0	4.4.5 9.2		
P4-08★	PKEY	Input Status of the Drive Keypad	N/A	N/A	0	О	0	0	-		
P4-09★	MOT	Digital Output Status	N/A	N/A	0	0	0	0	4.4.6		
P4-10 ▲	CEN	Adjustment Selection	0	N/A	0	0	0	0	-		
P4-11	SOF1	Analog Speed Input Offset Adjustment 1	Factory Setting	N/A	0	0	0	0	-		
P4-12	SOF2	Analog Speed Input Offset Adjustment 2	Factory Setting	N/A	0	0	0	0	-		
P4-13	TOF1	Analog Torque Input Offset Adjustment 1	Factory Setting	N/A	0	0	Ο	0	-		
P4-14	TOF2	Analog Torque Input Offset Adjustment 2	Factory Setting	N/A	0	0	Ο	0	-		
P4-15	COF1	Current Detector (V1 Phase) Offset Adjustment	Factory Setting	N/A	0	0	0	0	-		
P4-16	COF2	Current Detector (V2 Phase) Offset Adjustment	Factory Setting	N/A	0	0	0	0	-		
P4-17	COF3	Current Detector (W1 Phase) Offset Adjustment	Factory Setting	N/A	0	0	0	0	-		
P4-18	COF4	Current Detector (W2 Phase) Offset Adjustment	Factory Setting	N/A	0	О	Ο	0	-		
P4-19	TIGB	IGBT NTC Adjustment Detection Level	Factory Setting	N/A	0	0	0	0	-		
P4-20	DOF1	Offset Adjustment Value of Analog Monitor Output (Ch1)	0	mV	0	0	0	0	6.4.4		
P4-21	DOF2	Offset Adjustment Value of Analog Monitor Output (Ch2)	0	mV	0	0	Ο	0	6.4.4		
P4-22	SAO	Analog Speed Input OFFSET	0	mV			0		-		
P4-23	TAO	Analog Torque Input OFFSET	0	mV				0	-		

 $^{(\}bigstar)$ Read-only register, can only read the status. For example: parameter P0-00, P0-10 and P4-00, etc.

^(▲) Setting is unable when Servo On, e.g. parameter P1-00, P1-46 and P2-33, etc.

(●) Not effective until re-power on or off the servo drive, e.g. parameter P1-01 and P3-00.

(**■**) Parameters of no data retained setting, e.g. parameter P2-31 and P3-06.

8-12 Revision February, 2017

8.3 Parameter Description

P0-xx Monitor Parameters

Operational Interface : Panel / Software Communication Related Section: - Default : Factory Setting Control Mode : Unit : - Range : - Data Size : 16-bit Format : Decimal	P0-00★	VER Fir	VER Firmware Version		
Control Mode: Unit: - Range: - Data Size: 16-bit			Danal / Cafferana	Communication	Related Section: -
Mode: Unit: - Range: - Data Size: 16-bit		Default :	Factory Setting		
Range : - Data Size : 16-bit					
Data Size : 16-bit		Unit:	-		
		Range :	-		
Format : Decimal		Data Size :	16-bit		
		Format :	Decimal		

Settings: This parameter shows the firmware version of the servo drive.

ALE	ALE Alarm Code Display of Drive (Seven-segn		of Drive (Seven-segmen	Address: 0002H 0003H
Operation Interfact	. D 1	/ Software	Communication	Related Section: 11.1, 11.2, 11.3
Defau	lt : -			
Cor Mod	itrol e : ALL			
Un	it : -			
Rang	e : 0x000 clear t	00∼0xFFFF: I the alarm (Sa	t only can be set to 0 me as DI.ARST).	to
Data Siz	e: 16-bit			
Forma	at: BCD	BCD		
Setting	s : Hexad	decimal forma	t: displays the alarm cod	e

Alarm of Servo Drive

001: Over current

002 : Over voltage

003: Under voltage (In default setting, the alarm occurs only when the voltage is not enough in Servo ON status; In Servo ON status, when it applies to power R, S, T, the alarm still will not be cleared. Please refer to P2-66.)

004 : Motor combination error (The drive corresponds to the wrong motor)

005: Regeneration error

006: Over load

007: Over speed

008: Abnormal pulse command

009: Excessive deviation of position command

010: Reserved

011 : Encoder error (The servo drive cannot connect to the encoder because of disconnection or abnormal wiring)

012 : Adjustment error

013: Emergency stop

014: Reverse limit error

015: Forward limit error

016: IGBT overheat

8-14 Revision February, 2017

017: Abnormal EEPROM

018: Abnormal signal output

019 : Serial communication error

020 : Serial communication time out

021: Reserved

022 : Main circuit power lack phase

023: Early warning for overload

024 : Encoder initial magnetic field error (The magnetic field of the encoder U,V, W signal is in error)

025 : The internal of the encoder is in error. (The internal memory of the encoder and the internal counter are in error)

026: Unreliable internal data of the encoder

027: Encoder reset error

028 : The encoder is over voltage or the internal of the encoder is in error

029 : Gray code error

030: Motor crash error

031 : Incorrect wiring of the motor power line U, V, W (Incorrect wiring of the motor power line U, V, W, GND)

034: Internal communication of the encoder is in error

040: Excessive deviation of full closed-loop position control

041: Communication of CN5 is breakdown

042 : Analog input voltage error

044: Warning of servo drive function overload

060: The absolute position is lost

061 : Encoder under voltage

062: The multi-turn of absolute encoder overflows

068 : Absolute data transmitted via I/O is in error

069: Wrong motor type

099 : DSP firmware upgrade

Alarm of CANopen Communication

111 : CANopen SDO receives buffer overflow

112 : CANopen PDO receives buffer overflow

121: Index error occurs when accessing CANopen PDO

122 : Sub-Index error occurs when accessing CANopen PDO 123 : Data size error occurs when accessing CANopen PDO

- 124 : Data range error occurs when accessing CANopen PDO 125 : CANopen PDO mapping object is read-only and writeprotected.
- 126 : CANopen PDO mapping object is not allowed in PDO
- 127: CANopen PDO mapping object is write-protected when Servo ON
- 128 : Error occurs when reading CANopen PDO mapping object via EEPROM
- 129 : Error occurs when writing CANopen PDO mapping object via EEPROM
- 130 : The accessing address of EEPROM is out of range when using CANopen PDO mapping object
- 131 : CRC of EEPROM calculation error occurs when using CANopen PDO mapping object
- 132 : Enter the incorrect password when using CANopen PDO mapping object
- 185 : Abnormal CAN Bus hardware

Alarm of Motion

- 201: An error occurs when loading CANopen data
- 207: Parameter group of PR#8 is out of range
- 209 : Parameter number of PR#8 is out of range
- 213 ~ 219 : An error occurs when writing parameter via PR procedure. Please refer to Chapter 11 of the manual for further information.
- 231: The setting of monitor item of PR#8 is out of range
- 235 : PR command overflows
- 237: Indexing coordinate is undefined
- 245 ~ 277 : Reserved
- 283 : Forward software limit
- 285 : Reverse software limit
- 289 : Feedback position counter overflows
- 291 : Servo OFF error
- 301: CANopen fails to synchronize
- 302: The synchronized signal of CANopen is sent too fast
- 303: The synchronized signal of CANopen is sent too slow
- 304 : CANopen IP command is failed

8-16 Revision February, 2017

305 : SYNC Period is in error

380 : Position Deviation Alarm of DO.MC_OK. Please refer to parameter

P1-48.

P0-02

STS Di	rive Status		Address: 0004H 0005H
Operationa Interface :		Communication	Related Section: 7.2
Default :	00		
:	Control Mode :		
Unit :	_		
Range :	00 ~ 127		
Data Size :	16-bit		
Format :	Decimal		

Settings: 00: Motor feedback pulse number (after the scaling of electronic gear ratio) [PUU]

01 : Input pulse number of pulse command (after the scaling of electronic gear ratio) [PUU]

02 : Deviation between control command pulse and feedback pulse number[PUU]

03 : The number of motor feedback pulse [Encoder unit, 1,280,000 Pulse/rev]

04 : Distance to command terminal (Encoder unit) [Pulse]

05 : Error pulse number (after the scaling of electronic gear ratio) (Encoder unit) [Pulse]

06 : The frequency of pulse command input [Kpps]

07 : Motor speed [r/min]

08 : Speed command input [Volt]

09 : Speed command input [r/min]

10 : Torque command input [Volt]

11 : Torque command input [%]

12 : Average torque [%]

13 : Peak torque [%]


14 : Main circuit voltage (BUS voltage) [Volt]

15 : Load/motor inertia ratio [0.1times]

16: IGBT temperature

17: The frequency of resonance suppression

18 : The distance from the current position to Z. The range of the value is between -5000 and +5000;



The interval of the two Z-phase pulse command if 10000 Pulse.

19: Mapping Parameter #1: P0 - 25

20 : Mapping Parameter #2 : P0 - 26

21: Mapping Parameter #3: P0 - 27

22: Mapping Parameter #4: P0 - 28

23: Monitoring variable #1: P0 - 09

24: Monitoring variable #2: P0 - 10

25: Monitoring variable #3: P0 - 11

26 : Monitoring variable #4 : P0 - 12

38 : It display the battery voltage [0.1 Volt]. For example, if it displays 36, it means the battery voltage is 3.6 V.

72 : Analog speed command [0.1 r/min] (This is supported by A2-M/- U/-L.)

P0-03


MON	Analog Output Monito	or	Address: 0006H 0007H
Operatior Interface	nal Panel / Software :	Communication	Related Section: 6.6.4
Default	: 00		
Control Mode	: ALL		
Unit	: -		
Range	: 00 ~ 0x77		· · · · · · · · · · · · · · · · · · ·

8-18 Revision February, 2017

Data Size: 16-bit

Format : Hexadecimal

Settings:



MON1, MON2 Setting Value	Description					
0	Motor speed (+/-8 Volts/Max. speed)					
1	Motor torque (+/-8 Volts/Max. torque)					
2	Pulse command frequency (+8 Volts / 4.5Mpps)					
3	Speed command (+/-8 Volts/ Max. speed command)					
4	Torque command (+/-8 Volts/Max. torque command)					
5	VBUS voltage (+/-8 Volts / 450V)					
6	Reserved					
7	Reserved					



Please refer to parameter P1-04, P1-05 for proportional setting of analog output voltage.

For example: P0-03 = 01 (MON1 is the analog output of motor speed; MON2 is the analog output of motor torque)

MON1 output voltage =
$$8 \times \frac{\text{Motor speed}}{(\text{Max. speed} \times \frac{P1-04}{100})}$$
 (unit : Volts)
MON2 output voltage = $8 \times \frac{\text{Motor torque}}{(\text{Max. torque} \times \frac{P1-05}{100})}$ (unit: Volts)



P0-08★	TSON F	Power On Time	ver On Time			
	Operation Interface	al Panel / Software :	Communication	Related Section : -		
	Default	: 0				
	Contr Mode	_				
	Unit	: Hour				
	Range	: 0 ~ 65535				
	Data Size	: 16-bit				
	Format	: Decimal				

Settings: It shows the total startup time of the servo drive.

P0-09★	CM1 Sta	atus Monitor Registo	us Monitor Register 1		
	Operationa Interface:	Panel / Software	Communication	Related Section: 4.3.5	
	Default :	-			
	Contro Mode :	ALL			
	Unit:	-	-		
	Range :	-			
	Data Size :	32-bit			
	Format :	Decimal			

Settings: The setting value which is set by P0-17 should be monitored via P0-09.

(Please refer to Chapter 7.2.1, Description of Monitoring Variable for

the setting value.)

For example, if P0-17 is set to 3, when accessing P0-09, it obtains the total feedback pulse number of motor encoder. For MODBUS communication, two 16-bit data, 0012H and 0013H will be read as a 32-bit data; (0013H:0012H) = (Hi-word: Low-word).

Set P0-02 to 23, the panel displays **VAR-1** first, and then shows the content of P0-09.

8-20 Revision February, 2017

P0-10★	CM2	Status Monitor Regist	tus Monitor Register 2			
	Operatio Interface	nal Panel / Software e:	Communication	Related Section: 4.3.5		
	Defaul	t : -				
	Con Mode	trol ə :				
	Uni	t : -				
	Range	э : -				
	Data Size	e : 32-bit				

Settings: The setting value which is set by P0-18 should be monitored via P0-10.

(Please refer to Chapter 7.2.1, Description of Monitoring variable for the setting value.) Set P0-02 to 24, the panel displays **VAR-2** first, and

then shows the content of P0-10.

P0-11★	СМЗ	Status Monitor Regist	tatus Monitor Register 3		
	Operation Interfac	onal Panel / Software e:	Communication	Related Section: 4.3.5	
	Defau	lt : -			
	Con	ntrol e :			
	Un	it : -			

Data Size: 32-bit

Range: -

Format: Decimal

Format : Decimal

Settings: The setting value which is set by P0-19 should be monitored via P0-11.

(Please refer to Chapter 7.2.1, Description of Monitoring Variable for the setting value.) Set P0-02 to 25, the panel displays **VAR-3** first, and

then shows the content of P0-11.

D0 40 1	0114	04-4 84i 4 Di	Address: 0018H		
P0-12★	CM4	Status Monitor Regist	us Monitor Register 4		
	Operatior Interface	nal Panel / Software :	Communication	Related Section: 4.3.5	
	Default	: -			
	Cont Mode	rol ALL	ALL		
	Unit	: -			
	Range	: -			
	Data Size	: 32-bit			
	Format	: Decimal			

Settings: The setting value which is set by P0-20 should be monitored via P0-12.

(Please refer to Chapter 7.2.1, Description of Monitoring Variable for the setting value.) Set P0-02 to 26, the panel displays **VAR-4** first, and

then shows the content of P0-12.

P0-13★	CM5	Status Monitor Regist	er 5	Address: 001AH 001BH
	Operation Interface	nal Panel / Software :	Communication	Related Section: 4.3.5
	Default	: -		
	Conti Mode	Δ11		
	Unit	: -		
	Range	: -		
	Data Size	: 32-bit		
	Format	: Decimal		

Settings: The setting value which is set by P0-21 should be monitored via P0-13.

(Please refer to Chapter 7.2.1, Description of Monitoring Variable for

the setting value.)

P0-	14 ~
P0	-16

Reserved

8-22 Revision February, 2017

7	CM1A	Statu	ıs Monitor Registo	er 1 Selection	Address: 0022H 0023H
	Operatio Interface	:D	anel / Software	Communication	Related Section: -
	Defaul	It : 0			
-	Con Mode	_			
	Uni	it : -			
	Range	e: 0	~ 127		
	Data Size	e : 10	6-bit		
	Forma	at : D	ecimal		

Settings: Please refer to Chapter 7.2.1, Description of Monitoring Variable for the

setting value.

P0-1

For example, if P0-17 is set to 07, then reading P0-09 means reading

「Motor speed (r/min) 」.

P0-18		Status Monitor Register 2 Selection		Address: 0024H 0025H
	Operational Interface:	Panel / Software	Communication	Related Section: -
	Default :	: 0		
	Contro Mode :	<u>_</u>		
	Unit :	: -		
	Range :	: 0 ~ 127		
	Data Size :	: 16-bit		
	Format :	: Decimal		

Settings: Please refer to Chapter 7.2.1, Description of Monitoring Variable for the

setting value.

P0-19	СМЗА	Status Monitor Regist	ter 3 Selection	Address:0026H 0027H
	Operation Interface		Communication	Related Section: -
	Defaul	t : 0		
	Cont Mode	_		
	Uni	t : -		
	Range	e : 0 ~ 127		
	Data Size	e : 16-bit		
	Forma	t : Decimal		

Settings: Please refer to Chapter 7.2.1, Description of Monitoring Variable for the setting value.

P0-20	CM4A Sta	atus Monitor Regist	er 4 Selection	Address: 0028H 0029H
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	0		
	Control Mode :	-		
	Unit :	-		
	Range :	0 ~ 127		
	Data Size :	16-bit		-
	Format :	Decimal		4

Settings: Please refer to Chapter 7.2.1, Description of Monitoring Variable for the setting value.

P0-21	CM5A	Status Monitor Regist	er 5 Selection	Address: 002AH 002BH
	Operation Interfac	onal Panel / Software e:	Communication	Related Section: -
	Defau	lt : 0		
	Con Mod	:		
		it : -		

8-24 Revision February, 2017

Chapter 8 Parameters

Range: 0 ~ 127

Data Size: 16-bit

Format: Decimal

Settings: Please refer to Chapter 7.2.1, Description of Monitoring Variable for the

setting value.

P0-22 ~ P0-24

Reserved

P0-25

MAP1 Ma	apping Parameter # 1	Address: 0032H 0033H		
Operationa Interface :	:D 1/O (1	Communication	Related Section: 4.3.5	
Default:	No need to initialize	No need to initialize		
Contro Mode :	ΔΙΙ			
Unit :	-			
Range :	determined by the corresponding parameter of P0-35			
Data Size :	32-bit			
Format :	Hexadecimal			

Settings: Users can rapidly continuously read and write parameters that are not in the same group. The content of parameter that is specified by P0-35

will be shown in P0-25.

Please refer to the description of P0-35 for parameter setting.

P0-26	MAP2 Ma	apping Parameter #	2	Address: 0034H 0035H
	Operationa Interface:	l Panel / Software	Communication	Related Section: 4.3.5
	Default :	Default : No need to initialize		
	Contro Mode :	Control Mode :		
	Unit :	-		
	Range :	determined by the coof P0-36	orresponding parameter	
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-36.

P0-27	MAP3 Ma	pping Parameter # 3	3	Address: 0036H 0037H
	Operational Interface :	Panel / Software	Communication	Related Section: 4.3.5
	Default :	No need to initialize	lo need to initialize	
	Control Mode :	ALL		
	Unit : -			
	Range :	determined by the corresponding parameter of P0-37 32-bit		
	Data Size :			
	Format :	Hexadecimal		

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-37.

P0-28	MAP4 Ma	pping Parameter #	Address: 0038H 0039H			
	Operational Interface:	:D-:I / O-#:	Communication	Related Section: 4.3.5		
	Default :	No need to initialize			need to initialize	
	Control Mode :	ALL				
	Unit:	-				
	Range :	determined by the o	corresponding parameter			
	Data Size :	32-bit				
	Format :	Hexadecimal				

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-38.

8-26 Revision February, 2017

P0-29	MAP5 Ma	apping Parameter # 5		Address: 003AH 003BH
	Operational Interface :	Panel / Software	Communication	Related Section: 4.3.5
	Default:	No need to initialize		
	Control Mode :	ALL		
	Unit:	-		
	Range :	determined by the co of P0-39	rresponding parameter	
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-39.

P0-30	MAP6 Ma	pping Parameter # 6	3	Address: 003CH 003DH
	Operational Interface:	Panel / Software	Communication	Related Section: 4.3.5
	Default :	No need to initialize		
P	Contro Mode :	ALL		
	Unit:	-		
	Range :	determined by the co	orresponding parameter	
	Data Size :	32-bit		
	Format :	Hexadecimal		-

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-40.

P0-31	MAP7	Mapping Parameter # 7	,	Address: 003EH 003FH
	Operation	onal Panel / Software e :		Related Section:
	Interfac	:	Communication	4.3.5
	Defau	It: No need to initialize		
	Mod	e :		

Unit: Range: determined by the corresponding parameter of P0-41

Data Size: 32-bit

Format: Hexadecimal

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-41.

P0-32	MAP8 Ma	pping Parameter # 8		Address: 0040H 0041H
	Operational Interface:	Panel / Software	Communication	Related Section: 4.3.5
	Default :	No need to initialize		
	Contro Mode :	ALL		
	Unit :	-		
	Range :	determined by the corr of P0-42	responding parameter	
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: The using method is the same as P0-25. The mapping target is set by parameter P0-42.

P0-33 ~ P0-34

Reserved

P0-35	MAP1A Ta	rget Setting of Mappir	g Parameter P0-25	Address: 0046H 0047H
	Operationa Interface :	Panel / Software	Communication	Related Section: 4.3.5
	Default:	0x0		
	Contro Mode :	ALL		
	Unit:	-		
	Range :	determined by the com the parameter group	munication address of	
	Data Size :	32-bit		
	Format :	Hexadecimal		


8-28 Revision February, 2017

Settings:

Select the data block to access the parameter corresponded by register 1.


The mapping content is 32 bits wide and can map to two 16-bit parameters or one 32-bit parameter.

P0-35:



Mapping parameter: P0-35; Mapping content: P0-25.

When PH≠PL, it means the content of P0-25 includes two 16-bit parameters.




Mapping parameter: P0-35; Mapping content: P0-25.

When PH=PL=P, it means the content of P0-25 includes one 32-bit parameter.

If P=060Ah (parameter P6-10), then V32 is P6-10.

The setting format of PH, PL is:



A: The hexadecimal of parameter indexing

B: The hexadecimal of parameter group

For example:

If the mapping target is P2-06, set P0-35 to 0206.

If the mapping target is P5-42, set P0-35 to 052A.

For example:

If users desire to read / write P1-44 (32-bit) through P0-25, set P0-35 to 0x012C012C via panel or communication. Then, when reading / writing P0-25, it also reads / writes P1-44.

Moreover, users can also access the value of P2-02 and P2-04 through P0-25.

P2-02 Position feed forward gain (16-bit)

P2-04 Speed control gin (16-bit)

Users only need to set P0-35 to 0x02040202. Then, when reading / writing P0-25, it also reads / writes the value of P2-02 and P2-04.

Address: 0048H P0-36 MAP2A Target Setting of Mapping Parameter P0-26 0049H Related Section: Operational Panel / Software Communication 4.3.5 Interface: Default: 0x0 Control ALL Mode: Unit: determined by the communication address of Range: the parameter group Data Size: 32-bit Format: Hexadecimal Settings: P0-36 P0-26

P0-37	МАРЗА Та	rget Setting of Mappi	ing Parameter P0-27	Address: 004AH 004BH
	Operational Interface :	Panel / Software	Communication	Related Section: 4.3.5
	Default :	0x0		
	Control Mode :	ALL		
	Unit:	-		
	Range :	determined by the co the parameter group	mmunication address of	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	P0-37		

8-30 Revision February, 2017

Address: 004CH P0-38 MAP4A Target Setting of Mapping Parameter P0-28 004DH Related Section: Operational Panel / Software Communication Interface: 4.3.5 Default: 0x0 Control ALL Mode: Unit: determined by the communication address of Range: the parameter group Data Size: 32-bit Format: Hexadecimal Settings: P0-38 P0-28

P0-39	MAP5A Ta	rget Setting of Mappi	ng Parameter P0-29	Address: 004EH 004FH
	Operationa Interface:	l Panel / Software	Communication	Related Section: 4.3.5
	Default :	0x0		
	Contro Mode :	I ALL		
	Unit :	-		
	Range :	determined by the cor the parameter group	mmunication address of	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	P0-39		

Address: 0050H P0-40 MAP6A Target Setting of Mapping Parameter P0-30 0051H Related Section: Operational Panel / Software Communication 4.3.5 Interface: Default: 0x0 Control ALL Mode: Unit: determined by the communication address of Range: the parameter group Data Size: 32-bit Format: Hexadecimal Settings: P0-40 P0-30

P0-41	МАР7А	Target Se	tting of Map	ping Parameter P0-31	Address: 0052H 0053H
	Operatio Interface	וסססו	/ Software	Communication	Related Section: 4.3.5
	Defaul	lt: 0x0			
	Con Mode	ΛII			
	Uni	it : -			
	Range	e : determ the par	nined by the crameter group	ommunication address of	
	Data Size	e: 32-bit			
	Forma	t : Hexad	ecimal		
	Settings	s: _{P0-41}	1 1		·

8-32 Revision February, 2017

P0-42	MAP8A T	arget Setting of Mapping	g Parameter P0-32	Address: 0054H 0055H
	Operational Interface	Donal / Coffware	Communication	Related Section: 4.3.5
	Default	: 0x0		
	Contro Mode	ΛII		
	Unit	: -		
	Range	determined by the comr the parameter group	munication address of	
	Data Size	; 32-bit		
	Format	; Hexadecimal		
	Settings	P0-42		

P0-43 Reserved

P0-44★	PCMN S	tatus Monitor Registo	er (for PC software)	Address: 0058H 0059H
	Operation Interface		Communication	Related Section: 4.3.5
	Default	: 0x0		
	Contr Mode	ΛΙΙ		
	Unit	: -		
	Range	determined by the co	ommunication address of	
	Data Size	: 32-bit		
	Format	: Decimal		
	Settings	: Same as parameter	P0-09.	•

P0-45∎	PCMNA	Status Monitor Registe for PC software)	r Selection	Address: 005AH 005BH
	Operatior Interface	nal Panel / Software :	Communication	Related Section: 4.3.5
	Default	: 0x0		
	Cont Mode	ΛΙΙ		
	Unit	: -		
	Range	: 0~127		
	Data Size	: 16-bit		
	Format	: Decimal		

P0-46★	svsts s	ervo Digital Output \$	Address: 005CH 005DH	
	Operational Interface	Donal / Cottwore	Communication	Related Section: -
	Default	: 0		
	Contro Mode	ΛΙΙ		
	Unit	: -		
	Range	0x00 ~ 0xFF		
	Data Size	: 16-bit		
	Format	Hexadecimal		
	Settings	Bit 0: SRDY (Servo Bit 1: SON (Servo 0		

Bit 2: ZSPD (Zero speed detection)
Bit 3: TSPD (Target speed reached)
Bit 4: TPOS (Target position reached)

Bit 5: TQL (Torque limiting)
Bit 6: ALRM (Servo alarm)

Settings: Same as parameter P0-17

Bit 7: BRKR (Brake control output)

Bit 8: HOME (Homing finished)

Bit 9: OLW (Early warning for overload)

Bit 10: WARN (When Servo warning, CW, CCW, EMGS, under

voltage, Communication error, etc., occurs, DO is ON)


Bit 11 ~ Bit 15: Reserved

8-34 Revision February, 2017

P0-49**■**

Address: 0062H **UAP Renew Encoder Absolute Position** 0063H Related Section: N/A Operational: :Panel / Software :Communication Interface: Default: 0x0 Control Mode: Unit: N/A Range : $0x00 \sim 0x02$ Data Size: 16-bit Format: Hexadecimaladecimal

Settings: This parameter is used to renew the absolute position data of the encoder.



Parameter Renew Setting:

- 1: Renew the encoder data to parameters P0-50~P0-52 only.
- 2: Renew the parameters P0-50~P0-52, and clear the position error as well. While this setting is activated, the current position of the motor will be reset as the target position of position command (same function as CCLR).

APSTS A	bsolute Coordinate System Status		Address: 0064H 0065H
Operation Interface	Danal / Caffurana	Communication	Related Section: N/A
Default	: 0x0		:
Conti Mode	rol . ALL		
Unit	: N/A		
Range	: 0x00 ~ 0x1F		
Data Size	: 16-bit		;
Format	: Hexadecimal		
Settings	:		

Revision February, 2017 8-35

Bit 13

Bit 5

Bit 4

Bit 12

Bit 3

Bit 11

Bit 2

Bit 10

Bit 1

Bit 9

Bit 0

Bit 8

Bit 7

Bit 15

Bit 6

Bit 14

Bit 0: Absolute position status

0: Normal

1: Absolute position is lost

Bit 1: Voltage level of battery

0: Normal

1: Low battery

Bit 2: Status of encoder multiturn

0: Normal

1: Overflow

Bit 3: Status of PUU

0: Normal

1: Overflow

Bit 4: Absolute coordinate system status

0: Normal

1: Absolute coordinate system has not been set

Bit 5 ~ Bit 15: Reserved. Must be set to 0.

P0-51★	APR	Encoder Absolute Pos	ncoder Absolute Position (Multiturn)	
: : : : :	Operatio Interface	Danal / Caffurara	Communication	Related Section: N/A
	Defaul	lt: 0x0		
	Con Mode	:ΔI I		
	Uni	it: rev	rev	
; ; ;	Range	e : -32768 ~ +32767		
	Data Size	e : 32-bit		
	Forma	it : Decimal		

Settings: While the Bit 1 of P2-70 is set to 1 to read the encoder pulse number, this parameter represents the turns of encoder absolute position. While the Bit 1 of P2-70 is set to 0 to read the PUU number, this parameter becomes disabled and the setting value of this parameter is 0.

8-36 Revision February, 2017

P0-527


	ncoder Absolute Posi ulse number within S	Address: 0068H 0069H	
Operationa Interface :	l Panel / Software	Communication	Related Section: N/A
Default:	Default: 0x0		
Contro Mode :	Control Mode :		
Unit:	Pulse or PUU		
Range :	ange : 0~1280000-1 (Pulse Number); -2147483648 ~ 2147483647 (PUU)		† : : : : : : : : : : : : : : : : : : :
Data Size : 32-bit			
Format : Decimal			

Settings: While the Bit 1 of P2-70 is set to 1 to read the pulse number, this parameter represents the pulse number of encoder absolute position. While the Bit 1 of P2-70 is set to 0 to read the PUU number, this parameter represents PUU number of motor absolute position.

P0-53

ZDRT	General Range Compa Filtering Time	Address: 006AH 006BH	
Operation Interfac	Donal / Coffware	Communication	Related Section: N/A
Defau	It: 0x0000		7 7 7
Con Mod	trol ALL e:		
Un	it : ms	ms	
Rang	e: 0x0000 ~ 0x000F		
Data Siz	e : 16-bit		
Forma	t : Hexadecimal		7 : : :
Settings			•

Seungs .



X: Filtering time for 1st monitoring variable


UYZ: Reserved

While the value of the monitoring variable is changed within the range between the setting values of P0-54 and P0-55, this parameter is used

8-37 Revision February, 2017

to set the filter timing for the monitoring variable. The value of monitoring variable will output after the filtering time determined by parameter P0-53.

For example: when P0-09 is used



P0-54	/ () N/ 1	eneral Range Compar ower Limit of 1st Mon	3	Address: 006CH 006DH
	Operational Interface:	Danal / Coffwara	Communication	Related Section: N/A
	Default :	0		
	Contro Mode :	ALL		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		1 1 1 1
	Data Size :	32-bit		
	Format :	Decimal		•

Settings: The value of parameter P0-09 will change within the range between P0-54 and P0-55 and then output after the filtering time determined by parameter P0-53.

P0-55		neral Range Compa per Limit of 1st Moi	Address: 006EH 006FH	
	Operational Interface:	Panel / Software	Communication	Related Section: N/A
	Default :	0		
	Control Mode :	ALL		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		

8-38 Revision February, 2017

Format : Decimal

Settings: The value of parameter P0-09 will change within the range between P0-

54 and P0-55 and then output after the filtering time determined by

parameter P0-53.

P0-56 ~ P0-62

Reserved

P0-63

VGT The Time when Voltage Exceeding 400V			Address: 007EH 007FH
Operational Interface :	Panel / Software	Communication	Related Section: N/A
Default :	0x0		
Control Mode :	ALL		
Unit :	ms		
Range : 0x00000000 ~ 0x7FFFFFF			
Data Size :	32-bit		
Format :	Decimal		

Settings : Record the accumulative time when the drive's voltage exceeding 400V.


8-39 Revision February, 2017

P1-xx Basic Parameters

Ρĺ	-0	O	\mathbf{A}

PTT	The	e Type of External P	Address: 0100H 0101H	
Operation Interfac		Panel / Software	Communication	Related Section: 6.2.1
Defau	lt :	0x2		
Con Mod		PT		
Un	it:	-		
Rang	e :	0 ~ 0x1132		
Data Siz	e :	16-bit		
Forma	at:	Hexadecimal		

Settings:



- Pulse Type
 - 0: AB phase pulse (4x)
 - 1: Clockwise (CW) and Counterclockwise (CCW) pulse
 - 2: Pulse + symbol

Other setting: reserved


• Filter Width

If the received frequency is much higher than the setting, it will be regarded as the noise and filtered out.

Setting Value	Min. pulse width*note1 (Low-speed filter frequency)	Setting Value	Min. pulse width*note1 (High-speed filter frequency)
0	600ns (0.83Mpps)	0	150ns (3.33Mpps)
1	2.4us (208Kpps)	1	600ns (0.83Mpps)
2	4.8us (104Kpps)	2	1.2us (416Kpps)
3	9.6us (52Kpps)	3	2.4us (208Kpps)
4	No filter function	4	No filter function

8-40 Revision February, 2017

Note: When the source of external pulse is from the high-speed differential signal and the setting value is 0 (the high-speed filter frequency is 3.33Mpps at the moment), then:




When High, Low duty of the pulse width are longer than 150 ns, it can ensure the pulse command will not be filtered.


If the user uses 2~4 MHz input pulse, it is suggested to set the filter value to 4. Please note that the applicable version is: DSP version 1.036 sub05 and CPLD version above 10.

Note: When the signal is the high-speed pulse specification of 4 Mpps and the settings value of the filter is 4, then pulse will not be filtered.

Logic Type


			High-speed and Low-speed pulse input					
Lo	Logic Pulse Type		Forward	Reverse				
			A Pulse Phase Lead	A Pulse Phase Lag				
0	Log	AB phase pulse	(38) Pulse (29) (46) Sign (40)	(38) Pulse (29) (46) Sign (40) T1 T1 T1 T1 T1 T1				
	Positive	CW and CCW pulse	(38) Pulse (29) (46) Sign (40)	T3 T2 T2 T2 T2 T2 T2 T7 T7 T7 T7 T7 T7 T7 T7 T7 T7 T7 T7 T7				





For digital circuit, it uses 0 and 1 represents two status, which is high voltage and low voltage. In Positive Logic, 1 represents high voltage and 0 represents low voltage and vice versa in Negative Logic.

For example:



Pulse Specification		Max. Input	Minimum time width					
		Frequency	T1	T2	T3	T4	T5	T6
High-speed pulse	Differential Signal	4Mpps	62.5ns	125ns	250ns	200ns	125ns	125ns
Low-speed pulse	Differential Signal	500Kpps	0.5µs	1µs	2µs	2µs	1µs	1µs
	Open- collector	200Kpps	1.25µs	2.5µs	5µs	5µs	2.5µs	2.5µs

Pulse Specification		Max. Input Frequency	Voltage Specification	Forward Current
High-speed pulse	Differential Signal	4Mpps	5V	< 25mA
Low-speed pulse	Differential Signal	500Kpps	2.8V ~ 3.7V	< 25mA
	Open-collector	200Kpps	24V (Max.)	< 25mA

8-42 Revision February, 2017

• The Source of External Pulse:


0: Low-speed optical coupler (CN1 Pin: PULSE, SIGN)

1: High-speed differential (CN1 Pin: HPULSE, HSIGN)

P1-01•

	CTL	_	out Setting of Control I mmand	Address : 0102H 0103H	
	Operatio Interface		Panel / Software	Communication	Related Section: Section 6.1
-	Defau	lt:	0	Table 8.1	
	Con Mode		ALL		
	Uni	it:	P (pulse); S (r/min, m/s		
	Range	e :	00 ~ 0x110F		
	Data Size	e :	16-bit		
	Forma	ıt :	Hexadecimal		

not in use



Control Mode Settings


Mode	PT	PR	S	Т	Sz	Tz	
	Single Mode						
00	A						
01		A					
02			A				
03				A			
04					A		
05						A	
		Dual	Mode)			
06	A		A				
07	A			A			
08		A	A				
09		A		A			
0A			A	A			
0B	C	ANope [en Mo Delta's			ith	
		DI	MCNE	Т Мо	de		
00		CA	Nop€	en Mo	de		
0C	EtherCAT Mode						
0D	A	A					
	Multiple Mode						
0E	A	A	A				
0F	A	A		A	0F		

Dual Mode: It can switch mode via the external Digital Input (DI). For example, if it is set to the dual mode of PT/S (Control mode setting: 06), the mode can be switched via DI. S-P (Please refer to table 8.1).

Multiple Mode: It can switch mode via the external Digital Input (DI). For example, if it is set to multiple mode of PT/PR/S (Control Mode Setting: 12), the mode can be switched via DI. S-P, PT-PR (Please refer to table 8.1).

8-44 Revision February, 2017

Torque Output Direction Settings




- Digital Input / Digital Output (DIO) Setting
 - 0: When switching mode, DIO (P2-10 ~ P2-22) remains the original setting value and will not be changed.
 - 1: When switching mode, DIO (P2-10 ~ P2-22) can be reset to the default value of each operational mode automatically.

P1-02▲

PSTL	Speed and Torque Lir	eed and Torque Limit Setting			
Operation Interfac	Donal / Cottinore	Communication	Related Section: Section 6.6 Table 8.1		
Defau	lt : 0	0			
Con Mod	: Λ I I				
Un	it : -	-			
Rang	e: 00 ~ 0x11				
Data Siz	e : 16-bit				
Forma	at : Hexadecimal				
Setting	c · []		•		


Settings:



- Disable / enable speed limit function
 - 0: Disable speed limit function
 - 1: Enable speed limit function (it is effective in T / Tz mode only)

Other: Reserved


Block diagram of speed limit setting:



- Disable / enable torque limit function
 - 0: Disable torque limit function
 - 1: Enable torque limit function (it is effective in P / S / Sz mode)

Other: Reserved

Block diagram of torque limit setting:




When desiring to use torque limit function, users could use parameter to set this value to 1 and limit the torque for good. Thus, the user can save one DI setting. Also, users could enable or disable the limit function via DI.TRQLM, which is a more flexible way but would need to take one DI setting. Torque limit can be enabled by P1-02 or DI.

DI.TCM0 and DI.TCM1 are for selecting the limiting source.

P1-03	AOUT Po	olarity Setting of End	Address: 0106H 0107H	
	Operational Interface:	al Panel / Software	Communication	Related Section: 3.3.3
	Default :	ALL		
	Contro Mode :			
	Unit :			
	Range :			
	Data Size :	16-bit		
	Format :	Hexadecimal		

8-46 Revision February, 2017



Polarity of monitor analog output

0: MON1(+), MON2(+)	2: MON1(-), MON2(+)
1: MON1(+), MON2(-)	3: MON1(-), MON2(-)

Polarity of encoder pulse output

0: Forward output 1	1: Reverse output
---------------------	-------------------

P1-04	MON1 MC	ON1 Analog Monitor	Address: 0108H 0109H	
	Operational Interface :	Panel / Software	Communication	Related Section: 6.4.4
	Default :	ALL % (full scale) 0 ~ 100		
	Control Mode :			
	Unit :			
	Range :			
	Data Size :			
	Format :	Decimal		

Settings: Please refer to parameter P0-03 for the setting of analog output selection.

For example:

P0-03 = 0x00 (MON1 is the speed analog output)

When the output voltage value of MON1 is V1: Motor speed = (Max. speed ×V1/8)×P1-04/100

P1-05	MON2	MON2 Analog Monito	Address: 0108H 0109H	
	Operational Panel / Software Communication		Related Section:	
	Interfac		Communication	6.4.4
	:	Default: 100		
	Con Mod	itrol e:		

Unit: % (full scale)

Range: 0 ~ 100

Data Size: 16-bit

Format: Decimal

Settings: Please refer to parameter P0-03 for the setting of analog output

selection.

Settings: 0: Disabled

Settings: 0: Disabled

For example: P0-03 = 0x00 (MON2 is the speed analog output)

When the output voltage value of MON2 is V2: Motor speed = (Max. ×

V2/8) ×P1-05/100

P1-06	SFLT An	alog Speed Comma	nd (Low-pass Filter)	Address: 010CH 010DH
	Operational Interface :	Panel / Software	Communication	Related Section: 6.3.3
	Default :	0		
	Control Mode :	S		
	Unit:	ms 0 ~ 1000 (0: disable this function)		
	Range :			
	Data Size :	16-bit		
	Format :	Decimal		

P1-07	TFLT	analog Torque Comma	alog Torque Command (Low-pass Filter)		
	Operation Interface		Communication	Related Section: 6.4.3	
	Default	0			
	Contr Mode	Т			
	Unit	: ms			
	Range	: 0 ~ 1000 (0: disable the	0 ~ 1000 (0: disable this function)		
	Data Size	16-bit			
	Format	: Decimal			

8-48 Revision February, 2017

Smooth Constant of Position Command (Low-Address: 0110H P1-08 PFLT pass Filter) Related Section: Operational Interface : Panel / Software Communication 6.2.6 Default: 0 Control Mode: PT / PR Unit: 10 ms Range : 0 ~ 1000 Data Size: 16-bit Format : Decimal

Settings: 0: Disabled

Example : 11 = 110 ms

P1-09	OF I	nternal Speed Comm _imit 1	ernal Speed Command 1 / Internal Speed		
	Operatior Interface	:Danal / Caftwara	Communication	Related Section: 6.3.1	
	Default	: 1000	1000		
	Cont Mode	C / T	S/T		
	Unit	: 0.1rpm			
	Range	: -60000 ~ +60000			
	Data Size	: 32-bit			
	Format	: Decimal			
	Example: Internal speed command: 120 = 12 r/min Internal Speed Limit: Positive value is the same. Please respective the following description.		mit: Positive value an he same. Please refer to		

Settings: Internal Speed Command 1: The setting of the first internal speed command

Internal Speed Limit 1: The setting of the first internal speed limit Example of inputting internal speed limit:

Speed limit setting value of P1-09	Allowable Speed Range	Forward Speed Limit	Reverse Speed Limit
1000	-100 ~ 100	100 r/min	-100 r/min
-1000	r/min		100 ////

SF2	ternal Speed Command 2 mit 2	2 / Internal Speed	Address: 0114H 0115H
Operational Interface:	l Panel / Software C	ommunication	Related Section: 6.3.1
Default :	2000		
Contro Mode :	S/T		
Unit :	0.1rpm	0.1rpm	
Range :	-60000 ~ +60000 32-bit Decimal		
Data Size :			
Format :			
Example :	Internal speed command 120 = 12 r/min Internal Speed limit: negative value is the sa	Positive value an	

Settings: Internal Speed Command 2: The setting of the 2nd internal speed command

the following description.

Internal Speed Limit 2: The setting of the second internal speed limit Example of inputting internal speed limit:

Speed limit setting value of P1-10	Allowable Speed Range	Forward Speed Limit	Reverse Speed Limit
1000	-100 ~ 100 r/min	100 r/min	-100 r/min
-1000	100 100 17111111	100 1/111111	-100 1/111111

8-50 Revision February, 2017

SDA-A2				Chapter 8 Parameters
P1-11	SPS	nternal Speed Comm	and 3 / Internal Speed	Address: 0116H 0117H
	Operation Interface	Danal / Software	Communication	Related Section: 6.3.1
	Default	: 3000		
	Conti Mode	rol : S / T	S/T	
	Unit	0.1rpm		
	Range	-60000 ~ +60000		
	Data Size	: 32-bit		
	Format	: Decimal		
	Example	: Internal Speed Com 120 = 12 r/min Internal Speed lir	mand: nit: Positive value and	d

negative value is the same. Please refer to

Settings: Internal Speed Command 3: The setting of the third internal speed

command

the following description.

Internal Speed Limit 3: The setting of the third internal speed limit Example of inputting internal speed limit:

Speed limit setting of P1-11	Allowable Speed Range	Forward Speed Limit	Reverse Speed Limit
1000	-100 ~ 100 r/min	100 r/min	-100 r/min
-1000	100 100 1/11	100 1/111111	100 1/111111

P1-12	ועו	Internal Torque Command 1 / Internal Torque Limit 1		Address: 0118H 0119H
	Operation Interface		Communication	Related Section: 6.4.1
	Default	t : 100		
	Cont Mode	rol T / P, S	T / P, S	
	Unit	t: %		
	Range	e : -300 ~ +300		
	Data Size	e : 16-bit		
	Format	t : Decimal		

> Internal Torque Command: 30 = 30 % Example: Internal Torque Limit: Positive value and negative value is the same. Please refer to the following description.

Settings:

Internal Torque Command 1: The setting of the first internal torque

command

Internal Torque Limit 1: The setting of the first internal torque limit

Example of inputting internal torque limit:

Torque limit setting value of P1-12	Allowable Torque Range	Forward Torque Limit	Reverse Torque Limit
30	-30 ~ 30 %	30 %	-30 %
-30	00 00 70	00 /0	00 /0

I QZ	Internal Torque Commar Limit 2	ernal Torque Command 2 / Internal Torque nit 2		
Operatio Interface	Danal / Coffware	Communication	Related Section: 6.4.1	
Defaul	t : 100			
Con Mode	ontrol ode:			
Uni	t: %	: %		
Range	e : -300 ~ +300			
Data Size	e : 16-bit			
Forma	at : Decimal			
Example	Internal Torque Command: 30 = 30 % Internal Torque Limit: Positive value and negative value is the same. Please refer to the following description.			

Settings: Internal Torque Command 2: The setting of the second internal torque command

> Internal Torque Limit 2: The setting of the second internal torque limit Example of inputting internal torque limit:

Torque limit setting value of P1-13	Allowable Torque Range	Forward Torque Limit	Reverse Torque Limit
30	-30 ~ 30 %	30 %	-30 %
-30	00 00 /0	00 //	00 /0

8-52 Revision February, 2017

I-14	I Q3	nternal Torque Command 3 / Internal Torqu Limit 3	ue Address: 011CH 011DH
	Operation Interface	Danal / Cafferiana Cananarinal adian	Related Section: 6.4.1
	Defaul	t : 100	
	Cont Mode	rol T / P, S	
	Uni	t: %	
	Range	e : -300 ~ +300	
	Data Size	e : 16-bit	
	Forma	: Decimal	
	Example	Internal Torque Command: 30 = 30 % Internal Torque Limit: Positive value a negative value is the same. Please refer	

Settings: Internal Torque Command 3: The setting of the third internal torque

command


the following description.

Internal Torque Limit 3: The setting of the third internal torque limit Example of inputting internal torque limit:

Torque limit setting value of P1-14	Allowable Torque Range	Forward Torque Limit	Reverse Torque Limit
30	-30 ~ 30 %	30 %	-30 %
-30	00 00 70	00 /0	00 70

P1-15	CALI	Capture Synchronous Correction	pture Synchronous Axis – Threshold of rrection	
	Operation Interface	nal Panel / Software e :	Communication	Related Section:
	Defaul	t: 0000h		
	Cont Mode	ΔΙΙ		
	Uni	t : -		
	Range	e: 0000h ~ 0x1F5F		
	Data Size	e: 16-bit		
	Forma	t : Hexadecimal		

Settings:



YX: Threshold of correction (%)

Z: Filter intensity

U: Filter is functioning (read-only)

(It will be provided after the version of V1.0.38 sub15)

YX: When synchronous axis captures the signal, the system will calculate the error. This function is enabled only when the error is less than the setting range. Otherwise, the system will use the new threshold of correction to perform the operation.

YX	00	01~05F
Function	Disabled	It will be enabled when error is between 1% and YX%.

Z	0	1~F
Function	Disabled	Average of 2^Z: Enabled

- Z: The setting of filter intensity (Bigger value brings less severe change and better filter effect)
- U: Value Definition (read-only):
- 0: Filter function is disabled. It means the error is greater than Y & X Range.
- 1: Filter function is enabled. It means the error is within Y & X range. If value Z or YX is 0, filter function is disabled.

P1-16

CSOF

Capture Synchronous Axis – Offset Compensation

Operational Interface : Panel / Software Communication

Default : 0

Control Mode : PR

Unit : Pulse unit of Capture Axis

8-54 Revision February, 2017

Range: -32768 ~ +32767

> Data Size: 16-bit Format: Decimal

Settings: When capture synchronous axis is enabled, if desire to change the synchronous error (P5-79), setting this parameter will do.

Write P1-16: P5-79 = P5-79 + writing value

Read P1-16: Read value = P5-79

NOTE 1) The setting value of this parameter is the accumulative value, which will not be influenced by current error value.

2) The value of P5-79 can be monitored by monitoring variable 0x54.

P1-17

	mpensation of Follow ne Setting	ing Error - Additional	Address: 0122H 0123H
Operational Interface :	Panel / Software	Communication	Related Section:
Default :	0		
	Control Mode :		
Unit:	it:Ms; the smallest unit is usec		
Range :	Range: -20.000 ~ +20.000 (three decimal point)		
Data Size :	Data Size: 16-bit		
Format :	Format : Decimal		
Example :	Example: 1.5 = Motor speed x 1.5 ms (PUU)		

Settings:

When this function is enabled (P1-36 = 1), the system will make the position error (PUU) close to 0 according to the compensation amount of command. If the time delay is caused by other reasons, users could setup the additional compensation time to compensate the position error.

Additional compensation distance = P1-17 x Motor speed

NOTE 1) Value of P1-36 has to set to 1.

8-55 Revision February, 2017

P1-18

СРСТ	•	ectronic Cam (E-Cam) Pulse Phase empensation – Time Setting	
Operation Interfac	nal Panel /Software e:	Panel /Software Communication	
Defau	It : 0	0	
Con Mod	·DD	DD	
Un	it: ms with fraction dov	ms with fraction down to usec	
Rang	e: -20.000 ~ +20.000 (-20.000 ~ +20.000 (Three decimal point)	
Data Siz	16-bit		
Forma	ormat : Decimal		

Settings: (This function is available in firmware version V1.038 sub48 and later models only)

This parameter is used to compensate the delay pulse phase when the electronic cam function is enabled during operation. Please use this parameter with P1-21.

Compensated Pulse Phase (pls) = P1-18 x (Pulse Frequency of E-Cam Master Axis (Kpps) - P1-21)

Please note:


- 1. The setting value of this parameter is proportioned to the value of the pulse frequency of E-Cam master axis.
- 2. The pulse phase compensation function is enabled only when the setting value of parameter P1-18 is not equal to 0.
- 3. The pulse phase compensation function is enabled only when the value of the pulse frequency of E-Cam master axis (monitoring variable is 060) Pulse number of E-Cam master axis (Incremental)) is higher than the setting value of parameter P1-21.

CAPTURE / COMPARE – Additional Function | Address: 0126H **CPEX** P1-19 Settings 0127H Operational: Related Section: N/A Communication Panel/Software Interface: Default: 0 Control ALLMode: Unit: N/A Range: :0x0000 ~ 0x0101 Data Size: 16-bit

8-56 Revision February, 2017

Format : Hexadecimal

Settings:



X: Bit settings of Capture additional function settings:

-		-		_
Bit	3	2	1	0
Function	-	-	-	Repeating Mode
Explanation	-	-	-	Enable the repeating mode. After the last position is captured, the system will automatically repeat this CAPTURE function. The captured data is still stored in the data array that the starting address is specified by P5-36! (This function is available in firmware version V1.038 sub19 and later models only)

Y: Reserved

Z: Bit settings of Compare additional function settings:

_				
Bit	3	2	1	0
Function	-	-	- Automatically set P1-24 to 0.	
Explanation	-	-	-	When Bit0 is set to 1, P1-24 will only be effective once and reset to 0 automatically! Otherwise, the value of P1-24 will remain unchanged.
				(This function is available in firmware version V1.038 sub19 and later models only)

U: Reserved

P1-20	СРМК СА	PTURE – Masking	Range Setting	Address: 0128H 0129H
	Operational Interface :	Panel/Software	Communication	Related Section: N/A
	Default :	0		
	Control Mode :	ALL		
	Unit :	The Pulse Unit of (Capture Axis	
	Range :	0 ~ +100000000		
	Data Size :	32-bit		

Format : Decimal

Settings: When multiple points are required to be captured, after each point is captured, the masking range can be set in this parameter. In the masking area, the CAPTURE function will not work. The masking range

is defined as follows:

(CAP_DATA-P1-20 , CAP_DATA+P1-20)

Please note:

When the setting value of this parameter is set to 0, the masking function is disabled.

P1-21

	Cam Pulse Phase Cequency Setting of	Address: 012AH 012BH	
Operationa Interface :	Panel/Software	Communication	Related Section: N/A
Default:	0		
Contro Mode:	PR		7
Unit:	Kpps (Kpulse/sec)		
Range :	-32768 ~ +32767		
Data Size :	16-bit		
Format :	Decimal		

Settings: (This function is available in firmware version V1.038 sub48 and later models only)

This parameter is used to compensate the delay pulse phase when the electronic cam function is enabled during operation. Please use this parameter with P1-18.

Compensated Pulse Phase (pls) = P1-18 x (Pulse Frequency of E-Cam Master Axis (Kpps) - P1-21)

Please note:

- 1. The setting value of this parameter is proportioned to the value of the pulse frequency of E-Cam master axis.
- 2. The pulse phase compensation function is enabled only when the setting value of parameter P1-18 is not equal to 0.
- 3. The pulse phase compensation function is enabled only when the value of the pulse frequency of E-Cam master axis (monitoring variable is 060) Pulse number of E-Cam master axis (Incremental)) is higher than the setting value of parameter P1-21.

8-58 Revision February, 2017

SPF1	PR	Special Filter Setti	Address: 012CH 012DH	
Operation Interfac		Panel/Software	Communication	Related Section: N/A
Defau	lt:	000h		
Con Mod		PR		
Un	it:	N/A		
Rang	e :	0000h ~ 0x107F		
Da Size		16-bit format = UZY	X	
Forma	at:	Hexadecimal		

Settings: YX: Acceleration time limit (0: Disabled, [1~127] x 10ms), Units: 10ms

Z: Reserved


U: Reverse inhibit (0: Disabled; 1: Enabled)

YX: The acceleration time limit is 0 ~ 1270 ms. When the changes of PR (or E-Cam) commands are too fast, it will cause the vibration of the mechanical system and affect the system performance. This function can be used to control the acceleration (deceleration) speed without exceeding the limit and can smooth the operation, reduce the noise and extend the system life.

This function is different from the general filter. The traditional one filter the command regardless the command change. This causes the delay of command delivered and reduces the efficiency of the system. This function can help to disable the filter function when the command changes within the limit. Then, the commands can be delivered without any time delay. The definition of this setting is the required acceleration time when the motor runs from 0 to 3000 r/min. The required time is longer, the effect of the filter function is better and the acceleration / deceleration will become smoother.

Please note:

The unit of acceleration time limit is 10ms. For example, if YX=12h, the acceleration time limit is 180ms. It means the filter function is enabled when the acceleration or deceleration time is faster than 180ms. Otherwise, the command will remain unchanged.




Note: When this filter function is enabled, it may cause the motor goes beyond the original position. Usually, the motor will return to the original position after the command becomes stable. However, if the command does not become stable, the internal position errors may be accumulated and result in AL.404.

Note: The filter time has to be set properly. It should be shorter than the acceleration time and longer than the abnormal command.

Note: The function of U item can be used to avoid the reverse operation.

U: Reverse Inhibit Function (0: Disable the function; 1: enable the function) When this reverse inhibit function is enabled, the reverse command will be inhibited. The reverse command will be reserved and output after the received forward command exceeds the reserved reverse command.



8-60 Revision February, 2017

Address: 012EH COMPARE - Offset Data of CMP (non-volatile) **CMOF** 012FH Operational Related Section: Panel / Software Communication Interface: Default: 0 Control ALL Mode: Unit: Pulse unit of compare source Range : -10000000 ~ +10000000 Data Size: 32-bit Format: Decimal

Settings: The real compared data is offset by this value.

 $CMP_DATA = DATA_ARRAY[*] + P1-23 + P1-24$

NOTE 1) P1-23: Non-volatile parameter

P1-23

- 2) P1-24: After setting, if P1-19.Z0 = 1, the value will be 0 automatically.
- 3) CMP_DATA can be monitored via monitoring variable 0x25.

P1-24∎		COMPARE - Offset Data 0 automatically)	of CMP (can reset to	Address: 0130H 0131H
	Operation Interface	Donal / Catturara	Communication	Related Section:
	Defaul	t : 0		
	Cont Mode	ΔΙΙ		
	Uni	t:Pulse unit of compare s	source	
	Range	e : -32768 ~ +32767		
	Data Size	e : 16-bit		
	Forma	t : Decimal		

Settings: The real compared data is offset by this value.

CMP DATA = DATA ARRAY[*] + P1-23 + P1-24

NOTE 1) P1-24: volatile parameter.

2) After setting, if P1-19.Z0 = 1, the value will be 0 automatically.

Address: 0132H P1-25 VSF1 Low-frequency Vibration Suppression (1) 0133H Related Section: Operational Panel / Software Communication 6.2.9 Interface: Default: 1000 Control PT / PR Mode: Unit: 0.1 Hz Range: 10 ~ 1000 Data Size: 16-bit Format: Decimal

Settings: The setting value of the first low-frequency vibration suppression. If P1-

26 is set to 0, then it will disable the first low-frequency filter.

P1-26	VSG1 Lo	w-frequency Vibratio	on Suppression Gain	Address: 0134H 0135H
	Operational Interface :	Panel / Software	Communication	Related Section: 6.2.9
	Default :	0		
	Control Mode :	PT / PR		
	Unit :	-		
	Range :	0 ~ 9 (0: Disable the fi	rst low-frequency filter)	
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The first low-frequency vibration suppression gain. The bigger value it is, the better the position response will be. However, if the value is set too big, the motor will not be able to smoothly operate. It is suggested

to set the value to 1.

Example: 150= 15 Hz

8-62 Revision February, 2017

SDA-AZ				Chapter o Farameters			
P1-27	VSF2 L	.ow-frequency Vibrati	ow-frequency Vibration Suppression (2)				
	Operation Interface		Communication	Related Section: 6.2.9			
	Default	: 1000					
	Contr Mode	DT / DD					
	Unit	: 0.1 Hz					
	Range	: 10 ~ 1000					
	Data Size	: 16-bit					

Settings: The setting value of the second low-frequency vibration suppression. If P1-28 is set to 0, then it will disable the second low-frequency filter.

P1-28	VSG2	_ow-frequency Vibra	tion Suppression Gain (2)	Address: 0138H 0139H	
	Operation Interface	al Panel / Software	Communication	Related Section: 6.2.9	
	Default	: 0			
	Contr Mode	DT / DD	PT / PR		
	Unit	: -			
	Range	: 0 ~ 9 (0: Disable the filter)	e second low-frequency		
	Data Size	: 16-bit			
	Format	: Decimal			

Settings: The second low-frequency vibration suppression gain. The bigger value it is, the better the position response will be. However, if the value is set

too big, the motor will not be able to smoothly operate. It is suggested to

set the value to 1.

Format : Decimal

Example : 150 = 15 Hz

P1-29

AVSIVI	uto Low-frequency Viketting	Address: 013AH 013BH		
Operationa Interface :	Panel / Software Communication		Related Section: 6.2.9	
Default:	0	0		
Contro Mode :	I PT / PR			
Unit:	-	-		
Range :	0 ~ 1	0 ~ 1		
Data Size :	16-bit			
Format :	DEC			

Settings: 0: The function is disabled.

1: The value will set back to 0 after vibration suppression.

Description of Auto Mode Setting:

When the parameter is set to 1, it is in auto suppression. When the vibration frequency is not being detected or the value of searched frequency is stable, the parameter will set to 0 and save the lowfrequency vibration suppression to P1-25 automatically.

P1-30

VCL	Low-frequency Vibrat	ion Detection	Address: 013CH 013DH
Operation Interface		Communication	Related Section: 6.2.9
Default	: 500		
Cont Mode	DT / DD		
Unit	: Pulse		
Range	: 1 ~ 8000		
Data Size	: 16-bit		
Format	: Decimal		
	\A/I= I= I: 4I= -	outo oupprossion (D1 20 -	**

Settings: When enabling the auto suppression (P1-29 = 1), it will automatically search the detection level. The lower the value is, the more sensitive the detection will be. However, it is easy to misjudge the noise or regard the other low-frequency vibration as the suppression frequency. If the value is bigger, it will make more precise judgment. However, if the vibration of the mechanism is smaller, it might not detect the frequency of low-frequency vibration.

8-64 Revision February, 2017

P1-31 Reserved

Address: 0140H P1-32 **LSTP Motor Stop Mode** 0141H Related Section: -Operational Panel / Software Communication Interface: Default: 0 Control Mode: Unit: -Range: $0 \sim 0x20$ Data Size: 16-bit Format: Hexadecimal Settings: Not in use

Selection of executing dynamic brake: Stop Mode when Servo Off or Alarm (including EMGS) occurs.

Selection of executing dynamic brake

Not in use

- 0: Execute dynamic brake
- 1: Motor free run
- 2: Execute dynamic brake first, then execute free run until it stops (The motor speed is slower than P1-38).

When PL and NL occur, please refer to event time setting value of P5-03 for determining the deceleration time. If the setting is 1 ms, it can stop instantaneously.

P1-33 Reserved

P1-34	TACC	Acceleration Constan	celeration Constant of S-Curve		
		nal Panel / Software e :	Communication	Related Section: 6.3.3	
	Defaul	t : 200			
	Con Mode	trol s			
	Uni	it : ms			

Range :	1 ~ 65500
Data Size :	16-bit
Format :	Decimal

Settings: Acceleration Constant of Rotary Motor:

The time that speed command accelerates from 0 to the rated speed.

Acceleration Constant of Linear Motor

The time that speed command accelerates from 0 to 5m/s.

P1-34, P1-35 and P1-36, the acceleration time of speed command from zero to the rated speed, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.



- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-34 will be set within 20000 automatically.

DИ	26
ГΙ	200

TDEC De	celeration Constant of	S-Curve	Address: 0146H 0147H
Operational Interface :	Panel / Software	Communication	Related Section: 6.3.3
Default :	200		
Control Mode :	S		
Unit :	ms		
Range :	1 ~ 65500		
Data Size :	16-bit		
Format :	nat : Decimal		

Settings: Deceleration Constant of Rotary Motor:

The time that speed command decelerates from the rated speed to 0.

Deceleration Constant of Linear Motor:

The time that speed command decelerates from 5m/s to 0.

P1-34, P1-35 and P1-36, the deceleration time of speed command from the rated speed to zero, all can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.




- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-35 will be set within 20000 automatically.

8-66 Revision February, 2017

P1-36

Address: 0148H Acceleration / Deceleration Constant of S-**TSL** Related Section: Operational Panel / Software Communication 6.3.3 Interface: Default: 0 Control S, PR Mode: Unit: ms Range: $0 \sim 65500$ (0: disable this function) Data Size: 16-bit Format: Decimal

Settings: Acceleration / Deceleration Constant of S-Curve:



0149H

- P1-34: Set the acceleration time of acceleration / deceleration of trapezoid-curve
- P1-35: Set the deceleration time of acceleration / deceleration of trapezoid-curve
- P1-36: Set the smoothing time of S-curve acceleration and deceleration
- P1-34, P1-35 and P1-36 can be set individually. Even when P1-36 is set to 0, it still has acceleration / deceleration of trapezoid-curve.

Version after V1.036 sub00 provides the compensation function of following error.

	P1-36 = 0	P1-36 = 1	P1-36 > 1
Smoothing function of S-curve	Disable	Disable	Enable
Compensation function of following error	Disable	Enable	Determine by P2-68.X



- NOTE 1) When the source of speed command is analog, and P1-36 is set to 0, it will disable S-curve function.
 - 2) When the source of speed command is analog, the max. range of P1-36 will be set within 10000 automatically.

8-67 Revision February, 2017

P1-37

	Ine Mo	tia Ratio and Load Weight Ratio to Servo Address: 014AH or 014BH			
Operatio Interface		Panel / Software	Communication	Related Section: -	
Defaul	lt:	1.0	10		
Con Mode		ALL			
Uni	it:	1times	0.1times		
Range	e :	0.0 ~ 200.0	0 ~ 2000		
Data Size	e :	16-bit			
Forma	t:	One decimal	DEC		
Example	e :	1.5 = 1.5 times	15 = 1.5 times		

Settings : Inertia ratio to servo motor (rotary motor):

(J_load / J_motor)

Among them:

J_motor: Rotor inertia of the servo motor

J_load: Total equivalent of inertia of external mechanical load.

Total weight of movable section and load (linear motor) (will be

available soon):
(M_load+M_motor)

Among them:

M_motor: the weight of servo motor

M_load: Total equivalent weight of mechanical loading

P1-38	ZSPD Zei	ro Speed Range Se	tting	Address: 014CH 014DH
	Operational Interface :	Panel / Software	Communication	Related Section: Table 8.2
	Default :	10.0	100	
	Control Mode :	ALL		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.0 ~ 200.0	0 ~ 2000	
	Data Size :	16-bit		
	Format :	One decimal	DEC	
	Example :	1.5 = 1.5 r/min	15 = 1.5 r/min	

8-68 Revision February, 2017

Settings: Setting the output range of zero-speed signal (ZSPD). When the forward / reverse speed of the motor is slower than the setting value, the digital output will be enabled.

P1-39	SSPD	Farget Motor Detection	on Level	Address: 014EH 014FH
	Operation Interface	Danal / Caffurara	Communication	Related Section: Table 8.2
	Default	: 3000		
	Cont Mode	ΔΙΙ		
	Unit	: r/min		
	Range	: 0 ~ 5000		
	Data Size : 16-bit			
	Format	: Decimal		

Settings: When the target speed is reached, DO (TSPD) is enabled. It means when the motor speed in forward / reverse direction is higher than the

setting value, the target speed is reached and enables DO.

Ρſ	-40	Λ

VCM Ma	ximum Output of Ana	log Speed Command	Address: 0150H 0151H	
Operational Interface :	Panel / Software Communication		Related Section: 6.3.4	
Default :	Same as the rated spe	Same as the rated speed of each model		
Control Mode :	S/T			
Unit :	r/min			
Range :	0 ~ 5000			
Data Size :	16-bit			
Format :	Decimal			
<u> </u>	·····		•	

Settings: Maximum Speed of Analog Speed Command:

In speed mode, the analog speed command inputs the swing speed setting of the max. voltage (10V).

For example, if the setting is 3000, when the external voltage input is 10V, it means the speed control command is 3000r/min. If the external voltage input is 5V, then the speed control command is 1500r/min.

Speed control command = input voltage value x setting value / 10

In position or torque mode, analog speed limit inputs the swing speed limit setting of the max. voltage (10V).

Speed limit command = input voltage value x setting value / 10

P1-41 ▲	TCM Ma	ximum Output of A	nalog Torque Speed	Address: 0152H 0153H
	Operational Interface :	Panel / Software	Communication	Related Section: 6.4.4
	Default:	100		
	Control Mode :			
	Unit :	%		
	Range : 0 ~ 1000			
	Data Size :	16-bit		
	Format : Decimal			

Settings: Maximum Output of Analog Torque Speed:

In torque mode, the analog torque command inputs the torque setting of the max. voltage (10V). When the default setting is 100, if the external voltage inputs 10V, it means the torque control command is 100% rated torque. If the external voltage inputs 5V, then the torque control command is 50% rated torque.

Torque control command = input voltage value x setting value / 10 (%)

In speed, PT and PR mode, the analog torque limit inputs the torque limit setting of the max. voltage (10V).

Torque limit command = input voltage value x setting value / 10 (%)

P1-42	MBT1 En	able Delay Time of Brake		Address: 0154H 0155H
	Operationa Interface:	l Panel / Software	Communication	Related Section: 6.5.5
	Default:	0		
	Contro Mode :	ALL		
	Unit :	ms		
	Range :	0 ~ 1000		
	Data Size :	16-bit		
	Format :	Decimal		


8-70 Revision February, 2017

> Set the delay time from servo ON to activate the signal of mechanical Settings: brake (BRKR).

D1	1.43
1	-43

MBT2	Disable Delay Time of	sable Delay Time of Brake		
Operatio Interface		Panel / Software Communication		
Defau	lt : 0			
Con Mode	:Δ11			
Un	it : ms	ms		
Range	e : -1000 ~ 1000	-1000 ~ 1000		
Data Size: 16-bit				
Format : Decimal				
	0 1 1 1 1			

Settings: Set the delay time from servo OFF to switch off the signal of brake (BRKR).



- NOTE 1) If the delay time of P1-43 has not finished yet and the motor speed is slower than P1-38, the signal of brake (BRKR) will be disabled.
 - 2) If the delay time of P1-43 is up and the motor speed is higher than P1-38, the signal of brake (BRKR) will be disabled.
 - 3) When Servo OFF due to Alarm (except AL022) or emergency, the setting of P1-43 is equivalent to 0 if P1-43 is set to a negative value.

GR1	Gear Ratio (Numerato	ar Ratio (Numerator) (N1)	
Operatio Interface	nal Panel / Software e :	Communication	Related Section: 6.2.5
Defau	lt : 1		
Con Mode	trol e: PT / PR		
Uni	it : Pulse		
Range	e: 1 ~ (2 ²⁹ -1)		

8-71 Revision February, 2017

Data Size : 32-bit

Format : Decimal

Settings: Please refer to P2-60~P2-62 for the setting of multiple gear ratio (numerator).

(numerator

NOTE 1. In PT mode, the setting value can be changed when Servo ON.


2. In PR mode, the setting value can be changed when Servo OFF.

Address: 015AH P1-45 GR2 Gear Ratio (Denominator) (M) 015BH Operational Related Section: Panel / Software Communication Interface: 6.2.5 Default: 1 Control PT / PR Mode: Unit: Pulse Range: $1 \sim (2^{31}-1)$ Data Size: 32-bit Format: Decimal

Settings: If the setting is wrong, the servo motor will easily have sudden unintended acceleration.

Please follow the rules for setting:

The setting of pulse input:



Range of command pulse input: 1 / 50 < Nx / M < 25600

NOTE 1) The setting value cannot be changed when Servo ON neither in PT nor in PR mode.

P1-46▲		ulse Number of Enc	oder Output	Address: 015CH 015DH
	Operational Interface	al Panel / Software	Communication	Related Section: -
	Default	: 2500	2500	
Control Mode:		: ALL		
		: Pulse		

8-72 Revision February, 2017

Range :	20 ~ 320000	
Data Size :	32-bit	
Format :	Decimal	

Settings: The number of single-phase pulse output per revolution.



NOTE The following circumstances might exceed the max. allowable input pulse frequency and occurs AL018:

- 1. Abnormal encoder
- 2. The motor speed is faster than the setting of P1-76.

3.
$$\frac{Motor\ Speed}{60} \times P1 - 46 \times 4 > 19.8 \times 10^6$$

P1-47	SPOK Sp	eed Reached (DO:	SP_OK) Range	Address: 015EH 015FH
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	10	100	
	Control Mode :	S / Sz	S / Sz	
	Unit :	r/min	0.1 r/min	
	Range :		0 ~ 3000	

Settings: When the deviation between speed command and motor feedback speed is smaller than this parameter, then the digital output DO.SP_OK (DO code is 0x19) is ON.


16-bit

Decimal

Block diagram:

Data Size: 16-bit

Format : Decimal



8-73 Revision February, 2017

1. Speed command: It is the command issued by the user (without acceleration / deceleration), not the one of front end speed circuit.

Source: Analog voltage and register

- 2. Feedback speed: The actual speed of the motor and have gone through the filter.
- 3. Obtain the absolute value.
- DO.SP_OK will be ON when the absolute value of speed error is smaller than P1-47, or it will be OFF. If P1-47 is 0, DO.SP_OK is always OFF.

P1-48	мсок Ор	peration Selection O.MC_OK)	of Motion Reached	Address: 0160H 0161H
	Operational Interface :	Panel / Software	Communication	Related Section: -
Default : Control Mode :		0x0000		
		PR		
	Unit:	-		
Range :		0x0000 ~ 0x0011		
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Control selection of digital output DO.MC_OK (DO code is 0x17).

(It will be available after firmware version V1.003 sub08)

The format of this parameter: 00YX


X = 0: It will not remain the digital output status

1: It will remain the digital output status

Y = 0: AL.380 (position deviation) is not working

1: AL.380 (position deviation) is working

8-74 Revision February, 2017



Description:

- 1. Command triggered: It means the new PR command is effective. Position command starts to output and clear signal 2, 4, 5, 6 at the same time.
- 2. CMD_OK: It means the position command is completely outputted and can set the delay time (DLY).
- 3. Command output: Output the profile of position command according to the setting acceleration / deceleration.
- 4. TPOS: It means the position error of the servo drive is smaller than the value of P1-54.
- 5. MC_OK: It means the position command is completely outputted and the position error of the servo drive is smaller than P1-54.
- 6. MC_OK (remains the digital output status): It is the same as 5. However, once this DO is ON, its status will be remained regardless signal 4 is OFF or not.
- 7. The output profile is determined by parameter P1-48.X.
- 8. Position Deviation: When number 7 happens, if 4 (or 5) is OFF, it means the position is deviated and AL380 can be triggered. Set this alarm via parameter P1-48.Y.

P1-49		cumulative Time of	Address: 0162H 0163H	
Operationa Interface :		Panel / Software	Communication	Related Section: Table 8.2
	Default:	0		
	Control Mode :	S/Sz		
	Unit :	ms	าร	
	Range :	0 ~ 65535		
	Data Size :	16-bit		

Format: DEC

Settings: In speed mode, when the deviation value between speed command and motor feedback speed is smaller than the range set by P1-47 and reaches the time set by P1-79, DO.SP_OK will be On. If the deviation value exceeds the range set by P1-47, it has to reclock the time.

P1-50 ~ P1-51

Reserved

P1-52

RES1	Regenerative Resistor	Value	Address: 0168H
0			0169H
Operation Interfact	:Danal / Software	Communication	Related Section: 2.7
IIILEITAC			2.1
Defau	It: Determined by the m following table.	odel. Please refer to the	
Cor Mod	ntrol e :		
Un	it : Ohm		
Rang	e : ^{220V}		
	Model	Setting Range	
	400W (included) or below	30 ~ 750	
	750W ~ 1.5kW	20 ~ 750	
	2kW ~ 4.5kW	10 ~ 750	
	5.5 W	8 ~ 750	
	7.5kW	5 ~ 750	
	11kW	8 ~ 750	
	15 kW	5 ~ 750	
	400V		
	Model	Setting Range	
	750W ~ 1.5kW	60 ~ 750	
	1.5kW ~ 2kW	40 ~ 750	
	3 W	30 ~ 750	
	4.5kW ~ 5.5kW	20 ~ 750	
	7.5kW	15 ~ 750	
Data Siz	e: 16-bit		
Forma	at : Decimal		

8-76 Revision February, 2017

Settings : 220V:

Model	Default
1.5 kW (included) or below	40Ω
2 kW ~ 4.5 kW (included)	20Ω
5.5 kW	15Ω
7.5 kW	15Ω

400V:

Model	Default
750W ~ 7.5kW	80Ω

Please refer to the description of P1-53 for the setting value when connecting regenerative resistor with different method.

P1-53

RES2 Re	generative Resistor	Capacity	Address: 016AH 016BH
Operational Interface :	Panel / Software	Communication	Related Section: 2.7
Default:	Determined by the model. Please refer to the following table.		
Control Mode :	ALL		
Unit:	Watt		
Range :	0 ~ 6000 (for 11kW, 15kW, th to 15000)	e setting range is from 0	
Data Size: 16-bit			
Format :	Format : Decimal		

Settings : 220V


220 V				
Model	Default			
200W (included) or below	0W			
400W	40W			
750W ~ 1.5kW	60W			
2 kW ~ 4.5 kW (included)	100W			
5.5 kW	0W			
7.5 kW	0W			

400V

Model	Default
750W ~ 1.5kW	100W
2 kW ~ 4.5 kW	0W

8-77 Revision February, 2017

Following describes the setting value when connecting regenerative resistor with different method:



P1-54		sition Completed Range		Address: 016CH 016DH
	Operationa Interface :	l Panel / Software	Communication	Related Section: Table 8.2
	Default :	12800		
	Contro Mode :	PT / PR		
	Unit :	Pulse		
	Range :	0 ~ 1280000)	
	Data Size :	32-bit		
	Format :	Decimal		

Settings:

In position mode (PT), if the deviation pulse number is smaller than the setting range (the setting value of parameter P1-54), DO.TPOS is ON.

In position register (PR) mode, if the deviation between the target position and the actual motor position is smaller than the setting range (the setting value of parameter P1-54), DO.TPOS is ON.

8-78 Revision February, 2017

P1-55

	MSPD Ma	aximum Speed Limit	Address: 016EH 016FH	
	Operational Interface:		Communication	Related Section: -
	Default : Same as the rated speed of each model Control Mode : Unit : r/min			
	Range :	0 ~ max.speed		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The default of the max. speed of servo motor is set to the rated speed.

P1-56	ovw	Output Overload War	put Overload Warning Level		
Operatio Interfac		nal Panel / Software :	Communication	Related Section: -	
	Default	: 120	20		
	Cont Mode	Δ11			
	Unit	: %	%		
	Range	: 0 ~ 120			
	Data Size	: 16-bit			
	Format	: Decimal			

Settings: The setting value is $0 \sim 100$, if the servo motor continuously outputs

the load and is higher than the setting proportion (P1-56), the early

warning for overload (DO is set to 10, OLW) will occur.

If the setting value is over 100, it will disable this function.

P1-57	CRSHA	Motor Crash Protection (torque percentage)		Address: 0172H 0173H
	Operation Interfac	onal Panel / Software e:	Communication	Related Section: -
	Default: 0			
	Con Mod	itrol e:		

Unit: %

Range: 0 ~ 300

Data Size: 16-bit

Format: Decimal

Settings: Setup protection level (for the percentage of rated torque, set the value

to 0 means to disable the function, set the value to 1 or number above

means to enable the function)

P1-58	CRSHT Mo	tor Crash Protectio	n Time	Address: 0174H 0175H
	Operational Interface:	Panel / Software	Communication	Related Section: -
	Default:	1		
	Control Mode :	ALL		
	Unit:	ms		
	Range :	0 ~ 1000		
	Data Size :	16-bit		
	Format :	Decimal		

Settings : Setup the protection time:

When it reaches the level, AL.030 occurs after exceeding the

protection time.

This function is only suitable for non-contactable application, such as electric discharge machines. (Please setup P1-37 correctly).

P1-59	MFLT An	alog Speed Comma	and	Address: 0176H 0177H
	Operational Interface :		Communication	Related Section: -
	Default :	0.0	0	
	Control Mode :	S		
	Unit :	1 ms	0.1 ms	
	Range :	0.0 ~ 4.0	0 ~ 40	
	Data Size :	16-bit		
	Format :	One decimal	DEC	

8-80 Revision February, 2017

Example: 1.5 = 1.5 ms 15 = 1.5 ms


Settings: (Moving Filter)

0: Disabled

P1-06 is low-pass filter and P1-59 is moving filter. The difference between both is that moving filter can smooth the command in the beginning and end of the step command; while the low-pass filter brings better smooth effect to command end.

Therefore, it is suggested that if the speed loop receives the command from the controller for forming the position control loop, then low-pass filter can be used. If it is only for the speed control, then it should use Moving Filter for better smoothing.

Original step analog speed command



P1-60 ~ P1-61

Reserved

P1-62	FRCL F	riction Compensatio	tion Compensation		
	Operation Interface	nal Panel / Software :	Communication	Related Section: -	
	Default	: 0			
	Contr Mode	rol . PT / PR / S	PT/PR/S		
	Unit	: %			
	Range	: 0 ~ 100			
	Data Size	: 16-bit			
	Format	: Decimal			

Settings: The level of friction compensation (the percentage of rated torque. Set the value to 0 means to disable the function; set the value to 1 or


number above means to enable it.)

P1-63			ction Compensatio	n	Address: 017EH 017FH
	Operatio Interface	nal e :	Panel / Software	Communication	Related Section: -
	Defaul	lt:	0		
	Con Mode	trol e :	PT / PR / S		
	Uni	it:	ms		
	Range	e :	0 ~ 1000		
	Data Size	e :	16-bit		
	Forma	ıt:	Decimal		

Settings: Setup smoothing constant of friction compensation.

P1-64		Analog Position Com	alog Position Command: Activation		
	Operation Interface	·Danal/Softwara	Communication	Related Section: N/A	
	Default: 0x00				
	Cont Mode	:PT			
	Uni	t :			
	Range	e: 0 x00~ 0x11			
	Data Size	e : 32-bit			
	Forma	t : Hexadecimal			

Settings:




X:


- 0: Disable the function of position command which is issued by analog
- 1: Enable the function of position command which is issued by analog

8-82 Revision February, 2017

- Y: Initial position setting
- 0: After servo on, the motor will regard the current position as the position when the voltage is 0. Then the motor will operate to the position according to the command issued by analog input.



1: After SERVO ON, if the command level is not changed, the motor will not operate. The position the motor stops is the position that corresponds to the current command level.



Z: Reserved U: Reserved

NOTE Version after firmware v1.031 sub8 supports this function.

P1-65	Smooth Constant of Analog P	Address: 0182H 0183H	
	Operational Panel/Software	Communication	Related Section: N/A
	Default: 1		
	Control PT Mode :		
	Unit: 10 ms		-

> Range : 1 ~ 1000 Data Size: 16-bit Format : Decimal

Settings: The smooth constant of analog position command is only effective to

analog position command.

P1-66	PLIVI	lax. Rotation Numbe	er of Analog Position	Address: 0184H 0185H
	Operation Interface	al Panel / Software	Communication	Related Section: -
	Default	: 1.0	10	
	Control Mode	PT		
	Unit	: 1 cycle	0.1 cycle	
	Range	: 0.0 ~ 200.0	0 ~ 2000	
	Data Size	: 16-bit		
	Format	: One decimal	DEC	
	Example	: 1.5 = 1.5 cycles	15 = 1.5 cycles	

Settings: It is the rotation number setting when analog speed command inputs the max. voltage (10V). If it is set to 30 and the external voltage inputs 10V, it means the position command is +3 cycles. 5V means the speed control command is 1.5 cycles.

-10V means the position command is -3 cycles.

Position control command = Input voltage value x Setting value / 10

NOTE It will be available after firmware version v1.031 sub8.

P1-67 Reserved

P1-68	PFLT2 Position Command Moving Filter			Address: 0188H 0189H
	Operationa Interface:	Panel / Software	Communication	Related Section: -
	Default :	4		
	Contro Mode :	PT / PR		
	Unit :			
	Range :			


8-84 Revision February, 2017

Data Size : 16-bit

Format : Decimal

Settings: 0: Disabled

Moving Filter can activate smooth function in the beginning and the end of step command, but it will delay the command.



P1-69 ~ P1-71

Reserved

P1-72		esolution of Linear S oop Control	Scale for Full-closed	Address: 0190H 0191H
	Operationa Interface:	l Panel / Software	Communication	Related Section: -
	Default:	5000		
	Contro Mode :	:PT		
	Unit:	pulse / rev		
	Range :	200 ~1280000		
	Data Size :	32-bit		
	Format :	Decimal		

Settings: A/B pulse corresponded by full-closed loop when motor runs a cycle (after quadruple frequency)

P1-73


FFRR	Error Protection Rang Control	e for Full-closed Loop	Address: 0192H 0193H	
Operation Interface		Communication	Related Section: P2-34	
Defaul	: 30000	30000		
Cont Mode	DT	PT		
Uni	Pulse (based on the loop)	Pulse (based on the feedback of full-closed loop)		
Range	: 1 ~ (2 ³¹ -1)	1 ~ (2 ³¹ -1)		
Data Size	: 32-bit	32-bit		
Forma	: Decimal			

Settings: The protection is for excessive deviation between feedback position of linear scale and the encoder. When the deviation is excessive, it might

result from the loose of connector or other mechanism problems.

P1-74▲

FCON	Full-closed Loop Co	Address: 0194H 0195H	
Operational Interface:	Panel / Software	Communication	Related Section: P1-46
Default :	1000h		
Control Mode :	PT		
Unit :	-		
Range :	0000h ~ 0x4122		
Data Size :	16-bit		
Format :	Hexadecimal		
Settings :		►Switch of full-closed loop	•



8-86 Revision February, 2017

- Switch of full-closed loop control
 - 0: Function of full-closed loop is not used
 - 1: Function of full-closed loop is used
 - 2: Use the function of synchronous control
- Selection of OA/OB/OZ output source
 - 0: Motor encoder is the output source
 - 1: Encoder of linear scale is the output source

Firmware version DSP V1.016 + CPLD 0.07(or the later version) will provide:

- 2: Pulse command of CN1 is the output source
- Positive / negative direction selection of linear scale feedback:
 - 0: It is in positive direction when A phase leads B phase of linear scale
 - 1: It is in negative direction when B phase leads A phase of linear scale
- Filter setting of linear scale
 - 0: BYPASS
 - 1: 20Mhz
 - 2: 10Mhz
 - 3: 6.66Mhz
 - 4: 1.66Mhz
 - 5:833K
 - 6: 416K

P1-75		w-pass Filter Time (op control	Address: 0196H 0197H	
	Operationa Interface:		Communication	Related Section: -
	Default :	100		
	Contro Mode :	PT		
	Unit:	ms		
	Range :	0 ~ 1000		
	Data Size :	16-bit		
	Format :	Decimal		

Settings:

When the stiffness of mechanical system between full- and half-closed loops is insufficient, users can setup the appropriate time constant to enhance the stability of the system.

Set the value to 0 to disable the function of low-pass filter (Bypass) The stiffness of mechanical system \uparrow , the setting value of P1-75 \downarrow

The stiffness of mechanical system ↓, the setting value of P1-75 ↑

I-76	AIVISPII		ximum Rotation of En A, OB)	Address: 0198H 0199H	
	Operatio Interface	nal e :	Panel / Software	Communication	Related Section: P1-46
	Default :		5500		
	Control Mode :		ALL		
	Uni	it:	r/min		
	Range	e :	0 ~ 6000		
	Data Sizo	e :	16-bit		
	Forma	at:	Decimal		

Settings: According to the real application, this parameter is set for the maximum

speed and the servo drive will generate smooth function automatically

for encoder output signals.

When the value is set to 0, the function is disabled.

P 1	-7	7	~
Ρ	1-	80)

Reserved

P1-81	VCM2 Ma	x. Speed of 2 nd Analog	Speed Command	Address: 01A2H 01A3H
	Operational Interface:	Panel / Software 0	Communication	Related Section: P1-40
Default :		Motor rated speed		
	Control Mode :	S/T		
Unit:		rpm/10V		
	Range :	0 ~ 50000		
Data Size :		32-bit		
	Format :	Decimal		
		D		<i>i</i>

Settings: Please refer to the description of P1-40.

8-88 Revision February, 2017

VCMLPF Filt	ter Switching Time bety	ween P1-40 and P1-	Address: 01A4H 01A5H
Operational Interface :	Panel / Software (Communication	Related Section:
Default :	0		
Control Mode :	S		
Unit :	msec		
Range :	0 ~ 1000 (0: disable this	s function)	
Data Size: 16-bit			
Format :	Decimal		
·			:

Address: 01A6H P1-83 **VCMLPF** Abnormal Analog Input Voltage Level 01A7H Related Section: Operational: Panel/Software Communication Interface: Default: 0 Control Mode: Unit: :mV Range : $0 \sim 12000$ (0: disable this function) Data Size : 16-bit Format : Decimal

Settings: 0: Disabled

Settings: When analog input voltage is over 50ms, AL.042 will occur. The compared level for this parameter is the original analog input voltage which has not been added by an offset value via parameter P4-22, Analog Speed Input Offset.

P1-87		orque Limit Setting		Address: 01A8H 01A9H
	Operational Interface	Panel/Software	Communication	Related Section:
	Default :	: 1		
	Contro Mode :	DD		
	Unit :	: %		
	Range :	: 1~300		
	Data Size :	: 16-bit		
	Format :	Decimal		

Settings: Torque limit setting in torque limit homing mode.

P1-88	HMTQT Torque Limit Time Setting			Address: 01AAH 01ABH
	Operational Interface :	Panel/Software	Communication	Related Section:
	Default :	2000		
	Control Mode :	PR ms 2~2000		
	Unit:			
	Range :			
	Data Size :			
	Format :	Decimal		

Settings: Torque limit time setting in torque limit homing mode.

8-90 Revision February, 2017

P2-xx Extension Parameters

P2-00	KPP P	osition Loop Gain		Address: 0200H 0201H
	Operation Interface	al Panel / Software :	Communication	Related Section: 6.2.8
	Default	: 35		
	Contr Mode	DT / DD	PT / PR	
	Unit	: rad/s		
	Range	: 0 ~ 2047		
	Data Size	: 16-bit		
	Format	; Decimal		

Settings: When the value of position loop gain is increased, the position response can be enhanced and the position error can be reduced. If the value is set too big, it may easily cause vibration and noise.

P2-01	PPR Sw	vitching Rate of Pos	sition Loop Gain	Address: 0202H 0203H
	Operational Interface :	Panel / Software	Communication	Related Section: 6.2.8
	Default:	100		
	Control Mode :	PT / PR		
	Unit:			
	Range :			
	Data Size :	16-bit		
	Format :	Decimal		
		0 '' 1 '' 1 '		

Settings: Switch the changing rate of position loop gain according to the gain-

Revision February, 2017 8-91

switching condition.

P2-02

PFG Po	sition Feed Forward (Gain	Address: 0204H 0205H
Operational Interface :	Panel / Software	Communication	Related Section: 6.2.8
Default:	50		
Control Mode :	Control Mode : PT / PR		
Unit :	· %		
Range :	ge : 0 ~ 100		
Data Size :	Data Size: 16-bit		
Format :	Decimal		

Settings: If the position command is changed smoothly, increasing the gain

value can reduce the position error.

If the position command is not changed smoothly, decreasing the gain

value can tackle the problem of mechanical vibration.

P2-03

PFF	Smooth Constant of Po	osition Feed Forward	Address: 0206H 0207H
Operation Interface		Communication	Related Section: -
Defaul	t : 5		
:	Control Mode :		
Uni	t: ms		
Range	e: 2 ~ 100		
Data Size	e : 16-bit		
Forma	t : Decimal		
	If the resition comm		

Settings: If the position command is changed smoothly, decreasing the value can reduce the position error. If the position command is not changed smoothly, increasing the value can tackle the problem of mechanical vibration.

8-92 Revision February, 2017

2-04	KVP Sp	eed Loop Gain		Address: 0208H 0209H
	Operational Interface:	Panel / Software	Communication	Related Section: 6.3.6
	Default :	500		
	Contro Mode :	I A I I		
	Unit:	rad/s		
	Range :	0 ~ 8191		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: Increase the value of speed loop gain can enhance the speed

response. However, if the value is set too big, it would easily cause

resonance and noise.

P2-05	SPR	Switching Rate of Spe	eed Loop Gain	Address: 020AH 020BH
	Operatior Interface	nal Panel / Software :	Communication	Related Section: -
	Default	: 100		
	Cont Mode	rol ALL	% 10 ~ 500	
	Unit	:: %		
	Range	: 10 ~ 500		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: Switch the changing rate of speed loop gain according to the gain

switching condition.

8-93 Revision February, 2017

P2-06		Speed Integral Compensation	Address: 020CH 020DH
	Operation Interface	nal Panel / Software Communication	Related Section: 6.3.6
	Defaul	t : 100	
	Cont Mode	rol a :	
	Uni	t : rad/s	
	Range	e : 0 ~ 1023	
	Data Size	e : 16-bit	

Format : Decimal

Settings: Increasing the value of speed integral compensation can enhance

speed response and diminish the deviation of speed control. However, if the value is set too big, it would easily cause resonance and noise.

P2-07	KVF	Speed Feed Forward	ed Feed Forward Gain		
	Operation Interface	nal Panel / Software e:	Communication	Related Section: 6.3.6	
	Defaul	t : 0			
	Cont Mode	trol ALL e:	ALL		
	Uni	t : %			
	Range	e: 0 ~ 100			
	Data Size	e : 16-bit			
	Forma	t : Decimal			

Settings: When the speed control command runs smoothly, increasing the gain value can reduce the speed command error. If the command does not run smoothly, decreasing the gain value can reduce the mechanical vibration during operation.

8-94 Revision February, 2017

P2-08**■**

PCTL Sp	pecial Parameter Wri	Address: 0210H 0211H			
Operationa Interface :	ll Panel / Software	Communication	Related Section: -		
Default:	0				
Contro Mode :	: A 1 1	ALL			
Unit:	-	-			
Range :	0 ~ 65535				
Data Size :	16-bit				
Format :	Decimal				

Settings : Special parameter write-in:

Parameter code	Function
10	Reset the parameter (Apply to the power again after reset)
20	P4-10 is writable
22	P4-11~P4-21are writable
30,35	Save the data of COMPARE, CAPTURE, E-Cam
406	Enable forced DO mode
400	When forced DO mode is enabled, it can switch back to the normal DO mode.

NOTE A2L does not support E-Cam function.

P2-09		Debouncing Time	ebouncing Time		
	Operational Interface :	Panel / Software	Communication	Related Section: -	
	Default:	2			
	Control Mode :	ALL			
	Unit:				
	Range :	0 ~ 20			
	Data Size :	16-bit			
	Format :	Decimal			

Settings: When the environmental noise is big, increasing the setting value can enhance the control stability. However, if the value is set too big, the response time will be influenced.

P2-10

DI1 DI	1 Functional Planning		Address: 0214H 0215H
Operationa Interface :	Panel / Software	Communication	Related Section: Table 8.1
Default:	101		
Contro Mode :	ALL		
Unit:	-		
Range :	0 ~ 0x015F (the last tw	o codes are DI code)	
Data Size :	16-bit		
Format :	Hexadecimal		
Settings:		Input function selection Input contact Not in use	

- Input function selection: Please refer to table 8.1
- Input contact: a or b contact
 - 0: Set the input contact as normally closed (**b** contact)
 - 1: Set the input contact as normally opened (a contact)

(P2-10 ~ P2-17) The setting value of function programmed

When parameters are modified, please re-start the servo drive to ensure it can work normally.

Note: Parameter P3-06 is used to set how digital inputs (DI) accepts commands, through external terminal or the communication which determined by P4-07.

P2-11	DI2	DI2 Functional Plannin	Functional Planning		
	Operatio Interface		Communication	Related Section: Table 8.1	
	Defaul	t : 104	<u> </u>		
	Con Mode	Δ11			
	Uni	: -			
	Range	e: 0 ~ 0x015F (the last	two codes are DI code)		
	Data Size	e : 16-bit			

8-96 Revision February, 2017

Format: Hexadecimal

Settings: Please refer to the description of P2-10

P2-12	DI3 D	3 Functional Planning	Functional Planning		
	Operational Interface	al Panel / Software	Communication	Related Section: Table 8.1	
	Default :	116	16		
	Contro Mode	ALL			
	Unit	-	0 ~ 0x015F (the last two codes are DI code)		
	Range	0 ~ 0x015F (the last t			
	Data Size	16-bit			
	Format	Hexadecimal			

Settings: Please refer to the description of P2-10

P2-13	DI4	DI4 Functional Planni	Functional Planning		
	Operatio Interface		Communication	Related Section: Table 8.1	
	Defaul	t : 117			
	Con Mode	trol ALL e:	ALL		
	Uni	t : -	-		
	Range	e: 0 ~ 0x015F (the las	: 0 ~ 0x015F (the last two codes are DI code) : 16-bit		
	Data Size	e : 16-bit			
	Forma	t : Hexadecimal			

Settings: Please refer to the description of P2-10

P2-14	DI5	DI5	Functional Plannir	Address: 021CH 021DH	
	Operation Interfac		Panel / Software	Communication	Related Section: Table 8.1
	Defau	lt:	102		
	Control Mode :		ALL		
	Unit :		-		
	Range :		0 ~ 0x015F (the last	two codes are DI code)	
			16-bit		
	Format :		Hexadecimal		
	Settings:		Please refer to the d	escription of P2-10	•

P2-15	DI6	DI6 Functional Planni	Functional Planning		
	Operatio Interface		Communication	Related Section: Table 8.1	
	Defaul	t : 22	22		
	Con Mode	ΔΙΙ			
	Uni	t : -			
	Range	e: 0 ~ 0x015F (the las	: 0 ~ 0x015F (the last two codes are DI code)		
	Data Size	e : 16-bit			
	Forma	t : Hexadecimal			

P2-16		17 Functional Plannin	g	Address: 0220H 0221H
	Operational Interface	al Panel / Software	Communication	Related Section: Table 8.1
	Default	: 23		
	Contro Mode			
	Unit	-		
	Range	0 ~ 0x015F (the last	two codes are DI code)	

Settings: Please refer to the description of P2-10

8-98 Revision February, 2017

Data Size: 16-bit

Format: Hexadecimal

Settings: Please refer to the description of P2-10

Address: 0222H P2-17 DI8 DI8 Functional Planning 0223H Operational Related Section: Panel / Software Communication Table 8.1 Interface: Default: 21 Control Mode : ALL Unit: -Range: $0 \sim 0x015F$ (the last two codes are DI code) Data Size: 16-bit Format: Hexadecimal

Settings: Please refer to the description of P2-10

DO1 [OO1 Functional Planr	ning	Address: 0224H 0225H
Operation Interface	:Danal / Coffwara	Communication	Related Section: Table 8.2
Default	: 101		
Conti Mode	: A I I		
Unit	: -		
Range	: 0 ~ 0x013F (the las	0 ~ 0x013F (the last two codes are DO code)	
Data Size	: 16-bit		
Format	: Hexadecimal		
Settings		Output function selection Output contact Not in use	

Output function selection: Please refer to table 8.2

• Output contact: **a** or **b** contact

0: Set the output contact as normally closed (**b** contact)

1: Set the output contact as normally opened (**a** contact) (P2-18 ~ P2-22) The setting value of function programmed

When parameters are modified, please re-start the servo drive to ensure it can work normally.

P2-19	DO2	OO2 Functional Plann	2 Functional Planning		
	Operation Interface	DI/O-#	Communication	Related Section: Table 8.2	
	Default	: 103			
	Contr Mode	ol : ALL	ALL		
	Unit	: -	-		
	Range	: 0 ~ 0x013F (the last	t two codes are DO code)		
	Data Size	: 16-bit	16-bit		
	Format	: Hexadecimal	Hexadecimal		
	Settings	gs: Please refer to the description of P2-18		•	

P2-20	DO3	O3 Functional Plann	ing	Address: 0228H 0229H
	Operation Interface	Donal / Cathware	Communication	Related Section: Table 8.2
	Default	: 109	109	
	Contr Mode	ΔΙΙ		
	Unit	: -	-	
	Range	0 ~ 0x013F (the last two codes are DO code)		
	Data Size	ata Size:16-bit		

8-100 Revision February, 2017

Settings: Please refer to the description of P2-18

Format: Hexadecimal

2-21	DO4	DO4 Functional Plannin	4 Functional Planning	
	Operation Interface	Danal / Software	Panel / Software Communication	
	Defaul	t : 105	105	
	Cont Mode	ΑΙΙ	ALL	
	Uni	t:-	-	
	Range	e: 0 ~ 0x013F (the last t	wo codes are DO code)	
	Data Size	e : 16-bit	16-bit	
	Forma	t : Hexadecimal	Hexadecimal	

P2-22

DO5 Functional Planning

Operational Interface:

Panel / Software

Communication

Table 8.2

Control Mode:

Unit: -

Settings: Please refer to the description of P2-18

Data Size: 16-bit

Format: Hexadecimal

Range : $0 \sim 0x013F$ (the last two codes are DO code)

Settings: Please refer to the description of P2-18

P2-23	NCF1 R	esonance Suppressio	n (Notch filter) (1)	Address: 022EH 022FH
	Operational Interface	Panel / Software	Communication	Related Section: 6.3.7
	Default :	: 1000		
	Contro Mode :			
	Unit	: Hz		
	Range	50 ~ 1000		

Data Size : 16-bit

Format : Decimal

Settings: The first setting value of resonance frequency. If P2-24 is set to 0, this

function is disabled. P2-43 and P2-44 are the second Notch filter.

Address: 0230H **Resonance Suppression (Notch filter)** P2-24 DPH1 Attenuation Rate (1) 0231H Operational Related Section: Panel / Software Communication 6.3.7 Interface: Default: 0 Control ALL Mode: Unit: dB Range: $0 \sim 32$ (0: disable the function of Notch filter) Data Size: 16-bit Format : Decimal

Settings: The first resonance suppression (notch filter) attenuation rate. When this parameter is set to 0, the function of Notch filter is disabled.

NOTE If the value of attenuation rate is set to 5, then, it would be -5dB.

P2-25	NLP I	_ow-pass Filter of Res	Address: 0232H 0233H	
	Operatior Interface	:D 1/O (1	Communication	Related Section: 6.3.7
	Default	0.2 (under 1kW) or 0.5 (other model)		
	Cont Mode	ΔΙΙ		
	Unit	; 1 ms	0.1 ms	
	Range	: 0.0 ~ 100.0	0 ~ 1000	
	Data Size	: 16-bit		
	Format	: One decimal	DEC	
	Example	: 1.5 = 1.5 ms	15 = 1.5 ms	

Settings: Set the low-pass filter of resonance suppression. When the value is set to 0, the function of low-pass filter is disabled.

8-102 Revision February, 2017

DST	Anti-interference Gain		Address: 0234H 0235H
Operation Interface	al Panel / Software :	Communication	Related Section: -
Default	: 0		
	Control Mode :		
Unit	Unit : 1		
Range	: 0 ~ 1023 (0: disable t	his function)	
Data Size	: 16-bit		
Format	: Decimal		

P2-26


Settings: Increasing the value of this parameter can increase the damping of speed loop. It is suggested to set P2-26 equals to the value of P2-06. If users desire to adjust P2-26, please follow the rules below.

- 1. In speed mode, increase the value of this parameter can reduce speed overshoot.
- 2. In position mode, decrease the value of this parameter can reduce position overshoot.

P2-27	GCC G	Sain Switching and S	in Switching and Switching Selection		
	Operational Interface	Panel / Software	Communication	Related Section: -	
	Default	: 0			
	Contro Mode	ALL	ALL		
	Unit	: -			
	Range	: 0x0000 ~ 0x0018			
	Data Size	: 16-bit			
	Format	: Hexadecimal			

8-103 Revision February, 2017

Settings:



- Gain switching condition:
 - 0: Disable gain switching function.
 - 1: The signal of gain switching (GAINUP) is ON.
 - 2: In position control mode, the position error is bigger than the value of P2-29.
 - 3: The frequency of position command is bigger than the value of P2-29.
 - 4: When the speed of servo motor is faster than the value of P2-29.
 - 5: The signal of gain switching (GAINUP) is OFF.
 - 6: In position control mode, the position error is smaller than the value of P2-29.
 - 7: When the frequency of position command is smaller than the value of P2-29.
 - 8: When the speed of servo motor is slower than the value of P2-29.
- Gain switching method:
 - 0: Gain switching

1: Integrator switching, P -> PI

Setting Value	Control Mode P	Control Mode S	
0	P2-00 x 100% P2-04 x 100%	P2-04 x 100%	Before switching
0	P2-00 x P2-01 P2-04 x P2-05	P2-04 x P2-05	After switching
1	P2-06 x 0% P2-26 x 0%		Before switching
1	P2-06 x P2-26 x	After switching	

P2-28	GUT G	ain Switching Time (Constant	Address: 0238H 0239H
	Operation Interface	al Panel / Software :	Communication	Related Section: -
	Default			
	Contr Mode	ol		
		: 10ms		
		: 0 ~ 1000		

8-104 Revision February, 2017

Data Size: 16-bit

Format: Decimal

Example: 15 = 150 ms

Settings: It is for switching the smooth gain. (0: disable this function)

P2-29	GPE	Gain Switching	n Switching		Address: 023AH 023BH
	Operatio Interface	nal Panel / Softw e:	vare	Communication	Related Section: -
	Defau	t: 1280000			
	Con Mode	: A I I			
	Uni	t: Pulse, Kpps,	r/min		
	Range	e: 0 ~ 3840000			
	Data Size	e : 32-bit			
	Forma	t : Decimal			

Settings: The setting of gain switching (Pulse error, Kpps, r/min) is determined

	by the selection of gain switching (P2-27).				
P2-30∎	INH	Aux	kiliary Function		Address: 023CH 023DH
	Operatio Interface		Panel / Software	Communication	Related Section: -
	Defaul	t : (0		
	Control Mode :		ALL		
	Unit :		-		
	Range	e : ·	-8 ~ +8		
	Data Size	e :	16-bit		
	Forma	t :	Decimal		

> 0: Disable all functions described below Settings:

> > 1: Force to Servo On the software

2~4: (reserved)

5: This setting allows the written parameters not retain after power off. When the data is no need to save, it can avoid the parameters continuously writing into EEPROM and shortening the lifetime of EEPROM.

Setting this parameter is a must when using communication control.

6: In simulation mode (command simulation), the external Servo On signal cannot work and DSP Error (variable 0x6F) is regarded as 0. Parameter P0-01 only shows the external Error (positive/negative limit, emergency stop, etc)

In this status, DO.SRDY is ON. Command is accepted in each mode and can be observed via scope software. However, the motor will not operate. The aim is to examine the command accuracy.

- 7: (It will be available after firmware version V1.013) High-speed oscilloscope, disable Time-Out function (It is for PC software)
- 8: (It will be available after firmware version V1.013) Back up all parameters (current value) and save in EEPROM. The value still exists when re-power on.

The panel displays 'to.rom' during execution. (It can be executed when Servo ON.)

-1,-5,-6,-7: (It will be available after firmware version V1.013) Individually disable the function of 1,5,6,7

-2~-4, -8: (Reserved)



NOTE Please set the value to 0 in normal operation. The value returns to 0 automatically after re-power on.

P2-31		Speed Loop Frequenc Auto and Semi-auto M	y Response Setting in lode	Address: 023EH 023FH
	Operatior Interface	Danal / Coffware	Communication	Related Section: 5.6 and 6.3.6
	Default	: 80		
	Cont Mode	ΔΙΙ		
	Unit	: Hz		
	Range	: 1 ~ 1000		
	Data Size	: 16-bit		
	Format	: Decimal		4

8-106 Revision February, 2017

Settings: 1~50Hz: Low stiffness, low response

51~250Hz: Medium stiffness, medium response

251~850Hz: High stiffness, high response

851~1000Hz: Extremely high stiffness, extremely high response

NOTE 1) According to the speed loop setting of P2-31, the servo drive sets the position loop response automatically.

> 2) The function is enabled via parameter P2-32. Please refer to Chapter 5.6 for corresponding bandwidth size of the setting value.

P2-32 ▲		uning Mode Selection	n	Address: 0240H 0241H
	Operational Interface	Panel / Software	Communication	Related Section: 5.6 and 6.3.6
	Default	: 0		
	Contro Mode	ΔΙΙ		
	Unit	: -		
	Range	0 ~ 0x2		
	Data Size	: 16-bit		
	Format	: Hexadecimal		

Settings: 0: Manual Mode

1: Auto Mode (continuous adjustment)

2: Semi-auto Mode (non- continuous adjustment)

8-107 Revision February, 2017

Relevant description of manual mode setting:

When P2-32 is set to 0, parameters related to gain control, such as P2-00, P2-04, P2-06, P2-25 and P2-26, all can be set by the user.

When switching mode from auto or semi-auto to manual, parameters about gain will be updated automatically.

Relevant description of auto mode setting:

Continue to estimate the system inertia, save the inertia ratio to P1-37 every 30 minutes automatically and refer to the stiffness and bandwidth setting of P2-31.


- 1. Set the system to manual mode 0 from auto 1 or semi-auto 2, the system will save the estimated inertia value to P1-37 automatically and set the corresponding parameters.
- 2. Set the system to auto mode 1 or semi-auto mode 2 from manual mode 0, please set P1-37 to the appropriate value.
- 3. Set the system to manual mode 0 from auto mode 1, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the corresponding parameters of auto mode.
- 4. Set the system to manual mode 0 from semi-auto mode 2, P2-00, P2-04, P2-06, P2-25, P2-26 and P2-49 will be modified to the corresponding parameters of semi-auto mode.

Relevant description of semi-auto mode setting:

- 1. When the system inertia is stable, the value of P2-33 will be 1 and the system stops estimating. The inertia value will be saved to P1-37 automatically. When switching mode to semi-auto mode (from manual or auto mode), the system starts to estimate again.
- 2. When the system inertia is over the range, the value of P2-33 will be 0 and the system starts to estimate and adjust again.

Address: 0242H P2-33 ▲ AUT3 Semi-auto Inertia Adjustment 0243H Operational Related Section: -Communication Panel / Software Interface: Default: 0 Control ALL Mode: Unit: -Range: $0 \sim 0x1$ Data Size: 16-bit Format: Hexadecimal

8-108 Revision February, 2017



- Semi-auto Setting:
 - 1: It means the inertia estimation in semi-auto mode is completed. The inertia value can be accessed via P1-37.
 - 0: 1. When the display is 0, it means the inertia adjustment is not completed and is adjusting.
 - 2. When the setting is 0, it means the inertia adjustment is not completed and is adjusting.

P2-34		The Condition of Ove	rspeed Warning	Address: 0244H 0245H
	Operation Interface	nal Panel / Software e :	Communication	Related Section: -
	Defaul	t : 5000		
	Cont Mode	i Q		
	Uni	t : r/min		
	Range	e: 1 ~ 5000		
	Data Size	e : 16-bit		
	Forma	t : Decimal	Decimal	

Settings: The setting of over speed warning in servo drive error display (P0-01)

P2-35	PDEV	ondition of Excessive Position Control eviation Warning		Address: 0246H 0247H
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	3840000		
	Control Mode :	PT / PR		
	Unit :	pulse		
	Range :	1 ~ 128000000		
	Data Size :	32-bit		
	Format :	Decimal		

> The setting of excessive position control deviation warning in servo Settings: drive error display (P0-01)

6	EDI9	Ext	ended EDI9 Functi	onal Planning	Address: 0248H 0249H
	Operational Interface :		Panel / Software	Communication	Related Section: Table 8.1
	Defau	lt:	0		
	Cor Mod		ALL		
	Unit :		-		
	Range :		0 ~ 0x015F (the last two codes are EDI code)		
	Data Size :		16-bit		
	Format :		Hexadecimal		
	Setting	s:		—— Input function selection —— Input contact	

Input function selection: Please refer to table 8.1

─ Not in use

Input contact: a or b contact

0: Set the input contact as normally closed (**b** contact)

1: Set the input contact as normally opened (a contact)

(P2-36 ~ P2-41) The setting value of function programmed

When parameters are modified, please re-start the servo drive to ensure it can work normally.

P2-37	EDI10	Extended EDI10 Funct	ional Planning	Address: 024AH 024BH
	Operation Interface	nal Panel / Software e :	Communication	Related Section: Table 8.1
	Defaul	t : 0	0	
	Cont Mode	ΔΙΙ		
	Uni	t : -	0 ~ 0x015F (the last two codes are EDI code)	
	Range	e: 0 ~ 0x015F (the last		
	Data Size	e : 16-bit		

8-110 Revision February, 2017

Format : Hexadecimal

Settings: Please refer to the description of P2-36

Address: 024CH P2-38 EDI11 **Extended EDI11 Functional Planning** 024DH Operational Related Section: Panel / Software Communication Interface: Table 8.1 Default: 0 Control Mode : ALL Unit: -Range : $0 \sim 0x015F$ (the last two codes are EDI code) Data Size: 16-bit Format : Hexadecimal

Settings: Please refer to the description of P2-36

P2-39	EDI12 Ex	ctended EDI12 Funct	ional Planning	Address: 024EH 024FH
	Operational Interface:	Danal/Caffurana	Communication	Related Section Table: 8.1
	Default :	-		
	Contro Mode :	ALL		
	Unit :	-		
	Range :	0 ~ 0x015F (the last	0 ~ 0x015F (the last two codes are EDI code)	
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Please refer to the description of P2-36

P2-40	EDI13	Ext	ended EDI13 Function	onal Planning	Address: 0250H 0251H
	Operatio Interface		Panel / Software	Communication	Related Section: Table 8.1
	Mode : Unit :		-		
			ALL		
			-		
			0 ~ 0x015F (the last t	wo codes are EDI code)	
			16-bit		
	Forma	at:	Hexadecimal		

Address: 0252H P2-41 **EDI14** Extended EDI14 Functional Planning 0253H Operational Related Section: Panel / Software Communication Table 8.1 Interface: Default: -Control Mode: ALL Unit: -Range: $0 \sim 0x015F$ (the last two codes are EDI code) Data Size: 16-bit Format : Hexadecimal

Settings: Please refer to the description of P2-36

Settings: Please refer to the description of P2-36

P2-42 Reserved

8-112 Revision February, 2017

43	NCF2	Resonance Suppressi	ion (Notch filter) (2)	Address: 0256H 0257H
	Operation Interface	al Panel / Software :	Communication	Related Section: 6.3.7
	Default	: 1000		
	Contr Mode	ol : ALL	ALL	
	Unit	: Hz	Hz	
	Range	: 50 ~ 2000		
	Data Size	16-bit		
	Format	: Decimal		

The second setting value of resonance frequency. If P2-44 is set to 0,

this function is disabled. P2-23 and P2-24 are the first Notch filter.

Address: 0258H **Resonance Suppression (Notch filter)** P2-44 DPH2 Attenuation Rate (2) 0259H Related Section: Operational Panel / Software Communication 6.3.7 Interface: Default: 0 Control Mode: Unit: dB Range: 0 ~ 32 (0: disable Notch filter) Data Size: 16-bit Format: Decimal

Settings: The second resonance suppression (notch filter) attenuation rate. When this parameter is set to 0, the function of Notch filter is disabled.



Settings:

If the value of attenuation rate is set to 5, then it would be -5dB.

2-45	NCF3 Re	esonance Suppressi	ion (Notch filter) (3)	Address: 025AH 025BH
	Operationa Interface:	Panel / Software	Communication	Related Section: 6.3.7
	Default :	1000		
	Contro Mode :	ALL		
	Unit:	Hz		
	Range :	50 ~ 2000		
	Data Size :	16-bit		
	Format :	Decimal		

Settings : The third group of mechanism resonance frequency setting value. If P2-46 is set to 0, this function will be disabled. P2-23 and P2-24 are

the first group of resonance suppression (Notch filter).

IDES		n (Notch filter)	Address: 025CH 025DH
Operational Interface :	Panel / Software	Communication	Related Section: 6.3.7
Default :	0		
Control Mode :	ALL dB 0 ~ 32		
Unit :			
Range :			
Data Size :			
Format :	Decimal		
	Operational Interface : Default : Control Mode : Unit : Range : Data Size :	Panel / Software Operational Interface : Panel / Software Default : 0 Control Mode : ALL Unit : dB Range : 0 ~ 32 Data Size : 16-bit Format : Decimal	Operational Interface : Panel / Software Communication Default : 0 Control Mode : Unit : dB Range : 0 ~ 32 Data Size : 16-bit

Settings: The third group of resonance suppression (Notch filter) attenuation rate. Set the value to 0 to disable the function of Notch filter.

P2-47	ANCF	Auto Resonance Supp	pression Mode Setting	Address: 025EH 025FH
	Operation Interfac	onal Panel / Software e:	Communication	Related Section: -
	Defau	lt : 1		
	Con Mod	e :		

8-114 Revision February, 2017

Unit :	-
Range :	0 ~ 2
Data Size :	16-bit
Format :	Decimal

Settings:

0: The value of P2-43, P2-44 and P2-45, P2-46 will retain.

1: The value of P2-43, P2-44 and P2-45, P2-46 will retain after resonance suppression.

2: Continuous resonance suppression

Description of Auto Mode Setting:

When it is set to 1: Auto resonance, the value returns to 0 automatically and saves the point of resonance suppression when it is stable. If it is unstable, repower on or set back to 1 for re-estimation again.

When it is set to 2: Continuous suppression automatically. When it is stable, the point of resonance suppression will be saved. If it is unstable, re-power on for reestimation.

When switching to mode 0 from mode 2 or 1, the setting of P2-43, P2-44, P2-45 and P2-46 will be saved automatically.

P2-48

ANCL	Resonance Suppressi	on Detection Level	Address: 0260H 0261H			
Operatior Interface		Communication	Related Section: -			
Default	: 100					
Cont Mode	: A I I					
Unit	:: -					
Range	: 1 ~ 300%					
Data Size	: 16-bit					
Format	: Decimal	Decimal				

Settings: (The smaller the setting value is, the more sensitive the resonance will

P2-48↑, resonance sensitiveness↓

P2-48↓, resonance sensitiveness↑

8-115 Revision February, 2017

Settings: The filter of speed estimation

Format : Decimal

Setting Value	Speed Estimation Bandwidth (Hz)
00	2500
01	2250
02	2100
03	2000
04	1800
05	1600
06	1500
Setting Value	Speed Estimation Bandwidth (Hz)
07	1400
08	1300
09	1200
0A	1100
0B	1000
0C	950
0D	900
0E	850
0F	800
10	750
11	700
12	650
13	600
14	550
15	500
16	450
17	400

8-116 Revision February, 2017

18	350
19	300
1A	250
1B	200
1C	175
1D	150
1E	125
1F	100

P2-50	DCLR Pu	lse Clear Mode	Address: 0264H 0265H	
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	0		
	Control Mode :	PT		
	Unit:	-		
	Range :	0x0 ~ 0x1		
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Please refer to table 8.1 for digital input setting.

When set digital input (DI) as CCLR, the function of pulse clear is effective. Clear the position error (It is applicable in PT, PR mode).

If this DI is ON, the accumulative position error will be cleared to 0.

0: The triggering method of CCLR is rising-edge.

1: The triggering method of CCLR is level.

P2-51 Reserved

P2-52 ▲	IDXS Indexing Coordinates Scale		Address: 0268H 0269H	
	Operation Interfac	·Danal/Caftwara	Communication	Related Section:
	Defau	It: 1000000000		
	Con Mod	itrol e : ^{ALL}		
	Un	it : PUU		

8-117 Revision February, 2017

Range: 0 ~ 1000000000

Data Size: 32-bit

Format : Decimal

Settings: This parameter is used to set the scale of the indexing coordinates,

indexing command position and indexing feedback position. If the setting value is too small, it may cause the error of indexing

coordinates.

Range of setting value of P2-52:

$$P2-52>1.05\times$$
Max. Motor Speed $(r/min)\times\frac{1280000}{60000}\times\frac{P1-45}{P1-44}$

> 22.4×Max. Motor Speed (r/min)×
$$\frac{P1-45}{P1-44}$$

P2-53

KPI Po	osition Integral Compo	ensation	Address: 026AH 026BH
Operationa Interface :			Related Section: 6.3.6
Default :	0		
Contro Mode :	All		
Unit :	rad/s		
Range :	Range : 0 ~ 1023		
Data Size :	16-bit		
Format :	Decimal		

Settings: When increasing the value of position control integral, reducing the position steady-state error, it may easily cause position overshoot and

noise if the value is set too big.

P2-54

SVP The	e Gain of Synchron	Address: 026CH 026DH		
Operational Interface :	al Panel / Software Communication		Related Section: -	
Default:	0			
Control Mode:	ALL			
Unit:	Rad/s			
Range :	0~8191			
Data Size :	16-bit			
Format:	Decimal			

8-118

Settings: When increasing the value of synchronous speed control, it can enhance the speed following of two motors. However, if the value is set too big, it may easily cause vibration and noise.

P2-55	. SVI	Integral Compensatio Speed	n to Synchronous	Address: 026EH 026FH
	Operatio Interface	nal Panel / Software	Communication	Related Section: -
	Defaul	t: 0		
	Con Mode	trol ə:		
	Uni	t:Rad/s		
	Range	e: 0~1023		
	Data Size	e: 16-bit		
	Forma	t : Decimal		

Settings: When increasing integral compensation to synchronous speed, two motors speed following can be enhanced and the speed error between two motors can be reduced. However, if the value is set too big, it may easily cause vibration and noise.

P2-56	201	Integral Compensatio Position	n to Synchronous	Address: 0270H 0271H
	Operatio Interface	nal e : Panel / Software	Communication	Related Section: -
	Defaul	lt: 0		
	Con Mode	trol e:		
	Uni	it:Rad		
	Range	e: 0~1023		
	Data Size	e: 16-bit		
	Forma	it: Decimal		

Settings: When increasing integral compensation to synchronous position, two motors speed following can be enhanced and the speed error between two motors can be reduced. However, if the value is set too big, it may easily cause vibration and noise It is suggested to set the value the same as P2-06.

P2-57		Γhe Bandwidth of Syr	nchronous Control	Address: 0272H 0273H
	Operatior Interface	nal Panel / Software	Communication	Related Section: -
	Default	: 0		
	Cont Mode	rol : ALL		
	Unit	: Hz		
	Range	: 0~1023		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: If users do not know how to set P2-54~P2-56, setting the bandwidth of synchronous control value will do since the value will correspond to P2-54~P2-56. The bigger the bandwidth of synchronous control value is, the better the synchronous effect will be. When increasing the bandwidth of speed loop and synchronous control, pay special attention to the response of P2-25 which should be faster than the

setting of the both bandwidth.

P2-58	SVL L	ow-pass Filter of Sy	Address: 0274H 0275H	
	Operational Interface	Panel / Software	Communication	Related Section: -
	Default:	0		
	Contro Mode :	^{ol} ALL		
	Unit :	0.1ms		
	Range :	0~1000		
	Data Size :	16-bit		
	Format :	Decimal		*
	Example :	15 = 1.5 ms		
	Sottings:	If the complement of	control is influenced by la	.: waa aliukia wa awal aasia.


Settings: If the synchronous control is influenced by low resolution and causes noise (not a high-pitched but rough sound), low-pass filter can be used to solve this problem. Please note that bandwidth of the synchronous control should be set as large as possible and should larger than the bandwidth of speed-loop.

P2-59 Reserved

8-120 Revision February, 2017

Address: 0278H P2-60 GR4 Gear Ratio (Numerator) (N2) 0279H Operational Related Section: -Panel / Software Communication Interface: Default: 128 Control Mode: Unit: pulse Range: $1 \sim (2^{29}-1)$ Data Size: 32-bit Format : Decimal

Settings: The numerator of electronic gear ratio can be selected via DI.GNUM0 and DI.GNUM1 (Please refer to table 8.1). If DI.GNUM0 and DI.GNUM1 are not set, P1-44 will automatically be the numerator of electronic gear ratio. Please switch GNUM0 and GNUM1 in stop status to avoid the mechanical vibration.



P2-61	GR5 G	ear Ratio (Numerato	ar Ratio (Numerator) (N3)	
	Operational Interface:	al Panel / Software	Communication	Related Section: -
	Default :			
	Contro Mode :			
	Unit :			
	Range :	1 ~ (2 ²⁹ -1)	1 ~ (2 ²⁹ -1)	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P2-60.

8-121 Revision February, 2017

Address: 027CH P2-62 GR6 Gear Ratio (Numerator) (N4) 027DH Related Section: -Operational Panel / Software Communication Interface: Default: 128 Control Mode: Unit: pulse Range: $1 \sim (2^{29}-1)$ Data Size: 32-bit

Settings: Please refer to the description of P2-60.

P2-63 ~ P2-64

Reserved

Format : Decimal

Address: 0282H P2-65 **GBIT** Special-bit Register 0283H Related Section: -Operational Panel / Software Communication Interface: Default: 0 Control PT/PR/S Mode: Unit: -Range: $0 \sim 0 \times FFFF$ Data Size : -Format : -

Settings:


Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Bit15	Bit14	Bit13	Bit12		Bit10	Bit9	Bit8

- Bit 3, 4, 5, 7 and Bit14: Reserved, please set to 0.
- Bit 0 ~ Bit1

Bit 0: SPD0/SPD1 speed trigger mode (0: level triggered; 1: rising-edge triggered) Bit 1: TCM0/TCM1 torque trigger mode (0: level triggered; 1: rising-edge triggered)

8-122 Revision February, 2017

When rising-edge is triggered, refer to the following for the setting of register command:



- A: Execute internal register command 1
- B: Execute internal register command 2
- C: Execute internal register command 3
- D: Execute internal register command 3
- Bit 2: IGBT software protection
 - 0: Enable the function of IGBT software protection
 - 1: Disable the function of IGBT software protection
- Bit 6: In PT mode, the switch of pulse error protection function (pulse frequency is over high)
 - 0: Normally use the function of pulse error protection
 - 1: Disable the function of pulse error protection
- Bit 8 : U, V, W wiring error protection
 - 1: Enable U, V, W wiring error protection
- Bit 9: U, V, W wiring cut-off detection
 - 1: Enable U, V, W wiring cut-off detection
- Bit 10: DI.ZCLAMP function selection


When the following conditions are all established, the function of ZCLAMP is enabled.

Condition 1: speed mode


Condition 2: DI. ZCLAMP is on.

Condition 3: Motor speed is slower than the value of P1-38.


0: The command source is analog, ZCLAMP function will use the analog speed command without acceleration / deceleration processing to judge if this function should be enabled. The motor will be locked at the position where ZCALMP conditions are established.




0: The command source is register. ZCLAMP function will use the register speed command with acceleration / deceleration processing to judge if this function is enabled. The motor will be locked at the position where ZCALMP conditions are established.



1: The command source is analog speed command. ZCLAMP function will use the analog speed command without acceleration / deceleration processing to judge if this function is enabled. When ZCALMP conditions are established, the motor speed decelerates to 0 through S-curve. If not, the motor follow the analog speed command through S-curve.



1: The command source is register. ZCLAMP function will use the register with acceleration / deceleration processing to judge if this function is enabled. When ZCLAMP conditions are established, the motor speed will be set to 0.



- Bit 11: Pulse inhibit function
 - 0: Disable NL / PL pulse input inhibit function. In PT mode, the external position pulse command will be input into the servo drive in any condition.
 - 1: Enable NL / PL pulse input inhibit function. In PT mode, if NL exists, the external NL pulse will be inhibited to input to the servo. PL pulse input will be accepted. In PT mode, if PL exists, the external PL pulse will be inhibited to input to the servo. NL pulse will be accepted.

Please note: In PT mode, if NL and PL both exist, both of them will be inhibited to input to the servo.

Bit12: Lack phase detection

8-124 Revision February, 2017

- 0: Enable lack phase (AL022) detection
- 1: Disable lack phase (AL022) detection
- Bit13: Encoder output error detection function
 - 0: Enable encoder output error (AL018) detection function
 - 1: Disable encoder output error (AL018) detection function
- Bit15: Friction compensation mode selection
 - 0: If the speed is slower than the value of P1-38, the compensation value remains.
 - 1: If the speed is slower than the value of P1-38, the compensation will become 0 according to the smoothing time of P1-63.

P2-66	GBIT2 Sp	pecial-bit Register 2		Address: 0284H 0285H
	Operational Interface:	l Panel / Software	Communication	Related Section: -
	Default:	0		
	Contro Mode :	PT/PR/S		
	Unit :	0 ~ 0x000F		
	Range :			
	Data Size :			
	Format :	Hexadecimal		

Settings : Special-bit Register 2:

B7	В6	B5	B4	В3	B2	B1	В0
-	-	-	-	-	-	-	-

B0~B1: Reserved

B2: Cancel latch function of low-voltage error

0: Latch function of low-voltage error: the error will not be cleared automatically.

1: Cancel latch function of low-voltage error: the error will be cleared automatically.

B3: Reserved

B4: Cancel the detection of AL.044

0: AL.044 will occur

1: AL.044 will be ignored.

B5: Enable disconnection detection of linear scale (only when the fullclosed loop control function is enabled)

0: AL.041 will be ignored

1: AL.041 will occur

B6~B8: Reserved

B9: When AL.003 occurs, switch on DO.ALM or DO.WARN

0: When AL.003 occurs, switch on DO.WARN.

1: When AL.003 occurs, switch on DO.ALM

B10~B15: Reserved.

2-67	JSL Th	e Stable Level of Inertia Estimation		Address: 0286H 0287H
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	1.5	15	
	Control Mode :	ALL		
	Unit :	1times	0.1times	
	Range :	0 ~ 200.0	0 ~ 2000	
	Data Size :	16-bit		
	Format :	One decimal	Decimal	
	Example :	1.5 = 1.5 times	15 = 1.5 times	

Settings: In semi-auto mode, if the value of inertia estimation is smaller than P2-67 and the status remains for a while, the system will regard the inertia estimation as completed.

8-126 Revision February, 2017

Address: 0288H P2-68 **TEP Switch of Following Error Compensation** 0289H Related Section: -Operational Panel / Software Communication Interface: Default: 0 Control ALL Mode: Unit: -Range: 0x00000000 ~ 0x00002101 Data Size: 16-bit Format: Hexadecimal

Settings: X = 0: P1-36 > 1, following error compensation is disabled.

1: P1-36 > 1, following error compensation is enabled.

(The function is available after V1.036 sub00)

Y = 0: When E-CAM is engaged, JOG cannot work.

1: When E-CAM is engaged, JOG can work.

(This function is not available now.)

Z = 0: DI.STP is triggered by rising edge.

1: DI.STP is level triggered.

(The function is available after V1.042 sub00)

U = 0: unit is 0.1 rpm in speed mode

1: unit is 0.01 rpm in speed mode

2: unit is 0.05 rpm in speed mode

-69∙	ABS Absolute Encoder Setting		Address: 028AH 028BH	
	Operation Interfaction	onal Panel / Software e:	Communication	Related Section: N/A
	Defau	It : 0		
	Con Mod	e : ALL		
	Un	it: N/A		
	Rang	e: 0x0000 ~ 0x0011		
	Data Siz	e: 16-bit		
	Forma	at : Hexadecimal		
	Sottings	s · Format·II 7 V V		

Settings: Format: UZYX

X: Setup the operation mode

0: Incremental mode. Servo motor with absolute encoder can be

operated as incremental motor.

- 1: Absolute mode. (This setting is only available for the servo motor with absolute encoder. When an incremental servo motor is connected, AL069 will occur.)
- Y: Setup the pulse command when absolute position is lost
 - 0: When AL060 or AL06A occurs, it cannot accept pulse command
 - 1: When AL060 or AL06A occurs, it can accept pulse command
- Z: Function setting when index coordinates overflow
 - 0: Index coordinates is lost when overflows
 - 1: Index coordinates will not overflow, but absolute coordinates will not remain

U: Reserved

NOTE This parameter is effective only after the servo drive is re-powered on.

Address: 028CH P2-70 **MRS Read Data Format Selection** 028DH Operational: Related Section: N/A Panel / Software Communication Interface: Default: 0x0 Control: :ALL Mode: Unit: N/A Range: $0x00 \sim 0x07$ Data Size: 16-bit Format : Hexadecimal

Settings:

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8

Bit 0: Data unit setting of digital input/output (DI/DO);

1: Pulse, 0: PUU

Bit 1: Communication data unit setting; 1: Pulse, 0: PUU

Bit 2: Overflow warning; 1: No overflow warning, 0: Overflow warning, AL.289 (PUU), AL.062 (pulse).

Bit 3 ~ Bit15: Reserved. Must be set to 0.

8-128 Revision February, 2017

Address: 028EH **CAP Absolute Position Homing** 028FH Related Section: N/A Operational: :Panel / Software :Communication Interface: Default: 0x0 Control Mode: Unit: N/A Range: $0x0 \sim 0x1$ Data Size: 16-bit Format: Hexadecimal

Settings: When P2-71 is set to 1, the current position will be set as home position. This function is the same as the digital input, ABSC. This function can

be enabled only when parameter P2-08 is set to 271.

P2-72 Reserved

P2-71■

ALOP	E-Cam Alignment - Օր	Address: 0292H 0293H	
Operation Interfaction	nal Panel / Software e :	Communication	Related Section: N/A
Defau	t: 0x0000000		
	Control: PR Mode:		
Un	it: N/A		
Rang	nge : 0x00000000 ~ 0x5F3F6F5F		
Data Siz	ata Size : 32-bit format = DCBA : UZYX		
Forma	Format : Hexadecimal		

Settings: (This function is available in firmware version V1.038 sub26 and later models)

YX: Range of filter $(0 \sim 95\%)$

UZ: Max. allowable correction rate (0 ~ 100%)

BA: PR number $(0 \sim 63)$

DC: Masking range setting (0 ~ 95%)

YX: Range of filter (%)

When digital input, ALGN is triggered, E-Cam alignment function is enabled. The system will detect the current E-Cam position. When the error between current E-Cam position and the last alignment position is less than this setting range (%), filter function is enabled

and the system will average the errors before correction to avoid noise. If the error is bigger than filter threshold, the system will use the new position to do the correction.

YX	00	01 ~ 05F
Function	Disabled	Error <= (1~YX) % : Enabled

^{*}Using filter will allow the alignment action to be more stable and reduce position error caused by digital input noise.

UZ: Max. Max. allowable correction rate (%)

When alignment correction is enabled, the limitation of max. correction rate (C) for each correction is defined as follows:

| C | <= (P5-84/P5-83) x P2-73 UZ %

*When the alignment error is too big, to correct this error with one time may cause the motor vibration or overloading. Using this parameter will break the alignment correction into several smaller actions to smooth the correction action. But it may need more time to finish the alignment correction.

BA: PR number

After each alignment action is done, the shortage of pulse numbers of slave axis will be stored in this specified PR. Using this PR can compensate the slave position at appropriate timing.

*If BA is set to 0, it will not store the shortage of pulse numbers to PR.

DC: Masking range setting (%)

When digital input, ALGN is triggered, no another alignment action is allowed before the increasing pulse numbers of master axis exceeds the masking distance (M). After the increasing pulse numbers of master axis is greater than the distance (M) masking, the next alignment action is allowed.

The masking distance (M) is defined as follows:

 $M >= (P5-84/P5-83) \times P2-73 DC \%$

*This masking function only allows increasing pulse input. This function will not work for decreasing pulse input.

P2-74

		am Alignment - DI mpensation	Address: 0294H 0295H	
Operatio Interface		Panel / Software	Communication	Related Section: N/A
Defau	lt:	0.000		1 : : : :
Control Mode :		PR		- - - - - - - - - -
Unit: ms with fraction down to usec		! : : :		
 Range : -25.000 ~ +25.000, with 3 fraction digits		= : : : :		

8-130 Revision February, 2017

Data Size: 16-bit

Format: Decimal

Settings: (This function is available in firmware version V1.038 sub26 and later

models)

This parameter is used to set for the compensation of delay time from

digital input.

P2-75∎	ALTG E-Cam Alignment - Alignment Target Position			Address: 0296H 0297H
	Operationa Interface :	·Danal / Caftwara	Communication	Related Section: N/A
	Default :	0		
	Contro Mode :	: PR		
	Unit :	The pulse unit of Ma	aster axis	
	Range :	0 ~ (P5-84 /P5-83)-	1	
	Data Size :	32-bit		** : : : : : : : : : : : : : : : : : :
	Format :	Decimal		!

Settings: (This function is available in firmware version V1.038 sub26 and later models)

Note: When the input value is over the setting range, an error will occur. Then, the user cannot input the setting value.

Note: When a correct value is already set in P2-75 and does not exceed the setting range, if a change on P5-84 or P5-83 cause the value to exceed the setting range, this parameter will be reset to 0 automatically.

New value of P2-75 = 0 if P2-75 >= (P5-84 / P5-83)

2-76∎	ALCT E-0	Cam Alignment - So	urce Setting	Address: 0298H 0299H
	Operational Interface : Panel / So Default : 0x0000 Control Mode : PR	Panel / Software	Communication	Related Section: N/A
		0x0000		
	Unit :	N/A		
Range :	0x0000 ~ 0x6FF7			
	Data Size :	16-bit		

Format : Hexadecimal

Settings: (This function is available in firmware version V1.038 sub26 and later

models)

Format=UZYX. The functions are listed below.

X: E-CAM Alignment Control

Bit	Bit 3	Bit 2	Bit 1	Bit 0
Function	Reserved	Phase Alignment Category	Trigger PR immediately	Enable Alignment
Description	-	Set 0 to disable the function. Set 1 to enable the function. This function is applicable to film delivery control of reverse flying shear.	Set 1 to enable. When the alignment DI is triggered, the correcting error will be calculated and stored in PR specified by P2-73. If this bit is set to 1, trigger the PR immediately after DI activated, otherwise the user should trigger the PR manually or use P5-88.BA to call the PR when E-Cam disengaged.	Set 0 to disable. Set 1 to enable. If enable, the E-CAM alignment correction will be executed when DI.ALGN ON.

Y: Filter intensity

Y	0	1 ~ F
Function	Disabled	Average of 2 [^] Z: Enabled

When the value of Y is increased, the change of correction is getting slow and it can expedite the performance of the filter function. This can avoid the disturbance caused by a sensor noise and a big error to be corrected within one time. Setting P2-76 too big will cause the alignment not able to work properly. The recommendatory value is 3.

UZ: Alignment path definition. Forward direction as setting \cdot reference here (0 ~ 100%)

0: Backward alignment only

30: Forward 30%, Backward 70%

50: Alignment with the shortest distance

80: Forward 80%, Backward 20%

>=100: Forward alignment only

P2-77∎	CMSK E-Cam Master Axis – I	Address: 029AH 029BH	
	Operational Interface : Panel / Software	Communication	Related Section: N/A
	Default: 0000h		
	Control Mode :		

8-132 Revision February, 2017

Unit: N/A

Range : |0000h ~ 0xFF7D

Data Size : 16-bit

Format : Hexadecimal

Settings: (This function is available in firmware version V1.038 sub54 and later models)

X: Pulse masking function of master axis / JOG function of master axis / INCH function of master axis

Y: Correction of lead command length for pulse masking

Y3	Y2	Y1	Y0
-	Extra 1 Cycle	Write to ROM	CALC
-	Calculate the value of P5-87 and plus a cycle of a resolution of pulse command, i.e. (P5-84/P5-83).	Calculate the value of P5-87 and write the value of P5-87 into EEPROM at the same time to ensure the correct position of E-Cam after the servo drive is restarted (after switching power off and on).	Calculate the value of P5-87.

- Y=0 → 1: Calculate the value of P5-87 correctly according to actual masking pulse number and additional virtual pulse number.
- Y=0 → 2: Calculate the value of P5-87 correctly according to actual masking pulse number and additional virtual pulse number. Then, write the revised value of P5-87 into EEPROM to keep the same phase after the servo drive is restarted.
- Y=0 → 7: Calculate the value of P5-87 correctly according to actual masking pulse number and additional virtual pulse number.

 But, the revised value of P5-87 will plus a value of (P5-84/P5-83) to make lead pulse wait for an E-Cam cycle.
- UZ: Pulse data when the master axis performs JOG or INCH function

For example:

Start masking → UZYX = 0x0001

 $JOG +3Kpps \rightarrow UZYX = 0x0302$

 $JOG + 20Kpps \rightarrow UZYX = 0x1402$

 $JOG -32Kpps \rightarrow UZYX = 0x2003$

INCH +255 PLS → UZYX = 0xFF04

INCH -18 PLS → UZYX = 0x1205

Complete and correct lead pulse \rightarrow UZYX = 0x0020 (Write into EEPROM)

Disable this function \rightarrow UZYX = 0x0000 (This step can be ignored)

P2-78

CIVIAP	Cam: Area Number #2 esitive)	Address: 029CH 029DH	
Operationa Interface:	Panel / Software	Related Section: N/A	
Default:	270		
Contro Mode :	PR		
Unit :	degree (it becomes de version V1.038 sub25	gree in firmware and later models)	
Range :	0 ~ 360		
Data Size :	16-bit	1 1 2 2	
Format :	Decimal		

Settings : P2-78 <= P2-79:

E-Cam degree	0°	~	P2-78	~	P2-79	~	360°
DO:CAM_AREA2	OFF	OFF	ON	ON	ON	OFF	OFF

P2-78 > P2-79:

E-Cam degree	0°	~	P2-79	~	P2-78	~	360°
DO:CAM_AREA2	ON	ON	OFF	OFF	OFF	ON	ON

When the E-Cam is disengaged, the status of digital output, CAM_AREA2 is always OFF.

P2-79

	E-Cam: Area Number Negative)	Cam: Area Number #2 - (Polarity is gative)					
Operation Interface	nal Panel / Software	Communication	Related Section: N/A				
Defaul	t: 360	360					
Cont Mode	PR						
Uni	t : degree (it becomes version V1.038 sub2	degree (it becomes degree in firmware version V1.038 sub25 and later models)					
Range	e: 0 ~ 360						
Data Size							
Forma	t : Decimal						
Cattings	. D2 70 <= D2 70		•				

Settings : P2-78 <= P2-79:

E-Cam degree	0°	~	P2-78	~	P2-79	~	360°
DO:CAM_AREA2	OFF	OFF	ON	ON	ON	OFF	OFF

P2-78 > P2-79:

8-134 Revision February, 2017

E-Cam degree	0°	~	P2-79	~	P2-78	~	360°
DO:CAM_AREA2	ON	ON	OFF	OFF	OFF	ON	ON

When the E-Cam is not engaged, the status of digital output, CAM_AREA2 is always OFF.

P2-80		Z Phase Source of	Address: 02A0H 02A1H	
	Operational Interface :	Panel / Software	Communication	Related Section: N/A
	Default :	0x0000		
	Control Mode :	PR		
	Unit:	-		
	Range :	0x0000 ~ 0x0011		
	Data Size :	16-bit		
	Format :	Hexadecimal		
	Setting:		nase source of full-closed loop homing nase source of half-closed loop homing	

- Z phase source of full-closed loop homing
 - 0: Auxiliary encoder
 - 1: Motor
- Z phase source of half-closed loop homing
 - 0: Motor
 - 1: Auxiliary encoder

P3-xx Communication Parameters

Range: $0x01 \sim 0x7F$

Format : Hexadecimal

Data Size: 16-bit

P3-00∙	ADR	Address Setting	dress Setting				
		nal Panel / Software e :	Communication	Related Section: 9.2			
	Defaul	t : 0x7F					
	Con	1					
	Uni	t : -					

Settings · The communication address setting is divided into Y, X (hexadecimal):

	0	0	Y	Х
Range	-	-	0 ~ 7	0 ~ F

When using RS-232/RS-485 to communicate, one servo drive can only set one address. The duplicate address setting will cause abnormal communication.

This address represents the absolute address of the servo drive in communication network. It is also applicable to RS-232, RS-485, CANopen and DMCENT.

When the communication address setting of MODBUS is set to 0xFF, the servo drive will automatically reply and receive data regardless of the address. However, P3-00 cannot be set to 0xFF.

8-136 Revision February, 2017

P3-01

BRT Tra	ansmission Speed	Address: 0302H 0303H	
Operationa Interface :	Panel / Software	Communication	Related Section: 9.2
Default:	0x0203		
Contro Mode :	ALI		
Unit:	bps		
Range :	0x0000 ~ 0x0405		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: The setting of transmission speed is divided into Z, Y, X (hexadecimal):

	U	Z	Y	Х
Communication Port	DMC	CAN / DMC	-	RS-232/485
Range	0/3	0~4	0	0~5

- Definition of X setting value
 - 0:4800
 - 1:9600
 - 2: 19200
 - 3: 38400
 - 4: 57600
 - 5: 115200
- Definition of Z setting value
 - 0: 125 Kbit/s
 - 1: 250 Kbit/s
 - 2: 500 Kbit/s
 - 3: 750 Kbit/s
 - 4: 1.0 Mbit/s
- Definition of Z setting value
 - 0: Use Delta's controller, such as PLC and HMI
 - 3: Use Delta's motion card



- NOTE 1) If this parameter is set via CAN, only Z can be set and the others remain.
 - 2) The communication speed of USB is 1.0 Mbit/s only and is unchangeable.

8-137 Revision February, 2017

Address: 0304H P3-02 **PTL Communication Protocol** 0305H Operational Related Section: Panel / Software Communication 9.2 Interface: Default: 6 Control ALL Mode: Unit: -Range: $0 \sim 0x8$ Data Size: 16-bit Format: Hexadecimal The definition of the setting value is as the followings: Settings: 0: 7, N, 2 (MODBUS, ASCII) 1: 7, E, 1 (MODBUS, ASCII) 2: 7, O,1 (MODBUS, ASCII)

3: 8, N, 2 (MODBUS, ASCII)
4: 8, E, 1 (MODBUS, ASCII)
5: 8, O, 1 (MODBUS, ASCII)
6: 8, N, 2 (MODBUS, RTU)
7: 8, E, 1 (MODBUS, RTU)

8: 8, O, 1 (MODBUS, RTU)

Address: 0306H P3-03 **FLT Communication Error Disposal** 0307H Related Section: Operational Panel / Software Communication 9.2 Interface: Default: 0 Control Mode: Unit: :-Range: $0 \sim 0x1$

Settings: The definition of the setting value is as the following:

0: Warning and keeps running

Data Size: 16-bit

Format: Hexadecimal

1: Warning and stops deceleration (The deceleration time is set to parameter P5-03.B)

8-138 Revision February, 2017

3-04	CWD	Co	mmunication Time	Address: 0308H 0309H	
	Operationa Interface :		Panel / Software	Communication	Related Section: 9.2
	Defau	lt:	0	·	
	Con Mod		ALL		
	Un	Unit : sec			
	Range :		0 ~ 20		
	Data Size :		16-bit		
	Forma	at : DEC			
	Setting			s not 0, enable communica set to 0, disable the functio	

P3-05		ommunication Mech	Address: 030AH 030BH	
	Operationa Interface:	l Panel / Software	Communication	Related Section: 9.2
	Default :	0		
	Contro Mode :	ALL		
	Unit:	-		
	Range :	0x00 ~ 0x01		
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Communication port can select one or more than one communications.

Communication Interface

0: RS232 1: RS485

6∎	SDI C	Control Switch of Digi	ital Input (DI)	Address: 030CH 030DH
	Operation Interface	Donal / Coffusoro	Communication	Related Section: 9.2
	Default	: 0		
	Contr Mode	ALI		
	Unit	: -		
	Range	: 0x0000 ~ 0x3FFF		
	Data Size	; 16-bit		
	Format	: Hexadecimal		

Settings: The source of DI controls the switch.

P3-0

Each bit of this parameter decides one input source of DI signal:

Bit0 ~ Bit7 correspond to DI1 ~ DI8.

Bit8 ~ Bit13 correspond to extended DI EDI9 ~ EDI14;

The setting of bit is as the followings:

0: The input status is controlled by the external hardware.

1: The input status is controlled by P4-07.

For the functional planning of digital input, please refer to:

DI1 ~ DI8: P2-10 ~ P2-17 EDI9 ~ EDI14: P2-36 ~ P2-41

P3-07	CDT Co	mmunication Resp	onse Delay Time	Address: 030EH 030FH
	Operational Interface:	Panel / Software	Communication	Related Section: 9.2
	Default :	0		
	Control Mode :	ALL		
	Unit:	1ms		
	Range :	0 ~ 1000		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: Delay the time of communication response from servo drive to

controller

8-140 Revision February, 2017

P3-08**■**

MNS Mo	onitor Mode		Address: 0310H 0311H
Operational Interface :	Panel / Software	Communication	Related Section: 9.2
Default :	0000		
Control Mode :	ALL		
Unit:	-		
Range :	Shown as below		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: The setting of monitor mode is divided into L and H. (hexadecimal):

Item	-	-	L	Н
Function	-	-	Low-speed monitoring time	Monitor Mode
Range	0	0	0 ~ F	0 ~ 3

The status of this axis or multi-axis can be monitored by USB. The definition of setting value is as follows:

- The definition of H setting value
 - 3: USB is high-speed monitor. The sampling frequency is 16K and can only monitor 2CH.
 - 2: USB is high-speed monitor. The sampling frequency is 8K and can monitor 4CH.
 - 1: USB is low-speed monitor. The sampling time is set by L and can monitor 4CH.
 - 0: disable the monitor function
- L: the sampling time of USB low-speed monitor. Its unit is ms. It means the axial status will be set via USB every L ms. So the controller can monitor the axial status. Each monitoring message includes 4 CH data (16 bit x 4). If L is set to 0, this function is disabled. L is enabled when H is set to 1.

P3-09

SYC CA	Nopen / DMCNET S	Address: 0312H 0313H	
Operationa Interface :	Panel / Software	Communication	Related Section: 9.2
Default :	0x5055 (for -B, -L, -N 0x3511 (for -F type)	M, -U type)	
Contro Mode :	CANopen / DMCNE	Т	
Unit :	-		
Range :	Shown as below		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: The synchronous setting of CANopen / DMCNET is divided into E, T, D and M (hexadecimal):

Item	E	Т	D	M
Function	Range of Synchronous error	Target Value	Deadband	Adjusting amount
Range	1 ~ 9	0 ~ 9	0 ~ F	1 ~ F

The slave of CANopen / DMCNET synchronizes with the master via SYNC. See as the followings:

- M: If the slave needs to synchronize with the master, correct the clock is a must. This parameter sets the maximum correction value per time. (Unit: usec)
- D: Set the size of deadband (Unite: usec). If the deviation between the SYNC reaching time and the target value does not exceed the deadband, correction is no need.
- T: SYNC arrival time. The standard value is 500usec but it might be different from the target value. Thus, the buffer is necessary.

Target value = $400 + 10 \times T$.

For instance, if T=5, the target value will be 450.

E: If the deviation between SYNC reaching time and the target value is smaller than the range, it means the synchronization is successful. (Unit: 10 usec)

8-142 Revision February, 2017

Address: 0314H CANEN | CANopen / DMCNET Protocol Setting 0315H Related Section: Operational Panel / Software Communication Section 9.2 Interface: Default: 0x0000 Control CANopen / DMCNET Mode: Unit: -Range: Shown as below Data Size: 16-bit Format: Hexadecimal

Settings: CANopen / DMCNET synchronization setting is divided into X, Y, Z, U (hexadecimal):

Item	U	Z	Y	X
Function	If PDO alarm will be cleared automatically	Reserved	If motor will servo off when CAN Bus / DMCNET error occurs	Reserved
Range	0 ~ 1	0 ~ F	0 ~ 1	0 ~ 1

Definition:

P3-10

- X: Reserved
- Y: 0: The motor keeps running when communication error occurs;
 - 1: The motor servo Off when communication error occurs.
- Z: Reserved
- U: 0: If PDO error occurs, it must be cleared by Alarm Rest
 - 1: If PDO error occurs, it will be cleared automatically.

Note:

For A2-M, X bit is invalid.

For A2-F, it is suggested to set X to 1.

P3-11

Address: 0316H **CANOP** | CANopen / DMCNET Selection 0317H Related Section: Operational Panel / Software Communication Section 9.2 Interface: Default: 0x0000 Control CANopen / DMCNET Mode: Unit: -Range: Shown as below Data Size: 16-bit Format: Hexadecimal

Settings: Synchronous / DMCNET setting of CANopen is divided into X, Y, Z and U (hexadecimal):

Item	U	Z	Y	X
Function	Undefined	Undefined	Undefined	Whether the parameter is saved into EEPROM
Range	-0 ~ 1	0 ~ F	0 ~ F	0 ~ 1

The definition is as follows:

X = 1: When writing parameters via PDO, parameters will be saved in EEPROM.

X = 0: When writing parameters via PDO, parameters will not be saved in EEPROM.

Y, Z, U: Undefined

NOTE If X is set to 1 and write parameters by PDO continuously, it will shorten the lifetime of EEPROM.

P3-12	QSTPO CA	Nopen / DMCNET S	Address: 0318H 0319H	
	Operational Interface :	Panel / Software	Communication	Related Section: Section 9.2
	Default :	0x0000		
	Control Mode :	CANopen / DMCNE	T	
	Unit :	-		
	Range :	0x0000 ~ 0x0111		
	Data Size :	16-bit		
	Format :	Hexadecimal		

8-144 Revision February, 2017

Settings: CANopen / DMCNET synchronization setting is divided into X, Y, Z, U (hexadecimal):

Item	U	Z	Y	X
Function	None	CANopen / DMCNET value will be loaded in	If the motor will enter Quick Stop mode when in auto protection.	If OD-6040 supports Quick Stop
Range	None	0~1	0 ~ 1	0 ~ 1

Aiming to CANopen Quick Stop mode, we have X and Y setting (Hexadecimal.) which is showed as below. It is only suitable in CAN mode: oxb mode selection (P1-01 = b).

- X: Trigger Servo ON sequence and Quick Stop support setting
- X = 0: Servo On the servo drive by turning On OD-6040 Bit 3 (Enable Operation). OD-6040 Bit 2 enters Quick Stop mode is not supported.
- X = 1: The servo drive can be Servo ON only when OD-6040 Bit 0, Bit1, Bit 3 are ON. And will enter Quick Stop mode via OD-6040 Bit2 (Quick Stop)
- Y: When warning alarms (positive / negative limit, communication error, under voltage, abnormal fan) occur, it can determine if Quick Stop mode can be triggered.
- Y = 0: When warning alarms occur, if motor decelerates to stop because of auto protection function, it will not enter Quick Stop mode. Users only need to troubleshoot the alarm and clear the alarm message from the servo drive, the servo drive status will resume.
- Y = 1: When warning alarms occur, if motor decelerates to stop because of auto protection function, OD-6040 will enter Quick Stop mode. Users have to issue Fault Reset to continue other commands and clear the alarm message from the servo drive.

The following table shows P parameters and its corresponding CANopen OD or DMCNET parameter. The setting of Z (Hexadecimal.) can determine if it should be modified. This function is applicable in CAN mode: 0xB or 0xC (P1-01 = b or c) or DMC mode: 0xB (P1-01 = b).

- Z: Determine if the value of OBJECT will overlap parameters from P groups.
- Z = 0: When re-servo on the servo drive or reset the communication, P parameters that mentioned in the following table will load in the default value in CANopen /DMCNET mode.
- Z = 1: When re-servo on the servo drive or reset the communication, P parameters that mentioned in the following table will keep the value that before power off.

CANopen mode:

Related variables during initialization	P3-12.Z = 0	P3-12.Z = 1	Note
P1-32	0x0010	EEPROM	
P2-35	3840000	EEPROM	_

P1-47	10	EEPROM	
P1-49	0	EEPROM	
P1-38	100	EEPROM	
Home offset	0	EEPROM	Used in HM mode
P1-44	1	EEPROM	
P1-45	1	EEPROM	

DMCNET mode:

Related variables during initialization	P3-12.Z = 0	P3-12.Z = 1	Note
P1-32	0x0010	EEPROM	
P2-35	3840000	EEPROM	
P1-47	100	EEPROM	
P1-49	0	EEPROM	
P1-38	100	EEPROM	
Home offset	0	Undefined	Used in HM mode
Acc	200	Undefined	Used in PV, PP mode
Dec	200	Undefined	Used in PV, PP mode
P1-44	1	EEPROM	
P1-45	1	EEPROM	

Methods that save parameters in EEPROM (even when the power is off):

SDO: When setting parmeters, parameters will be stored in EEPROM.

PDO: Please refer to the setting of P3-11.X

X = 1: When setting parameters via PDO, parameters will be stored in EEPROM.

X = 0: When setting parameters via PDO, parameters will not be stored in EEPROM.

Note: In CANopen mode, when using the funciton of OD 1010 Store Parameter and P3-12.Z = 0, the default value will be different from the value that showed above. Please refer to CANopen Standard for further information.

8-146 Revision February, 2017

P4-xx Diagnosis Parameters

P4-00★

ASH1 Fa	ult Record (N)	Address: 0400H 0401H	
Operational Interface :	Panel / Software	Communication	Related Section: 4.4.1
Default :	0		
Control Mode :	ALL		
Unit :	-		
Range :	-		
Data Size :	32-bit		
Format :	Hexadecimal		

Settings: The last abnormal status record

Low word: LXXXX: display ALM number

High word: hYYYY: display the error code corresponds to CANopen /

DMCNET.

ASH2 F	ault Record (N-1)	ult Record (N-1)		
Operational Interface	Panel / Software	Communication	Related Section: 4.4.1	
Default	: 0	0		
Contro Mode	I A I I			
Unit	-			
Range	-			
Data Size	32-bit			
Format	Hexadecimal			

Settings: The last second abnormal status record

Low word: LXXXX: display ALM number

High word: hYYYY: display the error code corresponds to CANopen /

DMCNET

Address: 0404H P4-02★ ASH3 Fault Record (N-2) 0405H Related Section: Operational Panel / Software Communication 4.4.1 Interface: Default: 0 Control Mode : ALL Unit: -Range: -Data Size: 32-bit

Settings: The last third abnormal status record

Low word: LXXXX: display ALM number

High word: hYYYY: display the error code corresponds to CANopen /

DMCNET

Format: Hexadecimal

Address: 0406H P4-03★ ASH4 Fault Record (N-3) 0407H Operational Related Section: Panel / Software Communication Interface: 4.4.1 Default: 0 Control Mode : ALL Unit: -Range: -Data Size: 32-bit Format : Hexadecimal

Settings: The last fourth abnormal status record

Low word: LXXXX: display ALM number

High word: hYYYY: display the error code corresponds to CANopen /

DMCNET

8-148 Revision February, 2017

P4-04★

ASH5 Fac	ult Record (N-4)	Address: 0408H 0409H	
Operational Interface :	Panel / Software	Communication	Related Section: 4.4.1
Default :	0		
Control Mode :	ALL		
Unit :	-		
Range :	-		
Data Size :	32-bit		
Format :	Hexadecimal		

Settings: The last fifth abnormal status record

Low word: LXXXX: display ALM number

High word: hYYYY: display the error code corresponds to CANopen /

DMCNET

P4-05

Settings: Three control methods are as follows:

1. Operation Test

After the JOG speed is set by P4-05 via panel, the panel will display the symbol of JOG. Pressing the UP Key can control JOG operation in positive direction, pressing the DOWN Key can control negative direction. Stop pressing to stop the JOG operation. If there is any error in this setting, then the motor cannot operate. The maximum JOG speed is the maximum speed of the servo motor.

2. DI Control

If the DI is set to JOGU and JOGD (refer to table 8.1), then the JOG operation in positive or negative direction can be controlled via this DI.

3. Communication Control

1 ~ 5000: JOG speed

4998: JOG operation in positive direction

4999: JOG operation in negative direction

0: Stop operation



NOTE When writing via communication, if the frequency is high, please set P2-30 to 5.

P4-06▲■	F()	gital Output Regis itable)	ter (Readable and	Address: 040CH 040DH
	Operational Interface :	Panel / Software	Communication	Related Section: 4.4.3
	Default :	0		
	Control Mode :	ALL		
	Unit :	-		
	Range :	0 ~ 0xFF		
	Data Size :	16-bit		
	Format :	Hexadecimal		
	Settings:	bit 00: correspond to D	O code=0x30	
		bit 01: correspond to D	O code=0x31	
		bit 02: correspond to D	O code=0x32	
		bit 03: correspond to D	O code=0x33	
		bit 04: correspond to D	O code=0x34	
		bit 05: correspond to D	O code=0x35	
		bit 06: correspond to D	O code=0x36	
		bit 07: correspond to D	O code=0x37	
		bit 08: correspond to D	O code=0x38	
		bit 09: correspond to D	O code=0x39	
		bit 10: correspond to D	O code=0x3A	
		bit 11: correspond to D	O code=0x3B	
		bit 12: correspond to D	O code=0x3C	
		bit 13: correspond to D	O code=0x3D	
		bit 14: correspond to D	O code=0x3E	
		bit 15: correspond to D		
			30, then the DO#1is bit (

8-150 Revision February, 2017


write into P4-06.

DO Code (0x30~0x3F) can be set via communication DO, and then

P4-07**■**

ITST Mu	ılti-function of Digital	Address: 040EH 040FH	
Operational Interface :	Panel / Software	Related Section: Section 4.4.4	
Default :	0		Table 9.2
Control Mode :	ALL		
Unit:	-		
Range :	0 ~ 0x3FFF		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: The DI input signal can come from external terminal (DI1 ~ DI8; EDI9 ~ EDI14) or software SDI1 ~ 14 (Bit 0 ~ 13 of corresponding parameter P4-07) and is determined by P3-06. The corresponding bit of P3-06 is 1, which means the source is software SDI (P4-07). If the corresponding bit is 0, then the source is hardware DI. See the following graph:



Read parameters: shows the DI status after combination

Write parameters: writes the software SDI status

For example:

The value of reading P4-07 is 0x0011, which means DI1 and DI5 is ON after combination.

The value of writing P4-07 is 0x0011, which means software SDI1 and SDI5 is ON.

Please refer to P2-10 ~ P2-17 for the function program of digital input pin DI (DI1~DI8) and P2-36 ~ P2-41 for extended DI (EDI9 ~ EDI14).

8-151 Revision February, 2017

P4-08★	PKEY	Inp	ut Status of the Drive	Address: 0410H 0411H	
	Operation Interface		Panel / Software	Communication	Related Section: -
	Defaul	lt:	-		
	Cont Mode		ALL		
	Uni	it:	-		
	Range	e :	(read-only)		
	Data Size	e :	16-bit		
	Forma	ıt:	Hexadecimal		

Settings: The aim is to check if the five Keys, MODE, UP, DOWN, SHIFT and SET can work normally. This parameter is also used to check if the $\frac{1}{2}$

Keys are all functional when producing servo drives.

P4-09★	MOT Dig	gital Output Status	Address: 0412H 0413H	
	Operational Interface :	Panel / Software Communication		Related Section: 4.4.5
	Default :	-		
	Control Mode :	ALL		
	Unit :	-		
	Range :	0 ~ 0x1F		
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Note: There is no difference whether read by panel or communication.

P4-10∎	CEN	Adjustment Selection		Address: 0414H 0415H
		onal Panel / Software e:	Communication	Related Section: -
	Defau			
	Con Mod	e: ^{ALL}		
	Un	it : -		

8-152 Revision February, 2017

> Range: 0 ~ 6 Data Size: 16-bit Format: Decimal

0: reserved Settings:

- 1: Execute the adjustment of analog speed input offset
- 2: Execute the adjustment of analog torque input offset
- 3: Execute the adjustment of current detector (V phase) hardware
- 4: Execute the adjustment of current detector (W phase) hardware offset
- 5: Execute the adjustment of 1~4 hardware offset
- 6: Execute the adjustment of IGBT ADC



NOTE The adjustment function needs to be enabled by the setting of parameter P2-08. When adjusting, the external wiring which connects to analog speed or torque needs to be removed completely and must be in Servo Off status.

P4-11	SOF1 An	nalog Speed Input C	Address: 0416H 0417H	
	Operationa Interface:	Panel / Software	Communication	Related Section: -
	Default : Factory default			
	Contro Mode :	ALL		
	Unit:	-		
	Range :	0 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings:

Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to adjust the auxiliary adjustment. This parameter cannot be reset.

8-153 Revision February, 2017

P4-12	SOF2	Analog Speed Input C	alog Speed Input Offset Adjustment 2		
	Operatio Interface	Danal / Caffurana	Communication	Related Section: -	
	Defaul	t : Factory default			
	Con Mode	: A I I			
	Uni	it : -			
	Range	e: 0 ~ 32767			
	Data Size	e : 16-bit			
	Forma	t : Decimal			

Settings: Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to

adjust the auxiliary adjustment. This parameter cannot be reset.

P4-13	TOF1 Analog Torque Input Offset Adjustment 1		Offset Adjustment 1	Address: 041AH 041BH
	Operationa Interface:	l Panel / Software	Communication	Related Section: -
	Default :	Factory default		
	Contro Mode :	: ALL : - : 0 ~ 32767		
	Unit :			
	Range :			
	Data Size :			
	Format :	Decimal		

Settings: Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to adjust the auxiliary adjustment. This parameter cannot be reset.

8-154 Revision February, 2017

P4-14	TOF2	Analog Torque Input (log Torque Input Offset Adjustment 2		
	Operation Interface	Donal / Cathware	Communication	Related Section: -	
	Default	: Factory default			
	Contr Mode	. Λ I I			
	Unit	: -			
	Range	: 0 ~ 32767			
	Data Size	: 16-bit			
	Format	: Decimal			

Settings: Manually adjust the hardware offset. The adjustment function needs to

be enabled by the setting of parameter P2-08. It is not suggested to adjust the auxiliary adjustment. This parameter cannot be reset.

P4-15	COF1 Current Detector (V1 Phase) Offset Adjustment			Address: 041EH 041FH
	Operation Interface	al Panel / Software :	Communication	Related Section: -
	Default	Factory default		
	Contr Mode	ol ALL	ALL - 0 ~ 32767	
	Unit	: -		
	Range	: 0 ~ 32767		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to

adjust the auxiliary adjustment. This parameter cannot be reset.

P4-16		Adjustment		
	Operation Interface	Donal / Cottinora	Communication	Related Section: -
	Default	: Factory default		
	Contr Mode	ALL		
	Unit	: -		
	Range	: 0 ~ 32767		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to

adjust the auxiliary adjustment. This parameter cannot be reset.

P4-17		Current Detector (W1 Phase) Offset Adjustment		Address: 0422H 0423H
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	ALL - 0 ~ 32767 16-bit		
	Control Mode :			
	Unit :			
	Range :			
	Data Size :			
	Format :			

Settings: Manually adjust the hardware offset. The adjustment function needs to be enabled by the setting of parameter P2-08. It is not suggested to adjust the auxiliary adjustment. This parameter cannot be reset.

8-156 Revision February, 2017

P4-18	(.()F4	rrent Detector (W2 Ph ljustment	rent Detector (W2 Phase) Offset ustment		
	Operational Interface:	Panel / Software	Communication	Related Section: -	
	Default :	Factory default			
	Control Mode :	ΛΙΙ			
	Unit:	-			
	Range :	0 ~ 32767			
	Data Size :	16-bit			
	Format :	Decimal			

Settings: Manually adjust the hardware offset. The adjustment function needs to

be enabled by the setting of parameter P2-08. It is not suggested to adjust the auxiliary adjustment. This parameter cannot be reset.

P4-19	111.5	BT NTC Adjustment Detection Level innot reset)		Address: 0426H 0427H	
	Operationa Interface:	:DI/O-#	Communication	Related Section: -	
	Default :	Factory default			
	Contro Mode :	ALL - 1~4			
	Unit :				
	Range :				
	Data Size :				
	Format :				

Settings: Please cool down the drive to 25 Celsius degree when adjusting

P4-20	1) () F 1		set Adjustment Val tput (Ch1)	Address: 0428H 0429H	
	Operational Interface : Default :		Panel / Software	Communication	Related Section: 6.4.4
			0		
	Control Mode :		ALL		
	Unit :		mV		
	Range :		-800 ~ 800		
			16-bit		
	Format : Decimal				
	Settings : Offset adjustment value (cannot reset)		alue (cannot reset)		

P4-21			set Adjustment Valu tput (Ch2)	e of Analog Monitor	Address: 042AH 042BH
	Operational Interface : Default :		Panel / Software	Communication	Related Section: 6.4.4
			0		
	Control Mode :		I ALL		
	Unit :		mV		
	Range :		-800 ~ 800 16-bit		
	Format :		Decimal		
	Setting	s:	Offset adjustment val	ue (cannot reset)	

P4-22	SAO	Analog Speed Input OFFSET		Address: 042CH 042DH
	Operatio Interface	nal Panel / Software e:	Communication	Related Section: -
	Default: 0			
	Con Mode	e: S		
		it : mV		

8-158 Revision February, 2017

Range: -5000 ~ 5000

Data Size: 16-bit

Format: Decimal

Settings: Users manually adjust the OFFSET

TAO Analog Torque Input OFFSET		Address: 042EH 042FH	
Operationa Interface:	l Panel / Software	Communication	Related Section: -
Default :	T mV -5000 ~ 5000		
Contro Mode :			
Unit:			
Range :			
Data Size :			
Format :	Decimal		
	Operationa Interface: Default: Contro Mode: Unit: Range: Data Size:	Operational Interface : Panel / Software Default : 0 Control	Operational Interface : Panel / Software Communication Default : 0 Control Mode : T Unit : mV Range : -5000 ~ 5000 Data Size : 16-bit

Settings: Users manually adjust the OFFSET

220V Series

P4-24	LVL L	evel of Under voltag	el of Under voltage Error		
	Operation Interface	al Panel / Software	Communication	Related Section: -	
	Default	: 160	160		
	Contr Mode	. Λ I I			
	Unit	: V (rms)	V (rms)		
	Range	: 140~190			
	Data Size	: 16-bit	16-bit		
	Format	: Decimal			

Settings : When the voltage of DC BUS is lower than P4-24* $\sqrt{2}$, the under voltage alarm occurs.

400V Series

P4-24			vel of Under voltage Error		Address: 0430H 0431H
	Operatio Interface	nal e :	Panel / Software	Communication	Related Section: -
	Defaul	lt:	320		
	Con Mode	:	ALL		
	Uni	it:	V (rms)		
	Range	e :	140~380		
	Data Size	е:	16-bit		
	Forma	ıt:	Decimal		

Settings : When the voltage of DC BUS is lower than P4-24* $\sqrt{2}$, the under voltage alarm occurs.

8-160 Revision February, 2017

P5-xx Motion Setting Parameters

P5-00	~
P5-0	2

Reserved

P5-03

PDEC	Deceleration Time of A	celeration Time of Auto Protection		
Operatio Interface		Communication	Related Section: -	
Defaul	t: 0XEEEFEEFF	0XEEEFEEFF		
Con Mode	ΔΙΙ			
Uni	t : -	-		
Range	e: 0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF		
Data Size	e : 32-bit			
Forma	t : Hexadecimal	Hexadecimal		

Settings:

The parameter setting is divided into D, C, B, A, W, Z, Y, X (hexadecimal), including:

- 1. The deceleration time when activating the auto-protection function: OVF (DO.0x11, poisiiton command / feedback overflows), CTO (communication timeout AL020), SPL, SNL, PL, NL
- 2. Deceleration time of Stop Command: STP


Item	D	С	В	Α	W	Z	Y	Х
Function	STP	PFQS	СТО	OVF	SNL	SPL	NL	PL
Range	0~F	0∼F	0~F	0~F	0~F	0~F	0~F	0~F

0 ~ F is used to indexing the deceleration time of P5-20~P5-35.

For example: If X is set to A, then the deceleration time of PL is determined by P5-30.

P5-04	HMOV H	oming Mode	ming Mode	
		al Panel / Software	Communication	Related Section: -
	Default :	0		
	Contro Mode :	ol PR		
	Unit :	-		
	Range :	0 ~ 0x128		





The definition of the setting value is as the followings:

W: Reserved Not in use


W	Z	Y	X
Reserved	Limit Setting	Z pulse Setting	Homing Method
-	0 ~ 1	0 ~ 2	0 ~ 8
		Y = 0: Stop and return to Z pulse	X = 0: Homing in forward direction and regard PL as the homing origin.
		Y = 1: Go forward to Z pulse Y = 2: Do not look	X = 1: Homing in reverse direction and regard NL as the homing origin.
	When encounter limit:	for Z pulse	X = 2: Homing in forward direction
	Z = 0: shows error		ORGP: OFF > ON, as the homing origin
	Z = 1: rotates backwards		X = 3: Homing in reverse direction
			ORGP: OFF > ON, as the homing origin
			X = 4: Look for Z pulse in forward direction and regard it as the homing origin
			X = 5: Look for Z pulse in reverse direction and regard it as the homing origin
			X = 6: Homing in forward direction
			ORGP: ON >OFF, as the homing origin
			X = 7: Homing in reverse direction ORGP: ON > OFF, as the homing origin

8-162 Revision February, 2017

W	Z	Y	X
Reserved	Limit Setting	Z pulse Setting	Homing Method
-	0 ~ 1	0 ~ 2	0 ~ 8
	When encounter limit: Z = 0: shows error Z = 1: rotates backwards	Y = 0: Stop and return to Z pulse Y = 1: Go forward to Z pulse Y = 2: Do not look for Z pulse	X = 7: Homing in reverse direction ORGP: ON > OFF, as the homing origin X = 8: directly define the current position as the origin
		Y = 0: Return to Z pulse Y = 1: Do not look	X = 9: Regard the collision point as the original point in forward direction
		for Z pulse	X = A: Regard the collision point as the original point in reverse direction

P5-05	HSPD1 1st	Speed Setting of Hig	gh Speed Homing	Address: 050AH 050BH
	Operationa Interface :	: D I / O - ft	Communication	Related Section: -
	Default:	100.0	1000	
	Contro Mode :	(This has to be set w		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 2000.0	1 ~ 20000	
	Data Size :	32-bit		
	Format :	Decimal		
	Example :	1.5 = 1.5 r/min	15 = 1.5 r/min	

Settings: The 1st speed of high speed homing



P5-06	HSPD2 2 nd	Speed Setting of Low	/ Speed Homing	Address: 050CH 050DH
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default :	20.0	200	
	Control Mode :	PR (This has to be set	with P5-04)	
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 2000.0	1 ~ 20000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1.5 = 1.5 r/min	15 = 1.5 r/min	
	Settings :	The 2 nd speed setting of	of low speed homing	

P5-07∎	PRCM Tri	igger Position Com	ger Position Command (PR mode only)		
	Operationa Interface:	Panel / Software	Communication	Related Section: -	
	Default :	0			
	Contro Mode :	PR			
	Unit :	-			
	Range :	0 ~ 1000			
	Data Size :	16-bit			
	Format :	Decimal			

Settings: Set P5-07 to 0 to start homing

Set P5-07 to 1~63 to execute PR procedure which is the same as DI.CTRG+POSn

It is prohibited to set P5-07 to 64 \sim 9999 (The value exceeds the valid range)

Set P5-07 to 1000 to execute Stop Command which is the same as DI.STP

When reading P5-07:

If the command is incomplete, the drive will read the current command.

If the command is completed, the drive will read the current command + 10000.

If the command is completed and DO.TPOS is ON, reach the motor position, the drive will read the current command +20000.

8-164 Revision February, 2017

When PR is triggered by DI, the reading value is the same For example:

Set P5-07 to 3, PR#3 will be triggered.

If the reading value is 3, it means PR #3 is incomplete.

If the reading value is 10003, it means PR#3 is issued completed, but the motor has not reached the target position yet.

If the reading value is 20003, it means PR#3 is issued completed and the motor has reached the target position.

P5-08	SWLP Fo	rward Software Lim	nit	Address: 0510H 0511H
	Operational Interface:	Panel / Software	Communication	Related Section: -
	Default :	2147483647		
	Control Mode :	PR		
	Unit:	PUU		
	Range :	-2147483648 ~ +21	2147483648 ~ +2147483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: In PR mode, if the motor rotates in forward direction and its command position exceeds the setting value of P5-08, it will trigger AL.283.

P5-09	SWLN Re	everse Software Lim	nit	Address: 0512H 0513H
	Operationa Interface:	Panel / Software	Communication	Related Section: -
	Default :	-2147483648		
	Contro Mode :	PR		
	Unit:	PUU		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		

Settings: In PR mode, if the motor rotates in reverse direction and its command position exceeds the setting value of P5-09, it will trigger AL.285.

P5-10★	AYSZ	Data Array - Data Size)	Address: 0514H 0515H
	Operatior Interface	DI/O-#	Communication	Related Section: 7.2
	Default	t : -		
	Cont Mode	rol ALL	NLL	
	Unit	t:-		
	Range	: Read-only		
	Data Size	e : 16-bit		
	Format	: Decimal		
	Settings	Data size (N x 32 bi	ts) means size N of data a	rray

Address: 0516H P5-11∎ Data Array - Address of Reading / Writing AYID 0517H Operational Related Section: Panel / Software Communication 7.2 Interface: Default: 0 Control ALL Mode: Unit: -Range: $0 \sim \text{(value set by P5-10 minus 1)}$ Data Size: 16-bit Format : Decimal

Settings: The address of specified data when reading or writing data array.

8-166 Revision February, 2017

-12∎	AYD0 Da	ata Array - Window	Address: 0518H 0519H	
	Operationa Interface:	l Panel / Software	Communication	Related Section: 7.2
	Default :	0		
	Contro Mode :	l ALL		
	Unit:	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		-! !
	Ĺ		NE 44 : - 1\	

Settings: Window #1 (Array[P5-11++])

When reading the parameter via panel, the value set by P5-11 will not

add 1, but the others will.

5-13∎	AYD1 Da	ta Array - Window	#2 for Reading / Writing	Address: 051AH 051BH
	Operationa Interface :	Panel / Software	Communication	Related Section: 7.2
	Default:	ALL		
	Contro Mode :			
	Unit:			
	Range :			
	Data Size: 32-bit			
-	Format :	Decimal		

Settings: Window #2 (Array[P5-11++])

When reading and writing the parameter via panel or communication,

the value set by P5-11 will add 1. Panel is write-protected.

P5-14 Reserved

5-15∎			Data Retained Setting	Address: 051EH 051FH
	Operational Interface:	Panel / Software	Communication	Related Section: -
	Default :	0x0		
	Control Mode :	ALL		
	Unit :	-		
	Range :	0x0 ~ 0x0011		
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: The parameter is divided into 00YX:

X=0: PATH#1 Data retained X=1: PATH#1 No data retained Y=0: PATH#2 Data retained

Y=1: PATH#2 No data retained

Others are reserved

Users can continuously write the new position into the drive through communication by P5-05.

P5-16∎	AXEN AX	kis Position - Motor Encoder	Address: 0520H 0521H
	Operationa Interface:		Related Section: 7.3
	Default :	0	
	Contro Mode :	I ALL	
	Unit:	PUU (User position unit)	
	Range :	-2147483648 ~ +2147483647	
	Data Size :	32-bit	
	Format :	Decimal	

Settings: Read: The feedback position of the motor encoder, which is the monitor various V000 + the offset value. (This function is supported

after firmware version V1.015)

Write: Any value can be written into the parameter and will neither change V000 nor influence the positioning coordinate system. It is only for observation when adjusting the offset value.

8-168 Revision February, 2017

-17	AXAU	Axis Position - Auxilia	ary Encoder	Address: 0522H 0523H
	•	Operational Panel / Software Communication		Related Section: 7.3
	Default	: -	ALL	
	Cont Mode	: A 1 1		
	Unit	: Pulse number		
	Range	: -2147483648 ~ +21	-2147483648 ~ +2147483647	
	Data Size	: 32-bit	32-bit	
	Format	: Decimal		

Settings: Sends back: pulse counts of the auxiliary encoder (linear scale)

P5-18	AXPC Ax	AXPC Axis Position - Pulse Command		
	Operational Interface : Panel / Software Communication		Related Section: 7.3	
	Default:	-		
	Contro Mode :	ALL		
	Unit :	Pulse number		
	Range :	-2147483648 ~ +214	7483647	
	Data Size :	32-bit		
	Format : Decimal			
	Settings:	Sends back: pulse co	ounts of pulse commar	nd

hapter 8 Para	meters	ASDA-A2			
P5-19	TBS E	-Cam Curve Scaling	am Curve Scaling		
	Operational Interface		Communication	Related Section: -	
Default :		1.000000			
	Contro Mode :	PR 0.000001 times, which is 1 / (10^6) -2147.000000 ~ +2147.000000			
	Unit				
	Range :				
	Data Size	: 32-bit	32-bit		
	Format	DEC			

Settings: (It will be provided after firmware version V1.017)

Example: 1100000 = 1.1 times

This parameter is used to magnify or minify the E-Cam table without changing its setting value.

For example, the data in the table is 0,10,20,30,40,20, magnification x 2.000000 equals to the data in the table: 0,20,40,60,80,40, magnification x 1.000000.

Enable the operation of E-Cam by using the same pulse frequency of the master axis. Magnify the magnification will enlarge the route of E-Cam operation. The speed will be magnified as well.

NOTE This parameter can be set anytime, but will be effective only when preengaged → engaged.

P5-20	AC0	Acceleration/Deceleration Time (Number #0)	Address: 0528H 0529H
	Operation Interface		Related Section: 7.10
	Defaul	t: 200	
	Cont Mode	PR	
	Uni	t: ms	
	Range	e : 1 ~ 65500	
	Data Size	e : 16-bit	
	Forma	t : Decimal	

The setting time of acceleration/deceleration in PR mode, which is the Settings: time it needs when accelerating from 0 to 3000r/min

8-170 Revision February, 2017 **Chapter 8 Parameters**

5-21	AC1	Acceleration/Decelera	ation Time (Number #1)	Address: 052AH 052BH
	Operatio Interface	Danal / Caffurana	Communication	Related Section: 7.10
	Defaul	t : 300		
	Con Mode	DD		
	Uni	it : ms		
	Range	e: 1 ~ 65500		
	Data Size	e : 16-bit		
	Forma	t : Decimal		

Settings : Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-22	AC2	Acceleration/Decelera	celeration/Deceleration Time (Number #2)		
	Operatior Interface	nal Panel / Software	Communication	Related Section: 7.10	
	Default	: 500			
	Conti Mode	PR			
	Unit	; ms			
	Range	: 1 ~ 65500	1 ~ 65500		
	Data Size	: 16-bit			
	Format	: Decimal			

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-23	AC3	Acceleration/Decelera	ition Time (Number #3)	Address: 052EH 052FH
	Operation	nal Panel / Software	Communication	Related Section:
	Interface	i .	Communication	7.10
		t : 600		
	Cont Mode	trol PR e :		
		t : ms		

8-171 Revision February, 2017

> Range: 1 ~ 65500 Data Size: 16-bit Format: Decimal

Please refer to P5-20 for the setting of acceleration/deceleration time in Settings: PR mode.

Address: 0530H P5-24 AC4 Acceleration/Deceleration Time (Number #4) 0531H Related Section: Operational Panel / Software Communication Interface: 7.10 Default: 800 Control Mode: Unit: ms Range: 1 ~ 65500 Data Size: 16-bit Format : Decimal

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in

PR mode.

Address: 0532H P5-25 AC5 Acceleration/Deceleration Time (Number #5) 0533H Related Section: Operational Panel / Software Communication 7.10 Interface: Default: 900 Control PR Mode: Unit: ms Range: 1 ~ 65500 Data Size: 16-bit Format : Decimal

> Please refer to P5-20 for the setting of acceleration/deceleration time in Settings:

PR mode.

8-172 Revision February, 2017

5-26	AC6	Acceleration/Decelera	celeration/Deceleration Time (Number #6)		
	Operatior Interface	DI/O-#	Communication	Related Section: 7.10	
	Default	: 1000			
	Cont Mode	DD			
	Unit	: ms			
	Range	: 1 ~ 65500			
	Data Size	: 16-bit			
	Format	: Decimal			

Settings : Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-27	AC7	Acceleration/Decelera	ation Time (Number #7)	Address: 0536H 0537H
	Operation Interface	nal Panel / Software :	Communication	Related Section: 7.10
	Default	: 1200		
	Cont Mode	PR		
	Unit	: ms		
	Range	: 1 ~ 65500		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-28			ation Time (Number #8)	Address: 0538H 0539H
	Operatio Interface	nal Panel / Software e :	Communication	Related Section: 7.10
		t : 1500		
	Con Mode	trol PR		
	Uni	it : ms		

> Range: 1 ~ 65500 Data Size: 16-bit Format: Decimal

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-29			tion Time (Number #9)	Address: 053AH 053BH
	Operation Interface	nal Panel / Software e :	Communication	Related Section: 7.10
	Defaul	t : 2000		
	Cont Mode	DD		
	Uni	t : ms		
	Range	e: 1 ~ 65500		
	Data Size	e : 16-bit		
	Forma	t : Decimal		

Settings : Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-30			ation Time (Number #10)	Address: 053CH 053DH
	Operatio Interface	nal Panel / Software e :	Communication	Related Section: 7.10
	Defaul	t : 2500		
	Con Mode	PR		
	Uni	t : ms		
	Range	e: 1 ~ 65500		
	Data Size	e : 16-bit		
	Forma	t : Decimal		

Settings : Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

8-174 Revision February, 2017

P5-31	AC11	Acce	eleration/Decelera	tion Time (Number #11)	Address: 053EH 053FH
	Operatio Interface	nal e :	anel / Software	Communication	Related Section: 7.10
	Defaul	lt : 30	000		
	Con Mode	P	R		
	Uni	it: m	ns .		
	Range	e : 1	~ 65500		
	Data Size	e : 16	6-bit		
	Forma	ıt : D	ecimal		

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-32	AC12	Acceleration/Decelera	ation Time (Number #12)	Address: 0540H 0541H
	Operation Interface	nal Panel / Software	Communication	Related Section: 7.10
	Default	: 5000		
	Contr Mode	PR		
	Unit	; ms		
	Range	: 1 ~ 65500		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in PR mode.

P5-33	AC13	Acceleration/Decelera	ation Time (Number #13)	Address: 0542H 0543H
	Operatio Interface	nal Panel / Software e :	Communication	Related Section: 7.10
	:	t : 8000		
	Con			
	Uni	t: ms		

Range: 1 ~ 65500

Data Size: 16-bit

Format: Decimal

Settings: Please refer to P5-20 for the setting of acceleration/deceleration time in

PR mode.

P5-34

AC14 Ac	celeration/Deceleratio	n Time (Number #14)	Address: 0544H 0545H
Operational Interface :	Panel / Software	Communication	Related Section: 7.10
Default :	50		
Control Mode :	PR		
Unit:	ms		
Range :	1 ~ 1500		
Data Size :	16-bit		
Format :	Decimal		

Settings: The default value of this parameter is smaller (short deceleration time)

and it is used for deceleration time setting of auto protection.

P5-35	AC15 Ac	celeration/Decelera	ation Time (Number #15)	Address: 0546H 0547H
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.10
	Default:	30		
	Contro Mode :	PR		
	Unit:	ms		
	Range :	1 ~1200		
	Data Size :	16-bit		
	Format :			

Settings: The default value of this parameter is smaller (short deceleration time) and it is used for short deceleration time and stops promptly of auto

protection.

8-176 Revision February, 2017

P5-36	CAST CA	PTURE - Start Add	dress of Data Array Address: 0548H 0549H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11.1
	Default :	0		
	Control Mode :	ALL		
	Unit :	-		
	Range :	0 ~ (value set by P5-10 minus 1)		
	Data Size :	16-bit		
	Format :	Decimal		
	Settings :	The first data CAPT	URE obtained should b	e saved in the address o

NOTE It is writable only when COMPARE stops (please refer to P5-39)

data array.

	APTURE - Axis Position CNT		Address: 054AH 054BH
Operation Interface	al Panel / Software	Communication	Related Section: 7.11.1
Default	: 0	0	
Contr Mode	ΛII	ALL	
Unit	-		
Range	: -2147483648 ~ +21	2147483648 ~ +2147483647	
Data Size	; 32-bit	32-bit	
Format	: Decimal		

Settings: Shows the axis position of CAPTURE pulse source

NOTE 1) It is writable only when COMPARE stops (please refer to P5-39)

2) If the source is the main encoder, this parameter is write-protected and the content is the feedback position of the motor (monitoring variable 00h).

Address: 054CH P5-38∎ CANO **CAPTURE** - The Number of Capturing Times 054DH Operational Related Section: Panel / Software Communication Interface: 7.11.1 Default: 1 Control ALL Mode: Unit: -1 ~ (the value set by P5-10 minus the value Range: set by P5-36) Data Size: 16-bit Format : Decimal

> When CAP stops, it means the number of data that expect to capture Settings: (readable and writable)

> > When CAP activates, it means the number of data that has not been captured (read-only); Every time, when it captures one data, the value of P5-38 will minus one. When the value is 0, it means the capturing is completed.




- NOTE 1. The number of data which is used by COMPARE, CAPTURE and E-Cam cannot exceed 800.
 - 2. A2L does not support E-Cam function.

P5-39∎	CACT CA	APTURE - Activate (CAP Control	Address: 054EH 054FH
	Operational Interface:	Panel / Software	Communication	Related Section: 7.11.1
	Default :	0x2010		
	Contro Mode :	: A L L		
	Unit :	-		
	Range :	0x0000 ~ 0xF13F 16-bit		
	Data Size :			
	Format :	Hexadecimal		

8-178 Revision February, 2017

Low word



X: See the following table

Y: 0 - CAPTURE is not working

1 - AUX ENC (linear scale) is set as the source

2 - PULSE Cmd

3 - Main ENC (main encoder)

When the source of CMP is CAP axis, the source Y of CAP cannot be changed.

Z: 0 - NO, 1 - NC

U: trigger the minimum interval (Unit: ms)

bit	3	2	1	0
X function	Execute PR when finishing capturing	After capturing the first data, CMP is activated.	Reset the position of the first data	Activate CAP
Description	Execute PR # 50 after finishing CAP	It is invalid when CMP is activated.	After capturing the first data, reset the position coordinate	Starts to capture when it is set to 1. After finishing capturing, this bit becomes 0 automatically

bit 0: When the value set by P5-38 is bigger than 0, set bit 0 to 1 will activate CAP function and DO.CAP_OK is OFF. Every time, when a data is captured, the value of P5-38 will minus one. When the P5-38 is 0, it means the capture function is completed, DO.CAP_OK is ON and bit 0 will be reset to 0 automatically. If P5-38 equals to 0, set bit 0 to 1 will not activate CAP function. DO.CAP_OK is OFF and bit 0 will automatically be set to 0. If CAP function is activated, it cannot set 1 to bit 0. It only can be written 0 to disable CAP function.

- bit 1: If this bit is 1, when capturing the first data, the current position of CAP axis will be set to the value of P5-76.
- bit 2: If this bit is 1, when capturing the first data, CMP will be activated. (When bit 0 of P5-59 is set to 1 and P5-58 is set to the previous value.) If CMP has been activated, then this function is invalid.
- bit 3: If this bit is 1, as soon as the CAP finished, PR procedure #50 will be triggered automatically.

P5-40	DLY0 De	elay Time After Position)	Address: 0550H 0551H	
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Contro Mode :	PR		
	Unit:	ms 0 ~ 32767		
	Range :			
	Data Size :	16-bit		
	Format :	Decimal		

Settings : The $\mathbf{1}^{\text{st}}$ Delay Time of PR mode

P5-41	DLY1 De	lay Time After Position	Address: 0552H 0553H	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	100		
	Control Mode :	PR		
	Unit:	ms		
	Range :	Range : 0 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The 2nd Delay Time of PR mode

8-180 Revision February, 2017

P5-42		Del #2)	ay Time After Position	Address: 0554H 0555H	
	Operatio Interface		Panel / Software	Communication	Related Section: 7.10
	Default :		200		
	Control Mode :		PR		
	Unit :		ms		
	Range	e :	0 ~ 32767		
	Data Size	e :	16-bit		
	Forma	ıt:	Decimal		

Settings: The 3rd Delay Time of PR mode

P5-43	DLY3 De #3)	lay Time After Posi	Address: 0556H 0557H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	400		
	Control Mode :	PR		
	Unit :	ms 0 ~ 32767		
	Range :			
	Data Size :	16-bit	oit	
	Format :	Decimal		

Settings: The 4th Delay Time of PR mode

P5-44		Delay Time After Posi #4)	Address: 0558H 0559H	
	Operation Interface	nal Panel / Software e:	Communication	Related Section: 7.10
	Defaul	t : 500	500	
		Control lode :		
	Uni	t : ms		

Range: 0 ~ 32767

Data Size: 16-bit

Format: Decimal

Settings: The 5th Delay Time of PR mode

Delay Time After Position Completed (Number Address: 055AH P5-45 DLY5 Related Section: Operational Panel / Software Communication Interface: 7.10 Default: 800 Control Mode: Unit: ms Range : 0 ~ 32767 Data Size: 16-bit Format: Decimal

Settings : The 6^{th} Delay Time of PR mode

P5-46	DLY6 Delay Time After Position Completed (Number #6)			Address: 055CH 055DH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	PR		
	Control Mode :			
	Unit :			
	Range :			
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The 7th Delay Time of PR mode

8-182 Revision February, 2017

Delay Time After Position Completed (Number Address: 055EH DLY7 P5-47 Operational Related Section: Panel / Software Communication Interface: 7.10 Default: 1500 Control Mode: Unit: ms Range: 0 ~ 32767 Data Size: 16-bit Format : Decimal

Settings: The 8th Delay Time of PR mode

P5-48		Delay Time After Posi f8)	Address: 0560H 0561H	
	Operation Interface	nal Panel / Software :	Communication	Related Section: 7.10
	Default	: 2000		
	Conti Mode	:DD		
	Unit	: ms		
Range :		: 0 ~ 32767	0 ~ 32767	
	Data Size	: 16-bit		
	Format	: Decimal		

Settings : The 9^{th} Delay Time of PR mode

P5-49		Delay Time After Posi #9)	Address: 0562H 0563H	
	:	nal Panel / Software e:	Communication	Related Section: 7.10
		t : 2500		
	Con Mode	trol		
		t : ms		

Range: 0 ~ 32767

Data Size: 16-bit

Format: Decimal

Settings: The10th Delay Time of PR mode

P5-50	DLY10 De	lay Time After Position	n Completed (Number	Address: 0564H 0565H
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	3000		
	Control Mode :	PR		
	Unit:	ms		
	Range :	0 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The 11th Delay Time of PR mode

1 DLY11	Delay Time After Position Completed (Number #11)		er Address: 0566H 0567H
Operation Interfact	onal Panel / Software	Communication	Related Section: 7.10
Defau	ılt : 3500		
	Control Mode :		
Ur	nit : ms		
Range :	e: 0 ~ 32767		
Data Siz	e : 16-bit		
Form	at : Decimal		

Settings : The 12^{th} Delay Time of PR mode

8-184 Revision February, 2017

P5-52	DLY12 De		tion Completed (Number	Address: 0568H 0569H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	4000		
	Control Mode :	PR		
	Unit :	ms		
	Range :	0 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings : The 13^{th} Delay Time of PR mode

P5-53		elay Time After Posi 13)	tion Completed (Number	Address: 056AH 056BH
	Operational Interface		Communication	Related Section: 7.10
	Default	: 4500		
	Contro Mode	PR		
	Unit	: ms		
	Range	: 0 ~ 32767		
	Data Size	: 16-bit		
	Format	: Decimal		

Settings: The 14th Delay Time of PR mode

P5-54		Delay Time After Posi #14)	tion Completed (Number	Address: 056CH 056DH
		onal Panel / Software e:	Communication	Related Section: 7.10
		Default: 5000		
	Con Mod	e : PR		
	Un	it : ms		

Range: 0 ~ 32767

Data Size: 16-bit

Format: Decimal

Settings: The 15th Delay Time of PR mode

P5-55	#1	5)	ion Completed (Number	Address: 056EH 056FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	5500		
	Control Mode :	PR		
	Unit :	ms		
Range :		0 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The 16th Delay Time of PR mode

P5-56	CMST	COMPARE - Start Add	ress of Data Array	Address: 0570H 0571H
	Operation Interface		Communication	Related Section: 7.11.2
	Defaul	t : 0		
	Cont Mode	ΔΙΙ		
	Uni	t : -		
	Range	e: 0~(The value of P5	i-10 minus 1)	
	Data Size	e : 16-bit		
	Format : Decimal			
•		TI 6 100MDADE		:

Settings: The first COMPARE data is saved in the address of data array.

NOTE It is writable only when COMPARE stops (please refer to P5-59)

8-186 Revision February, 2017

-57∎	CMAX CC	OMPARE - Axis Posi	ition	Address: 0572H 0573H
	Operationa Interface:		Communication	Related Section: 7.11.2
	Default :	0		
	Contro Mode :	ALL		
	Unit:	-		
	Range :	-2147483648 ~ +214	47483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: The axis position of COMPARE pulse source is displayed here.

It is writable only when COMPARE stops (please refer to P5-59)

NOTE 1) It is write-protected when the source is Capture axis.

P5

2) When the source is the main encoder, P5-57 is also write-protected. The pulse revolution is determined by parameter P1-46. When P5-59.Y is set to the main encoder, this parameter is set to the motor feedback position (monitoring variable 00h). If this parameter is not the same as the motor feedback position due to homing or reset by CAP function, the user can set P5-59.Y = 0 and

homing or reset by CAP function, the user can set P5-59.Y = 0 and then P5-59.Y = 3. In this way, this parameter will be reset to the motor feedback position.

P5-58∎	смио со	CMNO COMPARE - Compare Amount		Address: 0574H 0575H
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.11.2
	Default:	1		
	Contro Mode :	ALI		
	Unit :	-		
	Range :	1 ~ (the value set by set by P5-56)	1 ~ (the value set by P5-10 minus the value set by P5-56)	
Data Size		16-bit		
	Format :	Decimal		

Settings:


When COMPARE stops, it means the number of data that expect to compare (readable and writable)

When COMPARE activates, it means the number of data that has not been compared (read-only); Every time, when it compares one data, the value of P5-38 will minus one. When the value is 0, it means the comparing is completed.

P5-59

смст сс	DMPARE - Activate CN	Address: 0576H 0577H		
Operational Interface :	Panel / Software	Communication	Related Section: 7.11.2	
Default :	00640010h	00640010h		
Control Mode :	ALL			
Unit:	-	-		
Range :	00010000h ~ 0x0FFF3			
Data Size :	32-bit			
Format :	Hexadecimal			

Settings:



X: See the following table.

- Y: 0 When selecting CAPTURE AXES, the source of CAP cannot be changed.
 - 1 AUX ENC (linear scale) is set as the source
 - 2 PULSE Cmd
 - 3 Main ENC (main encoder)
- Z: 0 NO, 1 NC outputs the polarity

8-188 Revision February, 2017

U: See table U below:

bit	15	14	13	12
U function	-	-	-	Trigger PR
Description	-	-	-	When this bit is set to 1, PR#45 will be triggered after the last compare is completed. It is provided in V1.038
				sub09 (or the later version)

CBA: Output the pulse length; Unit: 1ms

bit	3	2	1	0
X function	After finishing comparing, the counter returns to 0.	When finishing comparing, CAP is activated.	Cycle mode	CMP is activated
Description	As soon as the last data is compared, P5-57 is set to 0.	It is invalid when CAP is activated.	Never end	Starts to compare when this bit is set to 1. It returns to 0 when finishing comparing.

- bit 0: When the value of P5-58 is more than 0, set bit to 1 will activate CMP. When comparing one data, the value of P5-58 will minus 1. When P5-58 is set to 0, the comparing is completed and returns to 0. If P5-58 is 0, set bit 0 to 1 will not do any comparing and return to 0 automatically. If bit 0 has already been set to 1, it is not allowed to write 1 as the new value into the parameter. But it is ok to write 0 to disable CMP.
- bit 1: If this bit is 1, P5-58 will be reset after comparing the last data. Then, start from the first data again. The cycle will never end and bit 0 is always 1.
- bit 2: If this bit is 1, CAP will be activated after comparing the last data. (Set bit 0 of P5-39 to 1 and reset P5-38 to the previous value) If CAP has already been activated, this function is invalid.
- bit 3: If this bit is 1, set the counter (P5-57) to 0 after comparing the last data. For example, if the comparing data is set to 3000 (one data in total), the default value of the counter (P5-57) is 0. It is expected to input 4000 pulse. When it reaches the 3000th pulse, the CMP is completed and P5-57 returns to 0. When the pulse reaches 4000, P5-57=1000. (No accumulative error)

P5-60	POV0 Ta	rget Speed Setting #	ŧ0	Address: 0578H 0579H
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	20.0	200	
	Contro Mode :	PR		
	Unit:	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	15 = 15 r/min	150 = 15 r/min	

Settings: The 1st target speed of PR mode

P5-61	POV1 Target Speed Setting #1			Address: 057AH 057BH
	Operational Interface		Communication	Related Section: 7.10
	Default	50.0	500	
	Contro Mode	:PR		
	Unit	1 r/min	0.1 r/min	
	Range	0.1 ~ 6000.0	1 ~ 60000	
	Data Size	: 16-bit		
	Format	Decimal		
	Example	1= 1 r/min	10 = 1r/min	

Settings : The 2^{nd} target speed of PR mode

8-190 Revision February, 2017

-62	POV2	Farget Speed Setting	#2	Address: 057CH 057DH
	Operation Interface	Danal / Caffurara	Communication	Related Section: 7.10
	Default	: 100.0	1000	
	Cont Mode	DD		
	Unit	; 1 r/min	0.1 r/min	
	Range	: 0.1 ~ 6000.0	1 ~ 60000	
	Data Size	: 16-bit		
	Format : Decimal			
	Example	: 1= 1 r/min	10 = 1r/min	

Settings: The 3rd target speed of PR mode

P5-63	POV3	Target Speed Setting	#3	Address: 057EH 057FH	
	Operation Interface	nal Panel / Software	Communication	Related Section: 7.10	
	Defaul	t: 200.0	2000		
	Cont Mode	PR			
	Uni	t:1 r/min	0.1 r/min		
	Range	e: 0.1 ~ 6000.0	1 ~ 60000		
	Data Size	e: 16-bit			
	Forma	t : Decimal			
	Example	e : 1= 1 r/min	10 = 1r/min		

Settings: The 4th target speed of PR mode

P5-64	POV4 Ta	rget Speed Setting	#4	Address: 0580H 0581H
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	300.0	3000	
	Contro Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size: 16-bit			
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings: The 5th target speed of PR mode

P5-65	POV5 Ta	rget Speed Setting	Address: 0582H 0583H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	500.0	5000	
	Control Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings : The 6^{th} target speed of PR mode

8-192 Revision February, 2017

5-66	POV6 Ta	rget Speed Setting	get Speed Setting #6		
	Operationa Interface :	:D 1/O (1	Communication	Related Section: 7.10	
	Default :	600.0	6000		
	Contro Mode :	l PR			
	Unit :	1 r/min	0.1 r/min		
	Range :	0.1 ~ 6000.0	1 ~ 60000		
	Data Size : 16-bit Format : Decimal				
	Example :	1= 1 r/min	10 = 1r/min		

Settings: The 7^{th} target speed of PR mode

P5-67	POV7 T	arget Speed Setting	#7	Address: 0586H 0587H
	Operational Interface		Communication	Related Section: 7.10
	Default	: 800.0	8000	
	Contro Mode	:PR		
	Unit	: 1 r/min	0.1 r/min	
	Range	: 0.1 ~ 6000.0	1 ~ 60000	
	Data Size	: 16-bit		
	Format	: Decimal		
	Example	: 1= 1 r/min	10 = 1r/min	

Settings: The 8th target speed of PR mode

P5-68	POV8 Tai	rget Speed Setting #	8	Address: 0588H 0589H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	1000.0	10000	
	Control Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

POV9 Target Speed Setting #9

Operational Interface:

Default: 1300.0

Address: 058AH
058BH

Related Section:
7.10

0.1 r/min

Control Mode : PR Unit : 1 r/min

Range: 0.1 ~ 6000.0 1 ~ 60000

Settings: The 9th target speed of PR mode

Data Size: 16-bit

Format : Decimal

Settings: The 10th target speed of PR mode

8-194 Revision February, 2017

70	POV10 Ta	get Speed Setting #10		Address: 058CH 058DH
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default:	1500.0	15000	
	Contro Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings: The 11th target speed of PR mode

P5-71	POV11 Target Speed Setting #		#11	Address: 058EH 058FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	1800.0	18000	
	Control Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings: The 12th target speed of PR mode

-72	POV12	Target Speed Setting	#12	Address: 0590H 0591H			
	Operation Interface	Danal / Caffiriana	Communication	Related Section: 7.10			
	Defaul	t: 2000.0	20000				
	Cont Mode	DD					
	Uni	t:1 r/min	0.1 r/min				
	Range	e: 0.1 ~ 6000.0	11 ~ 600001				
Data Size : 16-bit							
	Forma	t : Decimal					
	Example	e: 1= 1 r/min	10 = 1r/min				
	Settings	s: The 13 th target spee	Settings: The 13 th target speed of PR mode				

-73	POV13 Target Speed Setting #13		Address: 0592H 0593H	
	Operationa Interface :		Communication	Related Section: 7.10
	Default :	2300.0	23000	
	Contro Mode :	PR		
	Unit:	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	16-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings: The 14th target speed of PR mode

8-196 Revision February, 2017

POV14 Tai	get Speed Setting #14		Address: 0594H 0595H
Operational Interface :	Panel / Software	Communication	Related Section: 7.10
Default :	2500.0	25000	
Control Mode :	PR		
Unit :	1 r/min	0.1 r/min	
Range :	0.1 ~ 6000.0	1 ~ 60000	
Data Size :	16-bit		
Format :	Decimal		
Example :	1= 1 r/min	10 = 1r/min	

Settings: The 15th target speed of PR mode

-75	POV15 Target Speed Setting #15		Address: 0596H 0597H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	3000.0	30000	
	Control Mode :	PR		
	Unit :	1 r/min	0.1 r/min	
	Range :	0.1 ~ 6000.0	1 ~ 60000	
	Data Size :	32-bit		
	Format :	Decimal		
	Example :	1= 1 r/min	10 = 1r/min	

Settings: The 16th target speed of PR mode

P5-76★	CPRS CA	NPTURE - First Positio	n Reset Data	Address: 0598H 0599H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	ALL		
	Unit :	- -1073741824 ~ +1073741823		
	Range :			
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P5-39 X 1

P5-77∎		e Position of Sync AP SYNC AXES)	chronous Capture Axis	Address: 059AH 059BH
	Operational Interface:		Communication	Related Section: -
	Default :	0		
	Contro Mode :	ALL		
	Unit :	-		
	Range :	-2147483648 ~ +214	7483647	
	Data Size :	32-bit		4
	Format :	Decimal		

Settings: The position of this axis will synchronize with CAP signal. That is to say, when activating CAP every two times, the motor moving distance of this axis is the value of P5-78. (There is no accumulative error and only in single-way operation) The synchronous capture axis can be the source of Master.

8-198 Revision February, 2017

5-78		he Interval Pulse Nւ ynchronous Capture A		Address: 059CH 059DH
	Operational Interface	al Panel / Software ·	Communication	Related Section: -
	Default	: 100		
	Contro Mode :	ΛII		
	Unit	; Pulse		
	Range	: 10 ~ +100000000		
	Data Size	; 32-bit		
	Format	: Decimal		

Settings: It is the moving distance of synchronous capture axis between two

CAP actions.

The new value can be written into the parameter not until CAP is disabled (P5-39, X0=0).

P5-79∎	CSDS Err	_	of Synchronous Capture	Address: 059EH 059FH
	Operational Interface :	Panel / Software	Communication	Related Section: -
	Default:	0		
	Control Mode :	ALL		
	Unit:	Pulse unit of capture	e axis	
	Range : -2147483648 ~ +2147483647		47483647	
	Data Size :	32-bit		¥
	Format :	Decimal		4

Settings:

When synchronous capture axis is operating, the synchronous error should be 0. This parameter shows this error value. The followings are its concept:

Synchronous Error = Output value of synchronous axis - Setting value of synchronous axis

= the accumulative amount of P5-77 - (P5-78 x Capturing number of times)

When capturing the data, the synchronous axis works normally. This parameter updates once.

This parameter can be written into as well. It indicates the offset of synchronous master. When the synchronous capture axis is regarded as the master of flying shear, modify this parameter can deviate the cutting position to the left/right.



NOTE A2L does not support E-Cam function.

P5-80	CSDS	Axis	or Synchronous Capture	05A1H
	Operation Interfact	:D 1/0 (1	Communication	Related Section: -
	Defau	ılt : 10		

Control ALL Mode:

Unit: %

Range : 0 ~ 90

Data Size : 16-bit

Format : Decimal

Settings: This parameter limits the percentage (%) of synchronous adjustment.

Correction rate

= pulse number output by synchronous axis /pulse number input by synchronous axis (100 - P5 - 80)% < correctionrate < (100 + P5 - 80)%

The bigger correction rate, the faster the synchronous error becomes 0. However, the speed changing will be more severe.

The smaller correction rate, the slower the synchronous error becomes 0. However, the speed changing will be smoother.

In the application of flying shear, after adjusting the synchronous error, P5-79: the bigger parameter value will reduce the time the slave axis goes to the desired position. However, the speed is not synchronized.

NOTE A2L does not support E-Cam function.

8-200 Revision February, 2017

Chapter 8 Parameters

81	ECHD E-	CAM: Start Address	of Data Array	Address: 05A2H 05A3H
	Operationa Interface :	Danal / Cathurana	Communication	Related Section: 7.11
	Default :	100		
	Contro Mode :	l PR		
	Unit :	-		
	Range :	0 ~ (800 - P5-82)		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: The first data of E-Cam table is saved in the address of data array.



- NOTE 1. Version V1.015 (before): This parameter cannot be modified when E-Cam is activated (P5-88, X = 1).
 - 2. Version V1.015 (included or after): This parameter can be set anytime, but will be effective only when pre-engaged → engaged.
 - 3. A2L does not support this function.

P5-82	ECMN E-C	CAM: Area Number	Address: 05A4H 05A5H	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.11
	Default :	5		
	Control Mode :	PR		
	Unit :	-		
	Range :	5 ~ 720, must < = (F And P5-82 x P5-84	,	
	Data Size :	16-bit		
	Format :	Decimal		

Settings: It means the E-Cam curve is divided into N area, and the table should include N+1 data.



- NOTE 1. This parameter can be wrote when E-Cam stops (Please refer toP5-88, X=0).
 - 2. A2L does not support E-Cam function.

8-201 Revision February, 2017

83	ECMM E-C	CAM: Master Gear F	Address: 05A6H 05A7H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	1		
	Control Mode :	PR		
	Unit:	-		
	Range :	1 ~ 32767		
	Data Size :	16-bit		
	Format :	Decimal		

Settings: When receiving pulse number P of the Master, E-Cam will rotate M circle, which means the M cycle of the E-Cam table.



- NOTE 1. This parameter can be wrote when E-Cam stops (Please refer toP5-88, X=0).
 - 2. A2L does not support E-Cam function.

P5-84	ECMP E-0	CAM: Master Gear F	Address: 05A8H 05A9H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	3600	3600	
	Control Mode :	PR		
	Unit :	-		
	Range :	10 ~ 1073741823, and P5-82 x P5-83 and P5-82 x P5-84		
	Data Size :	32-bit		
	Format :	Decimal		

Settings: When receiving pulse number P of the Master, E-Cam will rotate M circle, which means the M cycle of the E-Cam table.



- This parameter can be wrote when E-Cam stops (Please refer toP5-88, X=0).
- 2. This parameter can be modified anytime, and has no limit that mentioned above.
- 3. A2L does not support E-Cam function.

8-202 Revision February, 2017

P5-85	ECME E-0	CAM: Number of Ar	Address: 05AAH 05ABH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	0 ~ (P5-82 - 1)		
	Data Size :	16-bit		
	Format :	Decimal		
	Settings: The area number of E-cam when E-cam NOTE A2L does not support E-			

Address: 05ACH P5-86**■ ECAX E-CAM: Master Axis Position** 05ADH Operational Related Section: Panel / Software Communication 7.11 Interface: Default: 0 Control Mode: Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit Format : Decimal

Settings: The position counter of the E-Cam Master

NOTE 1. This parameter can be wrote when E-Cam stops (Please refer toP5-88, X=0).

2. A2L does not support E-Cam function.

PLED E-	CAM: Lead Pulse		Address: 05AEH 05AFH
Operational Interface:	Panel / Software	Communication	Related Section: 7.11
Default :	0		
Contro Mode :	PR		
Unit :	-		
Range :	-1073741824 ~ +107374	41823	
Data Size :	32-bit		
Format :	Decimal		


P5-87

Settings: When the engaging condition (P5-88.Z) of E-cam is satisfied, the pulse number from the master has to exceed the setting value of this parameter, so that E-cam is fully engaged.

> In other words, E-cam engages after neglecting the lead pulse specified by this parameter.

If the symbol of this parameter is +, it means the received forward pulse is regarded as the lead pulse.

If the symbol of this parameter is - , it means the received reverse pulse is regarded as the lead pulse.



P5-88∎	ECON E	-CAM: Activate E-Cam Control		Address: 05B0H 05B1H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	0000000h		
	Control Mode :	PR		
	Unit :	-		
	Range :	0 ~ 0x203FF257		
	Data Size :	32-bit		
	Format :	Hexadecimal		

8-204 Revision February, 2017

Settings: The format of this parameter: (High word h) S0BA: (Low word L) UZYX

Definition of each column is as follows:

• X: E-Cam command Description of each bit:

Х3	-	-
X2	P5-19 is effective immediately	It is available after V1.038 sub48: 0: P5-19 is effective after the next engage. 1: P5-19is effective immediately.
X1	E-Cam does not disengage when Servo OFF	It is available after 1.038 sub29: 0: E-Cam does not work 1: When E-Cam stops because of alarm or Servo Off, it can keep in engaged status. When reservo on, E-cam can operate directly. It can return to the correct position by macro #D.
X0	E-Cam is enabled	Cam is disabled E-Cam is enabled (E-CAM is enabled while other functions cannot be modified.)

- Y: Command source
 - 0: CAP axis
 - 1: AUX ENC
 - 2: Pulse Cmd
 - 3: PR command
 - 4: Time Axis (1ms)
 - 5: Synchronous Capture Axis (P5-77)
 - 6: Analog channel 1 (virtual axis, Unit: 1M pulse/s /10V)
- Z: Engaging Time (No multiple choice)
 - 0: Immediately
 - 1: DI.CAM ON
 - 2: Any one of the Capture

 U: Disengaging Condition (2, 4 and 6 cannot be selected at the same time)

U	Disengaged Condition	Action after disengaged
0	Never disengaged	-
1	DI.CAM is OFF	In STOP status
2	Master axis receives the pulse number which is set by P5-89 and stops immediately. (The symbol represents the direction)	
6	(It is available after firmware version V1.009)	In STOP status
	Same as 2, the E-cam starts to decelerate when disengaging. It is suitable for the application of calling the next PR position command right after disengaged.	
4	(It is available after firmware version V1.009)	Back to the pre-engage status
	Master axis exceeds the setting value of P5-89 (Sign indicates the direction)	The lead pulse is P5- 92
8	When U = 1, 2 or 6:	Set X to 0
	Disable E-Cam after it is disengaged.	
	When U = 4:	N/A
	To avoid jittering when it returns to lead status.	



The servo is Off, when ALM or forward/reverse limit occur or PR is doing homing procedure, it disengages (P5-88, X = 0)

- BA: When disengaging condition is satisfied (P5-88, U = 2, 4, 6), a PR 00~63 (hexadecimal; 00 means no action) will automatically be executed.
- S:Shows the engage status (Read-only, the setting is invalid)
 - 0: Stop
 - 1: Engage status
 - 2: Pre-engage status

8-206 Revision February, 2017

Address: 05B2H P5-89 **ECRD** E-CAM: Information of Disengaging Time 05B3H Operational Related Section: Panel / Software Communication 7.11 Interface: Default: 0 Control PR Mode: Unit: -Range: -1073741824 ~ +1073741823 Data Size: 32-bit Format : Decimal

Settings: (Please refer to the definition of P5-88 U setting value 2)

NOTE A2L does not support E-Cam function.

P5-90	CMAP E-CAM: AREA No. + The Point of DO ON		Address: 05B4H 05B5H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	PR Degree (It was changed after firmware V1.009) 0 ~ 360 16-bit		
	Control Mode :			
	Unit:			
	Range :			
	Data Size :			
	Format :			
	Settings:	When E-cam is eng CAM_AREA).	aged, set the start angle	of DO output (DO.

NOTE A2L does not support E-Cam function.

5-91	CMAN E	-CAM: AREA No T	CAM: AREA No The Point of DO OFF		
	Operational Interface	·Danal/Caffiriana	Communication	Related Section: 7.11	
	Default	: 0			
	Contro Mode	PR	PR		
	Unit	: Degree			
	Range	: 0 ~ 360	0 ~ 360		
	Data Size	: 16-bit	16-bit		
	Format	: Decimal			

Settings: When E-cam is engaged, set the end angle of DO output (DO. CAM_AREA).

P5-92	PLED E-0	CAM: Pre-engaged T	Address: 05B8H 05B9H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.11
	Default :	0		
	Control Mode :	PR		
	Unit:	-		
	Range :	-2147483648 ~ +2147483647 32-bit		
	Data Size :			
	Format :	Decimal		

Settings:

P5

This parameter goes with the selection of P5-88, U=4 (E-cam will disengage if it exceeds the moving distance):

After disengaging, it does not enter the Stop status but pre-engaged status. The lead pulse is determined by this parameter.

The pulse number sent by the Master must exceed the setting value of this parameter so that E-cam will engage again.

In other words, E-cam will engage not until the lead pulse is ignored.

If the symbol of this parameter is +, it means the received positive pulse will be regarded as the lead pulse.

If the symbol of this parameter is -, it means the received negative pulse will be regarded as the lead pulse.

8-208 Revision February, 2017

P5-93 CSDS		otion Control Macro C rameter # 4	Address: 05BAH 05BBH	
Opera Interfa	tional ace :	Panel / Software	Communication	Related Section: -
Defa	ault :	0		
	ontrol	ALL		
l	Jnit :	-		
Raı	nge :	-100000000 ~ +100000000		
Data S	ize :	32-bit		

Settings: Before issuing the macro command, the relevant parameters # 4 must

be set in advance.

Format : Decimal

The function of the parameter is determined by the macro command. Not every macro command has its relevant parameters.

DE	•	И
II C	┺~	

CSDS	otion Control Macro C rameter # 3	ommand: Command	Address: 05BCH 05BDH
Operational Interface :	Panel / Software	Communication	Related Section: -
Default :	0		
Control Mode :	ALL		
Unit :	-		
Range :	-2147483648 ~ +21474	183647	
Data Size :	32-bit		
Format :	Decimal		

Settings: Before issuing the macro command, the relevant parameters # 3 must be set in advance.

The function of the parameter is determined by the macro command. Not every macro command has its relevant parameters.

Address: 05BEH **Motion Control Macro Command: Command** P5-95 **CSDS** Parameter # 2 05BFH Operational Related Section: -Panel / Software Communication Interface: Default: 0 Control ALL Mode: Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit

Settings: Before issuing the macro command, the relevant parameters # 2 must

be set in advance.

Format : Decimal

The function of the parameter is determined by the macro command. Not every macro command has its relevant parameters.

P5-96	(:51)5	otion Control Macro Command: Command rameter # 1	Address: 05C0H 05C1H
	Operationa Interface:	Panel / Software Communication	Related Section: -
	Default :	0	
	Contro Mode :	I ALL	
	Unit:	-	
	Range :	-2147483648 ~ +2147483647	
	Data Size :	32-bit	
	Format :	Decimal	

Settings: Before issuing the macro command, the relevant parameters # 1 must be set in advance.

The function of the parameter is determined by the macro command. Not every macro command has its relevant parameters.

8-210 Revision February, 2017

P5-97∎

CSDS		tion Control Macro Command: Issue mmand / Executing Result	
Operatior Interface	Daniel / Caffriana	Communication	Related Section: -
Default	: 0		
Cont Mode	ΔΙΙ		
Unit	: -		
Range	: 0 ~ 0x99F		
Data Size	: 16-bit		
Format	: Hexadecimal		

Settings: Write-in: It is used to issue the macro command (0CBAh)

Read: It is used to examine the execution result of macro command (If success, the result will be sent back to 1CBAh).

If the command issues 0001, 1001h will be sent back when success; and Fxxxh when failed (depending on the command description).

If issuing the command that is not supported, the failure code F001h will be sent back.

The provided command code is as the followings.

The following macros are available from Version V1.027 (included):

Command code 0003h	Motion parameter protection: password setting, protection activation
Macro parameters	P5-93= Parameter write-protected level (0~1) (0 means no protection)
	P5-94= Protection level of data array (0~7) (-1 means no protection)
	P5-95= Set new password (1~16777215)
	P5-96= Confirm new password (1~16777215)
	Among them:
	For success setting, the setting of P5-95 must equal to P5-96 and the password must be set within the allowable range.
This function can be protection.	executed before activating the function of parameter
If the protection function code will be sent back	ction is activated, when repeat execute this function, the failure ck.
Failure code F031h	Protection function has been activated and cannot be set repeat.
Failure code F032h	Wrong password setting: P5-95 not equals to P5-96.
Failure code F033h	Password setting exceeds the allowable range (1~16777215).
Failure code F034h	The protection level, P5-94 exceeds the allowable range (-1~7).

Failure code F035h	The protection level, P5-94 exceeds the allowable range (0~1).
Success code 1003h	

The following macros are available from version V1.026 (included):

Command code 0004h	Motion parameter protection: unlock the protection
Macro parameters	P5-96= enter the password (1~16777215)
If the protection function failure code. If entering the wrong	executed when activating the function of parameter protection. tion is unlocked, repeat execute this function will sent back the password, failure code Ennn will be sent back. nnn means the It will be misused one number after one failure. When the locked for good.
Failure code F041h	Protection function is unlocked and it cannot repeat unlock.
Failure code F043h	The password setting exceed the allowable range (1~16777215)
Failure code F044h	The number of times of entering wrong password exceeds the limit: Lock for good. Reset the parameter (P2-08=10) to unlock it is the only method. However, all parameter will return to the default value.
Failure code Ennnh	Incorrect password setting: Failed to unlock. nnn: the rest decode number. It will be minuses one number after one failure. When the number is 0, it will be locked for good.
Success code 1004h	

The following macros are available from version 1.024 (included):

Command code 0006h	Build up E-Cam table: flying shear, including synchronous area (7 areas)
General parameters	P5-81= Address of table (Data array) P5-82 = 7 (This macro is fixed to 7 areas) P1-44, P1-45 = E-gear ratio (it has to be setup in advance)
Macro parameters	P5-94 = A (Deceleration ratio: numerator) x C (Number of cutter) P5-95= B (Deceleration ratio: denominator) P5-96= 1000000 x R x V Among them: R (cutting ratio) = L (cutting length) / ℓ (Girth of cutter) Allowable cutting ratio: (0.3 ~ 2.5) times V (Speed factor) = target cutting speed / speed of delivered product

8-212 Revision February, 2017

V=1.0: When cutting, the speed of cutter is the same as the product
V=1.1: When cutting, the speed of cutter is 10% faster than the product
V=0.9: When cutting, the speed of cutter is 10% slower than the product

This macro will calculate the data of E-Cam table according to the above mentioned parameters, and store in data array which designated by P5-81.Parameters listed above are related to E-Cam table calculation. Please correctly setup those parameters before executing this macro.

After this macro is executed, if the above parameters have been changed, it has to recreate the E-Cam table and this macro will have to be executed again. Data in E-Cam table will be changed after executing this macro; thus, do not execute it when E-Cam is in engaged status.

In E-Cam application, parameters, such as P5-83 and P5-84 that are not related to this macro are not listed here. Users could setup parameters according to the real application. Please refer to Chapter 7, sections about E-Cam.

After executing this macro, E-Cam table will not be saved to EEPROM automatically.

Failure code F061h	When creating the table, E-Cam is in engaged status.
Failure code F062h	The setting value of P5-94 exceeds the range: (1 ~ 65535)
Failure code F063h	The setting value of P5-95 exceeds the range: (1 ~ 65535)
Failure code F064h	The setting value of P5-96 exceeds the range: (300000 ~ 2500000)
Failure code F065h	The address specified by P5-81is too long and the space of data array is not enough.
Failure code F066h	The setting value of P5-82 should be set to 7. Otherwise the command cannot be executed.
Failure code F067h	Data calculation error. Please decrease the setting value of (P1-44, P1-45) and keep the proportion will do.

Command code 0007h	Create E-Cam table: Flying cut
General parameters	P5-81 = Address of table (data array) P5-82 = N (30~72) (Area number of E-Cam)
	P1-44, P1-45 = E-gear ration (has to be setup first)
Macro parameters	P5-93.H16 (high 16-bit) = S
	P5-93.L16 (low 16-bit) = W
	Among them:
	S (curve level) = 1~4 levels
	W (degree of waiting area) = -1~170 degrees
	W = -1 is available in firmware version V1.038 (sub29) (or the later version)
	P5-94 = Y (degree of synchronous area) = 0~330 degrees
	P5-95.H16 (high 16-bit) = A x C

P5-95.L16 (low 16-bit) = B
Among them:
A (Deceleration ratio: numerator), C (Number of cutter)
B (Deceleration ratio: denominator)
P5-96 = 1000000 x R x V
Among them:
R (cutting ratio) = L (target cutting length) / (Length of cutter)
Allowable cutting ratio: (0.05 ~ 5.0) times
V (speed factor) = target cutting speed / speed of delivered product
V=1.0: When cutting, the speed of cutter is the same as the product
V=1.1: When cutting, the speed of cutter is 10% faster than the product
V=0.9: When cutting, the speed of cutter is 10% slower than the product

Note:

W' = 180 + 360/N - 360/R + Y/2

When

- 1. P5-93.L16 < W´, E-cam table is in error (failure code F07Ah)
- 2. P5-93.L16 = W', the initial speed is 0 in E-Cam table
- 3. P5-93.L16 > W', the initial speed > 0 in E-Cam table

This macro will calculate the data of E-Cam table according to the above mentioned parameters, and store in data array which designated by P5-81. Parameters listed above are related to E-Cam table calculation. Please correctly setup those parameters before executing this macro.

After this macro is executed, if the above parameters have been changed, it has to recreate the E-Cam table and this macro will have to be executed again. Data in E-Cam table will be changed after executing this macro; thus, do not execute it when E-Cam is in engaged status.

In E-Cam application, parameters, such as P5-83 and P5-84 that are not related to this macro are not listed here. Users could setup parameters according to the real application. Please refer to Chapter 7, sections about

After executing this macro, E-Cam table will not be saved to EEPROM automatically.

Failure code F071h	When creating the table, E-Cam is in engaged status.
Failure code F072h	P5-94 degree of synchronous area exceeds the range: (0 ~ 330)
Failure code F073h	P5-93.H16 curve level exceeds the range: (1 ~ 4)
Failure code F074h	P5-93.L16 degree of waiting area exceeds the range: (0 \sim 170)
Failure code F075h	The setting value of P5-96 exceeds the range: (50000 ~ 5000000)
Failure code F076h	P5-82 area number of E-Cam exceeds the range: (30 ~ 72)

8-214 Revision February, 2017


Failure code F077h	The address specified by P5-81is too long and the space of data array is not enough.
Failure code F078h	Data calculation error. Please decrease the setting value of (P1-44, P1-45) and keep the proportion will do.
Failure code F079h	Acceleration degree is too small, and then please decreases the value of waiting area (W), synchronous area (Y) or curve level (S).
Failure code F07Ah	Waiting area is too small, then please increase the value of acceleration area (W) or decrease the value of synchronous area (Y)

The following macros are available from version V1.042 sub09 (included):

Command code 0008h	E-Cam curve scaling (P5-19) is effective immediately
Macro parameters	N/A

This macro can be triggered when E-cam is engaged. P5-19 is effective immediately.

Usually, E-Cam scaling is only changed by P5-19 when it entering the engaged condition (see transition 3). It cannot be changed in engaged condition. E-Cam scaling only can be changed after one E-Cam cycle so as to make sure the E-Cam can return to the original position without accumulative error.



In application, two ways can change the setting of E-Cam curve scaling.

- 1. **P5-88.X2 = 1**: When E-Cam is engaged, setup this bit at the same time. Function of P5-19 will be enabled immediately.
- 2. Use macro#8: Every time when this macro command is triggered, function of P5-19 will be enabled. However, if the value of P5-19 is changed and this macro is not triggered, function of P5-19 will not be enabled. This macro command has to be triggered again.

command has to be triggered again.		
Failure code	N/A	


The following macros are available from version V1.035 sub00 (included):

Command code 000Ch	Change position X, where E-Cam is engaged: E-Cam disengages after rotating one cycle at forward direction.
General parameters	N/A
Macro parameters	P5-93 = New engaged position X. Unit: pulse number of master axis.
	Monitoring variable 062(3Eh): It displays the current engaged position (X) of master axis.
This macro command can change the engaged position even when E-Cam is	

engaged. It will automatically calculate the residual engaged length. E-Cam will disengage after rotating one cycle at forward direction. Users have to set P5-88.U to 2, 4, and 6; otherwise, the E-cam will not disengage.

E-Cam will disengage when alarm occurs or the power supply is cut off. If users desire E-Cam to re-engage at the last disengaged position and continue its operation, it is recommended to record the disengaged position (X) and resume the operation by this macro command. Please note that when E-Cam is disengaged, the servo position might slightly shift and therefore cause position error when E-Cam re-engages again.

The Engaged direction is in forward direction (Master axis operates at forward direction):



Note: When using this macro command, it would be better to execute this command before operate the master axis.

Failure code F0C1h	When executing this macro command, E-Cam is not in engaged status. To modify the engaged position only when E-Cam is engaged.
Failure code F0C2h	The setting value of P5-93 is in error. The value cannot less than 0. It should $> = 0$.
Failure code F0C3h	The setting value of P5-93 is in error. The value has to less than the value of (P5-84 / P5-83)

The following macros are available from version V1.038 sub48 (included):

Command code 000Dh	Calculate the error between E-Cam and indexing coordinates for PR positioning.
General Parameters	N/A
Macro Parameters	P5-93.Low_Word = DCBA: UZYX (8 digits, HEXADECIMAL) YX (PR number) = 0~0x3F (it is invalid when the value is set to 0) UZ: The value has to be set to 0. BA (Function of P5-95): 0 (Use avoid point) 1 (Use available forward rate, V1.038 sub53)

8-216 Revision February, 2017

DC (Inhibit reverse rotation):

0 (invalid),

1(Inhibit reverse rotation, V1.038 sub53)


P5-95: Avoid point (cannot pass this point) = 0 ~ 100 (%) of E-Cam cycle or available forward rate 0 ~ 100 (%)

Monitoring variable 091(5Bh): It displays the current indexing coordinate position (PUU)

When E-Cam is engaged, and the motor is stopped because of Servo Off or alarm occurs, it would cause position error between the actual position and E-Cam position. After re-servo On, this macro command can be used to calculate the correction value and write the value into the specified PR for incremental positioning. So that the motor can return to the ideal E-Cam position.

When using this macro command:

- 1. P5-88.X1 = 1 to make E-Cam keep engaging when servo off and continue to calculate E-Cam position.
- 2. The height of indexing coordinate and E-Cam coordinate should be the same: P2-52= ECAM_H (The moving distance when E-cam operates one cycle)
- 3. E-Cam table scaling (P5-19) must be 1.0 time
- 4. When E-Cam is engaged for the first time, 0 degree of E-cam should aim at 0 degree of indexing coordinate.
- 5. This macro command only can be applicable on periodic cycle and when every cycle starts from the same position.




Note 1: ECAM H (height of E-Cam table) = E-Cam table (last point - first points)

Note 2: Indexing coordinate = (absolute coordinates / P2-52) take remainder.

Note 3: Use PR command for incremental positioning control.

When motor moves from the current position to the target position, it can operate at forward or reverse direction. Due to the cyclic operation, the motor will travel to the specified position either at forward or reverse direction. However, the moving distance is different between both. Uses avoid point to plan the timing of forward and reverse rotation.

* **Avoid point:** the point that cannot be passed by the planned PR.



The following macros are provided after version V1.038 sub26 (included):

Command code 000Eh	Perform E-Cam alignment immediately and write the correction value into the specified PR.
Macro parameters	P5-93 = DCBA: UZYX (8 digits, HEXADECIMAL) YX (PR number) = 0~0x3F, it is invalid when the value is set to 0. UZ (Max. alignment correction rate) = 0~0x64 (%) A (Trigger the specified PR directly) = 1: On, 0: Off DCB = has to be set to 0 P5-94 (DI delay time compensation) = -25000 ~ +25000; Unit: usec. P5-95 (available forward rate) = 0 ~ 100 (%)

8-218 Revision February, 2017


P5-96 (target position of alignment X); Unit: pulse number of master axis = $0 \sim (P5-84/P5-83) - 1$.

Monitoring variable 062(3Eh): It displays the current engaged position of master axis (X)

This macro command can move the engaged position to the alignment target position (X) when E-Cam is engaged. And write the alignment correction value into the specified PR.

During E-Cam operation (When E-Cam is engaged), if desire to quickly align the E-cam position to the mechanical referral point, sensor can be used to trigger DI.EVx to execute this macro command.


After E-Cam alignment is completed, the engaged position will move to the new position. The excess or not enough moving distance after E-Cam operates one cycle is called alignment correction value. It will be written into PR specified by P5-93.YX. PR incremental command can be used to compensate this value so that the slave axis position will remain and offset the phase of E-Cam to align the referral position of machine. For some applications, set value of P5-93.YX to 0 will do. Please note that PR can be executed only when triggering the host controller.



- * P5-93.UZ is able to limit the max. correction rate. The alignment target position
- ★ will be different from P5-96.
- | alignment target position★ current engaged position | / L <= P5-93.UZ %
- * DI time delay compensation can be set via P5-94, it can correct the error caused by different speed of motion.

When E-Cam moves from current position to the target one, it can rotate at forward or reverse position. Due to the cyclic operation, it can reach the target position either at forward or reverse direction. However, the moving distance between both is usually different. Use available forward rate to plan the timing of forward and reverse rotation.

* Available forward rate: The available max. proportion of forward path



The following macros are available from version V1.038 sub26 (included):

Command code 000Fh	Calculate the moving distance between current and target position of E-Cam for PR positioning.
General parameters	N/A
Macro parameters	P5-93.Low_Word = UZYX (4 digits, HEXADECIMAL) YX (PR number of going trip) = 0~0x3F, it is invalid if the value is set to 0. UZ (PR number of return trip) = 0~0x3F, it is invalid if the value is set to 0.

8-220 Revision February, 2017


P5-93.Hi_Word = it has to be set to 0
P5-95 (Available forward rate) = 0 ~ 100 (%)
P5-96 (target position X); Unit: pulse number of master axis =
0 ~ (P5-84/P5-83) - 1

Monitoring variable 062(3Eh): It displays the current engaged position (X) of master axis (X)

This macro command calculates the moving distance between current and target engaged position (X) and writes into the specified PR.

During E-Cam operation, if users desire to move the slave axis to the specified position when master axis stops and still in engaged status, this macro command can calculates the correct moving distance (Y_Drift) of going trip for PR positioning.


When master axis resumes the operation, use another PR to run the moving distance of return trip (-Y_Drift), it can back to the original position (moving distance of going trip + moving distance of return trip = 0). E-Cam position remains the same.



Note: PR command must be the incremental command, regardless in going trip or return trip.

When E-Cam moves from current position to the target one, it can rotate at forward or reverse position. Due to the cyclic operation, it can reach the target position either at forward or reverse direction. However, the moving distance between both is usually different. Use available forward rate to plan the timing of forward and reverse rotation.

* Available forward rate: The available max. proportion of forward path



The following macros are available from version V1.042 sub09 (included):


Command code 0010h	E-Cam stops for one cycle and resumes its operation at next cycle.
General parameters	N/A
Macro parameters	Value of P5-93 has to be set to 0.

After E-Cam is engaged, this macro command can stop the slave axis for a cycle of distance regardless the E-Cam degree.

The following conditions have to be established when using this macro command.

- E-Cam must be in engaged status.
- 2. E-Cam must be the forward operation curve (including straight line) so it can stop temporally.

8-222 Revision February, 2017



Refer to the figure below, triggering this macro command, E-Cam will stop for one cycle regardless the degree (X) where E-Cam is.

- Note 1: ECAM_H (E-Cam pause distance) = table (last point first point) x P5-19 (the effective scaling)
- Note 2: This function can accumulate times. If the command is triggered for N times consecutively, it will stop the E-Cam for N cycles. The accumulated pause distance cannot exceed (>2^31), or the macro command will be disabled.
- Note 3: When E-Cam resumes the operation, the accumulated pause distance will be cleared to 0.

Failure code F101h	When executing this macro command, E-Cam is not engaged.			
Failure code F102h	The setting value of P5-93 is incorrect: It has to be set to 0.			
Failure code F103h	E-Cam has to operate at forward direction. Please check the E-Cam table and make sure P5-19 > 0.			
Failure code F104h	The accumulated pause distance exceeds 2^31. Do not execute this macro command consecutively.			

Note: A2L does not support E-Cam function.

P/5E9}8

EVON PR	# Triggered by Eve	Address: 05C4H 05C5H	
Operational Interface:	Panel / Software	Communication	Related Section: -
Default:	0		
Contro Mode :	PR		
Unit:	-		
Range :	0000 ~ 0xDDDD		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: Four items: UZYX

When EVx is set to ON, the PR# will be executed.

X=0: When EV1 is ON, PR will not be triggered.

X=1~D: When EV1 is ON, execute PR # 51~63.

Y=0: When EV2 is ON, PR will not be triggered.

Y=1~D: When EV2 is ON, execute PR # 51~63.

Note: EV3 and EV4 are supported after firmware V1.009.

Z=0: When EV3 is ON, PR will not be triggered.

Z=1~D: When EV3 is ON, execute PR # 51~63.

U=0: When EV3 is ON, PR will not be triggered.

U=1~D: When EV4 is ON, execute PR # 51~63.

D -	. 0	O
-40	₽.	N- 1

EVOF	PR	# Triggered by Event	Address: 05C6H 05C7H			
Operatio Interface		Panel / Software	Communication	Related Section: -		
Defaul	lt:	0				
 Con Mode		PR				
Uni	it :	-		: -		
Range	e :	0000 ~ 0xDDDD				
Data Size	e :	16-bit				
Forma	ıt:	Hexadecimal				
		E '' 1137.07				

Settings : Four items: UZYX

When EVx is set to OFF, the PR# will be executed.

X=0: When EV1 is OFF, PR will not be triggered.

X=1~D: When EV1 is OFF, execute PR # 51~63.

Y=0: When EV2 is OFF, PR will not be triggered.

Y=1~D: When EV2 is OFF, execute PR # 51~63.

Note: EV3 and EV4 are supported after firmware V1.009.

Z=0: When EV3 is OFF, PR will not be triggered.

Z=1~D: When EV3 is OFF, execute PR # 51~63.

U=0: When EV4 is OFF, PR will not be triggered.

U=1~D: When EV4 is OFF, execute PR # 51~63.

8-224 Revision February, 2017

P6-xx PR Parameters (Please refer to Chapter 7 for detailed setting)

P6-00

ODEF	loming Definition	ming Definition				
Operatior Interface		Panel / Software Communication				
Default	: 0x00000000	0x0000000				
Cont Mode	PR					
Unit	: -	-				
Range	: 0x00000000 ~ 0x10	0x00000000 ~ 0x10FFF3F				
Data Size	: 32-bit	32-bit				
Format	: Hexadecimal	Hexadecimal				

Settings: Homing definition:

.31 ~ 28	.27 ~ 24	.23 ~20	.19 ~ 16	.15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
BOOT	ı	DLY	-	DEC1	ACC	PA	TH

PATH: Path type (64-bit)

0: Stop: Homing complete and stop

1 ~ 3F: Auto: Homing complete and execute the specified path $(Path#1 \sim Path#63)$

ACC: Select 0~F for acceleration time and corresponds to P5-20~P5-35.

DEC1: The deceleration time selection of 1st homing, the setting value of DEC is 0~F and corresponds to P5-20 ~ P5-35.

DLY: Select 0~F for the delay time and corresponds to P5-40 ~ P5-55

BOOT: When the servo drive applies to the power, if it will be executed searching the origin.

0: Do not do homing

1: Execute homing automatically (SRV ON for the first time after applying to power)

Apart from the above mentioned definition, the related setting of homing also includes:

- 1. P5-04 Homing mode
- 2. P5-05 ~ P5-06 Speed setting of searching the origin
- 3. P6-01: ORG DEF is the location of the origin. It may not be 0. This function is the offset of coordinate system.
- A. After the origin is found (Sensor or Z); it has to decelerate to stop. The stop position will exceed the origin for a short distance.

8-225 Revision February, 2017

If it does not return to the origin, set PATH to 0.

If it needs to return to the origin, set PATH to non-zero value and set PABS = ORG_DEF.

B. If the origin is found (Sensor or Z), desire to move an offset S and define the coordinate as P after moving, then PATH = non-zero and set ORG_DEF = P-S. The absolute position command = P.

Address: 0602H P6-01 **ODAT Origin Definition** 0603H Related Section: Operational Panel / Software Communication Interface: 7.10 Default: 0 Control Mode: Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit Format: Decimal Settings : Value of origin definition: .31 ~ .27 ~ .15 ~ 11 ~ 8 7 ~ 4 3~0 .19~ 28 24 ~20 16 12 ORG_DEF (32-bit)

P6-02	PDEF1 PA	TH#1 Definition	Address: 0604H 0605H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		

8-226 Revision February, 2017

Settings : Properties of PATH# 1:

	.31 ~ 28	.27 ~ 24	.23 ~ 20	.19 ~ 16	.15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
P6-02	-	-	DLY	-	-	-	OPT	TYPE
P6-03	DATA (32 bit)							

TYPE, OPT:

	OPT			TYPE	
7	6	5	4 BIT 3 ~ 0 BIT		
-	UNIT	22AUT O INS		1: SPEED, Speed setting control	
CN	4D			2: SINGLE, Positioning control. It will load in the next path when finished.	
	VID	OVLP	OVLP 2INS	3: AUTO positioning control. It will load in the next path when finished.	
-	-	-	INS	7: JUMP to the specified path	
- AUTO INS 8: Write the specified specified path		8: Write the specified parameter to the specified path			

TYPE: 1 ~ 3 accept DO.STP stop and software limit.

INS: When executing this PR, it interrupts the previous one.

OVLP: Allow the overlap of the next path. The overlap is not allowed in speed mode. When overlap happens in position mode, DLY has no function.

AUTO: When PR procedure completes, the next procedure will be loaded in automatically.

CMD: Refer to Chapter 7 for PR command description.

DLY: $0 \sim F$, delay time number (4 BIT). The delay after executing this PR. The external INS is invalid.

24DLY (4) Index P5-40 ~ P5-55

P6-03	PDAT1 PA	TH# 1 Data		Address: 0606H 0607H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10	
	Default :	0			
	Control Mode :	PR			
	Unit :	-			
	Range :	-2147483648 ~ +2147	-2147483648 ~ +2147483647		
	Data Size :	32-bit			
	Format :	Decimal			

Settings : PATH# 1 Data

.31 ~ 28	.27 ~ 24	.23 ~20	.19 ~ 16	.15 ~ 12	11 ~ 8	7 ~ 4	3 ~ 0
DATA (32 bit)							

Property of P6-02; P6-03 corresponds to the target position of P6-02 or jump to PATH_NO.



P6-04	PDEF2 PA	TH# 2 Definition		Address: 0608H 0609H	
	Operational Interface:	nal Panel / Software Communication		Related Section: 7.10	
	Default :	0x0000000	x0000000		
	Control Mode :	PR			
	Unit :	-			
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit			
	Format :	Hexadecimal			

Settings: Please refer to the description of P6-02

P6-05	PDAT2 PA	TH# 2 Data	Address: 060AH 060BH	
	Operational Interface :	al Panel / Software Communication		Related Section: 7.10
	Default:	0		
	Control Mode :	PR		
	Unit:	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	0-44	Please refer to the	description of P6-03	

Settings: Please refer to the description of P6-03.

8-228 Revision February, 2017

6-06		TH# 3 Definition		Address: 060CH 060DH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range : 0x00000000 ~ 0xFF		FFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings : Please refer to the description of P6-02.

P6-07	PDAT3 PA	TH# 3 Data		Address: 060EH 060FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the	description of P6-03.	············

P6-08	PDEF4 P	ATH# 4 Definition		Address: 0610H 0611H
	Operation Interface	al . Panel / Software	Communication	Related Section: 7.10
		: 0x00000000		
	Contr Mode	ol DD		
	Unit	: -		

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-09	PDAT4 PA	TH# 4 Data	Address: 0612H 0613H		
	Operational Interface :	rational Panel / Software Communication		Related Section: 7.10	
	Default :	0			
	Control Mode :	PR	'R		
	Unit :	-			
	Range :	-2147483648 ~ +21	2147483648 ~ +2147483647		
	Data Size :	32-bit			
	Format :	Decimal			

Settings: Please refer to the description of P6-03.

P6-10	PDEF5 P	ATH# 5 Definition	TH# 5 Definition		
	Operation Interface		Communication	Related Section: 7.10	
	Default	: 0x00000000	0x0000000		
	Contr Mode	PR			
	Unit	: -			
	Range	: 0x00000000 ~ 0xFF	FFFFFF		
	Data Size	: 32-bit			
	Format	: Hexadecimal			
	Settings	Please refer to the	description of P6-02.	············	

8-230 Revision February, 2017

-11	PDAT5	PATH# 5 Data	TH# 5 Data		
	Operatio Interface	Daniel / Cafferiana	Daniel / Cafferiana Camanarinal antique		
	Defaul	t : 0	0		
	Con Mode	PR			
	Uni	t : -			
	Range	e: -2147483648 ~ +2	-2147483648 ~ +2147483647		
	Data Size	e: 32-bit	32-bit		
	Format : Decimal				
	L	D		•	

Settings : Please refer to the description of P6-03.

P6-12	PDEF6 PA	TH# 6 Definition	Address: 0618H 0619H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the description of P6-02.		:

P6-13	PDAT6 P	ATH# 6 Data		Address: 061AH 061BH
	Operation Interface	al . Panel / Software	Communication	Related Section: 7.10
	Default			
	Contr Mode	PR :		
	Unit			-

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-14	PDEF7 PA	TH# 7 Definition	Address: 061CH 061DH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: Please refer to the description of P6-02.

P6-15	PDAT7 PA	TH# 7 Data		Address: 061EH 061FH
	Operational Interface :		Panel / Software Communication	
	Default :	0		
	Control Mode :	PR		
	Unit :	-	- -2147483648 ~ +2147483647	
	Range :	-2147483648 ~ +21		
	Data Size :	32-bit		
	Format :	Decimal		
	Cottingo	Please refer to the	description of P6-03.	

Settings: Please refer to the description of P6-03.

8-232 Revision February, 2017

16	PDEF8 PA	TH# 8 Definition	Address: 0620H 0621H	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000)x00000000	
	Control Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFFF		
	Data Size :	32-bit		
	Format : Hexadecimal			

Settings : Please refer to the description of P6-02.

P6-17	PDAT8 PA	TH# 8 Data	Address: 0622H 0623H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0	0	
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +214	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the d	escription of P6-03.	············

P6-18		ATH# 9 Definition		Address: 0624H 0625H
	Operation Interface	al Panel / Software :	Communication	Related Section: 7.10
	Default	: 0x0000000		
	Contr Mode	₽R		
	Unit	: -		**************************************

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-19	PDAT9 PA	TH# 9 Data	Address: 0626H 0627H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0)	
	Control Mode :	PR		
	Unit :	-	-	
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P6-20	PDEF10 PA	TH# 10 Definition	Address: 0628H 0629H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFf	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	

Revision February, 2017

8-234

6-21	PDAT10 PA	TH# 10 Data	Address: 062AH 062BH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Range :	-2147483648 ~ +214	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the d	lescription of P6-03	

 PDEF11
 PATH# 11 Definition
 Address: 062CH 062DH

 Operational Interface :
 Panel / Software
 Communication
 Related Section: 7.10

 Default :
 0x00000000
 7.10

 Unit :
 Range :
 0x00000000 ~ 0xFFFFFFFF

Settings: Please refer to the description of P6-02.

Data Size: 32-bit

Format: Hexadecimal

P6-23	PDAT11 PA	TH# 11 Data		Address: 062EH 062FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-24	PDEF12 PA	TH# 12 Definition	Address: 0630H 0631H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	············

PDAT1	2 PA	TH# 12 Data		Address: 0632H 0633H
Opera Interfa	tional ace :	Panel / Software	Communication	Related Section: 7.10
Defa	ault :	0)	
	ontrol ode :	PR		
ι	Jnit :			
Rar	nge :	-2147483648 ~ +21	2147483648 ~ +2147483647	
Data S	ize :	32-bit Decimal		
Forr	nat :			
Cottin		Please refer to the	description of P6-03.	

8-236 Revision February, 2017

P6-26	PDEF13	PATH# 13 Definition	TH# 13 Definition	
	Operation Interface	Danal / Coffware	Communication	Related Section: 7.10
	Default	: 0x0000000		
	Conti Mode	PR		
	Unit	: -		
	Range	: 0x00000000 ~ 0xFF	FFFFF	
	Data Size	; 32-bit		
	Format	: Hexadecimal		
	Settings	: Please refer to the o	description of P6-02.	•

P6-27	PDAT13 PA	TH# 13 Data		Address: 0636H 0637H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the des	scription of P6-03.	:

P6-28	PDEF14 PATH# 14 Definition	Address: 0638H 0639H
	Operational Panel / Software Communication	Related Section: 7.10
	Default: 0x00000000	
	Control Mode : PR	
	Unit: -	

Range: 0x0000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-03.

P6-29	PDAT14 PA	TH# 14 Data		Address: 063AH 063BH
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default :	0)	
	Control Mode :	PR		
	Unit:	-		
	Range :	-2147483648 ~ +21	-2147483648 ~ +2147483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the	description of P6-03.	···········

P6-30		TH# 15Definition		Address: 063CH 063DH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: Please refer to the description of P6-02.

8-238 Revision February, 2017

-31	PDAT15 PA	TH# 15 Data		Address: 063EH 063FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		4
	Unit :	-		
	Range :	-2147483648 ~ +214 ⁻	7483647	
	Data Size :	32-bit		-
	Format :	Decimal		
	L	DI		

Settings : Please refer to the description of P6-03.

P6-32	PDEF16 PA	TH# 16 Definition		Address: 0640H 0641H
	Operationa Interface:	:Danal / Coffwara	Communication	Related Section: 7.10
	Default :	0x00000000	0x0000000	
	Contro Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the	Please refer to the description of P6-02.	

P6-33	PDAT16 PA	ATH# 16 Data		Address: 0642H 0643H
	:	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	PR		
	Unit:			

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-34	PDEF17 PA	TH# 17 Definition		Address: 0644H 0645H
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default:	0x00000000		
	Control Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFf	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the	Please refer to the description of P6-02.	

Address: 0646H PDAT17 PATH# 17 Data P6-35 0647H Operational Related Section: Panel / Software Communication Interface: 7.10 Default: 0 Control Mode : PR Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit

Settings: Please refer to the description of P6-03.

Format : Decimal

8-240 Revision February, 2017

5-36	PDEF18	PATH# 18 Definition	ΓH# 18 Definition		
	Operational Panel / Software Communication		Related Section: 7.10		
	Default	: 0x0000000			
	Cont Mode	PR	PR		
	Unit	i : -			
	Range	: 0x00000000 ~ 0xFF	FFFFF		
	Data Size	: 32-bit	32-bit		
	Format	: Hexadecimal	Hexadecimal		
	Settings	Please refer to the o	description of P6-02.	•	

P6-37	PDAT18 PA	TH# 18 Data		Address: 064AH 064BH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147	483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the des	scription of P6-03.	··

P6-38	PDEF19 PA	ATH# 19 Definition		Address: 064CH 064DH
	Operationa Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x00000000		
	Contro Mode :	PR		
	Unit:			

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-39	PDAT19 PA	TH# 19 Data		Address: 064EH 064FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0)	
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	-2147483648 ~ +2147483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P6-40	PDEF20 PA	TH# 20 Definition	Address: 0650H 0651H	
	Operational Interface :		Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	······i

Settings: Thousand Toron to the decomption of the obs.

8-242 Revision February, 2017

1	PDAT20	PATH# 20 Data	TH# 20 Data		
	Operation Interface	Danal / Cafferiana	Communication	Related Section: 7.10	
	Default	t : 0			
	Cont Mode	PR			
	Unit	Unit : -			
	Range	Range : -2147483648 ~ +2147483647			
	Data Size	e : 32-bit	32-bit		
	Format	t : Decimal			
	Settings	Please refer to the o	description of P6-03.	-t	

P6-42	PDEF21 PA	TH# 21 Definition		Address: 0654H 0655H
	Operational Interface :		Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the de	scription of P6-02.	•

P6-43		TH# 21 Data	Address: 0656H 0657H	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Contro Mode :	: חח		
	Unit :			
		-2147483648 ~ +2147		

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-44	PDEF22 PA	TH# 22 Definition	Address: 0658H 0659H	
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default:	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit:	-		
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	

P6-45	PDAT22 PA	TH# 22Data		Address: 065AH 065BH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0)	
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +214	7483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the de	escription of P6-03.	

8-244 Revision February, 2017

P6-46	PDEF23	PATH# 23Definition	Address: 065CH 065DH	
	Operatior Interface		Communication	Related Section: 7.10
	Default	: 0x0000000)x00000000	
	Cont Mode	PR		
	Unit	: -	-	
	Range	: 0x00000000 ~ 0xF	0x00000000 ~ 0xFFFFFFF	
	Data Size	: 32-bit	32-bit	
	Format	: Hexadecimal	Hexadecimal	
	Settings	: Please refer to the	description of P6-02.	•

Address: 065EH P6-47 PDAT23 PATH# 23Data 065FH Operational Interface : Panel / Software Related Section: Communication 7.10 Default: 0 Control Mode : PR Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit Format : Decimal Settings: Please refer to the description of P6-03.

P6-48	PDEF24 PATH# 24Definition	Address: 0660H 0661H	
	Operational Interface : Panel / Software	Communication	Related Section: 7.10
	Default: 0x00000000		
	Control Mode : PR		
	Unit : -		

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-49	PDAT24 PA	PDAT24 PATH# 24Data		Address: 0662H 0663H
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	2147483648 ~ +2147483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P6-50		TH# 25Definition	Address: 0664H 0665H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the d	escription of P6-02.	

8-246 Revision February, 2017

5-51	PDAT25 P	ATH# 25Data		Address: 0666H 0667H
		Operational Interface : Panel / Software Communication		Related Section: 7.10
	Default	: 0		
	Contro Mode	PR		
	Unit	: -		
	Range	: -2147483648 ~ +214	47483647	
	Data Size	; 32-bit		
	Format	: Decimal		
	Settings	. Please refer to the d	lescription of P6-03	•

P6-52	PDEF26 PA	TH# 26Definition	Address: 0668H 0669H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		*
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the de	scription of P6-02.	·*

P6-53	PDAT26 PATH# 26Data	Address: 066AH 066BH
	Operational Interface : Panel / Software Communication	Related Section: 7.10
	Default: 0	
	Control Mode : PR	
	Unit: -	
	Range : -2147483648 ~ +2147483647	

Data Size: 32-bit

Format: Decimal

Settings: Please refer to the description of P6-03.

Settings: Please refer to the description of P6-02.

P6-55	PDAT27 PA	TH# 27Data	ΓH# 27Data		
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10	
	Default :	0			
	Control Mode :	PR			
	Unit :	-			
	Range :	-2147483648 ~ +2147483647			
	Data Size :	32-bit			
	Format :	Decimal			
	Settings :	Please refer to the description of P6-03.			

8-248 Revision February, 2017

P6-56	PDEF28 PA	ATH# 28Definition	Address: 0670H 0671H	
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.10
	Default:	0x0000000		
	Contro Mode :	PR		7
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size: 32-bit			
	Format :	Hexadecimal		
	Settings:	Please refer to the o	description of P6-02.	- -

P6-57	PDAT28 PA	TH# 28Data		Address: 0672H 0673H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the de	scription of P6-03.	

P6-58	PDEF29 PATH# 29Definition			Address: 0674H 0675H
	Operational Interface	Panel / Software	Communication	Related Section: 7.10
	Default	0x00000000		
	Contro Mode			
	Unit	: -		

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-59	PDAT29 PA	AT29 PATH# 29Data		Address: 0676H 0677H
Operatio Interface		Panel / Software	Communication	Related Section: 7.10
	Default :			
	Control Mode :			
	Unit :	-		
Range : -2147483648 ~ +2147483647				
	Data Size :			
	Format :			

Settings: Please refer to the description of P6-03.

P6-60	PDEF30 PA	ΓH# 30Definition		Address: 0678H 0679H
	Operational Panel / Software Comm		Communication	Related Section: 7.10
	Default:	0x0000000		
	Control Mode :	PR		
	Unit:	0x00000000 ~ 0xFFFFFFF		
	Range :			
	Data Size :			
	Format :			
	Settings :	Please refer to the	description of P6-02.	

8-250 Revision February, 2017

6-61	PDAT30 PA	TH# 30Data		Address: 067AH 067BH
	Operationa Interface :	Panel / Software Communication		Related Section: 7.10
	Default:	0		
	Contro Mode :	PR		
	Unit:	-		
	Range :	-2147483648 ~ +2147	483647	
	Data Size :	32-bit		
	Format :	Decimal		
	·			i

Settings: Please refer to the description of P6-03.

P6-62	PDEF31 PA	TH# 31Definition	Address: 067CH 067DH	
	Operational Interface :	D 1/0 (1	Communication	Related Section: 7.10
	Default :	ault : 0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	: 0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the de	scription of P6-02.	er.

P6-63	PDAT31 PA	ATH# 31Data		Address: 067EH 067FH
	Operationa Interface:	ll Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	חח		
	Unit :			

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03

P6-64	PDEF32 PATH# 32Definition		Address: 0680H 0681H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x00000000		
	Control Mode :	PR		
	Unit:	0x00000000 ~ 0xFFFFFFF		
	Range :			
	Data Size :			
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	

P6-65	PDAT32 PATH# 32Data			Address: 0682H 0683H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the	description of P6-03.	

8-252 Revision February, 2017

P6-66	PDEF33 PA	TH# 33Definition	Address: 0684H 0685H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x0000000		
	Control Mode :	Control Mode : Unit : - Range : 0x00000000 ~ 0xFFFFFFF		
	Unit :			
	Range :			
	Data Size: 32-bit			
	Format :	Hexadecimal		
	Settings :	Please refer to the o	description of P6-02.	

P6-67	PDAT33 PA	TH# 33Data	Address: 0686H 0687H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647 32-bit		
	Data Size :			
	Format :	Decimal		
	Settings :	Please refer to the d	lescription of P6-03.	

P6-68	PDEF34 PA	ATH# 34Definition	Address: 0688H 0689H	
	Operationa Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x0000000		
	Control Mode : PR			
	Unit:	-		

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-69	PDAT34 PA	TH# 34Data	Address: 068AH 068BH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P6-70	PDEF35 PA	TH# 35Definition	Address: 068CH 068DH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the de	scription of P6-02.	

8-254 Revision February, 2017

P6-71	PDAT35 PA	TH# 35Data		Address: 068EH 068FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the o	lescription of P6-03.	

P6-72	PDEF36 PA	TH# 36Definition		Address: 0690H 0691H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the de	scription of P6-02.	

P6-73	PDAT36 PATH# 36Data		Address: 0692H 0693H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	:		
	Control Mode :	PR		
	Unit :			

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-74	PDEF37 PA	TH# 37Definition	Address: 0694H 0695H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFI	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the description of P6-02.		··············

PDAT37 PATH# 37Data

Operational Interface:

Panel / Software

Communication

Address: 0696H
0697H

Related Section:
7.10

Operational Interface : Panel / Software Communication 7.10

Default : 0

Control Mode : PR

Unit :
Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

8-256 Revision February, 2017

6-76	PDEF38 PA	ATH# 38Definition	Address: 0698H 0699H		
	Operationa Interface :	Panel / Software Communication		Related Section: 7.10	
	Default :	0x0000000			
	Contro Mode :	PR			
	Unit :	-			
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit			
	Format :	Hexadecimal			
	Settings:	Please refer to the o	Please refer to the description of P6-02.		

PDAT38 PATH# 38Data

Operational Interface:

Default: 0

Control Mode:

Unit:
Range: -2147483648 ~ +2147483647

Data Size: 32-bit

Format: Decimal

Settings: Please refer to the description of P6-03.

P6-78		TH# 39Definition	Address: 069CH 069DH	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		4
	Unit :	-		

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-79	PDAT39 PA	TH# 39Data		Address: 069EH 069FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the	description of P6-03.	············

Address: 06A0H P6-80 PDEF40 PATH# 40Definition 06A1H Related Section: Operational Panel / Software Communication 7.10 Interface: Default: 0x00000000 Control Mode: Unit: -Range: 0x00000000 ~ 0xFFFFFFF Data Size: 32-bit

Settings: Please refer to the description of P6-02.

Format : Hexadecimal

8-258 Revision February, 2017

P6-81	PDAT40 PA	TH# 40Data	Address: 06A2H 06A3H	
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-	-	
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	L	DI	: I: (D0.00	•

Settings: Please refer to the description of P6-03.

P6-82	PDEF41 PA	TH# 41Definition	Address: 06A4H 06A5H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the d	escription of P6-02.	·······

P6-83		ATH# 41Data	Address: 06A6H 06A7H	
	Operational Interface:	al Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	DD		
	Unit :	-		

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

-84 PDEF42	PDEF42 PATH# 42Definition		Address: 06A8H 06A9H
Operation Interfac		Communication	Related Section: 7.10
Defau	It: 0x00000000		
Con Mod	DD		
Un	it : -		
Rang	e: 0x00000000 ~ 0x	(FFFFFFF	
Data Siz	e : 32-bit		
Forma	at : Hexadecimal		
Setting	s : Please refer to th	e description of P6-02.	

8-260 Revision February, 2017

Settings: Please refer to the description of P6-03.

Format : Decimal

H

Settings : Please refer to the description of P6-02.

P6-87	PDAT43 PA	TH# 43Data	Address: 06AEH 06AFH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +214	7483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings : Please refer to the description of P6-03.

P6-88	PDEF44 PA	ATH# 44Definition	Address: 06B0H 06B1H	
	Operationa Interface:	Panel / Software	Communication	Related Section: 7.10
		0x0000000		
	Contro Mode :	PR		
	Unit:			

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-89	PDAT44 PA	TH# 44Data	Address: 06B2H 06B3H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default:	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P6-90	PDEF45 PATH# 45Definition			Address: 06B4H 06B5H
	Operational Interface :	D 1 / O - #	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFf	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	i

Settings: Please refer to the description of P6-02

8-262 Revision February, 2017

6-91	PDAT45 PA	TH# 45Data	Address: 06B6H 06B7H	
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the o	description of P6-03.	•

P6-92	PDEF46 PA	TH# 46Definition		Address: 06B8H 06B9H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		4
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFI	FFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the des	scription of P6-02.	

P6-93	PDAT46 PA	TH# 46Data	Address: 06BAH 06BBH	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P6-94		TH# 47Definition	Address: 06BCH 06BDH	
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default :	0x0000000		
	Control Mode:	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	0x00000000 ~ 0xFFFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	·············

P6-95	PDAT47 PA	TH# 47Data		Address: 06BEH 06BFH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the o	description of P6-03.	············

8-264 Revision February, 2017

P6-96		TH# 48Definition		Address: 06C0H 06C1H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings : Please refer to the description of P6-02.

P6-97	PDAT48 PA	TH# 48Data		Address: 06C2H 06C3H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0	0	
	Contro Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +214	7483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the de	escription of P6-03.	.

PDEF49 PATH# 49Definition

Operational Interface:

Default: 0x00000000

Control Mode:

Unit: -

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P6-99	PDAT49 PA		Address: 06C6H 06C7H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

8-266 Revision February, 2017

P7-xx PR Parameters (Please refer to Chapter 7 for detailed setting)

P7-00	PDEF50	PATH# 50 Definition	ΓH# 50 Definition		
	Operatio Interface		Communication	Related Section: 7.10	
	Defaul	t: 0x0000000			
	Con Mode	פס			
	Uni	t : -			
	Range	e: 0x00000000 ~ 0xF	FFFFFF		
	Data Size	e : 32-bit	32-bit		
	Forma	t : Hexadecimal	Hexadecimal		
	Settings	gs: Please refer to the description of P6-02			

NOTE PATH (procedure)

7-01	PDAT50 PATH# 50 Data		Address: 0702H 0703H	
	Operational Interface :	Donal / Coffwore	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the	description of P6-03.	

P7-02	PDEF51 PA	TH# 51 Definition	Address: 0704H 0705H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR	PR	
	Unit :	nit : -		
	Range :	0x00000000 ~ 0xFF	FFFFF	
	Data Size :	e : 32-bit		
	Format :	-lexadecimal		
	Settings :	Please refer to the o	lescription of P6-02.	

Address: 0706H P7-03 PDAT51 PATH# 51 Data 0707H Operational Interface : Panel / Software Related Section: Communication 7.10 Default: 0 Control PR Mode: Unit: -Range: -2147483648 ~ +2147483647 Data Size: 32-bit Format : Decimal

P7-04	PDEF52 PATH# 52 Definition		Address: 0708H 0709H	
		Panel / Software	Communication	Related Section: 7.10
		0x00000000		
	Contro Mode :	l DD		
	Unit :	-		

Settings: Please refer to the description of P6-03.

8-268 Revision February, 2017

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: HEXADECIMAL

Settings: Please refer to the description of P6-02.

P7-05	PDAT52 PA	TH# 52 Data		Address: 070AH 070BH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P7-06	PDEF53 PA	TH# 53 Definition		Address: 070CH 070DH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the de	escription of P6-02.	

07		ATH# 53 Data		Address: 070EH 070FH
	Operationa Interface :	ll Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	ol PR	PR	
	Unit:	-		
	Range :	-2147483648 ~ +214	17483647	
	Data Size :	32-bit		
	Format :	Decimal		
		Diagon refer to the d	accription of DC 02	

Settings: Please refer to the description of P6-03.

P7-08	PDEF54 PA	TH# 54 Definition		Address: 0710H 0711H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFF	FFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the des	scription of P6-02.	•

P7-09		ATH# 54 Data		Address: 0712H 0713H
	1	Panel / Software	Communication	Related Section: 7.10
	Default :			
	Contro Mode :	PR		
	Unit:			

8-270 Revision February, 2017

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P7-10	PDEF55 PATH# 55 Definition			Address: 0714H 0715H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000		
	Control Mode :	PR	PR	
	Unit:	-		
	Range :	0x00000000 ~ 0xFf	FFFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the	description of P6-02.	

11	PDAT55 PA	ATH# 55 Data	Address: 0716H 0717H	
	Operationa Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	PR		
	Unit:	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		

Settings : Please refer to the description of P6-03.

Format : Decimal

P7-12	PDEF56 PA	TH# 56 Definition		Address: 0718H 0719H
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFI	FFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the des	scription of P6-02.	•

P7-13	PDAT56 PA	TH# 56 Data	ΓH# 56 Data		
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10	
	Default:	0)		
	Control Mode :	PR			
	Unit :	-			
	Range :	-2147483648 ~ +21	47483647		
	Data Size :	32-bit			
	Format :	Decimal			
	Settings :	Please refer to the o	lescription of P6-03.	·············	

P7-14	PDEF57 PA	ATH# 57 Definition		Address: 071CH 071DH
	Operationa Interface :	ll Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Contro Mode :	PR		
	Unit :			

8-272 Revision February, 2017

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P7-15	PDAT57 PA	TH# 57 Data		Address: 071EH 071FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		

Settings: Please refer to the description of P6-03.

P7-16	PDEF58 PA	TH# 58 Definition	Address: 0720H 0721H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the de	escription of P6-02.	

17	PDAT58 PA			Address: 0722H 0723H
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	Control Mode :		
	Unit :	-		
	Range : -2147483648 ~ +2147483647		7483647	
	Data Size: 32-bit			
	Format :	Decimal		
		DI		

Settings: Please refer to the description of P6-03.

P7-18	PDEF59 PA	TH# 59 Definition	Address: 0724H 0725H	
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0x0000000	0x0000000	
	Control Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	FFFFF	
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings :	Please refer to the o	lescription of P6-02.	············

P7-19	PDAT59 PA	ATH# 59 Data		Address: 0726H 0727H
	Operationa Interface:	l Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Contro Mode :	PR		
	Unit :			•

8-274 Revision February, 2017

Range : -2147483648 ~ +2147483647

Data Size : 32-bit

Format : Decimal

Settings: Please refer to the description of P6-03.

P7-20	PDEF60 PA	TH# 60 Definition	Address: 0728H 0729H	
	Operational Panel / Software Communication		Related Section: 7.10	
	Default :	0x00000000	0x0000000	
	Control Mode :	PR		
	Unit :	-	0x00000000 ~ 0xFFFFFFF	
	Range :	0x00000000 ~ 0xFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		

Settings: Please refer to the description of P6-02.

P7-21	PDAT60 PA	TH# 60 Data	Address: 072AH 072BH	
	Operational Interface :	Panel / Software Communication		Related Section: 7.10
	Default: 0			
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +21	47483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the	description of P6-03.	···········

7-22	PDEF61 PA	ATH# 61 Definition	Address: 072CH 072DH	
	Operationa Interface:	:D 1/O (1	Communication	Related Section: 7.10
	Default:	0x00000000		
	Contro Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFFFFFFF		
	Data Size :	32-bit		
	Format :	Hexadecimal		
	Settings:	Please refer to the o	lescription of P6-02.	•

P7-23	PDAT61 PA	TH# 61 Data		Address: 072EH 072FH
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147	483647	
	Data Size :	32-bit		
	Format :	Decimal		
	Settings :	Please refer to the de	scription of P6-03.	•

P7-24		TH# 62 Definition		Address: 0730H 0731H
		Panel / Software	Communication	Related Section: 7.10
	Default:	0x00000000		
	Control Mode :	PR		
	Unit:	-		

8-276 Revision February, 2017

Range: 0x00000000 ~ 0xFFFFFFF

Data Size: 32-bit

Format: Hexadecimal

Settings: Please refer to the description of P6-02.

P7-25		TH# 62 Data		Address: 0732H 0733H
	Operational Interface :	Panel / Software	Communication	Related Section: 7.10
	Default :	0		
	Control Mode :	PR		
	Unit :	-		
	Range :	-2147483648 ~ +2147483647		
	Data Size :	32-bit		
	Format :	Decimal		
	Settings:	Please refer to the	description of P6-03.	············

P7-26	PDEF63 PA	TH# 63 Definition		Address: 0734H 0735H
	Operational Interface:	Panel / Software	Communication	Related Section: 7.10
	Default :	0x00000000		
	Contro Mode :	PR		
	Unit :	-		
	Range :	0x00000000 ~ 0xFF	FFFFFF	
	Data Size :			

Settings: Please refer to the description of P6-02.

Format: Hexadecimal

P7-27

PDAT63	РА	TH# 63 Data		Address: 0736H 0737H
Operatio Interface	nal e :	Panel / Software	Communication	Related Section: 7.10
Defaul	lt:	0		
Con Mode		PR		
Uni	it:	-		
Range	e :	-2147483648 ~ +21	47483647	
Data Size	e :	32-bit		
Forma	nt:	Decimal		
Settings	s:	Please refer to the o	lescription of P6-03.	•

8-278 Revision February, 2017

Table 8.1 Function Description of Digital Input (DI)

Setting Va	Setting Value: 0x01				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode		
SON	When this DI is On, servo is activated (Servo On)	Level triggered	ALL		

Setting Va	Setting Value: 0x02				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode		
ARST	After the alarm has been cleared, when the DI is ON the drive will show that the alarm has been cleared.	Rising edge triggered	ALL		

Setting Va	Setting Value: 0x03					
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode			
GAINUP	In speed and position mode, when the DI is ON (P2-27 should be set to 1), the gain switched to the one multiplies the switching rate.	Level triggered	PT, PR, S			

Setting Va	alue: 0x04		
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
CCLR	Clear the pulse counter and the setting of parameter P2-50. 0: clear the position pulse deviation (It is suitable in PT mode). When DI is ON, the accumulative pulse deviation of the drive will be cleared to 0.	Rising edge triggered, Level triggered	PT, PR

Setting Va	Setting Value: 0x05						
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode				
ZCLAMP	When the speed is slower than the setting of zero speed (P1-38), if the DI is ON, the motor stops running.	Level triggered	S				
	Speed Command Setting value of P1-38 (Zero speed)						
	ZCLAMP input signal OFF ON						
	Motor Speed Setting value of P1-38 (Zero speed) Time						

Setting Value: 0x06				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
CMDINV	In speed mode, when the DI is ON, the input command will be in reverse direction.	Level triggered	S	

Setting Va	lue: 0x07					
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode			
	Reserved					


Setting Value: 0x08									
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode						
	In PR mode, after selecting the PR command (POS0 ~ 5), when the DI is ON, the motor will rotate according to the command issued by the register.	Rising edge triggered	PR						

Setting Value: 0x09									
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode						
	In speed and position mode, when the DI is ON, the motor torque will be limited, and the limited torque command will be internal register or analog voltage command.	Level triggered	PT, PR, S						

Setting Value: 0x0A									
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode						
GTRY	When gantry control function is enabled (P1-74 = 2), if it needs to temporarily disable this function, turn on DI.GTRY will do. And the axis that received the command from DI.GTRY no longer calculates the error between two axes.	Rising edge triggered	PT						

Setting Value: 0x0C								
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode					
VPL	Latch function of analog position command. When this DI is ON, the motor will be held on the current position. During the time of DI ON, the motor will not operate even when there is any change of analog command. When this DI is OFF, the motor will complete the command during the time the DI is triggered.	Level triggered	PT/PR Full- closed loop					

8-280 Revision February, 2017



Setting Va	alue: 0x0D		
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
VPRS	Clear function of analog position command When this DI is ON, the motor will be held in the current position. Despite the change of analog command during the time of DI ON, the motor will still stay in the current position even when the DI is OFF. However, the position the motor stays will correspond to the new analog command. Thus, the coordinate system of the motor will be redefined. Motor position (Turn) When DI is OFF, the motor stands still, but its coordinate will be redefined. When DI is OFF, the motor stands still, but its coordinate will be redefined.	Rising edge triggered	PT/PR Full- closed loop

Setting Value: 0x10							
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode				
SPDLM	In torque mode, when the DI is ON, the motor speed will be limited, the limited speed command will be internal register or analog voltage command.	Level triggered	Т				

Setting Value: 0x11, 0x12, 0x13, 0x1A, 0x1B, 0x1C													
DI Name		Function Description of Digital Input (DI)											
POS0	PR Comma	Level	PR										
POS1 POS2	Position Command	POS5	POS4	POS3	POS2	POS1	POS0	CTRG	Corresponding Parameter	triggered			
POS3 POS4	Homing	0	0	0	0	0	0	1	P6-00 P6-01				
POS5	Procedure1	0	0	0	0	0	1	1	P6-02 P6-03				
	~												
	Procedure 50	1	1	0	0	1	0	1	P6-98 P6-99				
	Procedure 51	1	1	0	0	1	1	1	P7-00 P7-01				
	~												
	Procedure 63	1	1	1	1	1	1	†	P7-26 P7-27				

Setting Value: 0x1D								
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode					
	When DI.ABSE is ON, it is in ABS mode. DI.ABSQ, DI.ABSC, DI.ABSR, DI.ABSD and DI.ABSC are enabled.	Lovol	ALL					
ABSE	When DI.ABSE is ON, the function of DI4, DO2, and DO3 will be disabled. Function of DI4 will be ASDQ, DO2 will be ABSR and DO3 will be ABSD.	Level triggered						

Setting Value: 0x1F									
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode						
	When DI.ABSC is ON, multi-turn data stored in absolute encoder will be cleared. When DI.ABSE is ON, this function is enabled.	Rising edge triggered	ALL						

8-282 Revision February, 2017

Setting Value: When DI.ABSE is ON, DI4 inputs ABSQ signal, function set by P disabled.								
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode					
ABSQ is always inputted by DI4	During I/O transmission, Handshaking signal will be sent to the servo drive by the controller. When DI.ABSQ is OFF, it means the controller issues Request; DI.ABSQ is ON means the controller has already recdived ABSD signal. When DI.ABSE is ON, this DI is enabled. Please refer to diagram 12.4 for detailed description.	Rising and Falling edge triggered	ALL					

Setting	Value: 0x14,	0x1	5									
DI Name		Function Description of Digital Input (DI)										
SPD0	Internal Spe	Internal Speed Command Selection (1~4)										
SPD1	Speed Command Number	DI sigr		Con	nmand	Content	Range	triggered				
	S1	0	0 0	0 0	S	External analog command	Voltage deviation between V-REF and GND	+/- 10V				
				S z	N/A	Speed command is 0	0					
	S2	0	1	_	jister ameter	P1-09	+/-5000 r/min					
	S3	1	0			P1-10	+/-5000 r/min					
	S4	1	1			P1-11	+/- 5000 r/min					

Setting '	Value: 0x16,	0x1	7								
DI Name		Function Description of Digital Input (DI)									
TCM0	Internal Toro	que C	comm	and S	Selection (1~	4)		Level	Т		
TCM1	Torque Command Number	DI sigr		Com	imand	Content	Range	triggered			
	T1	0	0	Т	External analog command	Voltage deviation between T-REF and GND	+/- 10V				
				Tz	N/A	Torque command is 0	0				
	T2	0	1	Regi		P1-12	+/- 300 %				
	Т3	1	0] Para	ımeter	P1-13	+/- 300 %				
	T4	1	1			P1-14	+/- 300 %				
		*				-	•				

Setting Value: 0x18			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
S-P	In position and speed mode, if the DI is OFF, it is in speed mode. And it is in position mode when the DI is ON. (P selects PT or PR via DI.PT-PR (0x2B).)	Level triggered	Dual Mode

Setting Value: 0x19			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
S-T	In speed and torque mode, if the DI is OFF, it is in speed mode. And it is in torque mode when the DI is ON.	Level triggered	Dual Mode

Setting Value: 0x20			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
T-P	In position and torque mode, if the DI is OFF, it is in torque mode; if the DI is ON, then it is in position mode.	Level triggered	Dual Mode

Setting Value: 0x21			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
EMGS	When this DI is ON, the motor stops urgently.	Level triggered	ALL

Setting Value: 0x22			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
NL (CWL)	Reverse inhibit limit (contact b)	Level triggered	ALL

Setting Value: 0x23				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
PL (CCWL)	Forward inhibit limit (contact b)	Level triggered	ALL	

8-284 Revision February, 2017

Setting Value: 0x24				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
	In PR mode, during the process of homing if the DI is ON ←→ OFF, the servo will regard this position as the homing origin. (Please refer to the setting of parameter P5-04)	Rising / Falling edge triggered	PR	

Setting Value: 0x27			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
	In PR mode, when searching the origin is needed, it will activate the function of searching the origin when the DI is ON. (Please refer to the setting of parameter P5-04)	Rising edge triggered	PR

Setting Value: 0x2B			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
	When selecting PT-PR dual mode or PT-PR-S multiple mode, source can be selected via this DI. If this DI is OFF, it is in PT mode; If the DI is ON, it is in PR mode.	Level triggered	Dual Mode

Setting Va	Setting Value: 0x36			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
CAM	E-Cam engaging control (Please refer to the setting of P5-88 U, Z value)	Rising / Falling edge triggered	PR	

Setting Value: 0x37			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
JOGU	When this DI is ON, the motor will JOG in forward direction.	Level triggered	ALL

Setting Value: 0x38			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
JOGD	When this DI is on, the motor will JOG in reverse direction.	Level triggered	ALL

Setting Value: 0x39			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
EV1	Event trigger command #1 (Refer to the setting of P5-98, P5-99)	Rising /Falling edge triggered	PR

Setting Value: 0x3A			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
EV2	Event trigger command #2 (Refer to the setting of P5-98, P5-99)	Rising /Falling edge triggered	PR

Setting Va	Setting Value: 0x3B			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
EV3	Event trigger command #3 (It is provided after firmware version V1.008 sub04.)	Rising /Falling edge triggered	PR	
Setting Va	alue: 0x3C			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
EV4	Event trigger command #4 (It is provided after firmware version V1.008 sub04)	Rising /Falling edge triggered	PR	

Setting Value: 0x43, 0x44				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode	
GNUM0	Gear Ratio Selection 0 (Numerator)	Level	PT	
GNUM1	Gear Ratio Selection 1 (Numerator) GNUM0, GNUM1 1st Numerator (N1) (P1-44) 2nd Numerator (N2) (P2-60) 3rd Numerator (N3) (P2-61) 4th Numerator (N4) (P2-62) Denominator (P1-45) Feed Back Pulse	triggered		

8-286 Revision February, 2017

Setting Value: 0x45			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
INHP	In position mode, when this DI is ON, the external pulse input command is not working. (Note: The function has to be set to DI8 so as to ensure the instantaneity of pulse prohibition)	Level triggered	PT

Setting Value: 0x46			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
STOP	Motor stops	Rising edge triggered	PR

Setting Value: 0x47			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
	This DI can be used to stop the emergency stop of deceleration time. The setting of deceleration time is identical to P5-03. When DI.PFQS is on, AL35F will occur. Then, motor starts to decelerate. When the speed reaches 0, AL3CF occurs and servo is off. Please turn on DI.ARST to servo on the drive again.	Rising edge triggered	PT,PR,T,S



- NOTE 1) 11 ~ 17 Single control modes; 18~20 Dual control mode.
 - 2) When P2-10 \sim P2-17 is set to 0, DI has no function.

8-287 Revision February, 2017

Table 8.2 Function Description of Digital Output (DO)

Setting Value: 0x01			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SRDY	When the controlled and main circuit power is applied to the drive, this DO is ON if no alarm occurs.	Level triggered	ALL

Setting Va	Setting Value: 0x02					
DO Name	Function Description of Digital Output (DO)	- 33	Control Mode			
SON	When the servo is ON, this DO is ON if no alarm occurs. As soon as it applies to the power, when it is automatically Servo On, the time difference between DO:SRDY and DO:SON ON ON ON ON ON Approx. 300 ns	Level triggered	ALL			

Setting Value: 0x03			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
	When the motor speed is slower than the setting speed of zero speed (P1-38), this DO is ON.	Level triggered	ALL

Setting Value: 0x04			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
	When the motor speed is faster than the target speed (P1-39), this DO is ON.	Level triggered	ALL

Setting Va	Setting Value: 0x05			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
	In position mode, when the deviation pulse number is smaller than the position range (the setting value of P1-54), this DO is ON. When the drive is in PR mode, this DO is ON when the position error between target position and current position is smaller than the setting value (value of P1-54).	Level triggered	PT, PR	

8-288 Revision February, 2017

Setting Value: 0x06			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
TQL	When it is in torque limit, this DO is ON.	Level triggered	ALL , except T, Tz

Setting Value: 0x07			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
	When the alarm occurs, this DO is ON. (Except DO: 0x11 (forward / reverse limit, communication error, under voltage))	Level triggered	ALL

Setting Value: 0x08			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
BRKR	When the signal of brake control is output, adjust the setting of parameter P1-42 and P1-43. ON SON OFF ON BRKR OFF MBT1(P1-42) MBT2(P1-43) Motor Speed ZSPD (P1-38)	Level triggered	ALL

Setting Value: 0x09			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
HOME	When homing is completed, it means the position coordinates system is available and this DO is ON.	Level triggered	PR
	When applying to the power, this DO is OFF. When homing is completed, this DO is ON. During the operation, this DO is ON until the counter overflows (including command or feedback) and the DO becomes OFF.		
	When PR triggers homing command, this DO becomes OFF. After homing, this DO becomes ON.		

Setting Value: 0x0D			
DO Name	Function Description of Digital Output (DO)	Control Mode	
ABSW	Warning of absolute encoder.	ALL	

Chapter 8 Parameters ASDA-A2

Setting Value: 0x0E		
DO Name	Function Description of Digital Output (DO)	Control Mode
IDXD	Indexing coordinates is valid.	PR

Setting Va	Setting Value: 0x10			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
OLW	When reaching the overload setting, this DO is ON. $t_{\text{OL}} = \text{Overload allowable time of the servo } x \text{ Setting value of P1-56,} \\ \text{when the overload accumulative time exceeds } t_{\text{OL}}, \text{ it will output pre-overload warning (OLW). However, if the overload accumulative time exceeds the overload allowable time of the servo, it will output pre-overload error (ALRM).} \\ \text{For example:} \\ \text{The setting value of pre-overload warning is 60% (P1-56=60).} \\ \text{When the output average load of the servo drive is 200%, if the output time exceeds 8 seconds, the servo drive will show the overload alarm (AL.006).} \\ }$	Level triggered	ALL	
	t _{OL} = The output average load of the servo exceeds 200% for 8 seconds x parameter setting value = 8sec x 60% = 4.8sec			
	Result: When the output average load of the servo drive exceeds 200% for 4.8 seconds, this DO is ON. If it exceeds for 8 seconds, then, DO.ALRM is ON.			

Setting Va	Setting Value: 0x11		
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
WARN	Warning output (Forward / reverse limit, emergency stop, communication error, under voltage)	Level triggered	ALL

Setting Va	Setting Value: 0x12		
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
OVF	Position Command /Feedback Overflows	Level triggered	PR

Setting Va	Setting Value: 0x13		
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SNL (SCWL)	Software limit (Reverse limit)	Level triggered	ALL

8-290 Revision February, 2017

ASDA-A2 Chapter 8 Parameters

Setting Va	Setting Value: 0x14			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
SPL (SCCWL)	Software limit (Forward limit)	Level triggered	ALL	

Setting Value: 0x15			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
_	Complete PR command and enter into PR mode, this DO is ON. When PR command is executing, this DO is OFF. After completing the command, this DO is ON. When the DO is ON, it means the command is completed, but not finishing motor positioning. Please refer to DO.TPOS.	Level triggered	PR

Setting Va	Setting Value: 0x16			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
CAP_OK	CAP procedure completed	Level triggered	ALL	

Setting Value: 0x17			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
_	When DO.Cmd_OK and TPOS are both ON, this DO is ON. Refer to P1-48.	Level triggered	PR

Setting Value	Setting Value: 0x18			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
CAM_AREA	Master of E-Cam locates in setting area.	Level	PR	
	A2L does not support E-Cam function.	triggered		

Setting Va	Setting Value: 0x19		
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
	Speed completed output: In speed mode, when the deviation between the speed feedback and the command is smaller than the setting value of P1-47, then this DO is ON.	Level triggered	S / Sz

Chapter 8 Parameters ASDA-A2

Setting Value: 0x2C				
DO Name	Function Description of Digital Output (DO)	Control Mode		
20111	When the value which is monitored by P0-09 is between P0-54 ~ P0-55, then this DO is ON.	ALL		

Setting Va	Setting Value: When DI.ABSE is ON, DO2 outputs ABSR signal, function set by P2-19 is disabled.				
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode		
always outputted	DO.ABSR is OFF means the Request sent by ABSQ has been received. DO.ABSR is ON means the data that is outputted by ABSD is valid. When DI.ABSE is ON, this DO is enabled. Please refer to diagram 12.4 for detailed description.	Level triggered	ALL		

Setting Va	Setting Value: When DI.ABSE is ON, DO3 outputs ABSD signal, function set by P2-20 is disabled.				
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode		
always	Position data of ABS is outputted. The data is valid when ABSR is ON. When DI.ABSE is ON, this DO is enabled. Please refer to diagram 13.4 for detailed description.	Level triggered	ALL		

Setting Value: 0x30				
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
SDO_0	Output the status of bit 00 of P4-06	Level triggered	ALL	

Setting Value: 0x31			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SDO_1	Output the status of bit 01 of P4-06	Level triggered	ALL

Setting V	Setting Value: 0x32			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
SDO_2	Output the status of bit 02 of P4-06	Level triggered	ALL	

8-292 Revision February, 2017

ASDA-A2 Chapter 8 Parameters

Setting Value: 0x33			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SDO_3	Output the status of bit 03 of P4-06	Level triggered	ALL

Setting Value: 0x34			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SDO_4	Output the status of bit 04 of P4-06	Level triggered	ALL

Setting Value: 0x35			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SDO_5	Output the status of bit 05 of P4-06	Level triggered	ALL

Setting Va	Setting Value: 0x36				
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode		
SDO_6	Output the status of bit 06 of P4-06	Level triggered	ALL		

Setting Value: 0x37			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
SDO_7	Output the status of bit 07 of P4-06	Level triggered	ALL

Setting Va	Setting Value: 0x38			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
SDO_8	Output the status of bit 08 of P4-06	Level triggered	ALL	

Setting Va	Setting Value: 0x39				
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode		
SDO_9	Output the status of bit 09 of P4-06	Level triggered	ALL		

ASDA-A2 **Chapter 8 Parameters**

Setting Value: 0x3A						
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode			
SDO_A	Output the status of bit 10 of P4-06	Level triggered	ALL			

Setting Value: 0x3B						
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode			
SDO_B	Output the status of bit 11 of P4-06	Level triggered	ALL			

Setting Va	Setting Value: 0x3C						
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode				
SDO_C	Output the status of bit 12 of P4-06	Level triggered	ALL				

Setting Va	Setting Value: 0x3D						
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode				
SDO_D	Output the status of bit 13 of P4-06	Level triggered	ALL				

Setting Value: 0x3E						
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode			
SDO_E	Output the status of bit 14 of P4-06	Level triggered	ALL			

Setting Va	Setting Value: 0x3F							
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode					
SDO_F	Output the status of bit 15 of P4-06	Level triggered	ALL					



NOTE 1) When P2-18 ~ P2-22 is set to 0, DO has no function.

8-294 Revision February, 2017


Chapter 9 Communications

9.1 RS-485 & RS-232 Communication Hardware Interface

This servo drive supports the serial communication of RS-485 and RS-232. Communication function enables the servo drive to access and change parameters inside the system. However, RS-485 and RS-232 cannot be used at the same time. Parameter P3-05 can use RS-485 and RS-232 as the communication protocol. Followings are the wiring description.

RS-232

■ Configuration






- 1) 15-meter communication cable is suitable for less interference environment. If the transmission speed is over 38400bps, the length of communication cable should be shorter than 3 meters so as to ensure the accuracy of transmission.
- 2) Numbers shown in the above diagram represent the pin number of each connector.

RS-485

■ Configuration





- 1) 100 meters of communication cable is suitable for less interference environment. If the transmission speed is over 38400bps, the length of communication cable should not longer than 15 meters so as to ensure the accuracy of transmission.
- 2) Numbers shown in the above diagram represent the pin number of each connector.
- 3) Please use the power supply unit whose direct current is over 12 volt.
- 4) Using RS-485 can connect up to 32 servo drives at the same time. REPEATER can be used to connect more servo drives. 127 is the maximum.
- 5) Please refer to Chapter 3.6 for CN3 Pin Definition.

9-2 Revision February, 2017

Chapter 9 Communications ASDA-A2

9.2 RS-485 / RS-232 Communication Parameters Setting

The following four parameters, P3-00 (Address Setting), P3-01 (Transmission Speed), P3-02 (Communication Protocol) and P3-05 (Communication Mechanism), are essential and must be set for the communication of the servo drive. The rest, such as P3-03 (Communication Error Disposal), P3-04 (Communication Timeout), P3-06 (Control Switch of Digital Input), P3-07 (Communication Response Delay Time) and P3-08 (Monitor Mode) is optional. Please refer to Chapter 8 of this user manual.

Address: 0300H P3-00• **ADR Address Setting** 0301H Related Section: Operational Panel / Software Communication 9.2 Interface: Default: 0x7F Control ALL Mode: Unit: |-Range: $0x01 \sim 0x7F$ Data Size: 16-bit Format: Hexadecimal

Settings: The communication address setting is divided into Y, X (hexadecimal):

	0	0	Y	Х	
Range	-	-	0 ~ 7	0 ~ F	

When using RS-232/RS-485 to communicate, one servo drive can only set one address. The duplicate address setting will cause abnormal communication.

This address represents the absolute address of the servo drive in communication network. It is also applicable to RS-232/485 and CAN bus.

When the communication address setting of MODBUS is set to 0xFF, the servo drive will automatically reply and receive data regardless of the address. However, P3-00 cannot be set to 0xFF.

P3-01

BRT Tra	ansmission Speed		Address: 0302H 0303H
Operational Interface :	Panel / Software	Communication	Related Section: 9.2
Default :	0x0203		
Control Mode :	ALL		
Unit:	bps		
Range :	0x0000 ~ 0x0405		
Data Size :	16-bit		
Format :	Hexadecimal		

Settings: The setting of transmission speed is divided into Z, Y, X (hexadecimal):

	0	Z	Y	Х
Communication Port	-	CAN	-	RS-232/485
Range	0	0~4	0	0~5

- Definition of X setting value
 - 0:4800
 - 1: 9600
 - 2: 19200
 - 3: 38400
 - 4: 57600
 - 5: 115200
- Definition of Z setting value
 - 0: 125 Kbit/s
 - 1: 250 Kbit/s
 - 2: 500 Kbit/s
 - 3: 750 Kbit/s
 - 4: 1.0 Mbit/s



- NOTE 1) If this parameter is set via CAN, only Z can be set and the others
 - 2) The communication speed of USB is 1.0 Mbit/s only and is unchangeable.

9-4 Revision February, 2017 P3-02

PTL	Со	mmunication Protoco	Address: 0304H 0305H	
Operationa Interface :		Panel / Software	Communication	Related Section: 9.2
Defau	lt:	6		
Con Mod		ALL		
Un	it :	-		
Rang	e :	0 ~ 0x8		
Data Size :		16-bit		
Format :		Hexadecimal		
0-4:		The definition of the se	tting value is as the follo	owings:

Settings : The definition of the setting value is as the followings:

0: 7, N, 2 (MODBUS, ASCII)

1: 7, E, 1 (MODBUS, ASCII)

2: 7, O,1 (MODBUS, ASCII)

3: 8, N, 2 (MODBUS, ASCII)

4: 8, E, 1 (MODBUS, ASCII)

5: 8, O, 1 (MODBUS, ASCII)

6: 8, N, 2 (MODBUS, RTU)

7: 8, E, 1 (MODBUS, RTU)

8: 8, O, 1 (MODBUS, RTU)

P3-05	СММ С	ommunication Mech	anism	Address: 030AH 030BH
	Operational Interface:	al Panel / Software	Communication	Related Section: 9.2
	Default :	0		
	Contro Mode :	ALL		
	Unit :			
	Range :			
	Data Size :	16-bit		
	Format :	Hexadecimal		

Settings: Communication port can select one or more than one communications.

Communication Interface

0: RS232 1: RS485

9.3 MODBUS Communication Protocol

There are two modes of MODBUS networks communication, ASCII (American Standard Code for information interchange) mode and RTU (Remote Terminal Unit) mode. Users could set the needed communication protocol via parameter P3-02. Apart from these two communication modes, this servo drive also supports function of 03H to access more than one data, 06H to write one character and 10H to write multiple characters. Please refer to the following descriptions.

■ Code Description

ASCII Mode:

The so-called ASCII mode is using American Standard Code for Information Interchange (ASCII) to transmit the data. Between two stations (Master and Slave) to transmit data 64H, the master will send '6' which represented by 36H of ASCII code and '4' represented by 34H of ASCII code.

ASCII code of digit 0 to 9 and characters A to F is as follows:

Character	'0'	'1'	'2'	'3'	'4'	' 5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

RTU Mode:

Every 8-bit of data is constituted by two 4-bits hexadecimal characters. If data 64H is transmitted between two stations, it will be transmitted directly, which is more efficient than ASCII mode.


Character Structure

Characters will be encoded into the following framing and transmitted in serial. The checking method of different bit is as the following.


9-6 Revision February, 2017

Chapter 9 Communications ASDA-A2

10-bit character frame (For 7-bit character)



11-bit character frame (For 8-bit character)



■ Communication Data Structure

ASCII Mode:

Start	Start character ': ' (3AH)	
Slave Address	Communication address: 1-byte consists of 2 ASCII codes	
Function	Function code: 1-byte consists of 2 ASCII codes	
Data (n-1)	Data content: n-word = 2n-byte includes 4n of ASCII code, n<=10	
Data (0)		
LRC	Error checking: 1-byte consists of 2 ASCII codes	
End 1	End code 1: (0DH)(CR)	
End 0	End code 0: (0AH)(LF)	

The start character of communication in ASCII mode is colon ':' (ASCII is 3AH), ADR is the ASCII code of two characters. The end code is CR (Carriage Return) and LF (Line Feed). And the communication address, function code, data content, error checking LRC (Longitudinal Redundancy Check), etc are between the start character and end code.

RTU Mode:

Start	A silent interval of more than 10ms	
Slave Address	Communication address: 1-byte	
Function	Function code: 1-byte	
Data (n-1)		
	Data content: n-word =2n-byte · n<=10	
Data (0)		
CRC	Error checking: 2-byte	
End 1	A silent interval of more than 10ms	

The start of communication in RTU (Remote Terminal Unit) mode is a silent interval. The end of it is another silent interval. The communication address, function code, data content, error checking CRC (Cyclical Redundancy Check), etc are between the start and the end.

9-8 Revision February, 2017

Chapter 9 Communications ASDA-A2

Example 1: function code 03H, access multiple words:

The Master issues the command to the 1st Slave and reads the continuous 2 words starting from the start address 0200H. In response message from the Slave, the content of starting address 0200H is 00B1H and the content of the 2nd data address 0201H is 1F40H. The maximum allowable data in one single access is 10. The calculation of LRC and CRC will be described in next chapter.

ASCII Mode:

Command message (Master):

Start	.,,	
Slave Address	'0'	
	'1'	
Function	'0'	
	'3'	
	'0'	
Starting data	'2'	
address	'0'	
	'0'	
	'0'	
Number of data	'0'	
(In Word)	'0'	
	'2'	
LRC Check	'F'	
LRC Check	'8'	
End 1	(0DH)(CR)	
End 0	(0AH)(LF)	

Response message (Slave):

Start	
Clave Address	'0'
Slave Address	'1'
Function	'0'
Function	'3'
Number of data	'0'
(In Byte)	'4 '
	'0'
Content of starting data	'0'
address 0200H	'B'
	'1'
	'1'
Content of second data address 0201H	'F'
	'4'
	'0'
LRC Check	'E'
LRC Check	'8'
End 1	(0DH)(CR)
End 0	(0AH)(LF)

RTU Mode:

Command message (Master):

Slave Address	01H
Function	03H
Starting data address	02H (High)
	00H (Low)
Number of data (In Word)	00H
	02H
CRC Check Low	C5H (Low)
CRC Check High	B3H (High)

Response message (Slave):

Slave Address	01H
Function	03H
Number of data (In Byte)	04H
Content of starting data address 0200H	00H (High)
	B1H (Low)
Content of	1FH (High)
second data address 0201H	40H (Low)
CRC Check Low	A3H (Low)
CRC Check High	D4H (High)

Please note:

Before and after the transmission in RTU mode, 10ms of silent interval is needed.

9-10 Revision February, 2017

Example 2: function code 06H, write single word:

The Master issues command to the 1st Slave and writes data 0064H to address 0200H. The Slave sends the response message to the Master after the writing is completed. The calculation of LRC and CRC will be described in next chapter.

ASCII Mode:

Command message (Master):

Start	· ·
Olava Addus	'0'
Slave Address	'1'
Function	'0'
	'6'
	'0'
Starting data	'2'
address	'0'
	'0'
	'0'
Data content	'0'
Data Content	'6'
	'4'
LRC Check	'9'
LRC Check	'3'
End 1	(0DH)(CR)
End 0	(0AH)(LF)

Response message (Slave):

Start	·.,
Slave Address	'0'
	'1'
Function	'0'
	'6'
	'0'
Starting data	'2'
address	'0'
	'0'
	'0'
Data content	'0'
Data Content	'6'
	'4'
LRC Check	'9'
	'3'
End 1	(0DH)(CR)
End 0	(0AH)(LF)

RTU Mode:

Command message (Master):

Address	01H
Slave Function	06H
Starting data	02H (High)
address	00H (Low)
Data content	00H (High)
	64H (Low)
CRC Check Low	89H (Low)
CRC Check High	99H (High)

Please note:

Response message (Slave):

Address	01H
Slave Function	06H
Starting data	02H (High)
address	00H (Low)
Data content	00H (High)
Data Content	64H (Low)
CRC Check Low	89H (Low)
CRC Check High	99H (High)

Before and after the transmission in RTU mode, 10ms of silent interval is needed.

Example 3: function code 10H, write multiple words:

The Master issues command to the 1st Slave and writes 0BB8H and 0000H to the starting address 0112H. That is to say, 0112H is written into 0BB8H and 0113H is written into 0000H. The maximum allowable data in one single access is 10. The Slave sends the response message to the Master after the writing is completed. The calculation of LRC and CRC will be described in next chapter.

ASCII Mode:

Command message (Master):

Command message (master).		
Start	•••	
Slave Address	'0'	
Slave Addiess	'1'	
Function	'1'	
Function	'0'	
	'0'	
Starting data	'1'	
address	'1'	
	'2'	
	'0'	
Number of data	'0'	
(In Word)	'0'	
	'2'	
Number of data	'0'	
(In Byte)	'4'	
	'0'	
The first data	'B'	
content	'B'	
	'8'	
	'0'	
The second data	'0'	
content	'0'	
	'0'	
LRC Check	'1'	
LKC CHECK	'3'	
End 1	(0DH)(CR)	
End 0	(0AH)(LF)	
	, ,, ,	

Response message (Slave):

Start	·.,
Clave Address	'0'
Slave Address	'1'
Function	'1'
	'0'
	'0'
Starting data	'1'
address	'1'
	'2'
	'0'
Number of data	'0'
Number of data	'0'
	'2'
LRC Check	'D'
	'A'
End 1	(0DH)(CR)
End 0	(0AH)(LF)

9-12 Revision February, 2017

Chapter 9 Communications ASDA-A2

RTU Mode:

Command message (Master):

Slave Address	01H
Function	10H
Starting data	01H (High)
address	12H (Low)
Number of data	00H (High)
(In Word)	02H (Low)
Number of data (In Byte)	04H
The first data	0BH (High)
content	B8H (Low)
The second data	00H (High)
content	00H (Low)
CRC Check Low	FCH (Low)
CRC Check High	EBH (High)

Response message (Slave):

Slave Address	01H
Function	10H
Starting data	01H (High)
address	12H (Low)
Number of data	00H (High)
(In Word)	02H (Low)
CRC Check Low	E0H (Low)
CRC Check High	31H (High)

Please note:

Before and after the transmission in RTU mode, 10ms of silent interval is needed.

■ LRC and CRC transmission Error Checking

The error checking in ASCII communication mode is LRC (Longitudinal Redundancy Check); CRC (Cyclical Redundancy Check) is for RTU communication mode. The algorithm of both is as the following.

LRC (ASCII mode):

Start		
Clave address	'7'	
Slave address	'F'	
Function	'0'	
Function	'3'	
	'0'	
Ctarting data address	' 5'	
Starting data address	,C,	
	'4'	
	'0'	
Number of data	'0'	
Number of data	'0'	
	'1'	
LRC Check	'B'	
LRC Check	'4'	
End 1	(0DH)(CR)	
End 0	(0AH)(LF)	

The LRC algorithm is: add all byte, round down the carry and take 2' s complement. For example, 7FH + 03H + 05H + C4H + 00H + 01H = 14CH, round down carry 1 and take 4CH.

2's complement of 4CH is B4H.

9-14 Revision February, 2017

Chapter 9 Communications ASDA-A2

CRC (RTU Mode):

The description of CRC is as the followings:

- Step 1: Load a 16-bits register of FFFFH, which is called **CRC** register.
- Step 2: (The low byte of CRC register) XOR (The first byte of command), and save the result in CRC register.
- Step 3: Right move one bit. Check the least significant bit (LSB) of CRC register. If the bit is 1, then (CRC register) XOR (A001H).
- Step 4: Return to Step 3 until Step 3 has been executed for 8 times. Go to Step 5.
- Step 5: Repeat the procedure from Step 2 to Step 4 until all byte is processing. Get the result of CRC value.

Description: After calculating CRC value, fill in the low word of CRC first in command message, and then fill in the high word of CRC. For example, if the result of CRC algorithm is 3794H, fill in 94H in low word and then 37H in high word.

ADR	01H	
CMD	03H	
Starting data address	01H (High)	
	01H (Low)	
Number of data	00H (High)	
(In Word)	02H (Low)	
CRC Check Low	94H (Low)	
CRC Check High	37H (High)	

Example of CRC program:

```
Produce CRC in C language. This function needs two parameters:
unsigned char* data;
unsigned char length
The function returns the CRC value as a type of unsigned integer.
  unsigned int crc_chk(unsigned char* data, unsigned char length) {
       int j;
       unsigned int reg_crc=0xFFFF;
       while( length-- ) {
            reg_crc^= *data++;
            for (j=0; j<8; j++) {
                 if( reg_crc & 0x01 ) { /*LSB(bit 0 ) = 1 */
                      reg\_crc = (reg\_crc >> 1)^0xA001;
                } else {
                     reg\_crc = (reg\_crc >> 1);
                }
            }
       return reg_crc;
  PC communication program example:
  #include<stdio.h>
  #include<dos.h>
  #include<conio.h>
  #include<process.h>
  #define PORT 0x03F8
                            /* the address of COM 1 */
  #define THR 0x0000
  #define RDR 0x0000
  #define BRDL 0x0000
  #define IER 0x0001
  #define BRDH 0x0001
  #define LCR 0x0003
  #define MCR 0x0004
  #define LSR 0x0005
  #define MSR 0x0006
  unsigned char rdat[60];
  /* read 2 data from address 0200H of ASD with address 1 */
  unsigned char tdat[60]={':','0','1','0','3','0','2','0','0','0','0','2','F','8','\r','\n'};
```

9-16 Revision February, 2017

```
void main() {
int I;
outportb(PORT+MCR,0x08);
                                      /* interrupt enable */
                                             /* interrupt as data in */
outportb(PORT+IER,0x01);
outportb(PORT+LCR,(inportb(PORT+LCR) | 0x80));
/* the BRDL/BRDH can be access as LCR.b7 == 1 */
outportb(PORT+BRDL,12);
outportb(PORT+BRDH,0x00);
outportb(PORT+LCR,0x06);
                                       /* set prorocol
                                              <7,E,1> = 1AH,
                                                                         <7,0,1> = 0AH
                                              <8,N,2> = 07H
                                                                  <8,E,1> = 1BH
                                                                                     */
                                              <8,0,1> = 0BH
for(I = 0; I <= 16; I ++ ) {
    while(!(inportb(PORT+LSR) & 0x20)); /* wait until THR empty */
    outportb(PORT+THR,tdat[I]);
                                             /* send data to THR */
}
I = 0;
while(!kbhit()) {
    if(inportb(PORT+LSR)&0x01) { /* b0==1, read data ready */
         rdat[I++] = inportb(PORT+RDR); /* read data from RDR */
    }
}
}
```

9.4 Write-in and Read-out Communication Parameters

Please refer to Chapter 8, Parameters for all parameter details. And the descriptions of parameters which can be wrote or read through communication are as follows.

Parameters are divided into 8 groups, Group 0: Monitor Parameters, Group 1: Basic Parameters, Group 2: Extension Parameters, Group 3: Communication Parameters, Group 4: Diagnosis Parameters, Group 5: Motion Setting, Group 6 and Group 7: PR Definition.

Write parameters via communication:

Parameters which can be written through communication include: Group 0, except (P0-00~P0-01), (P0-08~P0-13) and (P0-46) Group 1 (P1-00~P1-76)

Group 2 (P2-00~P2-67)

Group 3 (P3-00~P3-11)

Group 4, except (P4-00~P4-04) and (P4-08~P4-09)

Group 5 (P5-00~P5-99), except P5-10, P5-16 and P5-76

Group 6 (P6-00~P6-99)

Group 7 (P7-00~P7-27)

Please note that:

- (P3-01) When change to a new communication speed, the next data will be written in a new transmission speed after setting the new value.
- (P3-02) When change to the new communication protocol, the next data will be written with the new communication protocol after setting the new value.
- (P4-05) JOG controls parameters of the servo. Please refer to Chapter 8, Parameters for the description.
- (P4-06) Force to control output contact. This parameter is for DO (Digital Output) testing. Users can write 1, 2, 4, 8 and 16 to test DO1, DO2, DO3, DO4 and DO5 respectively. Please write 0 after the test so as to inform the servo drive that the test has been completed.
- (P4-10) Adjustment function selection. Write 20 (= 14H in hexadecimal format) in parameter P2-08 first to enable the adjustment so as to change the value of P4-10.
- (P4-11 ~ P4-21) This parameter is Offset Adjustment. Do not change the setting unless it is necessary. If it is necessary, please write 22 (= 16H, in hexadecimal format) in parameter P2-08 first to enable the function so as to change the value of (P4-11 ~ P4-21)

Read parameters through communication:

Parameters can be read through communication include:

Group 0 (P0-00~P0-46)	Group 4 (P4-00~P4-23)
Group 1 (P1-00~P1-76)	Group 5 (P5-00~P5-99)
Group 2 (P2-00~P2-67)	Group 6 (P6-00~P6-99)
Group 3 (P3-00~P3-11)	Group 7 (P7-00~P7-27)

9-18 Revision February, 2017

Chapter 10 Troubleshooting

10.1 Alarm of Servo Drive

Display	Alarm Name	Alarm Description	Corresponding DO	Servo Status
AL001	Over current	The current of the main circuit is 1.5 times more than the instantaneous current of the motor.	ALM	Servo Off
AL002	Over voltage	The voltage of the main circuit is higher than the standard voltage.	ALM	Servo Off
AL003	Under voltage	The voltage of the main circuit is lower than the standard voltage.	WARN	Servo Off
AL004	Motor Combination Error	The drive corresponds to the wrong motor.	ALM	Servo Off
AL005	Regeneration Error	Regeneration control is in error.	ALM	Servo Off
AL006	Overload	The motor and the drive is overload.	ALM	Servo Off
AL007	Over speed	The control speed of the motor exceeds the normal speed.	ALM	Servo Off
AL008	Abnormal Pulse Command	The input frequency of the pulse command is over the allowable value of the hardware interface.	ALM	Servo Off
AL009	Excessive Deviation of Position Command	The deviation of position command exceeds the allowable setting value.	ALM	Servo Off
AL011	Encoder Error	The encoder produces abnormal pulse.	ALM	Servo Off
AL012	Adjustment Error	When executing electrical adjustment, the adjusted value exceeds the allowable value.	ALM	Servo Off
AL013	Emergency Stop	Press the emergency stop button.	WARN	Servo Off
AL014	Reverse Limit Error	Activate the reverse limit switch.	WARN	Servo On
AL015	Forward Limit Error	Activate the forward limit switch.	WARN	Servo On
AL016	IGBT Overheat	The temperature of IGBT is over high	ALM	Servo Off

Display	Alarm Name	Alarm Description	Corresponding DO	Servo Status
AL017	Abnormal EEPROM	It is in error when DSP accesses EEPROM.	ALM	Servo Off
AL018	Abnormal signal output	The encoder output exceeds the rated output frequency.	ALM	Servo Off
AL019	Serial Communication Error	RS-232/485 communication is in error	ALM	Servo Off
AL020	Serial Communication Time Out	RS-232/485 communication time out	WARN	Servo On
AL022	Main Circuit Power Lack Phase	Only one single phase is inputted in the main circuit power.	WARN	Servo Off
AL023	Early Warning for Overload	Early Warning for Overload	WARN	Servo On
AL024	Encoder initial magnetic field error	The magnetic field of the encoder U, V, W signal is in error.	ALM	Servo Off
AL025	The Internal of the Encoder is in Error	The internal memory of the encoder and the internal counter are in error.	ALM	Servo Off
AL026	Unreliable internal data of the encoder	The error of the internal data has been detected for three times continuously.	ALM	Servo Off
AL027	The Internal of the Motor is in Error	The internal reset of the encoder is in error.	ALM	Servo On
AL028	Encoder voltage error or the internal of the encoder is in error	Charging circuit of the servo drive is not removed and the battery voltage is higher than the specification (>3.8 V) or the encoder signal is in error.	ALM	Servo On
AL029	Gray code error	Absolute position is in error.	ALM	Servo On
AL030	Motor Crash Error	The motor crashes the equipment, reaches the torque of P1-57 and exceeds the time set by P1-58.	ALM	Servo Off
AL031	Incorrect wiring of the motor power line U, V, W, GND	Incorrect wiring of the motor power line U, V, W, GND or the connection between both is breakdown.	ALM	Servo Off
AL034	Internal communication of the encoder is in error	 Internal communication error of the absolute encoder Internal error of other type of encoder 	ALM	Servo Off
AL035	Encoder	Encoder temperature exceeds the	ALM	Servo

10-2 Revision February, 2017

Display	Alarm Name	Alarm Description	Corresponding DO	Servo Status
	temperature exceeds the protective range	protective range		Off
AL040	Excessive Deviation of Full Closed-loop Position Control	Excessive Deviation of Full Closed-loop Position Control	ALM	Servo Off
AL041	Communication of CN5 is breakdown	Communication of CN5 (encoder) is breakdown	ALM	Servo Off
AL042	Analog input voltage error	The analog voltage is over than the setting value of P1-83.	ALM	Servo Off
AL044	Warning of servo drive function overload	When the servo drive function overloads, it might bring the abnormality of motion control, such as PR or E-Cam.	WARN	Servo On
AL045	Wrong setting of E-gear ratio	The setting of E-gear ratio exceeds the range (1/50~25600). Thus, when repower on the servo drive, an alarm occurs.	ALM	Servo off
AL060	The absolute position is lost	Due to battery undervoltage or the failure of power supply, the encoder lost the internal record.	WARN	Servo On
AL061	Encoder under voltage	The voltage of the absolute encoder is lower than the specification	WARN	Servo On
AL062	The multi-turn of absolute encoder overflows	The multi-turn of absolute encoder exceeds the maximum range: -32768 ~ +32767	WARN	Servo On
AL067	Encoder temperature warning	Encoder temperature exceeds the warning level. (But it is still within the protective range.)	WARN	N/A
AL068	Absolute data transmitted via I/O is in error	The sequence is wrong when reading the absolute position via DIO.	WARN	Servo On
AL069	Wrong motor type	Incremental motor is not allowed to activate the absolute function.	ALM	Servo Off
AL06A	The absolute coordinate has not been initialized	The possible causes might be: 1. The motor is used for the first time 2. The battery had run dry but has replaced a new one.	WARN	Servo On
AL070	Encoder does not complete the command which is issued by servo drive	Servo drive has not completely writing barcode into encoder or the encoder does not complete the command issued by servo drive.	WARN	Servo Off
AL083	Servo drive	When the output current from servo	ALM	Servo

Display	Alarm Name	Alarm Description	Corresponding DO	Servo Status
	outputs excessive current	drive exceeds the setting level, ALE083 will be triggered to protect IGBT. This could avoid IGBT to be burned out because of the excessive current.		Off
AL085	The absolute coordinate has not been initialized	The possible causes might be: 1. The motor is used for the first time 2. The battery had run dry but has replaced a new one.	WARN	Servo On
AL095	The servo drive does not connect to external regenerative resistor	The servo drive does not connect to external regenerative resistor *This alarm is only for 5.5 kW and 7.5 kW.	WARN	Servo On
AL099	DSP Firmware Upgrade	EEPROM has not been reset after upgrading the firmware. The fault can be cleared when firstly set P2-08 to 30. Then set P2-08 to 28. And re-power on the drive.	ALM	Servo Off

10-4 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

10.2 Alarm of CANopen Communication

Display	Alarm Name	Alarm Description	Corrective Actions	Corresponding DO	Servo Status
AL111	CANopen SDO receives buffer overflow	SDO Rx Buffer overflow (receives more than two SDOs within 1 millisecond)	NMT: Reset node or 0x6040.Fault Reset	ALM	Servo On
AL112	CANopen PDO receives buffer overflow	PDO Rx Buffer overflow (receives more than two same PDOs of the COBID within 1 millisecond)	Same as above	ALM	Servo On
AL121	Index error occurs when accessing CANopen PDO	The specified Index in the message does not exist.	Same as above	ALM	Servo On
AL122	Sub-Index error occurs when accessing CANopen PDO	The specified Sub-Index in the message does not exist.	Same as above	ALM	Servo On
AL123	Data Size error occurs when accessing CANopen PDO	The data length in the message does not match to the specified object.	Same as above	ALM	Servo On
AL124	Data range error occurs when accessing CANopen PDO	The data value in the message is over the range of the specified object.	Same as above	ALM	Servo On
AL125	CANopen PDO is read-only and write-protected	The specified object in the message is write-protected.	Same as above	ALM	Servo On
AL126	CANopen PDO is not allowed in PDO	The specified object in the message does not support PDO	Same as above	ALM	Servo On
AL127	CANopen PDO is write-protected when Servo On	The specified object in the message is write-protected when Servo ON	Same as above	ALM	Servo On
AL128	Error occurs when reading CANopen PDO via EEPROM	An error occurs when loading the default value via ROM at start-up. All objects of CAN returns to the default value automatically.	Same as above	ALM	Servo On

Display	Alarm Name	Alarm Description	Corrective Actions	Corresponding DO	Servo Status
AL129	Error occurs when writing CANopen PDO via EEPROM	An error occurs when saving the current value into ROM.	Same as above	ALM	Servo On
AL130	The accessing address of EEPROM is out of range when using CANopen PDO.	The quantity of the data inside ROM is over the planned space. It is probably because the software has been updated. The data inside ROM is stored by the old version. Thus, it cannot be used.	Same as above	ALM	Servo On
AL131	CRC of EEPROM calculation error occurs when using CANopen PDO	It indicates that the data stored in ROM has been damaged. All objects of CAN will return to the default setting automatically.	Same as above	ALM	Servo On
AL132	Enter the incorrect password when using CANopen PDO	When entering parameters via CAN, the parameters are password-protected. Users have to decode the password first.	Same as above	ALM	Servo On
AL170	Heartbeat or NodeGuarding error	Heartbeat or NodeGuarding error	Same as above	WARN	On
AL180	Heartbeat or NodeGuarding error	Heartbeat or NodeGuarding error	Same as above	ALM	On
AL185	Abnormal CAN Bus hardware	The communication of CAN Bus is breakdown or Error Rx/Tx Counter is over 128.	NMT: Reset node or re- servo on	ALM	Servo On
AL186	CAN Bus off	CAN data transmission error	-	ALM	On
AL130	The accessing address of EEPROM is out of range when using CANopen PDO.	The quantity of the data inside ROM is over the planned space. It is probably because the software has been updated. The data inside ROM is stored by the old version. Thus, it cannot be used.	Same as above	ALM	Servo On

10-6 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

10.3 Alarm of Motion Control

Display	Alarm Name	Alarm Description	Corrective Actions	Corresponding DO	Servo Status
AL201	An error occurs when loading CANopen data	An error occurs when loading data via EEPROM.	DI.ARST, CANopen 0x1011 Restore default parameter	WARN	Servo On
AL207	Parameter group of PR#8 is out of range	The group of PR#8 command source, P_Grp exceeds the range.	DI.ARST, CANopen 0x1011 Restore default parameter	WARN	Servo On
AL209	The parameter number of PR#8 is out of range	Parameter number P_ldx of PR#8 command exceeds the range.	DI.ARST, CANopen 0x1011 Restore default parameter	WARN	Servo On
AL213	The parameter setting of PR#8 is wrong	Write parameters via PR #8: the value is over the range. Please refer to Chapter 7 for detailed description.	DI.Alm Reset or P0-01= 0	WARN	Servo On
AL215	Write parameters: read-only	Write parameters via PR procedure: the parameter is read-only	DI.Alm Reset or P0-01= 0	WARN	Servo On
AL217	Write parameters: parameter locked	Write parameters via PR procedure: it is write-protected when the servo is ON or the input data is unreasonable.	Correct the PR command and parameter	WARN	Servo On
AL231	The setting of monitor item of PR#8 is out of range	The setting of monitor item of PR#8, Sys_Var exceeds the range.	DI.ARST, CANopen 0x1011 Restore default parameter	WARN	Servo On
AL235	PR command overflows	Feedback position counter overflows and executes the absolute positioning command.	NMT: Reset node or 0x6040.Fault Reset	WARN	Servo On

Display	Alarm Name	Alarm Description	Corrective Actions	Corresponding DO	Servo Status
AL237	Indexing coordinate is undefined	When executing indexing function, if the index positioning command is directly executing before defining the start point of index coordinate, the alarm will therefore occur.	DI.Alm Reset or write 0 into P0-01	WARN	Servo On
AL261 ~ AL277		Rese	rved		
AL283	Forward Software Limit	The value of position command is bigger than forward software limit (P5-08)	The fault will be cleared automatically when the motor operates backwards.	WARN	Servo On
AL285	Reverse Software Limit	The value of position command is smaller than reverse software limit (P5-09)	The fault will be cleared automatically when the motor operates backwards.	WARN	Servo On
AL289	Feedback position counter overflows	Feedback position counter overflows.	NMT: Reset node or 0x6040.Fault Reset	WARN	Servo On
AL291	Servo OFF error	Servo OFF when the motion path is incomplete.	Same as above	WARN	Servo On
AL301	CANopen fails to synchronize	CANopen IP mode fails to synchronize with the controller.	Same as above	WARN	Servo On
AL302	The synchronized signal of CANopen is sent too fast	The synchronized signal, SYNC of CANopen is sent too fast.	Same as above	WARN	Servo On

10-8 Revision February, 2017

Display	Alarm Name	Alarm Description	Corrective Actions	Corresponding DO	Servo Status
AL303	The synchronized signal of CANopen is sent too slow	The synchronized signal, SYNC of CANopen has not been received in time.	Same as above	WARN	Servo On
AL304	CANopen IP command is failed	Command cannot be issued in CANopen IP mode.	Same as above	WARN	Servo On
AL305	SYNC Period is in error	CANopen 301 Obj 0x1006 Data Error !	Same as above	WARN	Servo On
AL380	Position Deviation Alarm	Please refer to the description of parameter P1-48. After DO.MC_OK ON, DO.MC_OK becomes OFF because DO. TPOS turns OFF.	DI.Alm Reset or P0-01= 0	WARN	Servo On
AL400	Index coordinates error	The setting value of P2- 52 is set too small and cause index coordinates error	Adjust the value of P2-52 to the appropriate one	ALM	Off
AL401	NMT Reset command is received when Servo On	NMT Reset command is received when Servo On	NMT:Reset node or 0x6040.Fault Reset	ALM	Off
AL404	Value of PR special filter setting is too big	The setting value of P1- 22 causes inner position error overflows	Re-adjust the value of P1-22 until it is appropriate	ALM	Off
AL555	System Failure	DSP processing error	N/A		Do not Switch



If the alarm occurs and is different from the alarm showed in **Alarm of Servo Drive**, **Alarm of CANopen Communication** and **Alarm of Motion Control**, please contact with distributors or technical personnel.

10.4 Causes and Corrective Actions

Alarm Display

AL001 : Over current

Causes	Checking Method	Corrective Actions
The drive output is short-circuit	Check if the wiring between the motor and the drive is correct and see if the wire is short-circuited.	Eliminate short-circuit and avoid metal conductor being exposed.
The motor wiring is in error.	Check if the wiring steps are correct when connecting the motor to the drive.	Rewiring by following the wiring description from the user manual.
IGBT is abnormal	The temperature of the heat sink is abnormal	Send the drive back to the distributors or contact with Delta
The control parameter setting is in error.	Check if the setting value exceeds the default setting	Setting back to the default setting and then gradually adjust the value.
Unreasonable command	Check if the command doing reasonable acceleration time.	Less steep command used or filter applying to smooth command.

AL002 : Over voltage

Causes	Checking Method	Corrective Actions
The input voltage of the main circuit is higher than the rated allowable voltage.	Use the voltmeter to see if the input voltage of the main circuit is within the rated allowable voltage value. (please refer to Chapter 12.1)	Apply to the correct power supply or serial voltage regulator.
Wrong power input (incorrect power system)	Use the voltmeter to see if the power system matches the specification.	Apply to the correct power supply or serial adaptor.
The hardware of the servo drive is damaged.	Use the voltmeter to see if the input voltage of the main circuit is within the rated allowable voltage value but still shows the error.	Send the drive back to the distributors or contact with Delta.

AL003: Under voltage

Causes	Checking Method	Corrective Actions
The input voltage of the main circuit is lower than the rated allowable voltage.	Check if the input voltage wiring of the main circuit is normal.	Re-confirm the voltage wiring.
No power supply for the main circuit.	Use the voltmeter to see if the voltage of the main circuit is normal.	Check the power switch
Wrong power input (incorrect power system)	nower everam marchae tha	Apply to the correct power supply or serial adaptor.

10-10 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL004: Motor Combination Error

Causes	Checking Method	Corrective Actions	
The encoder is damaged.	The encoder is abnormal.	Change the motor	
The encoder is loose.	Check the encoder connector.	Install the motor again.	
Motor Combination Error	Connect to the right motor.	Change the motor	

AL005 : Regeneration Error

Causes	Checking Method	Corrective Actions
The regenerative resistor is unconnected or too low	Check the connection of regenerative resistor.	Reconnect the regenerative resistor or calculate the value of the regenerative resistor.
Parameter P1-53 is not set to zero when the regenerative resistor is not in use.	Check if parameter P1-53 of regenerative resister is set to zero.	Set parameter P1-53 of regenerative resistor to zero when it is not applying.
Wrong parameter setting	Check the setting value of parameter P1-52 and P1-53.	Correctly reset the setting.

AL006: Overload

Causes	Checking Method	Corrective Actions
Over the rated loading of the drive and continuously excessive using	Set parameter P0-02 to 11 and see if the average torque [%] is over 100% all the time.	Increase the motor capacity or reduce the load.
The setting of the control system parameter is inappropriate.	 Check if there is any mechanical vibration. Check if the acceleration / deceleration constant are set too fast. 	 Adjust the gain value of the control circuit. Slow down the acceleration / deceleration setting time.
Wrong wiring of the motor and the encoder.	Check the wiring of U, V, W and the encoder.	Correct wiring
The encoder of the motor is defective.	Send the drive back to the distributor	rs or contact with Delta.

AL007: Overspeed

Causes	Checking Method	Corrective Actions
Unreasonable command		Less steep command used or filter applying to smooth command.
Inappropriate parameter setting		Correctly set parameter P2-34 (the condition of over-speed warning).

AL008: Abnormal Pulse Command

Causes	Checking Method	Corrective Actions
	Trequency is over the rated input	Correctly set the input pulse frequency.

AL009: Excessive Deviation of Position Command

Causes	Checking Method	Corrective Actions
Parameter P2-35 is set too small	Check the setting value of parameter P2-35 (The warning condition of excessive position deviation)	Increase the setting value of P2-35 (The warning condition of excessive position deviation)
The setting of the gain value is too small.	Check if the setting value is appropriate	Correctly adjust the gain value
The torque limit is too low.	Check the torque limit value	Correctly adjust the torque limit value
Excessive external load	Check the external load	Reduce the external load or evaluate the motor capacity again
Improper setting of E- gear ratio	Make sure if the proportion of P1-44 and P1-45 is appropriate.	Correctly setup E-gear ratio

AL011 : Encoder Error

Causes	Checking Method	Corrective Actions
Wrong wiring of the encoder	Check if the wiring follows the suggested wiring of the user manual.	Correct wiring
The encoder is loose	Check the drive connector of CN2 and encoder	Install the encoder again
Bad connection of the encoder	Check if the connection between CN2 of the drive and the encoder of the servo motor is loose	Reconnect the wiring
The encoder is damaged	Check if the motor is damaged	Change the motor

AL012 : Adjustment Error

Causes	Checking Method	Corrective Actions
The analog input contact is incorrectly set back to zero	Measure if the voltage of the analog input contact is the same as the ground voltage	Correctly ground the analog input contact
The detection device is damaged		If the error still occurs after reset, send the drive back to the distributors or contact with Delta.

AL013 : Emergency Stop

Causes	Checking Method	Corrective Actions
Press the emergency stop button	Check if the emergency stop button is enabled.	Activate emergency stop

10-12 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL014: Reverse Limit Error

Causes	Checking Method	Corrective Actions
Reverse limit switch is activated.	Check if the limit switch is enabled.	Enable the reverse limit switch
The servo system is unstable.	Check the control parameter and inertia ratio	Re-adjust the parameter or evaluate the motor capacity.

AL015: Forward Limit Error

Causes	Checking Method	Corrective Actions
Forward limit switch is activated.	Check if the limit switch is enabled.	Enable the forward limit switch
The servo system is unstable.		Re-adjust the parameter or evaluate the motor capacity.

AL016: IGBT Overheat

Causes	Checking Method	Corrective Actions
Over the rated loading of the drive and continuously excessive using		Increase the motor capacity or reduce the load.
The drive output is short-circuit	Check the drive output wiring	Correct wiring

AL017: Abnormal EEPROM

Causes	Checking Method	Corrective Actions
It is in error when DSP accesses EEPROM.	Press the SHIFT Key on the panel and it shows EXGAB. X = 1, 2, 3	The fault occurs when applying to the power. It means one of the parameters is over the reasonable
	G = group code of the parameter	range. Please re-power on after adjusting.
	AB = hexadecimal of the parameter	
	If it shows E320A, it means it is parameter P2-10; If it shows E3610, it means it is parameter P6-16. Please check the parameter.	The fault occurs in normal operation. It means it is in error when writing the parameter. The alarm can be cleared by DI.ARST.
Abnormal hidden parameter	Press the SHIFT Key on the panel and it shows E100X	The fault occurs in parameter reset. The setting of the drive is wrong. Please set the correct type of the drive.
Data in ROM is damaged.	Press the SHIFT Key on the panel and it shows E0001	The fault occurs when it is servo- on. Usually it is because the data in ROM is damaged or there is no data in ROM. Please send the drive back to the distributors or contact with Delta.

AL018: Abnormal Signal Output

Causes	Checking Method	Corrective Actions
The encoder is in error and cause the abnormal signal output	Check the fault records (P4-00~P4-05). See if the alarm exists with the encoder error (AL011, AL024, AL025, AL026)	Conduct the corrective actions of AL.011, AL.024, AL.025, AL.026
The output pulse exceeds the hardware	Check if the following conditions produce: P1-76 < Motor Speed or	Correctly set parameter P1-76 and P1-46: P1-76 > Motor Speed or
allowable range.	$\frac{MotorSpeed}{60} \times P1 - 46 \times 4 > 19.8 \times 10^6$	$\frac{MotorSpeed}{60} \times P1 - 46 \times 4 < 19.8 \times 10^6$

AL019: Serial Communication Error

Causes	Checking Method	Corrective Actions
Improper setting of the communication parameter	Check the setting value of communication parameter	Correctly set the parameter value
Incorrect communication address	Check the communication address	Correctly set the communication address
Incorrect communication value	Check the accessing value	Correctly set the value

AL020: Serial Communication Time Out

Causes	Checking Method	Corrective Actions
time-out parameter	·	Correctly set the value
The drive hasn't received the communication command for a long time.	Check if the communication cable is loose or broken.	Correct wiring

AL022 : Main circuit power leak phase

Causes	Checking Method	Corrective Actions
The main circuit power is abnormal	Check if RST power cable is loose or does not connect to the power. This alarm occurs when no power connects to 3-phase for under 1.5 kW (included) servo drive. No power connects to single phase for 2 kW (included or above) servo drive, this alarm occurs.	Make sure it applies to the power. If issue persists, please send the drive back to the distributors or contact with Delta.

10-14 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL023: Early warning for overload

Causes	Checking Method	Corrective Actions
Early warning for overload	 Check if it is used in overload condition. Check if the value of parameter P1-56 is set to small. 	 Please refer to the corrective actions of AL006. Please increase the setting value of parameter P1-56. Or set the value over 100 and deactivate the overload warning function.

AL024 : Encoder initial magnetic field error

Causes	Checking Method	Corrective Actions
The initial magnetic field of the encoder is in error (Signal, U, V, W of the encoder magnetic field is in error.)	 Check if the servo motor is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	If issue persists, please send the drive back to the distributors or contact with Delta.

AL025: The internal of the encoder is in error

Causes	Checking Method	Corrective Actions
The internal of the encoder is in error. (The internal memory and the internal counter are in error)	 Check if the servo is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	 Please connect the UVW connector (color green) to the heat sink of the servo drive. Please check if the encoder cable separates from the power supply or the high-current circuit. Please use shielding mesh. If issue persists, please send the drive back to the distributors or contact with Delta.
When power on, the motor operates because of mechanical inertia or other causes	When power on, please make sure the motor shaft stands still and will not operate.	When power on, please make sure the motor shaft stands still and will not operate.

AL026: Unreliable internal data of the encoder

Causes	Checking Method	Corrective Actions
The encoder is in error. (Errors occur in the internal data for three times continuously)	 Check if the servo is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	 Please connect the UVW connector (color green) to the heat sink of the servo drive. Please check if the encoder cable separates from the power supply or the high-current circuit. Please use shielding mesh. If issue persists, please send the drive back to the distributors or contact with Delta.

AL027: The internal of the motor is in error

Causes	Checking Method	Corrective Actions
The internal reset of the encoder is in error.	 Check if the servo is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	 Please connect the UVW connector (color green) to the heat sink of the servo drive. Please check if the encoder cable separates from the power supply or the high-current circuit. Please use shielding mesh. If the situation is not improving, please send the drive back to the distributors or contact with Delta.

AL028 : Encoder voltage error or the internal of the encoder is in error

Causes	Checking Method	Corrective Actions
Battery voltage is too high	 Check if the charging circuit exists in the servo drive. Check if the battery is correctly installed 	According to the procedure of Over voltage to check. When corrective actions are done, AL.028 will be cleared automatically.
The internal encoder is in error.	 Check if it is the absolute type encoder. Check if the servo is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	 If the situation is not improving, please send the drive back to the distributors or contact with Delta. Please connect the UVW connector (color green) to the heat sink of the servo drive. Please check if the encoder cable separates from the power supply or the high-current circuit. Please use shielding mesh. If the situation is not improving, please send the drive back to the distributors or contact with Delta.

AL029 : Gray code error

Causes	Checking Method	Corrective Actions
Absolute position is in error		If the alarm occurs again, please change the encoder.

AL030 : Motor Crash Error

Causes	Checking Method	Corrective Actions
Motor Crash Error	 Check if P1-57 is enabled. Check if P1-57 is set too small and the time of P1-58 is set too short. 	 If it is enabled by mistake, please set P1-57 to zero. According to the actual torque setting, if the value is set too small, the alarm will be triggered by mistake. However, if the value is set too big, it will lose

10-16 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

	the function of protection.	

AL031: Incorrect wiring of the motor power line U, V, W

Causes	Checking Method	Corrective Actions
	incorrect connected or the	Follow the user manual to correctly wire U, V, and W and make sure it is grounded.

AL034: Internal communication of the encoder is in error

Causes	Checking Method	Corrective Actions
Internal communication of the encoder is in error		Conduct the wiring of the battery again and re-power on after that.

AL035: Encoder temperature exceeds the protective range

Causes	Checking Method	Corrective Actions
Encoder temperature exceeds the protective range, above 105°C	Check the setting: Set the value of P0-02 to 120 to display the temperature.	 Improve heat dissipation or reduce the loading of operation. The temperature should be lower than 100°C. If the encoder's temperature is higher than the motor's (more than 30 degree). Please send the motor back to the distributors.

AL040: Excessive deviation of full closed-loop position control

Causes	Checking Method	Corrective Actions
Excessive deviation of full closed-loop position control	 Check if P1-73 is set too small. Check if the connector is loose or there is any connection problem of other mechanism. 	 Increase the value of P1-73. Check if the connection is well connected.

AL041: Communication of linear scale is breakdown

Causes	Checking Method	Corrective Actions
The communication of linear scale is breakdown		Check the communication of linear scale again.

AL042 : Analog input voltage error

Causes	Checking Method	Corrective Actions
The analog input voltage is higher than the value of P1-83.	Check if analog input voltage is too high.	Check all analog input voltages. Check if there is any problem about the sources of analog speed commands.

AL044: Warning of servo drive function overload

Causes	Checking Method	Corrective Actions
Warning of servo drive function overload	IN/A	Set P2-66 Bit4 to 1 can disable the display of this alarm.

AL045: Wrong setting of E-gear ratio

Causes	Checking Method	Corrective Actions
Setting of E-gear ratio is wrong when power on the servo drive		Modify the range of E-gear ratio and repower on the servo drive.

AL060: The absolute position is lost

Causes	Checking Method	Corrective Actions
Battery undervoltage	Check if the voltage of the battery is lower than 2.8V.	After change the battery, conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.
Change the battery when the power is OFF which is controlled by the servo drive	Do no change or remove the battery when the power is OFF which is controlled by the servo drive.	Conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.
After activating the absolute function, the absolute coordinate initialization has not been completed.	 Install the battery. Check the wiring between the battery pack and the power cable of the servo drive. Check the wiring of the encoder. 	Conduct homing procedure. Please refer to the description of absolute coordinate initialization in Chapter 12.
Bad connection of the battery power circuit	 Check the wiring of the encoder. Check the wiring between the battery pack and the power cable of the servo drive. 	Connect or repair the wiring of the battery so as to supply the power to the encoder. Conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.

10-18 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL061: Encoder under voltage

Causes	Checking Method	Corrective Actions
Battery under voltage	 Check if the voltage of the battery on the panel is lower than 3.1 V (tentative specification). Measure if the voltage of the battery is lower than 3.1 V (tentative specification). 	Do not change the battery when the power is ON which is controlled by the servo drive. After change the battery, AL061 will be cleared automatically.

AL062: The multi-turn of absolute encoder overflows

Causes	Checking Method	Corrective Actions
exceeds the range the absolute encoder is able	exceeds the range, -32768 ~ +32767, the absolute encoder is	Conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.

AL067: Encoder temperature warning

Causes	Checking Method	Corrective Actions
Encoder temperature exceeds the warning level. (But it is still within the protective range85 ~100°ℂ.)	Check the setting: Set the value of P0-02 to 120 to display the temperature.	 Improve heat dissipation or reduce the loading of operation. The temperature should be lower than 100°C. If the encoder's temperature is higher than the motor's (more than 30 degree). Please send the motor back to the distributors.

AL068: Absolute data transmitted via I/O is in error

Causes	Checking Method	Corrective Actions
Sequence error	 Switch OFF DI ABSQ should wait until DO ABSR is OFF. Switch ON ABSQ should wait until DO ABSR is ON. 	Correct the reading sequence of I/O
Reading time out	Check if the time between switching ON DO ABSR and switching ON ABSQ exceeds 200ms.	After switching ON DO ABSR (the absolute position data is ready), read DO ABSD and switch ON DI ABSQ within 200ms so that to inform the servo drive data reading is completed.

AL069: Wrong motor type

Causes	Checking Method	Corrective Actions
Incremental motor is not allowed to activate the absolute function	incremental or absolute encoder.	If the user desires to use absolute function, please choose absolute motor. If not, please set parameter P2-69 to 0.

AL06A: The absolute coordinate has not been initialized

Causes	Checking Method	Corrective Actions
The motor is used for the first time or the battery had run dry but has replaced a new one.	Check if the absolute coordinate	Initialize the absolute coordinate.

AL070 : Encoder does not complete the command which is issued by servo drive

Causes	Checking Method	Corrective Actions
Servo drive has not completely written barcode into encoder or the encoder does not complete the command issued by servo drive.	Check if the wiring is correct or there is any loose connection.	Correct the wiring.

AL083: Servo Drive Outputs Excessive Current

Causes	Checking Method	Corrective Actions
UVW cable is short- circuited	Check the configuration of motor power cable and connector cable. See if the metal wire is exposed or AWG is worn and causes short circuit of UVW cable.	Replace by new UVW cable and avoid the metal conductor being exposed so as to eliminate short-circuit.
Wrong motor wiring	 If applying non-standard power cable recommended by Delta, please check if the wiring sequence of UVW cable is correct. Check if there is any problem of lack phase when connecting UVW from servo to motor (unconnected or wrong connection) 	Please refer to the description of wiring in Chapter 3 and conduct the wiring again.
Analog signal (GND) from servo drive is interfered	Check if the GND of analog signal is misconnected to other signal.	Please refer to Chapter 3 and conduct the wiring again. GND of analog signal cannot be grounded with other signals.

10-20 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL085: Regeneration Error

Causes	Checking Method	Corrective Actions
Choose wrong regenerative resistor or does not connect to external regenerative resistor	Check the connection of regenerative resistor.	Calculate the value of the regenerative resistor again and correctly set the value of P1-52 and P1-53. If issue persists, please send the drive back to the distributors or contact with Delta.
Parameter P1-53 is not set to zero when the regenerative resistor is not in use.	Check if parameter P1-53 of regenerative resister is set to zero.	Set parameter P1-53 of regenerative resistor to zero when it is not applying.
Wrong parameter setting	Check the setting value of parameter P1-52 and P1-53.	Correctly reset the value of P1-52 and P1-53.

AL095: The servo drive does not connect to external regenerative resistor

Causes	Checking Method	Corrective Actions
The input of regenerative resistor capacity is over 0 and the servo drive does not connect to external regenerative resistor	regenerative resistor	 If wish to apply regenerative brake, please connect to external regenerative resistor. Then, check if the setting of P1-53 is correct. If not applying to regenerative brake, please set P1-53 to 0. If issue persists after conducting the above two steps, please send the drive back to distributors or contact with Delta.

AL099 : DSP firmware upgrade

Causes	Checking Method	Corrective Actions
Upgrade DSP firmware	Check if the firmware is upgraded.	Firstly set P2-08 to 30. Then set P2-08 to 28, the alarm will be cleared when re-power on.

AL111: CANopen SDO receives overflow

Causes	Checking Method	Corrective Actions
	Check if the servo drive receives (sends) more than one SDO within 1ms.	NMT: Reset node or 0x6040.Fault Reset

AL112 : CANopen PDO receives overflow

Causes	Checking Method	Corrective Actions
PDO Rx Buffer overflow (receives more than two PDOs of COBID within one millisecond)	Check if the servo drive receives (sends) more than one PDO of COBID within 1ms.	NMT: Reset node or 0x6040.Fault Reset

AL121: Index error occurs when accessing CANopen PDO

Causes	Checking Method	Corrective Actions
the message does not	Check if the Entry Index of PDO Mapping is modified when PDO is receiving or sending	NMT: Reset node or 0x6040.Fault Reset

AL122: Sub-Index error occurs when accessing CANopen PDO

Causes	Checking Method	Corrective Actions
	PDO Mapping is modified when	NMT: Reset node or 0x6040.Fault Reset

AL123: Data Size error occurs when accessing CANopen PDO

Causes	Checking Method	Corrective Actions
message does not match	Check if the data length of Entry of PDO Mapping is modified when PDO is receiving or sending.	NMT: Reset node or 0x6040.Fault Reset

AL124: Data range error occurs when accessing CANopen PDO

Causes	Checking Method	Corrective Actions
		NMT: Reset node or 0x6040.Fault Reset

AL125 : CANopen PDO is read-only and write-protected

Causes	Checking Method	Corrective Actions
the moodage is write	Check if the specified object is read- only when PDO is receiving or sending.	NMT: Reset node or 0x6040.Fault Reset

AL126 : CANopen PDO is not allowed in PDO

Causes	Checking Method	Corrective Actions
the message does not	Check if the specified object allows PDO Mapping when PDO is receiving or sending.	NMT: Reset node or 0x6040.Fault Reset

AL127: CANopen PDO is write-protected when Servo On

Causes	Checking Method	Corrective Actions
the message is write-	Check that when PDO is receiving or sending, if the specified object is write-protected when Servo On.	NMT: Reset node or 0x6040.Fault Reset

10-22 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL128: Error occurs when reading CANopen PDO via EEPROM

Causes	Checking Method	Corrective Actions
via ROM at start-up. All	When PDO is receiving or sending, check if the error occurs because the specified object reads EEPROM.	NMT: Reset node or 0x6040.Fault Reset

AL129: Error occurs when writing CANopen PDO via EEPROM

Causes	Checking Method	Corrective Actions
An error occurs when saving the current value into ROM.	When PDO is receiving or sending, check if the error occurs because the specified object is wrote into EEPROM	NMT: Reset node or 0x6040.Fault Reset

AL130 : The accessing address of EEPROM is out of range when using CANopen PDO

Causes	Checking Method	Corrective Actions
The quantity of the data inside ROM is over the planned space. It is probably because the software has been updated. The data inside ROM is stored by the old version. Thus, it cannot be used.	Check that when PDO is receiving or sending, if the specified object enables EEPROM address exceeds the limit.	NMT: Reset node or 0x6040.Fault Reset

AL131: CRC of EEPROM calculation error occurs when using CANopen PDO

Causes	Checking Method	Corrective Actions
CANopen objects	Check if the specified object would cause CRC calculation error in EEPROM when PDO is receiving or sending.	NMT: Reset node or 0x6040.Fault Reset

AL132 : Enter the incorrect password when using CANopen PDO

Causes	Checking Method	Corrective Actions
When entering parameters via CAN, parameters are password-protected. Users have to decode the password first.	Check if the specified object enters the wrong password when PDO is receiving or sending.	NMT: Reset node or 0x6040.Fault Reset

AL170: CANopen Heartbeat or NodeGuarding error

Causes	Checking Method	Corrective Actions
CANopen communication breaks	Check if CANopen communication and connection is normal.	NMT:Reset node or 0x6040.Fault Reset

AL180 : CANopen Heartbeat or NodeGuarding error

Causes	Checking Method	Corrective Actions
CANopen communication breaks	Check if CANopen communication and connection is normal.	NMT:Reset node or 0x6040.Fault Reset

AL185: Abnormal CAN Bus hardware

Causes	Checking Method	Corrective Actions
Abnormal CAN Bus	Check if the communication cable of CAN Bus is good. Check if the communication	NMT: Reset node or re-servo on
hardware quality is good. (It is suggested to use common grounding and shielded cable)	NWIT. Reset flode of re-servo off	

AL186: Bus off

Causes	Checking Method	Corrective Actions
CAN Bus transfer error	Check if the communication is correctly connected or if there is any interference	Change the communication cable or clear the noise
	The number of slave station is excessive and the communication cycle period is too short.	Lengthen the communication cycle period

AL201: An error occurs when loading CANopen data

Causes	Checking Method	Corrective Actions
An error occurs when loading CANopen data	If the alarm is cleared when reservo on, it means the data error occurs instantaneously when accessing in the previous time.	DI.ARST, CANopen 0x1011
	2. If the error still exists after reservo on, it means the data in EEPROM is damaged. It has to enter the correct value again. The method is as the followings:	
	 a. If the user desires to enter the default value, it can set P2-08 to 30, 28 or CANopen object as 0x1011. 	Restore default parameter
	 b. If the user desires to enter the current value, it can set CANopen object to 0x1010. (Please refer to CANopen description.) 	

AL207: Parameter group of PR#8 is out of the range

Causes	Checking Method	Corrective Actions
command source	Writing parameter via PR procedure: The parameter group of command source exceeds the	DI.Alm Reset or write 0 into P0-01

10-24 Revision February, 2017

AL209: Parameter number of PR#8 is out of the range

Causes	Checking Method	Corrective Actions
The parameter number of command source exceeds the range	Writing parameter via PR procedure: The parameter number of command source exceeds the range	DI.Alm Reset or write 0 into P0-01

AL213 ~ AL217 : An error occurs when writing parameter via PR

Causes	Checking Method	Corrective Actions
PR commands TYPE 8 Error occurs when writing parameters	AL213 : parameter exceeds the range AL215 : the parameter is read-only	DI.Alm Reset or P0-01 = 0
	INI 27 / CARVA I IN AR INVAIID VAILIA	Re-adjust PR command and parameters

AL231 : The setting of monitor item of PR#8 is out of the range

Causes	Checking Method	Corrective Actions
The monitor item of the command source exceeds the range	Writing parameter via PR procedure: The monitor item number of command source exceeds the range	DI.Alm Reset or write 0 into P0-01

AL235 : PR command overflows

Causes	Checking Method	Corrective Actions
	Incremental type: PR mode continuously operates in one direction and causes feedback register (FB_PUU) overflows. And the coordinate system cannot reflect the correct position. If issuing the absolute positioning command at this time, the error will occur.	
PR command error	 Absolute type: The error occurs in following situations: Feedback register (FB_PUU) overflows After P1.01.Z is modified, the system neither returns to the original point nor conducts homing procedure. It does not conduct homing procedure after the E-gear ratio is modified (P1-44 and P1-45). Returning to the original point is 	Conduct homing procedure

	triggered and the homing procedure is not complete.	
5.	AL.060 and AL.062 occur.	

AL237: Indexing coordinate is undefined

Causes	Checking Method	Corrective Actions
When executing indexing function, if the index positioning command is directly executing before defining the start point of index coordinate, the alarm will therefore occur.	Indexing coordinate is undefined and then execute index positioning command.	 Before executing indexing function, please conduct homing first so as to avoid this alarm. When the alarm occurs, please use DI:Alm Reset or write 0 into P0-01to clear the alarm. The alarm can be cleared when it is Servo ON.

AL283: Forward Software Limit

Causes	Checking Method	Corrective Actions
Forward software limit	Forward Software Limit is determined by the position command, not the actual feedback position. It is because the command will arrive first and then the feedback. When the protection function is activated, the actual position might not over the limit. Therefore, setting an appropriate decelerating time could satisfy the demand. Please refer to the description of parameter P5-03.	NMT: Reset node or 0x6040.Fault Reset

AL285 : Reverse Software Limit

Causes	Checking Method	Corrective Actions
Reverse software limit	Reverse Software Limit is determined by the position command, not the actual feedback position. It is because the command will arrive first and then the feedback. When the protection function is activated, the actual position might not over the limit. Therefore, setting an appropriate decelerating time could satisfy the demand. Please refer to the description of parameter P5-03.	NMT: Reset node or 0x6040.Fault Reset

AL289 : Feedback position counter overflows

Causes	Checking Method	Corrective Actions
Feedback position counter overflows	This alarm will not occur at the moment. If it does, please contact the distributors.	NMT: Reset node or 0x6040.Fault Reset

10-26 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

AL291 : Servo Off error

Causes	Checking Method	Corrective Actions
Servo Off error		NMT: Reset node or 0x6040.Fault Reset

AL301 : CANopen fails to synchronize

Causes	Checking Method	Corrective Actions
CANopen fails to synchronize	Check if the communication quality of the circuit is bad.	
	Check if the controller sends SYNC signal successfully.	NMT: Reset node or 0x6040.Fault
	3. Check if the setting of P3-09 is reasonable. (It is better to use the default value)	Neset

AL302 : The synchronized signal of CANopen is sent too fast

Causes	Checking Method	Corrective Actions
The synchronized signal of CANopen is sent too fast	Check if synchronized cycle 0x1006 is the same as the setting of controller.	
	Check if the setting of P3-09 is reasonable. (It is better to use the default value)	NMT: Reset node or 0x6040.Fault Reset
	Check if the order of controller is incorrect.	

AL303: The synchronized signal of CANopen is sent too slow

Causes	Checking Method	Corrective Actions
The synchronized signal of CANopen is sent too slow	 Check if the communication quality of the circuit is bad. Check if synchronized cycle 0x1006 is the same as the setting of controller. Check if the setting of P3-09 is reasonable. (It is better to use the default value) Check if the order of controller is incorrect. 	NMT: Reset node or 0x6040.Fault Reset

AL304 : CANopen IP command fails

Causes	Checking Method	Corrective Actions
Talle	takes too long. Please disable LISB	NMT: Reset node or 0x6040.Fault Reset

AL305 : SYNC Period is in error

Causes	Checking Method	Corrective Actions
SYNC Period is in error	Examine the content of 0x1006.If it is smaller than or equals to 0, the alarm will occur.	NMT: Reset node or 0x6040.Fault Reset

AL380: Position Deviation Alarm

Causes	Checking Method	Corrective Actions
DO.MC_OK is ON and becomes OFF.	Please refer to the description of parameter P1-48. After DO.MC_OK ON, DO.MC_OK becomes OFF because DO.TPOS turns OFF. The position of the motor might be deviated by the external force after positioning. This alarm can be cleared by P1-48.Y=0.	DI.Alm Reset or P0-01= 0

AL400: Index coordinates error

Causes	Checking Method	Corrective Actions
Setting of P2-52 is wrong	Check if the setting of P2-52 is within the range. If the setting value is too small, it would cause index coordinates error.	Re-adjust the value of P5-52 until it is appropriate.

AL401: Receives NMT reset command when Servo On

Causes	Checking Method	Corrective Actions
	Check if the servo drive receives NMT reset command when Servo On	NMT:Reset node or 0x6040.Fault Reset

AL404 : Value of PR special filter setting is too big

Causes	Checking Method	Corrective Actions				
Inner position error overflows		Re-adjust the value of P1-22 until it is appropriate.				

AL555 : System Failure

Causes	Checking Method	Corrective Actions
DSP processing error	N/A	If AL555 occurs, do not do any anything and send the drive back to the distributors or contact with Delta.

10-28 Revision February, 2017

Chapter 10 Troubleshooting ASDA-A2

10.5 Corrective Actions after the Alarm Occurs

AL001	: Over current	Turn DI.ARST on to clear the alarm
AL002	: Over voltage	Turn DI.ARST on to clear the alarm
AL003	: Undervoltage	The alarm can be cleared after the voltage returns to normal.
AL004	: The magnetic field of the motor is abnormal	The alarm can be cleared after repower on.
AL005	: Regeneration error	Turn DI.ARST on to clear the alarm
AL006	: Overload	Turn DI.ARST on to clear the alarm
AL007	: Excessive speed deviation	Turn DI.ARST on to clear the alarm
AL008	: Abnormal pulse command	Turn DI.ARST on to clear the alarm
AL009	: Excessive deviation of position control	Turn DI.ARST on to clear the alarm
AL011	: Encoder error	The alarm can be cleared after repower on.
AL012	: Adjustment error	The alarm can be cleared when removing CN1 wiring and execute auto adjustment.
AL013	: Emergency stop	The alarm can be cleared automatically after turning DI.EMGS off
AL014	: Reverse limit error	Turn DI.ARST on or Servo Off to clear the alarm. The alarm also can be cleared when the motor operates backwards.
AL015	: Forward limit error	Turn DI.ARST on or Servo Off to clear the alarm. The alarm also can be cleared when the motor operates backwards.
AL016	: The temperature of IGBT is abnormal	Turn DI.ARST on to clear the alarm
AL017	: Abnormal EEPROM	If the alarm occurs, then parameter reset is a must. And re-servo on again. If it happens during the operation, please turn DI.ARST on to clear the alarm.
AL018	: Abnormal signal output	Turn DI.ARST on to clear the alarm
AL019	: Serial communication error	Turn DI.ARST on to clear the alarm
AL020	: Serial communication timeout	Turn DI.ARST on to clear the alarm
AL022	: Main circuit power leak phase	Turn DI.ARST on to clear the alarm

: Early warning for overload	Turn DI.ARST on to clear the alarm
: Encoder initial magnetic field error	The alarm can be cleared after repower on.
: The internal of the encoder is in error	The alarm can be cleared after repower on.
: The encoder is in error	The alarm can be cleared after repower on.
: Encoder reset error	The alarm can be cleared after repower on.
: The encoder is over voltage or the internal of the encoder is in error	The alarm can be cleared after repower on.
: Gray code error	The alarm can be cleared after repower on.
: Motor crash error	Turn DI.ARST on to clear the alarm
: Incorrect wiring of the motor power line U, V, W, GND	The alarm can be cleared after repower on.
: Internal communication of the encoder is in error	The alarm can be cleared after repower on.
: Encoder temperature exceeds the protective range	The temperature sensor of motor shall below 100°C. And the alarm can be cleared after re-power on.
: Excessive deviation of full closed-loop position control	Turn DI.ARST on to clear the alarm.
: The communication of linear scale is breakdown	Turn DI.ARST on to clear the alarm.
: Analog input voltage error	Turn DI.ARST on to clear the alarm.
: Warning of servo drive function overload	Set P2-66 Bit4 to 1 and then re-power on the servo drive.
: Wrong setting of E-gear ratio	The alarm can be cleared after correctly setting up the parameter.
: The absolute position is lost	The alarm can be cleared after repower on.
: Encoder under voltage	Change the battery and AL.061 will be cleared automatically.
: The multi-turn if absolute encoder overflows	The alarm can be cleared after repower on.
: Encoder temperature warning	Turn DI.ARST on to clear the alarm.
: Absolute data transmitted via I/O is in error	The alarm can be cleared after repower on.
: Wrong motor type	Set P2-69 to 0 and then re-power on the servo drive.
	Encoder initial magnetic field error The internal of the encoder is in error Encoder reset error The encoder is over voltage or the internal of the encoder is in error Motor crash error Incorrect wiring of the motor power line U, V, W, GND Internal communication of the encoder is in error Encoder temperature exceeds the protective range Excessive deviation of full closed-loop position control The communication of linear scale is breakdown Analog input voltage error Warning of servo drive function overload Wrong setting of E-gear ratio The absolute position is lost Encoder under voltage The multi-turn if absolute encoder overflows Encoder temperature warning Absolute data transmitted via I/O is in error

10-30 Revision February, 2017

AL06A	: The absolute coordinate has not been initialized	The alarm can be cleared after initializing the absolute coordinate.
AL070	: Encoder does not complete the command which is issued by servo drive	The alarm can be cleared after repower on.
AL083	: Servo drive outputs excessive current	Turn DI.ARST on to clear the alarm.
AL085	: The absolute coordinate has not been initialized	Turn DI.ARST on to clear the alarm.
AL095	: The servo drive does not connect to external regenerative resistor	Turn DI.ARST on to clear the alarm.
AL099	: DSP firmware upgrade	Firstly set P2-08 to 30. Then set it to 28. And the alarm will be cleared after re-power on.
AL111	: CANopen SDO receives buffer overflow	NMT: Reset node or 0x6040.Fault Reset
AL112	: CANopen PDO receives buffer overflow	NMT: Reset node or 0x6040.Fault Reset
AL121	: Index error occurs when accessing CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL122	: Sub-Index error occurs when accessing CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL123	: Data Size error occurs when accessing CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL124	: Data range error occurs when accessing CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL125	: CANopen PDO is read-only and write- protected.	NMT: Reset node or 0x6040.Fault Reset
AL126	: CANopen PDO is not allowed in PDO	NMT: Reset node or 0x6040.Fault Reset
AL127	: CANopen PDO is write-protected when Servo On	NMT: Reset node or 0x6040.Fault Reset
AL128	: Error occurs when reading CANopen PDO via EEPROM	NMT: Reset node or 0x6040.Fault Reset
AL129	: Error occurs when writing CANopen PDO via EEPROM	NMT: Reset node or 0x6040.Fault Reset
AL130	: The accessing address of EEPROM is out of range when using CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL131	: CRC of EEPROM calculation error occurs when using CANopen PDO	NMT: Reset node or 0x6040.Fault Reset

AL132	: Enter the incorrect password when using CANopen PDO	NMT: Reset node or 0x6040.Fault Reset
AL170	: Heartbeat or NodeGuarding error	NMT: Reset node or 0x6040.Fault Reset
AL180	: Heartbeat or NodeGuarding error	NMT: Reset node or 0x6040.Fault Reset
AL185	: Abnormal CAN Bus hardware	NMT: Reset node or re-servo on
AL186	: CAN bus off	NMT: Reset node or 0x6040.Fault Reset
AL201	: An error occurs when loading CANopen data	Turn DI.ARST on to clear the alarm. CANopen 0x1011 Restore default parameter
AL207	: Parameter group of PR#8 is out of range	 Turn DI.ARST on to clear the alarm. Set P0-01 to 0.
AL209	: Parameter number of PR#8 is out of range	 Turn DI.ARST on to clear the alarm. Set P0-01 to 0.
AL213	: An error occurs when writing parameter via PR : exceeds the range	DI.Alm Reset or P0-01 = 0
AL215	: An error occurs when writing parameter via PR : read-only	DI.Alm Reset or P0-01 = 0
AL217	: An error occurs when writing parameter via PR : parameter locked	Re-adjust PR command and parameter
AL231	: The setting of monitor item of PR#8 is out of range	 Turn DI.ARST on to clear the alarm. Set P0-01 to 0.
AL235	: PR command overflows	NMT: Reset node or 0x6040.Fault Reset
AL237	: Indexing coordinate is undefined	 Turn DI.ARST on to clear the alarm. Set P0-01 to 0.
AL283	: Forward Software Limit	NMT: Reset node or 0x6040.Fault Reset
AL285	: Reverse Software Limit	NMT: Reset node or 0x6040.Fault Reset
AL289	: Feedback position counter overflows	NMT: Reset node or 0x6040.Fault Reset
AL291	: Servo Off error	NMT: Reset node or 0x6040.Fault Reset

10-32 Revision February, 2017

AL301	: CANopen fails to synchronize	NMT: Reset node or 0x6040.Fault Reset			
AL302	: The synchronized signal of CANopen is sent too fast	NMT: Reset node or 0x6040.Fault Reset			
AL303	: The synchronized signal of CANopen is sent too slow	NMT: Reset node or 0x6040.Fault Reset			
AL304	: CANopen IP command is failed	NMT: Reset node or 0x6040.Fault Reset			
AL305	: SYNC Period is in error	NMT: Reset node or 0x6040.Fault Reset			
AL380	: Position Deviation Alarm	DI.Alm Reset or P0-01 = 0			
AL400	: Index coordinates error	Turn DI.ARST on to clear the alarm.			
AL401	: NMT Reset command is received when Servo On	Turn DI.ARST on to clear the alarm.			
AL404	: Value of PR special filter setting is too big	Turn DI.ARST on to clear the alarm.			
AL555	: System Failure	N/A			

(This page is intentionally left blank.)

10-34 Revision February, 2017

Chapter 11 Specifications

11.1 Specifications of Servo Drives

11.1.1 ASDA-A2 220 V Series

			100 W	200 W	400 W	750 W	1 6/0/	1 5 L/W	2 KW	2 L W	4 E 1/M	5.5 kW	7 F L/M	11 L/M	15 KW
1	ASDA-A2	2 Series													
			01	02	04	07	10	15	20	30	45	55	75	1B	1F
	Phase	/ Voltage	Sing	Single-phase / Three-phase 220 VAC Three-phase 220 VAC							•				
	Permissi	ble Voltage			-phase / 230 VAC			ı		Tł		ase 200 5% ~ 1		AC,	
Power	Unit	rrent (3PH) :: Arms	0.39	1.11	1.86	3.66	4.68	5.9	8.76	9.83	17.5	19.4	26.3	48	63
Δ.	Unit	rrent (1PH) :: ArmS	0.69	1.92	3.22	6.78	8.88	10.3	-	-	-	-	-	-	-
	Cu	ous Output Irrent I: Arms	0.9	1.55	2.6	5.1	7.3	8.3	13.4	19.4	32.5	40	47.5	54.4	70
	Cooling r	method	Nat	ural coc	ling					Fan	Cooling				
	ncoder R rvo Drive	esolution Resolution)				Incre	emental	type: 2	0-bit; A	bsolut	e type:	17-bit			
N	1ain Circu	it Control			SV	PWM (Space	Vector F	Pulse V	Vidth M	1odulatio	on) Cont	rol		
	Control	Mode						Aut	o / Mar	nual					
Re	egenerativ	e Resistor	No	None Built-in External											
		out Pulse uency	Line driver: 500 Kpps / 4 Mpps; Open collector: 200 Kpps												
Position Control Mode	Pulse	Туре	Pulse + Direction, A phase + B phase, CCW pulse + CW pulse												
o No	Comman	d Source		External pulse (DMCNET mode is not included) / Register											
Cont	Smoothin	g Strategy		Low-pass and P-curve filter											
ition	E-gea	r ratio		E-gear ratio N/M multiple (1/50 < N/M < 25600) N: 1 ~ 32767, M: 1:32767											
Pos	Torqu	e Limit		Parameter settings											
		orward ensation		Parameters settings											
_	Analog ommand	Voltage Range		0 ~ ±10 V _{DC}											
	Input DMCNET	Input Resistance		10 ΚΩ											
Ĭ	node is not included)	Time Constant							2.2 us						
Speed Control	Speed Cor	ntrol Range				1	: 5000					1:3	3000	1:2	000
) pa	Comman	d Source		E	cternal a	analog (comma	nd (DM	CNET	mode i	s not in	cluded)	Registe	er	
Sp	Smoothin	g Strategy					Lo	w-pass	and S-	curve	filter				
	Torque	e Limit				V	/ia para	ımeter s	ettings	or an	alog inp	out			
	Band	lwidth	Maximum 1 kHz												

	Speed Accuracy *2			0.01% or less at 0 to 100% load fluctuation					
	Speed	d Acc	uracy *2	0.01% or less at ±10% power fluctuation					
		N. 16		0.01% or less at 0°C to 50°C ambient temperature fluctuation					
Φ	Analog		Voltage Range	0 ~ ±10 V _{DC}					
Mode	Comma	nd R	Input esistance	10 ΚΩ					
ntro	Input		Time Constant	2.2 us					
orque Control	Comn		Source	External analog command (DMCNET mode is not included) / Register					
Pordu	Smoot	hing	Strategy	Low-pass filter					
	Sp	eed L	_imit	Via parameter settings or analog input (DMCNET mode is not included)					
1	Analog M	1onito	or Output	Monitor signal can set by parameters (Output voltage range: ±8 V)					
				Servo on, Fault reset, Gain switch, Pulse clear, Zero clamp, Command input reverse control, Internal position command trigger, Torque limit, Speed limit, Internal position command selection, Motor stop, Speed command selection, Speed / position mode switching, Speed /					
			lanut	torque mode switching, Torque / position mode switching, PT / PR command switching,					
lı	Digital		Input	Emergency stop, Positive / negative limit, Original point, Forward / reverse operation torque mit, Homing activated, E-CAM engage, Forward / reverse JOG input, Event trigger, E-gear election, Pulse input prohibition DMCNET mode is not included for the DI mentioned above. When applying DMCNET mode, it is suggested to use ommunication for DI input. Its DI only supports emergency stop, forward/reverse limit and homing.					
				A, B, Z Line Driver output					
		Output		Servo on, Servo ready, Zero speed, Target speed reached, Target position reached, torque limiting, Servo alarm, Brake control, Homing completed, Early warning for overload, Servo warning, Position command overflows, Software negative limit (reverse direction), Software positive limit (forward direction), Internal position command completed, Capture procedure completed, Servo procedure completed, Master position area of E-CAM					
	Protect	ive Fu	unction	Over current, Overvoltage, Under voltage, Overheat, Regeneration error, Overload, Excessive speed deviation, Excessive position deviation, Encoder error, Adjustment error, Emergency stop, Negative / positive limit error, Excessive deviation of full-closed loop control, Serial communication error, Rst leak phase, Serial communication timeout, Short-circuit protection of terminal U, V, W and CN1, CN2, CN3					
С	ommunic	cation	Interface	RS-232 / RS-485 / CANopen / USB / DMCNET					
			tallation Site	Indoors (avoid the direct sunlight), no corrosive fog (avoid fume, flammable gas and dust)					
			ltitude	Altitude 1000 m or lower above sea level					
			ospheric essure	86 kPa to 106 kPa					
		Ор	erating perature	0°C ~ 55°C (If operating temperature is above 45°C, forced cooling will be required)					
	ent	St	torage perature	-20°C to 65°C					
	Environment		umidity	Under 0 to 90% (non-condensing)					
	Envi	Vil	brating	9.80665m/s ² (1 G) less than 20 Hz, 5.88m/ s ² (0.6 G) 20 to 50 Hz					
		ΙP	Rating	IP20					
		Powe	er System	TN System ^{*3}					
		Ар	provals	IEC/EN 61800-5-1, UL 508C, C-tick C C UL US LISTED					

11-2 Revision February, 2017

Chapter 11 Specifications ASDA-A2

Note:

*1 When it is in rated load, the speed ratio is: the minimum speed (smooth operation) /rated speed.

- *2 When the command is the rated speed, the velocity correction ratio is: (rotational speed with no load rotational speed with full load) / rated speed.
- *3 TN system: The neutral point of the power system connects to the ground directly. The exposed metal components connect to the ground via the protective earth conductor.

4 Please refer to section 11.4 for overload features.

11.1.2 ASDA-A2 400 V Series

	1.2 ASDA-AZ		750 W	1 kW	1.5 kW	2 kW	3 kW	4.5 kW	5.5 kW	7.5 kW
	ASDA-A2 Se	eries	07	10	15	20	30	45	55	75
	Input Vo	Itage				24 VD	C, ±10%			
Power	Input Cu	rrent		0.89 A			1.1	8 A		1.66 A
<u>Ф</u>	Input Po	ower		21.4 W			28.	2 W		39.85 W
	Main Circuit F	Power			Three-p	hase, 380) ~ 480 \	/AC, ± 10	%	
	Input Current Unit: Arms		2.22	3.02	4.24	5.65	8.01	11.9	14.1	17.27
(Continuous Output Current Unit: Arms			3.52	5.02	6.66	11.9	20	22.37	30
	Cooling met					Fan	Cooling			
	Encoder Reso (Servo Drive Res			Inc	cremental	type: 20-	bit; Abso	lute type:	17-bit	
	Main Circuit C	ontrol		SVPWM	1 (Space \	/ector Pu	lse Width	n Modulati	ion) Cont	rol
	Control Mod	des				Auto	/ Manual			
	Regenerative R	Resistor		Built-in				Externa	ıl	
	Max. Input Pulse (DMCNET is no			Line driver: 500 Kpps / 4 Mpps; Open collector: 200 Kpps						
ode	Pulse Type (DMCNET is not included)		Pulse + Direction, A phase + B phase, CCW pulse + CW pulse							
_ ∑	Command Source		External pulse train (DMCNET is not included) / Internal parameters							
Cont	Smoothing Strategy		Low-pass and P-curve filter							
Position Control Mode	E-gear ı	ratio	E-gear ratio: N/M multiple (1/50 < N/M < 25600) N: 1 ~ 32767 / M: 1:32767							
A G	Torque I	_imit	Parameter settings							
	Feed Forward Co	ompensation	Parameters settings							
		Voltage Range	0 ~ ±10 V _{DC}							
	Analog Command Input	Input Resistance	10 ΚΩ							
		Time Constant				2.	.2 us			
Speed Control Mode	Speed Co Range	ontrol e*1			1:5	5000			1:	3000
Itrol	Command		Ext	ernal an	alog comr	mand (DN	//CNET is	s not inclu	ided) / Re	gister
Col	Smoothing	Strategy			Lov	v-pass ar	nd S-curv	e filter		
beec	Torque I	_imit	Via parameter settings or analog input							
0)	Bandwi	idth	Maximum 1 kHz							
			0.01% or less at 0 to 100% load fluctuation							
	Speed Acc	uracy *2		(0.01% or l	ess at ±	10% pow	er fluctua	tion	
			0.	01% or I	ess at 0°C	to 50°C	ambient	temperatu	ure fluctua	ation
on	Analog Command Input	Voltage Range				0 ~ ±	10 V _{DC}			

11-4 Revision February, 2017

Chapter 11 Specifications ASDA-A2

	(DMCNET is not included)	Input Resistance	10 ΚΩ				
		Time Constant	2.2 us				
	Command Source		External analog command (DMCNET is not included) / Register				
	Smoothing	Strategy	Low-pass filter				
	Speed L	_imit	Via parameter settings or analog input (DMCNET is not included)				
	Analog Monitor	Output	Monitor signal can set by parameters (Output voltage range: ± 8 V)				
Dig	Input Digital Input/Output Output		Servo on, Fault reset, Gain switching, Pulse clear, Zero speed CLAMP, Command input reverse control, Command triggered, Torque limit., Speed limit, Position command selection, Motor stop, Speed command selection, Position / Speed mode switching, Speed / Torque mode switching, Torque / Position mode switching, PT / PR command switching, Emergency stop, Forward / Reverse inhibit limit, Original point for homing, Forward / Reverse operation torque limit, Homing activated, E-Cam engage, Forward / Reverse JOG input, Event trigger PR command, Electronic gear ratio (Numerator) selection and Pulse inhibit input *DMCNET mode is not included for the DI mentioned above. When applying DMCNET mode, it is suggested to use communication for DI input. Its DI only supports emergency stop, forward/reverse limit and homing.				
			A, B, Z Line Driver output				
			Servo on, Servo ready, Zero speed, Target speed reached, Target position reached, torque limiting, Servo alarm, Brake control, Homing completed, Early warning for overload, Servo warning, Position command overflows, Software negative limit (reverse direction), Software positive limit (forward direction), Internal position command completed, Capture procedure completed, Servo procedure completed, Master position area of E-CAM				
	Protective Fu	nction	Over current, Overvoltage, Under voltage, Overheat, Regeneration error Overload, Excessive speed deviation, Excessive position deviation, Encoder error, Adjustment error, Emergency stop, Negative / positive limit error, Excessive deviation of full-closed loop control, Serial communication error, Rst leak phase, Serial communication timeout, Short-circuit protection of terminal U, V, W and CN1, CN2, CN3				
	Communication	Interface	RS-232 / RS-485 / CANopen / USB				
	Installatio	n Site	Indoor (avoid the direct sunlight), no corrosive fog (avoid fume, flammable gas and dust)				
	Altitud	de	Altitude 1000m or lower above sea level				
	Atmospheric	pressure	86 kPa to 106 kPa				
	Operating Temp	perature (°C)	0°C ~ 55°C (If operating temperature is above 45°C, forced air circulation will be required)				
ent	Storage Tempo	erature (°C)	-20°C to 65°C				
ronr	Humic	lity	0 to 90% (non-condensing)				
Environment	Vibrati	ng	9.80665m/s ² (1 G) less than 20 Hz, 5.88m/ s ² (0.6 G) 20 to 50 Hz				
	IP Rat	ing	IP20				
	Power Sy	/stem	TN System ^{*3}				
	Approvals		IEC/EN 61800-5-1, UL 508C, C-tick C C UL US LISTED				

Note:

- *1 When it is in rated load, the speed ratio is: the minimum speed (smooth operation) /rated speed.
- *2 When the command is the rated speed, the velocity correction ratio is: (rotational speed with no load rotational speed with full load) / rated speed.
- *3 TN system: The neutral point of the power system connects to the ground directly. The exposed metal components connect to the ground via the protective earth conductor.

 4 Please refer to section 11.6 for overload features.

11-6 Revision February, 2017 Chapter 11 Specifications ASDA-A2

11.2 Specifications of Servo Motors (ECMA Series)

11.2.1 ECMA 220 V Series

Low Inertia Series

Low mertia Series								
ECMA Series	C104 CA 04 CA 06			C	80	C	2 09	
LOWA Series	0F	01	02	04□S	04	07	07	10
Rated power (kW)	0.05	0.1	0.2	0.4	0.4	0.75	0.75	1.0
Rated torque (N-m) *1	0.159	0.32	0.64	1.27	1.27	2.39	2.39	3.18
Max. torque (N-m)	0.477	0.96	1.92	3.82	3.82	7.16	7.14	8.78
Rated speed (r/min)			300	00			30	000
Max. speed (r/min)			500	00			30	000
Rated current (A)	0.69	0.90	1.55	2.60	2.60	5.10	3.66	4.25
Max. instantaneous current (A)	2.05	2.70	4.65	7.80	7.80	15.3	11.0	12.37
Power rating (kW/s)	12.27	27.7	22.4	57.6	24.0	50.4	29.6	38.6
Rotor inertia (x 10 ⁻⁴ kg.m ²)	0.0206	0.037	0.177	0.277	0.68	1.13	1.93	2.62
Mechanical constant (ms)	1.2	0.75	0.80	0.53	0.74	0.63	1.72	1.20
Torque constant-KT (N-m/A)	0.23	0.36	0.41	0.49	0.49	0.47	0.65	0.75
Voltage constant-KE (mV/(r/min))	9.8	13.6	16.0	17.4	18.5	17.2	24.2	27.5
Armature resistance (Ohm)	12.7	9.30	2.79	1.55	0.93	0.42	1.34	0.897
Armature inductance (mH)	26.0	24.0	12.07	6.71	7.39	3.53	7.55	5.7
Electric constant (ms)	2.05	2.58	4.30	4.30	7.96	8.36	5.66	6.35
Insulation class	Class A (UL), Class B (CE)							
Insulation resistance	> 100 MΩ, DC 500 V							
Insulation strength				1.8k Va	c, 1 sec			
Weight (kg) (without brake)	0.42	0.5	1.2	1.6	2.1	3.0	2.9	3.8
Weight (kg) (with brake)		0.8	1.5	2.0	2.9	3.8	3.69	5.5
Radial max. loading (N)	78.4	78.4	196	196	245	245	245	245
Axial max. loading (N)	39.2	39.2	68	68	98	98	98	98
Power rating (kW/s) (with brake)		25.6	21.3	53.8	22.1	48.4	29.3	37.9
Rotor inertia (x 10 ⁻⁴ kg.m ²) (with brake)		0.04	0.19	0.30	0.73	1.18	1.95	2.67
Mechanical constant (ms) (with brake)		0.81	0.85	0.57	0.78	0.65	1.74	1.22
Brake holding torque [Nt-m (min)] *2		0.3	1.3	1.3	2.5	2.5	2.5	2.5

ECMA Series	C104	C _Δ 04	CA	. 06	CA	. 08	C	Δ 09	
ECIMA Series	0F	01	02	04□S	04	07	07	10	
Brake power consumption (at 20°C) [W]		7.3	6.5	6.5	8.2	8.2	8.2	8.2	
Brake release time [ms (Max)]		5	10	10	10	10	10	10	
Brake pull-in time [ms (Max)]		25	70	70	70	70	70	70	
Vibration grade (µm)	15								
Operating temperature (°C)				0°C to	40°C				
Storage temperature (°C)				-10°C t	O°08 o				
Operating humidity		2	20% to 9	0% RH (non-cor	ndensin	g)		
Storage humidity		2	20% to 9	0% RH (non-cor	ndensin	g)		
Vibration capacity	2.5 G								
IP Rating	IP65 (when waterproof connectors are used, or when an oil seal is used to be fitted to the rotating shaft (an oil seal model is used))								
Approvals	(€ c 712° us								

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__04 / 06 / 08 : 250 mm x 250 mm x 6 mm

ECMA-__10: 300 mm x 300 mm x 12 mm ECMA-__13: 400 mm x 400 mm x 20 mm ECMA-__18: 550 mm x 550 mm x 30 mm ECMA-__22: 650 mm x 650 mm x 35mm

Material: Aluminum - F40, F60, F80, F100, F130, F180, F220

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-8 Revision February, 2017

Chapter 11 Specifications ASDA-A2

	СΔ	.10	C∆13				
ECMA Series	10	20	30				
Rated power (kW)	1.0	2.0	3.0				
Rated torque (N-m) *1	3.18	6.37	9.55				
Max. torque (N-m)	9.54	19.11	28.65				
Rated speed (r/min)	30	00	3000				
Max. speed (r/min)	50	00	4500				
Rated current (A)	7.30	12.05	17.2				
Max. instantaneous current (A)	21.9	36.15	47.5				
Power rating (kW/s)	38.1	90.6	71.8				
Rotor inertia (x 10 ⁻⁴ kg.m ²)	2.65	4.45	12.7				
Mechanical constant (ms)	0.74	0.61	1.11				
Torque constant-KT (N-m/A)	0.44	0.53	0.557				
Voltage constant-KE (mV/(r/min))	16.8	19.2	20.98				
Armature resistance (Ohm)	0.20	0.13	0.0976				
Armature inductance (mH)	1.81	1.50	1.21				
Electric constant (ms)	9.30	11.4	12.4				
Insulation class	Class A (UL), Class B (CE)						
Insulation resistance	>1	100 MΩ, D	C 500 V				
Insulation strength	1.8k Vac, 1 sec						
Weight (kg) (without brake)	4.3	6.2	7.8				
Weight (kg) (with brake)	4.7	7.2	9.2				
Radial max. loading (N)	490	490	490				
Axial max. loading (N)	98	98	98				
Power rating (kW/s) (with brake)	30.4	82.0	65.1				
Rotor inertia (× 10 ⁻⁴ kg.m ²) (with brake)	3.33	4.95	14.0				
Mechanical constant (ms) (with brake)	0.93	0.66	1.22				
Brake holding torque [Nt-m (min)] *2	8.0	8.0	10.0				
Brake power consumption (at 20°C) [W]	18.7	18.7	19.0				
Brake release time [ms (Max)]	10	10	10				
Brake pull-in time [ms (Max)]	70	70	70				
Vibration grade (μm)		15					

ECMA Series	СΔ	10	C∆13			
ECIMA Series	10	20	30			
Operating temperature (°C)		0°C to 4	0°C			
Storage temperature (°C)		-10°C to	80°C			
Operating humidity	20% to 90% RH (non-condensing)					
Storage humidity	20% to 90% RH (non-condensing)					
Vibration capacity	2.5 G					
IP Rating	IP65 (use the waterproof connector and shaft seal installation (or oil seal) model)					
Approvals	C	€ c¶	N [®] US			

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__04 / 06 / 08 : 250 mm x 250 mm x 6 mm

ECMA-__10 : 300 mm x 300 mm x 12 mm ECMA-__13 : 400 mm x 400 mm x 20 mm ECMA-__18 : 550 mm x 550 mm x 30 mm ECMA-__22 : 650 mm x 650 mm x 35 mm

Material: Aluminum - F40, F60, F80, F100, F130, F180, F220

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-10 Revision February, 2017

Chapter 11 Specifications ASDA-A2

Medium / High Inertia Series

	E∆ 13					E∆ 18		G∆ 13		
ECMA Series	05	10	15	20	20	30	35	03	06	09
Rated power (kW)	0.5	1.0	1.5	2.0	2.0	3.0	3.5	0.3	0.6	0.9
Rated torque (N-m) *1	2.39	4.77	7.16	9.55	9.55	14.32	16.71	2.86	5.73	8.59
Max. torque (N-m)	7.16	14.3	21.48	28.65	28.65	42.97	50.13	8.59	17.19	21.48
Rated speed (r/min)				2000)				1000	
Max. speed (r/min)				3000)				2000	
Rated current (A)	2.9	5.6	8.3	11.01	11.22	16.1	19.2	2.5	4.8	7.5
Max. instantaneous current (A)	8.7	16.8	24.9	33.03	33.66	48.3	57.6	7.5	14.4	22.5
Power rating (kW/s)	7.0	27.1	45.9	62.5	26.3	37.3	50.8	10.0	39.0	66.0
Rotor inertia (× 10 ⁻⁴ kg.m ²)	8.17	8.41	11.18	14.59	34.68	54.95	54.95	8.17	8.41	11.18
Mechanical constant (ms)	1.91	1.51	1.10	0.96	1.62	1.06	1.08	1.84	1.40	1.06
Torque constant-KT (N-m/A)	0.83	0.85	0.87	0.87	0.85	0.89	0.87	1.15	1.19	1.15
Voltage constant-KE (mV/(r/min))	30.9	31.9	31.8	31.8	31.4	32.0	32.0	42.5	43.8	41.6
Armature resistance (Ohm)	0.57	0.47	0.26	0.174	0.119	0.052	0.052	1.06	0.82	0.43
Armature inductance (mH)	7.39	5.99	4.01	2.76	2.84	1.38	1.38	14.29	11.12	6.97
Electric constant (ms)	12.96	12.88	15.31	15.86	23.87	26.39	26.39	13.50	13.50	16.06
Insulation class				CI	ass A (U	L), Class	B (CE)			
Insulation resistance					>100 M	Ω, DC 50	00 V			
Insulation strength					1.8k	Vac, 1 se	С			
Weight (kg) (without brake)	6.8	7.0	7.5	7.8	13.5	18.5	18.5	6.8	7.0	7.5
Weight (kg) (with brake)	8.2	8.4	8.9	9.2	17.5	22.5	22.5	8.2	8.4	8.9
Radial max. loading (N)	490	490	490	490	1176	1470	490	490	490	490
Axial max. loading (N)	98	98	98	98	490	490	98	98	98	98
Power rating (kW/s) (with brake)	6.4	24.9	43.1	57.4	24.1	35.9	48.9	9.2	35.9	62.1
Rotor inertia (x 10 ⁻⁴ kg.m ²) (with brake)	8.94	9.14	11.90	15.88	37.86	57.06	57.06	8.94	9.14	11.9
Mechanical constant (ms) (with brake)	2.07	1.64	1.19	1.05	1.77	1.10	1.12	2.0	1.51	1.13
Brake holding torque [Nt-m (min)] *2	10.0	10.0	10.0	10.0	25.0	25.0	25.0	10.0	10.0	10.0
Brake power consumption (at 20°C) [W]	19.0	19.0	19.0	19.0	20.4	20.4	20.4	19.0	19.0	19.0

ECMA Series		E	∆ 13		E∆ 18			G∆ 13		
ECIMA Series	05	10	15	20	20	30	35	03	06	09
Brake release time [ms (Max)]	10	10	10	10	10	10	10	10	10	10
Brake pull-in time [ms (Max)]	70	70	70	70	70	70	70	70	70	70
Vibration grade (µm)	15									
Operating temperature (°C)		0°C to 40°C								
Storage temperature (°C)	-10°C to 80°C									
Operating humidity		20% to 90% RH (non-condensing)								
Storage humidity				20% t	o 90% R	H (non-co	ondensin	g)		
Vibration capacity	2.5 G									
IP Rating	IP65 (u	se the	waterpr	oof conn	ector an	d shaft se	al installa	ation (or c	oil seal) m	nodel)
Approvals	CE c TU us									

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__04 / 06 / 08 : 250 mm x 250 mm x 6 mm

ECMA-__10 : 300 mm x 300 mm x 12 mm

ECMA-__13: 400 mm x 400 mm x 20 mm

ECMA-__18 : 550 mm x 550 mm x 30 mm

ECMA-__22: 650 mm x 650 mm x 35 mm

Material: Aluminum - F40, F60, F80, F100, F130, F180, F220

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-12 Revision February, 2017

Chapter 11 Specifications ASDA-A2

Medium-High / High Inertia Series

Mediani riigii / riigi			. 13		F∆ 18				F122	
ECMA Series	05					45	55	75	1B	1F
D () (1)		08	13	18	30					
Rated power (kW)	0.5	0.85	1.3	1.8	3.0	4.5	5.5	7.5	11	15
Rated torque (N-m) *1	3.18	5.41	8.34	11.48	19.10	28.65	35.01	47.74	70	95.4
Max. torque (N-m)	8.92	13.8	23.3	28.7	57.29	71.62	87.53	119.36	175	224.0
Rated speed (r/min)					1	500				
Max. speed (r/min)					000				20	00
Rated current (A)	3.9	7.1	12.6	13.0	19.4	32.5	40.0	47.5	51.8	67.0
Max. instantaneous current (A)	12.1	19.4	38.6	36.0	58.2	81.3	100.0	118.8	129.5	162.0
Power rating (kW/s)	9.8	21.52	34.78	52.93	66.4	105.5	122.9	159.7	144.9	201.8
Rotor inertia (x 10 ⁻⁴ kg.m ²)	10.3	13.6	20.0	24.9	54.95	77.75	99.78	142.7	338	451
Mechanical constant (ms)	2.8	2.43	1.62	1.7	1.28	0.92	0.96	0.63	1.38	1.23
Torque constant-KT (N-m/A)	0.82	0.76	0.66	0.88	0.98	0.88	0.88	1.01	1.37	1.42
Voltage constant-KE (mV/(r/min))	29.5	29.2	24.2	32.2	35.0	32.0	31.0	35.5	49.0	50.0
Motor resistance (Ohm)	0.624	0.38	0.124	0.185	0.077	0.032	0.025	0.015	0.026	0.0184
Motor inductance (mH)	7.0	4.77	1.7	2.6	1.27	0.89	0.60	0.40	0.65	0.48
Electric constant (ms)	11.22	12.55	13.71	14.05	16.5	27.8	24.0	26.7	24.79	26.09
Insulation class				Cla	ss A (UL)	, Class B	(CE)			
Insulation resistance					>100 MΩ	2, DC 500	V			
Insulation strength					1.8k V	ac, 1 sec				
Weight (kg) (without brake)	6.3	8.6	9.4	10.5	18.5	23.5	30.5	40.5	56.4	75.0
Weight (kg) (with brake)	7.7	10.0	10.8	11.9	22.5	29.0	36.0	46.0	68.4	87.0
Radial max. loading (N)	490	490	490	490	1470	1470	1764	1764	3300	3300
Axial max. loading (N)	98	98	98	98	490	490	588	588	1100	1100
Power rating (kW/s) (with brake)	8.8	19.78	32.66	50.3	63.9	101.8	119.4	156.6	141.4	197.1
Rotor inertia (× 10 ⁻⁴ kg.m ²) (with brake)	11.5	14.8	21.3	26.2	57.06	80.65	102.70	145.55	346.5	461.8
Mechanical constant (ms) (with brake)	3.12	2.65	1.73	1.79	1.33	0.96	0.99	0.64	1.41	1.25
Brake holding torque [Nt-m (min)] *2	10.0	10.0	10.0	10.0	25.0	55.0	55.0	55.0	115	115
Brake power consumption (at 20°C) [W]	19.0	19.0	19.0	19.0	20.4	19.9	19.9	19.9	28.8	28.8
Brake release time [ms (Max)]	10	10	10	10	10	10	10	10	10	10

ECMA Series		FΔ	. 13			F.	F122			
ECIVIA SCITES	05	08	13	18	30	45	55	75	1B	1F
Brake pull-in time [ms (Max)]	70	70	70	70	70	70	70	70	70	70
Vibration grade (µm)	15									
Operating temperature (°C)		0°C to 40°C								
Storage temperature (°C)		-10°C to 80°C								
Operating humidity		20% to 90% RH (non-condensing)								
Storage humidity				20% to	90% RH	(non-cor	ndensing)			
Vibration capacity					2.	.5 G				
IP Rating	IP65 (use the waterproof connector and shaft seal installation (or oil seal) model)									
Approvals	C C C C US									

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__04 / 06 / 08 : 250 mm x 250 mm x 6 mm

ECMA-__10: 300 mm x 300 mm x 12 mm ECMA-__13: 400 mm x 400 mm x 20 mm ECMA-__18: 550 mm x 550 mm x 30 mm ECMA-__22: 650 mm x 650 mm x 35 mm

Material: Aluminum - F40, F60, F80, F100, F130, F180, F220

- *2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.
- 3 If desire to reach the max. torque limit of motor 250%, it is suggest to use the servo drive with higher watt.

11-14 Revision February, 2017

Chapter 11 Specifications ASDA-A2

High Inertia Series

ECMA	C △06	C △08				
ECIVIA	04□H	07□H				
Rated power (kW)	0.4	0.75				
Rated torque (N-m)*1	1.27	2.39				
Max. torque (N-m)	3.82	7.16				
Rated speed (r/min)	3000	3000				
Max. speed (r/min)	5000	5000				
Rated current (A)	2.6	5.1				
Max. instantaneous current (A)	7.8	15.3				
Max. power per second (kW/s)	21.7	19.63				
Rotor inertia (x 10 ⁻⁴ kg.m ²)	0.743	2.91				
Mechanical constant (ms)	1.42	1.6				
Torque constant – KT (N-m/A)	0.49	0.47				
Voltage constant – KE (mV/(r/min))	17.4	17.2				
Armature resistance (Ohm)	1.55	0.42				
Armature inductance (mH)	6.71	3.53				
Electric constant (ms)	4.3	8.36				
Insulation class	Class A (UL), Class B (CE)					
Insulation resistance	> 100MΩ, DC 500V					
Insulation strength	1.8k Va	c,1 sec				
Weight – without brake (kg)	1.8	3.4				
Weight – with brake (kg)	2.2	3.9				
Radial max. loading (N)	196	245				
Axial max. loading (N)	68	98				
Max. power per second (kW/s) (with brake)	21.48	19.3				
Rotor inertia (× 10 ⁻⁴ kg.m ²) (with brake)	0.751	2.96				
Mechanical constant (ms) (with brake)	1.43	1.62				
Brake holding torque [Nt-m (min)] *2	1.3	2.5				
Brake power consumption (at 20°C) [W]	6.5	8.2				
Brake release time [ms (Max)]	10	10				
Brake pull-in time [ms (Max)]	70 70					
Vibration grade (µm)	15					
Operating temperature (°C)	0°C ~	40°C				

ECMA	C △06	C △08		
ECIVIA	04□H	07□H		
Storage temperature (°C)	-10°C ~ 80°C			
Operating humidity	20 ~ 90%RH (non-condensing)			
Storage humidity	20 ~ 90%RH (non-condensing)			
Vibration capacity	2.5G			
IP Rating	IP65 (use the waterproof connector and sha seal installation (or oil seal)			
Approvals	C € c FL °us			

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__04 / 06 / 08 : 250 mm x 250 mm x 6 mm

ECMA-__10: 300 mm x 300 mm x 12 mm ECMA-__13: 400 mm x 400 mm x 20 mm ECMA-__18: 550 mm x 550 mm x 30 mm ECMA-__22: 650 mm x 650 mm x 35 mm

Material: Aluminum - F40, F60, F80, F100, F130, F180, F220

- *2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.
- 3 If desire to reach the max. torque limit of motor 250%, it is suggest to use the servo drive with higher watt.

11-16 Revision February, 2017

11.2.2 ECMA 400V Series

Low Inertia Series

ECMA Series	J∆06	J∆08	J∆	∆ 09	J∠	∆10	J∆13
	04	07	07	10	10	20	30
Rated power (kW)	0.4	0.75	0.75	1	1.0	2.0	3.0
Rated torque (N-m) *1	1.27	2.39	2.39	3.18	3.18	6.37	9.55
Max. torque (N-m)	3.82	7.16	7.14	8.78	9.54	19.1	28.65
Rated speed (r/min)	300	00	30	00	30	000	3000
Maximum speed (r/min)	500	00	30	00	50	000	4500
Rated current (A)	1.62	3.07	2.16	2.4	4.15	7.09	9.8
Max. instantaneous current (A)	4.85	9.5	6.37	7.17	12.46	21.28	29.99
Power rating (kW/s)	58.2	50.4	29.6	38.6	38.2	91.2	71.8
Rotor inertia (× 10 ⁻⁴ kg.m ²)	0.277	1.13	1.93	2.62	2.65	4.45	12.7
Mechanical constant (ms)	0.47	0.66	1.56	1.06	0.77	0.58	0.99
Torque constant-KT (N-m/A)	0.79	0.78	1.12	1.29	0.77	0.9	0.97
Voltage constant-KE (mV/(r/min))	30.6	28.24	42	50.9	29.0	34.4	37.3
Armature resistance (Ohm)	3.95	1.22	3.62	2.58	0.617	0.388	0.269
Armature inductance (mH)	21.3	10.68	21.2	15.28	6.03	4.62	3.55
Electric constant (ms)	5.39	8.75	5.85	5.93	9.77	11.9	13.2
Insulation class			Class A	(UL), Class	B (CE)		
Insulation resistance			>100	MΩ, DC 50	V 00		
Insulation strength			2.3	3k Vac, 1 se	ec		
Weight (kg) (without brake)	1.6	3.0	2.9	3.8	4.3	6.2	7.8
Weight (kg) (with brake)	2.0	3.8	-	-	4.7	7.2	9.2
Radial max. loading (N)	19.6	245	245	245	490	490	490
Axial max. loading (N)	68	98	98	98	98	98	98
Power rating (kW/s) (with brake)	53.8	48.4	29.3	37.9	30.4	82	65.1
Rotor inertia (× 10 ⁻⁴ kg.m ²) (with brake)	0.3	1.18	1.95	2.67	3.33	4.95	14.0
Mechanical constant (ms) (with brake)	0.52	0.65	1.57	1.08	0.96	0.65	1.09
Brake holding torque [Nt-m (min)] ^{*2}	1.3	2.5	2.5	2.5	8	8	10.0
Brake power consumption (at 20°C) [W]	6.5	8.5	8.2	8.2	18.5	18.5	19.0

ECMA Series	J∆06	J∆08	J△	√09	J∠	∆10	J∆13
	04	07	07	10	10	20	30
Brake release time [ms (Max)]	10	10	10	10	10	10	10
Brake pull-in time [ms (Max)]	70	70	70	70	70	70	70
Vibration grade (μm)		15					
Operating temperature (°C)		0°C to 40°C					
Storage temperature (°C)		-10°C to 80°C					
Operating humidity		20% to 90% RH (non-condensing)					
Storage humidity		20% to 90% RH (non-condensing)					
Vibration capacity		2.5 G					
IP Rating	IP65 (use the waterproof connector and shaft seal installation (or oil seal) model)						
Approvals	CE c SUs						

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__08: 250 mm x 250 mm x 6 mm ECMA-__13: 400 mm x 400 mm x 20 mm ECMA-__18: 550 mm x 550 mm x 30 mm Material: Aluminum – F80, F130, F180

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-18 Revision February, 2017

Medium Inertia Series

FCMA Sorios	K∆13 K∆18				
ECMA Series	05	10	15	20	20
Rated power (kW)	0.5	1.0	1.5	2.0	2.0
Rated torque (N-m) *1	2.39	4.77	7.16	9.55	9.55
Max. torque (N-m)	7.16	14.32	21.48	28.65	28.65
Rated speed (r/min)		<u> </u>	2000		
Maximum speed (r/min)			3000		
Rated current (A)	1.7	3.52	5.02	6.66	6.6
Max. instantaneous current (A)	5.2	10.56	15.06	19.98	19.88
Power rating (kW/s)	6.99	27.1	45.9	62.5	26.3
Rotor inertia (× 10 ⁻⁴ kg.m ²)	8.17	8.41	11.18	14.59	34.68
Mechanical constant (ms)	2.08	1.80	1.24	1.04	1.74
Torque constant-KT (N-m/A)	1.41	1.35	1.43	1.43	1.45
Voltage constant-KE (mV/(r/min))	51.5	53.2	55.0	55.0	54.0
Armature resistance (Ohm)	1.76	1.47	0.83	0.57	0.376
Armature inductance (mH)	22.4	17.79	11.67	8.29	7.87
Electric constant (ms)	12.73	12.04	14.04	14.39	20.9
Insulation class		Class A	(UL), Class	B (CE)	
Insulation resistance		>100) MΩ, DC 5	00 V	
Insulation strength		2.	3k Vac, 1 se	ЭС	
Weight (kg) (without brake)	6.8	7.0	7.5	7.8	13.5
Weight (kg) (with brake)	8.2	8.4	8.9	9.2	17.5
Radial max. loading (N)	490	490	490	490	1176
Axial max. loading (N)	98	98	98	98	490
Power rating (kW/s) (with brake)	6.39	24.9	43.1	59.7	24.1
Rotor inertia (× 10 ⁻⁴ kg.m ²) (with brake)	8.94	9.14	11.90	15.88	37.86
Mechanical constant (ms) (with brake)	2.28	1.96	1.32	1.13	1.9
Brake holding torque [Nt-m (min)] ^{*2}	10.0	10.0	10.0	10.0	25.0
Brake power consumption (at 20°C) [W]	19.0	19.0	19.0	19.0	20.4
Brake release time [ms (Max)]	10	10	10	10	10

ECMA Series	K∆13 K∆			K∆18	
	05	10	15	20	20
Brake pull-in time [ms (Max)]	70	70	70	70	70
Vibration grade (μm)		15			
Operating temperature (°C)	0°C ~ 40°C				
Storage temperature (°C)	-10°C~80°C				
Operating humidity	20% to 90% RH (non-condensing)				
Storage humidity	20% to 90% RH (non-condensing))	
Vibration capacity	2.5G				
IP Rating	IP65(use the waterproof connector and shaft seal installation (or oil seal) model)			naft seal	
Approvals	(

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__08: 250 mm x 250 mm x 6 mm ECMA-__13: 400 mm x 400 mm x 20 mm ECMA-__18: 550 mm x 550 mm x 30 mm Material: Aluminum – F80, F130, F180

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-20 Revision February, 2017

Medium-High Inertia Series

Trigit mertia deries		L/	\ 18	
ECMA Series	30	45	55	75
Rated power (kW)	3.0	4.5	5.5	7.5
Rated torque (N-m) *1	19.10	28.65	35.0	47.74
Max. torque (N-m)	57.29	71.62	87.53	119.36
Rated speed (r/min)		15	500	
Max. speed (r/min)		30	000	
Rated current (A)	11.53	20.8	22.37	27.3
Max. instantaneous current (A)	34.6	52.0	56.0	68.3
Power rating (kW/s)	66.4	105.5	122.9	159.7
Rotor inertia (x 10 ⁻⁴ kg.m ²)	54.95	77.75	99.78	142.7
Mechanical constant (ms)	1.11	0.94	0.88	0.77
Torque constant-KT (N-m/A)	1.66	1.38	1.56	1.75
Voltage constant-KE (mV/(r/min))	64.4	53.0	58.9	66.4
Motor resistance (Ohm)	0.21	0.09	0.07	0.06
Motor inductance (mH)	4.94	2.36	2.2	1.7
Electric constant (ms)	23.97	28.07	27.6	28.29
Insulation class			-	
Insulation resistance		>100 MΩ	, DC 500 V	
Insulation strength		2.3k Va	ac, 1 sec	
Weight (kg) (without brake)	18.5	23.5	30.5	40.5
Weight (kg) (with brake)	22.5	29	36	46
Radial max. loading (N)	1470	1470	1764	1764
Axial max. loading (N)	490	490	588	588
Power rating (kW/s) (with brake)	63.9	101.8	119.4	156.6
Rotor inertia (× 10 ⁻⁴ kg.m²) (with brake)	57.06	80.65	102.70	145.5
Mechanical constant (ms) (with brake)	1.16	0.95	0.91	0.79
Brake holding torque [Nt-m (min)]	25.0	55.0	55.0	55.0
Brake power consumption (at 20°C) [W]	20.4	19.9	19.9	19.9
Brake release time [ms (Max)]	10	10	10	10
Brake pull-in time [ms (Max)]	70	70	70	70
Vibration grade (μm)			15	

ECMA Series		L	18			
LOWA Series	30	45	55	75		
Operating temperature (°C)		0°C to 40°C				
Storage temperature (°C)	-10°C to 80°C					
Operating humidity	20% to 90% RH (non-condensing)					
Storage humidity	20% to 90% RH (non-condensing)					
Vibration capacity	2.5 G					
IP Rating	IP65 (use the waterproof connector and shaft seal installation (or oil seal) model)					
Approvals		ϵ	c Al ®us			

Note:

The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__08 : 250 mm x 250 mm x 6 mm ECMA-__13 : 400 mm x 400 mm x 20 mm ECMA-__18 : 550 mm x 550 mm x 30 mm ECMA-__22: 650 mm x 650 mm x 35 mm

Material type: Aluminum – F80, F130, F180, F220

*2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.

11-22 Revision February, 2017

High Inertia Series

		L _Δ 13		M∆ 13
ECMA Series	05	08	13	09
Rated power (kW)	0.5	0.85	1.3	0.9
Rated torque (N-m) ^{*1}	3.18	5.39	8.34	8.59
Max. torque (N-m)	8.92	13.8	23.3	21.48
Rated speed (r/min)		1500		1000
Max. speed (r/min)		3000		2000
Rated current (A)	2.1	3.4	5.02	4.4
Max. constant current (A)	6.1	8.85	15	13.1
Power rating (kW/s)	7.72	17.0	29.47	66
Rotor inertia (x 10 ⁻⁴ kg.m ²)	13.1	17.1	23.6	11.18
Mechanical constant (ms)	2.3	1.76	1.44	1.21
Torque constant-KT (N-m/A)	1.5	1.59	1.66	1.95
Voltage constant-KE (mV/(r/min))	55.5	58.9	61.1	71.7
Armature resistance (Ohm)	1.41	0.92	0.59	1.45
Armature inductance (mH)	20	14.1	9.54	23.3
Electrical constant (ms)	14.1	15.33	16.17	16.07
Insulation class		Class A (UL), (Class B (CE)	
Insulation resistance		> 100 MΩ,	DC 500 V	
Insulation strength		2.3k Vac	, 1 sec	
Weight (kg) (without brake)	6.8	8.6	10.7	7.5
Weight (kg) (with brake)	-	10		8.9
Radial max. loading (N)	490	490	490	490
Axial max. loading (N)	98	98	98	98
Power rating (kW/s) (with brake)	7.02	14.82	27.82	
Rotor inertia (× 10 ⁻⁴ kg.m²) (with brake)	14.4	19.6	25	
Mechanical time constant (ms) (with brake)	2.54	2.02	1.52	
Brake holding torque [Nt-m (min)] *2	10.0	10.0	10.0	
Brake power consumption (at 20°C)[W]	19.0	19.0	19.0	
Brake release time [ms (Max)]	10	10	10	
Brake pull-in time [ms (Max)]	70	70	70	
Vibration grade (µm)		15	;	
Operating temperature (°C)	0°C ~ 40°C			
Storage temperature (°C)	-10°C ~ 80°C			

ECMA Series		LΔ 13		M∆ 13
ECIVIA Series	05	08	13	09
Operating humidity	20 ~ 90%RH (non-condensing)			
Storage humidity	20 ~ 90%RH (non-condensing)			
Vibration capacity	2.5 G			
IP Rating	IP65 (use the waterproof connector and shaft seal installation (or oil seal) model)			
Approvals	C € c FL °us			

Note:

*1 The rated torque is the continuous permissible torque between 0~40°C operating temperature which is suitable for the following heat sink dimension.

ECMA-__ 08: 250 mm x 250 mm x 6 mm

ECMA-__ 13: 400 mm x 400 mm x 20 mm

ECMA-__ 18: 550 mm x 550 mm x 30 mm

ECMA-__ 22: 650 mm x 650 mm x 35 mm


Material type: Aluminum –F80, F130, F180, F220


- *2 The built-in brake of the servo motor is for remaining the item in stop status. Do not use it to decelerate or as the dynamic brake.
- 3 Model of ECMA-L11308 is applying for UL approval.

11-24 Revision February, 2017

11.3 Torque Features (T-N Curves)


11.3.1 220 V Series






11-26 Revision February, 2017

11.3.2 400 V Series





11-28 Revision February, 2017

11.4 Overload Features


Definition of overload protection

The overload protection is to prevent the motor in overheat status.

Cause of overload


- 1) When the motor operates over the rated torque, the operation time is too long
- 2) The inertia ratio is set too big and frequently accelerate / decelerate
- 3) Connection error between the power cable and encoder wiring
- 4) Servo gain setting error and cause resonance of the motor
- 5) The motor with brake operates without releasing the brake

The graph of load and operating time Low Inertia Series (ECMA C1, J1 Series)




Load	Operating Time
120%	263.8s
140%	35.2s
160%	17.6s
180%	11.2s
200%	8s
220%	6.1s
240%	4.8s
260%	3.9s
280%	3.3s
300%	2.8s

Medium and Medium-High Inertia Series (ECMA E1, F1, K1 and L1 Series)



Load	Operating Time
120%	527.6s
140%	70.4s
160%	35.2s
180%	22.4s
200%	16s
220%	12.2s
240%	9.6s
260%	7.8s
280%	6.6s
300%	5.6s

High Inertia Series (ECMA G1 Series)




Load	Operating Time
120%	527.6s
140%	70.4s
160%	35.2s
180%	22.4s
200%	16s
220%	12.2s
240%	9.6s
260%	7.8s
280%	6.6s
300%	5.6s


11-30 Revision February, 2017

11.5 Dimensions of Servo Drive


11.5.1 220 V Series

ASD-A2-0121; ASD-A2-0221; ASD-A2-0421 (100 W ~ 400 W)






screw: M4 x 0.7 tightening torque: 14 (kgf-cm)





- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.

ASD-A2-0721; ASD-A2-1021; ASD-A2-1521 (750 W ~ 1.5 kW)




Weight 2.0 (4.4)




- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.

11-32 Revision February, 2017

ASD-A2-2023; ASD-A2-3023 (2 kW ~ 3 kW)










- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.


ASD-A2-4523 (4.5 kW)



- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.

11-34 Revision February, 2017


ASD-A2-5523 (5.5 kW)








- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.

ASD-A2-7523 (7.5 kW)










Weight 5.9 (13)





- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.


11-36 Revision February, 2017

ASD-A2-1B23 (11 kW); ASD-A2-1F23 (15 kW)









Screw:M 4X 0.7 Screw Torque:14 (kgf-cm)


Weight 20 (44)



- 1) Dimensions are in millimeters (inches); Weights are in kilograms (kg) and (pounds (lbs)).
- 2) Dimensions and weights of the servo drive may be revised without prior notice.


11.5.2 400 V Series

ASD-A2-0743; ASD-A2-1043; ASD-A2-1543 (750 W ~ 1.5 kW)




11-38 Revision February, 2017


ASD-A2-2043; ASD-A2-3043, ASD-A2-4543; ASD-A2-5543 (2 kW ~ 5.5 kW)




Power	А	В	С	D	E	Weight
750 W~ 1.5 kW	216 (8.50)	203 (7.99)	82 (3.23)	62 (2.44)	203 (7.99)	2.89 (6.36)
2 kW ~ 5.5 kW	245 (9.65)	205.4 (8.09)	123 (4.88)	107 (4.21)	230 (9.06)	5.5 (12.1)


ASD-A2-7543 (7.5 kW)







screw: M4 x 0.7 tightening torque: 14 (kgf-cm)



Power	А	В	С	D	E	Weight
7.5 kW	254.2 (10.01)	205.5 (8.09)	136 (5.35)	107 (4.21)	247 (9.72)	5.5 (12.1)




- 1) Dimensions are in millimeters (inches)
- 2) Weights are in kilograms (kg) and (pounds (lbs)).
- 3) The servo drive images shown here may differ from actual product appearance. Please refer to actual product appearance.
- 4) Actual measured values are in metric units. Dimensions and weights in (imperial units) are for reference only.

11-40 Revision February, 2017

11.6 Dimensions of Servo Motors (ECMA Series)

11.6.1 220 V Series

Motor Frame Size: 86 mm and below Models (Units: mm)



Model	C1040F□S	C∆ 0401□S	C∆ 0602□S	C∆ 0604□S	C∆0604□H
LC	40	40	60	60	60
LZ	4.5	4.5	5.5	5.5	5.5
LA	46	46	70	70	70
S	8(+0,009)	8(+0,009)	14(+0,011)	14(+0,011)	14(+0,011)
LB	30(+0,-0.021)	30(+0,0021)	50(+0,025)	50(+0,025)	50(+0,025)
LL (without brake)	79.1	100.6	105.5	130.7	145.8
LL (with brake)		136.8	141.6	166.8	176.37
LS	20	20	27	27	27
LR	25	25	30	30	30
LE	2.5	2.5	3	3	3
LG	5	5	7.5	7.5	7.5
LW	16	16	20	20	20
RH	6.2	6.2	11	11	11
WK	3	3	5	5	5
W	3	3	5	5	5
Т	3	3	5	5	5
TP	M3 Depth 8	M3 Depth 8	M4 Depth 15	M4 Depth 15	M4 Depth 15


Model	C∆0804□7	C∆0807□S	C∆0807□H	C∆0907□S	C∆0910□S
LC	80	80	80	86	86
LZ	6.6	6.6	6.6	6.6	6.6
LA	90	90	90	100	100
S	14(+0 / -0.011)	19(+0 / -0.013)	19(+0 / -0.013)	16(⁺⁰ _{-0.011})	16(⁺⁰ _{-0.011})
LB	70(+0 / -0.030)	70(+0 / -0.030)	70(+0 / -0.030)	80(+0 / -0.030)	80(+0 / -0.030)
LL (without brake)	112.3	138.3	154.8	130.2	153.2
LL (with brake)	152.8	178	187.8	161.3	184.3
LS	27	32	32	30	30
LR	30	35	35	35	35
LE	3	3	3	3	3
LG	8	8	8	8	8
LW	20	25	25	20	20
RH	11	15.5	15.5	13	13
WK	5	6	6	5	5
W	5	6	6	5	5
Т	5	6	6	5	5
TP	M4 Depth 15	M6 Depth 20	M6 Depth 20	M5 Depth 15	M5 Depth 15



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (\(\Delta \) in the model names (which represents encoder type).

11-42 Revision February, 2017

Motor Frame Size: 100 mm ~ 130 mm Models (Units: mm)




Model	C∆1010□S	C∆1020□S	C∆1330□4	E∆1305□S	E∆1310□S	E∆1315□S	E∆1320□S
LC	100	100	130	130	130	130	130
LZ	9	9	9	9	9	9	9
LA	115	115	145	145	145	145	145
S	$22(^{+0}_{-0.013})$	$22(^{+0}_{-0.013})$	24(+0 -0.013)	$22(^{+0}_{-0.013})$	$22(^{+0}_{-0.013})$	$22(^{+0}_{-0.013})$	$22(^{+0}_{-0.013})$
LB	$95(^{+0}_{-0.035})$	$95(^{+0}_{-0.035})$	110(+0 / -0.035)	$110(^{+0}_{-0.035})$	$110(^{+0}_{-0.035})$	$110(^{+0}_{-0.035})$	110(+0 / -0.035)
LL (without brake)	153.3	199.0	187.5	147.5	147.5	167.5	187.5
LL (with brake)	192.5	226.0	216.0	183.5	183.5	202.0	216.0
LS	37	37	47	47	47	47	47
LR	45	45	55	55	55	55	55
LE	5	5	6	6	6	6	6
LG	12	12	11.5	11.5	11.5	11.5	11.5
LW	32	32	36	36	36	36	36
RH	18	18	20	18	18	18	18
WK	8	8	8	8	8	8	8
W	8	8	8	8	8	8	8
Т	7	7	7	7	7	7	7
TP	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (\triangle) in the model names (which represents encoder type).

Motor Frame Size: 100 mm ~ 130 mm Models (Units: mm)




Model	F∆1305□S	F∆1308□S	F∆1313□S	F∆1318□S	G∆1303□S	G∆1306□S	G∆1309□S
LC	130	130	130	130	130	130	130
LZ	9	9	9	9	9	9	9
LA	145	145	145	145	145	145	145
S	22(+0 / -0.013)	22(+0 -0.013)	22(+0 -0.013)	22(+0 -0.013)	22(+0 -0.013)	22(+0 -0.013)	22(+0 -0.013)
LB	110(+0 / -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)
LL (without brake)	139.5	152.5	187.5	202.0	147.5	147.5	163.5
LL (with brake)	168.0	181.0	216.0	230.7	183.5	183.5	198
LS	47	47	47	47	47	47	47
LR	55	55	55	55	55	55	55
LE	6	6	6	6	6	6	6
LG	11.5	11.5	11.5	11.5	11.5	11.5	11.5
LW	36	36	36	36	36	36	36
RH	18	18	18	18	18	18	18
WK	8	8	8	8	8	8	8
W	8	8	8	8	8	8	8
Т	7	7	7	7	7	7	7
TP	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (△) in the model names (which represents encoder type).

11-44 Revision February, 2017

Motor Frame Size: 180 mm and above Models (Units: mm)




Model	E∆ 1820⊐S	E∆ 1830□S	E∆ 1835⊐S	F∆ 1830⊐S
LC	180	180	180	180
LZ	13.5	13.5	13.5	13.5
LA	200	200	200	200
S	35(+0 -0.016)	35(⁺⁰ _{-0.016})	$35(^{+0}_{-0.016})$	35(⁺⁰ _{-0.016})
LB	114.3(+0 -0.035)	114.3(⁺⁰ _{-0.035})	114.3(+0 -0.035)	114.3(+00.035)
LL (without brake)	169.0	202.1	202.1	202.1
LL (with brake)	203.1	235.3	235.3	235.3
LS	73	73	73	73
LR	79	79	79	79
LE	4	4	4	4
LG	20	20	20	20
LW	63	63	63	63
RH	30	30	30	30
WK	10	10	10	10
W	10	10	10	10
Т	8	8	8	8
TP	M12 Depth 25	M12 Depth 25	M12 Depth 25	M12 Depth 25



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (△) in the model names (which represents encoder type).

Motor Frame Size: 180 mm Models (Units: mm)




Model	F∆1845□S	F∆1855□3	F∆1875□3
LC	180	180	180
LZ	13.5	13.5	13.5
LA	200	200	200
S	35(⁺⁰ _{-0.016}) 42(⁺⁰ _{-0.016})		42(+0,016)
LB	114.3(+0 / -0.035)	114.3(+0 / -0.035)	114.3(+0 / -0.035)
LL (without brake)	235.3	279.7	342.0
LL (with brake)	279.3	311.7	376.1
LS	73	108.5	108.5
LR	79	113	113
LE	4	4	4
LG	20	20	20
LW	63	90	90
RH	30	37	37
WK	10	12	12
W	10	12	12
Т	8	8	8
TP	M12 Depth25	M16 Depth32	M16 Depth32



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (\triangle) in the model names (which represents encoder type).

11-46 Revision February, 2017

Motor Frame Size: 220 mm and above Models (Units: mm)




Model	F1221B□3	F1221F□S
LC	220	220
LZ	13.5	13.5
LA	235	235
S	42(+0,016)	55(+0.031)
LB	200(+0,0046)	200(+0,046)
LL (without brake)	371.4	453.4
LL (with brake)	434.4	513.4
LS	108	108
LR	116	116
LE	4	4
LG	20	20
LW	90	90
RH	37	49
WK	12	16
W	12	16
Т	8	10
TP	M16 Depth 32	M20 Depth 40



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (Δ) in the model names (which represents encoder type).

11.6.2 400 V Series

Motor Frame Size: 80 mm and below Models (Units: mm)




Model	J∆0604□S	J∆0807□S	J∆0907□S	J∆0910□S
LC	60	80	86	86
LZ	5.5	6.6	6.6	6.6
LA	70	90	100	100
S	14 ⁺⁰ _{-0.011}	19(+0,013)	16(⁺⁰ _{-0.011})	16(⁺⁰ _{-0.011})
LB	50 ⁺⁰ _{-0.025}	70(+0 -0.030)	80(+0,030)	80(+0 / -0.030)
LL (without brake)	130.7	138.3	130.2	153.2
LL (with brake)	166.8	178.0	161.3	184.3
LS	27	32	30	30
LR	30	35	35	35
LE	3	3	3	3
LG	7.5	8	8	8
LW	20	25	20	20
RH	11	15.5	13	13
WK	5	6	5	5
W	5	6	5	5
Т	5	6	5	5
TP	M4 Depth15	M6 Depth 20	M5 Depth 15	M5 Depth 15



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (\triangle) in the model names (which represents encoder type).

11-48 Revision February, 2017

Motor Frame Size: 100 mm Models (Units: mm)



KEY DETAILS


SHAFT END DETAILS





- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (△) in the model names (which represents encoder type).

Motor Frame Size: 130 mm Models (Units: mm)




Model	J∆1330□4	K∆1305∏S	K∆1310□S	K∆1315□S	K∆1320□S
LC	130	130	130	130	130
LZ	9	9	9	9	9
LA	145	145	145	145	145
S	24(+0 -0.013)	$22(^{+0}_{-0.013})$	$22(^{+0}_{-0.013})$	22(+0 -0.013)	22(+0 -0.013)
LB	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 -0.035)	110(+0 / -0.035)
LL (without brake)	187.5	139.5	147.5	167.5	187.5
LL (with brake)	216.0	168.0	183.5	202.0	216.0
LS	47	47	47	47	47
LR	55	55	55	55	55
LE	6	6	6	6	6
LG	11.5	11.5	11.5	11.5	11.5
LW	36	36	36	36	36
RH	20	18	18	18	18
WK	8	8	8	8	8
W	8	8	8	8	8
Т	7	7	7	7	7
TP	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20	M6 Depth 20



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (\triangle) in the model names (which represents encoder type).

11-50 Revision February, 2017

Motor Frame Size: 130 mm Models (Units: mm)




Model	L∆1305∏S	L∆1313∏S	L∆1308□S	M∆1309□S
LC	130	130	130	130
LZ	9	9	9	9
LA	145	145	145	145
S	$22(^{+0}_{-0.013})$	22(+0,-0.013)	22(+0 -0.013)	22(+0 -0.013)
LB	110(+0 -0.035)	110(+0 / -0.035)	110(+0 -0.035)	110(+0 -0.035)
LL (without brake)	147.5	194.5	163.5	163.5
LL (with brake)	168.0	223.0	181.0	198.0
LS	47	47	47	47
LR	55	55	55	55
LE	6	6	6	6
LG	11.5	11.5	11.5	11.5
LW	36	36	36	36
RH	18	18	18	18
WK	8	8	8	8
W	8	8	8	8
Т	7	7	7	7
TP	M8 Depth 25	M6 Depth 20	M6 Depth 20	M6 Depth 20



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number of oil seal.
- 4) Please refer to Chapter 1 for the boxes (Δ) in the model names (which represents encoder type).

Motor Frame Size: 180 mm and above Models (Units: mm)



Model	L∆1830□S	L∆1845□S	L∆1855□S	L∆1875□S	K∆1820□S
LC	180	180	180	180	180
LZ	13.5	13.5	13.5	13.5	13.5
LA	200	200	200	200	200
S	$35(^{+0}_{-0.016})$	$35(^{+0}_{-0.016})$	42(+0 -0.016)	$42(^{+0}_{-0.016})$	$35(^{+0}_{-0.016})$
LB	114.3(+0 -0.035)	114.3(+0 -0.035)	114.3(+0 -0.035)	$114.3(^{+0}_{-0.035})$	$114.3(^{+0}_{-0.035})$
LL (without brake)	202.1	235.3	279.7	342.0	169.0
LL (with brake)	235.3	279.3	311.7	376.1	203.1
LS	73	73	108.5	108.5	73
LR	79	79	113	113	79
LE	4	4	4	4	4
LG	20	20	20	20	20
LW	63	63	90	90	63
RH	30	30	37	37	30
WK	10	10	12	12	10
W	10	10	12	12	10
Т	8	8	8	8	8
TP	M12 Depth 25	M12 Depth 25	M16 Depth 32	M16 Depth 32	M12 Depth 25



- 1) Dimensions are in millimeters. Actual measured values are in metric units.
- 2) Dimensions of the servo motor may be revised without prior notice.
- 3) The boxes (\Box) in the model names represent shaft end/brake or the number.
- 4) Please refer to Chapter 1 for the boxes (Δ) in the model names (which represents encoder type).

11-52 Revision February, 2017

Chapter 12 Absolute System

Introduction

Delta's absolute system includes an ASDA-A2 series servo drive, an ECMA series servo motor with an absolute encoder and a backup battery box for an absolute encoder. An ECMA series servo motor with an absolute encoder has an encoder which is able to rotate and tell the servo motor the actual position when the power is turned on. An absolute encoder in an ECMA series servo motor will constantly record the actual positions by its built-in coordinate system at any time. So the real position of the servo motor will be measured and recorded even if the motor shaft rotates after the power is turned off.

An ECMA series servo motor with an absolute encoder is essential and must be connected with an ASDA-A2 series servo drive for a Delta's absolute system. When an ECMA series servo motor with an incremental encoder is connected to an ASDA-A2 series servo drive, if the users enable the servo parameters for absolute system, a fault code, AL069 will be shown on the drive's LCD display to alert that an error occurs. When AL069 is displayed, please examine if the connected servo motor is a servo motor with an absolute encoder. While using absolute motor, as soon as it applies to the power, the motor speed cannot lower than 250rpm. When operating in battery mode, make sure the maximum speed does not exceed 200rpm. The model name of a servo motor with an absolute encoder is shown as below



One servo drive uses one single battery box. Two servo drives can share a dual battery box. We recommend the users to choose Delta's backup battery boxes and Delta's encoder connection cables for Delta's absolute systems for wiring and connection. Please perform the installation in order as specified in the quick start and user manual when connecting to an absolute system. Regarding the descriptions and specifications of battery boxes and corresponding accessories, please refer to the contents in the following sections.

12.1 Backup Battery Boxes

12.1.1 Specifications

Precautions

Please thoroughly understand and observe the following safety precautions. Failure to observe these precautions may void warranty! In order to prevent damage and danger, please use batteries in accordance with the specified specification.

> Do not use the product in a potentially explosive environment. Install the product in a clean and dry location free from corrosive and inflammable gases or liquids.



- > Do not place the battery dispersedly to prevent short circuiting and accidents.
- > Do not short circuit the positive pole and the negative pole of the batteries or install batteries in reverse polarity.
- > To prevent electric energy loss and lifetime reduction, it is recommended to use new batteries only.




- > Do not store batteries within an ambient temperature above +100°C. Failure to observe this precaution may cause fire or explosion.
- > The batteries are non-rechargeable. Do not charge the batteries or explosion may result.
- > Do not directly solder the battery surface.

Battery Specifications

Items	Li/SOCI2 Cylindrical Battery
Туре	ER14505
Delta Model Number	ASD-CLBT0100
International Standard Size	AA
Nominal Voltage	3.6 V
Nominal Capacity	2700 mAh
Maximum Continuous Operating Current	100 mA
Maximum Pulse Current	200 mA
Dimensions (D x H)	14.5 x 50.5 mm
Weight	Approx. 19 g
Operating Temperature	-40 ~ +85°C

12-2 Revision February, 2017

Battery Life



Above figure comes from EVE Energy Co. ER14505 Discharge Characteristics

- (1) The above figure illustrates the discharge current curve generated by constant current test. According to the testing result shown on the graph above, when the power consumption of an absolute encoder is 65uA or lower, if the voltage of the battery keeps 3V or higher, the expected battery life is about 21900hr, approximately 2.5 years (Note). Therefore, the lowest voltage level of battery for an absolute encoder is set to 3.1V.
- (2) The battery life expectancy is about 5 years and is able to provide 3.6V or higher voltage under normal temperature and humidity conditions.




The battery life was measured when one single battery box is connecting to one servo drive and one servo motor.

12.1.2 Battery Box Dimensions

Single Battery Box

Delta Model Number: ASD-MDBT0100







Weight 44 g


Units: mm

Dual Battery Box

Delta Model Number: ASD-MDBT0200







Weight 80 g


Units: mm

12-4 Revision February, 2017

12.1.3 Connection Cables for Absolute Encoder


A. Quick Connector

Delta part number: ASD-A2EB0003, ASD-A2EB0005




Connection method:

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.



B. Military Connector


Delta part number: ASD-A2EB1003, ASD-A2EB1005



Title	Model Name	L		
Title	Woder Name	mm	inch	
1	ASD-A2EB1003	3000 ± 100	118 ± 4	
2	ASD-A2EB1005	5000 ± 100	197 ± 4	

Connection method:

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.




12-6 Revision February, 2017

12.1.4 Battery Box Cords


Battery Box Cord AW

Delta Part Number: 3864573700



Battery Box Cord IW


Delta Part Number: 3864811900



12.2 Installation

12.2.1 Connection Examples

Single Battery Box



NOTE This is the wiring diagram for connecting to a single battery box. The scale of the objects does not match the dimensions as shown in the drawing above. For different models of AC servo drives and motors, the connection cables may differ.

1* and 2* Please refer to section 12.1.3.


3* Definition of CN2 connector

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.

	CN2 Connector			onnector
Pin No	Terminal Symbol	Function and Description	Military Connector	Quick Connector
5	T+	Serial communication signal input/output (+)	Α	1
4	T-	Serial communication signal input/output (-)	В	4
7	BAT+	Battery 3.6V	С	2
9	BAT-	Battery ground	D	5
14, 16	+5V	Power+5V	S	7
13, 15	GND	Power ground	R	8
-	Shield	Shield	L	9


12-8 Revision February, 2017

Single Battery Box (Connect to CN8)



NOTE This is the wiring diagram for connecting to a single battery box. The scale of the objects does not match the dimensions as shown in the drawing above. For different models of AC servo drives and motors, the connection cables may differ.

- 1* Make sure the battery box is firmly fixed with this connection method.
- 2* Connect to power base on single battery box, see the descriptions below:




Pin No	Terminal Symbol	Connector Cable
1	BAT+	Red
2	BAT-	Black

3* Definition of CN8 Connector:

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.

Pin No	Terminal Symbol
1	BAT+
2	BAT-

Dual Battery Box (Connect to CN2)





This is the wiring diagram for connecting to a single battery box. The scale of the objects does not match the dimensions as shown in the drawing above. For different models of AC servo drives and motors, the connection cables may differ.

1* and 2* Please refer to section 12.1.3.


3* Definition of CN2 connector

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.

CN2 Connector			Motor Co	onnector
Pin No	Terminal Symbol	Function and Description	Military Connector	Quick Connector
5	T+	Serial communication signal input/output (+)	Α	1
4	T-	Serial communication signal input/output (-)		4
7	BAT+	Battery 3.6V	С	2
9	BAT-	Battery ground	D	5
14, 16	+5V	Power+5V	S	7
13, 15	GND	Power ground	R	8
-	Shield	Shield	L	9

12-10 Revision February, 2017

Dual Battery Box (Connect to CN8)





This is the wiring diagram for connecting to a single battery box. The scale of the objects does not match the dimensions as shown in the drawing above. For different models of AC servo drives and motors, the connection cables may differ.

1* and 2* Please refer to section 12.1.3.


3* Definition of CN8 connector

Please conduct the wiring according to the following instructions. Wrong wiring might cause battery explosion.


Pin No	Terminal Symbol
1	BAT+
2	BAT-

12.2.2 How to Install a Battery

Single Battery Box



Dual Battery Box



12-12 Revision February, 2017


12.2.3 How to Replace a Battery

Please replace with a new battery if AL061 occurs, it means the battery is under voltage (Please refer to section 12.7.1 for detailed description). Or when accessing P0-02 for showing the battery power and it displays 31, which means the voltage is under 31V, so as to avoid data lost.


When the voltage is under 2.7V, it might lose the record of motor's position. Please conduct homing after replacing with a new battery. Please refer to 12.7.1 for detailed description

Please replace the battery while the power is applied to the servo drive in order to prevent the absolute position data lose.

Single Battery Box



Dual Battery Box



12-14 Revision February, 2017

12.3 System Initialization Procedure and Operation

12.3.1 System Initialization Procedure

When the servo system is power on, the host controller can get the motor coordinate position via communication with RS-485 or DI/O. There are two data in different units can be read, and they are in PULSE and PUU.

At the very first time to operate absolute system, there will be a fault code, AL060 shown when power on because the initialization procedure still not yet be done. The fault will be kept until the initialization procedure is finished. Besides, the AL060 will be displayed when the power from the servo and battery is discontinued that will lead to the coordinate system lost. There is a fault code, AL062 which is used to indicate when the motor position is exceeding the design range where - $32768 \sim 32767$ for motor turns. But from the view of PUU, the coordinate value must fall into the range - $2147483648 \sim 2147483647$ to avoid triggering the fault AL289.

For some applications which will rotate motor in one direction, the fault AL062 for checking turns number within -32763~32768 and the fault AL289 for detecting PUU within - 2147483648~2147483647 can be turned off by parameter P2-70.

Parameter Settings:

1. The AL060 will be cleared when the coordinate system has been initialized.

PR mode: The absolute coordinate system will be reset after any homing operation under PR mode.

Other modes: Two methods can be used to initialize the coordinated system. One is via digital inputs described in section 12.3.4, and another one is applying parameters in section 12.3.5.

2. For an initialized system when every time the power is turned on, the host controller can read the absolute coordinate data via digital inputs and digital outputs (see section 12.3.6) or parameters with communication (see section 12.2.6). Through the settings of parameter P2-70, the host controller can read the coordinated data in PUU (see section 12.3.3) or in number of turn plus the number of pulse within one turn (see section 12.3.2).

12.3.2 Pulse Counting

When the motor is running in clockwise direction, the counting number of turns will be minus where the counter clockwise rotating is plus. The number range for turns is from -32768 to 32767. The fault code, AL062 will appear when exceeding this counting range and it can be cleared by resetting the coordinate system. If parameter P2-70 has been set to ignore the over range alarming, the AL062 is disabled even exceeding the counting range. When the value reaches its largest number, it will rewind. For the counter clockwise counting, the sequence of the number is ...32767, -32768, -32767, -32766 and the clockwise will have a sequence like ...-32768, 23767, 32766

In addition, there are 1280000 pulses (0~1279999) in one rotation. Please pay attention on its direction. The communication or digital inputs/digital outputs can be used to read it.

Pulse number for the distance = m (turn) \times 1280000 + pulse number within one turn (0~1279999)

The conversion between Pulse and PUU:

When the rotating direction is CCW defined in P1-01.

PUU number = pulse number
$$\times \frac{(P1-45)}{(P1-44)} + (P6-01)$$

When the rotating direction is CW defined in P1-01.

PUU number = (-1) × pulse number ×
$$\frac{(P1-45)}{(P1-44)}$$
 + (P6-01)




Figure 12.1 Pulse counting in absolute coordinate system

12-16 Revision February, 2017

12.3.3 PUU Counting

A 32 bits number with sign is used to denote PUU number in an absolute system. The PUU number is increasing when motor is in positive rotating direction and decreasing for a negative running direction. The motor's rotating direction is defined in P1-01 Z setting.

In a word, the encoder feedback number is an easy way to distinguish the motor's rotating direction. Increasing number sequence is for positive direction and decreasing number sequence is for negative direction.

If the motor keeps rotating in one direction, the AL062 will be shown when exceeding the number range -32768 to 32767 for turns, and the AL289 is for PUU out of the range -2147483648 to 22147483647. Both of these fault codes can be cleared by homing.

And the parameter P2-70 can be used to take the range restrictions away in order to avoid occurring AL062 and AL289. When the counting number reaches the maximum number, the PUU pulse number sequence for forward rotation is ... 2147483647, -2147483648, -2147483647...where the number sequence -2147483648, 2147483647, 2147483646... is for reverse rotation. Two examples for evaluating the timing of overflow are as below:

Example 1:

When P1-44=128 and P1-45=10, there are 100000 PUU for motor to rotate one turn. 2147483647 ÷ 100000 ≒ 21474.8. The limit to trigger the fault AL289 is 21474.8 (< 32767).

Example 2:

When P1-44=128 and P1-45=1, there are 10000 PUU for motor to rotate one turn. 2147483647 \div 10000 = 214748.3. The limit to trigger the fault AL062 is 32767 (< 214748.3).





Figure 12.2 PUU counting in absolute coordinate system



When an absolute system has been initialized, if the parameter P1-01 Z setting, P1-44, and P1-45 be changed, the absolute coordinate system will be destroyed. A homing procedure is necessary at that moment.

12.3.4 Use Digital Inputs/Outputs to Initialize an Absolute System

Except PR mode, the digital inputs and outputs can be used for a driver to do homing when other modes are selected. Move the motor to home place, enable digital input, ABSE, then enable digital input, ABSC from OFF to ON, and the system will start to initialization. The pulse number will be set to zero and the number in P6-01 is for PUU to reference. Please refer to Figure 12.3 below for the signal controlling chart.



	T _{S(ms)}	$T_{Q(ms)}$	
Min.	P2-09+2		
Max.	P2-09+10		

Figure 12.3 The controlling chart for initializing an absolute system via digital inputs/outputs

The descriptions for the timing:

- 1. When the host controller switches ABSE from OFF to ON, a period of time Ts have to be waited for the next step to process.
- 2. After waiting time Ts, the host controller now can enable the ABSC from OFF to ON and hold the signal for T_Q to reset the coordinate system where pulse number will be zero and PUU number is defined in P6-01.

12.3.5 Use Parameters to Initialize an Absolute System

When the parameter P2-71 is set to 1(one) via digital keypad or communication, the system starts to initialization. In order to protect from accidentally writing on P2-71 to reset an absolute system, the number 271 should be written to P2-08 to unlock the writing of 1(one) to P2-71. The procedure is P2-08=271 and then P2-71=1. This mode is only for the other modes except PR mode that already has its homing procedure to apply.

12-18 Revision February, 2017

12.3.6 Use Digital Inputs/Outputs to Read the Absolute Coordinate Data

When Bit 0 is 0 in P2-70, the PUU number can be read by using digital inputs and outputs. The frame is as below.


Bit 79 ~ Bit 64	Bit 63 ~ Bit 32	Bit 31 ~ Bit 16	Bit 15 ~ Bit 0
Check Sum	Encoder PUU -2147483648 - 2147483647	0	Encoder status, P0-50

When Bit 0 is 1 in P2-70, the PULSE number can be read by using digital inputs and outputs. The frame is as below.

Bit 79 ~ Bit 64	Bit 63 ~ Bit 32	Bit 31 ~ Bit 16	Bit 15 ~ Bit 0
Check Sum	Pulse within one turn	Encoder turn	Encoder status,
	0 ~ 1279999 (= 1280000-1)	-32768 ~ +32767	P0-50

Explanation:

Check Sum = (((((((WORD_0+0xA700) XOR WORD_1)+0x605A) XOR WORD_2)+0x30A5) XOR WORD_3)+0x5A06)



Note:


- 1. This algorithm has no plus or minus sign.
- 2. 0xA700, 0x605A, 0x30A5 and 0x50A6 are the constans of hexadecimal.
- 3. WORD_0: encoder status (Bit 15~0)


WORD_1: encoder turn (Bit 31~16)

WORD_2: encoder pulse (Bit 47~32)

WORD_3: encoder pulse (Bit 63~48)

The setting in P2-70 with digital inputs/outputs communication can be used to read PULSE number or PUU data with below signal communication sequence.





	T _{R(ms)}	T _{S(ms)}	T _{Q(ms)}	T _{N(ms)}	T _{B(ms)}
Min	-		P2-	09+2	
Max	200		P2-0	9+10	

Figure 12.4 Timing of using digital inputs/outputs to read absolute data

12-20 Revision February, 2017

The step explanation for the communication:

- ①. At the very beginning of communication, the host controller must enable ABSE and all the communication starts from here.
- ②. A threshold time Ts for confirming the signal ABSE is necessary. After the signal has been recognized, the DI4, DO2, and DO3 (no matter what their functions are), will be switched to the function of ABSQ, ABSR, and ABSD respectively. At the moment of the communication function enabled, if the signal of ABSQ is in high level, it will keep high level for its original function and also will be high level signal for ABSQ. DI4, DO2, and DO3 are multiple functions pins, please be noted especially at the moment of communication function switching on and off. For the purpose of simplifying the application, the functions of these three digital inputs and outputs could to set to 0 for communication use only.
- ③. When ABSE is at high level and retaining Ts long, the function of DI4 will be switched to ABSQ. If the host controller switch ABSQ to low after it is defined, the servo drive will recognize that host controller wants to read data from it.
- 4. After confirming time T_Q, the data for communication is already well prepared on ABSD and the signal ABSR is enabled for signaling the host controller to get data from the servo drive side. If the longest possible waiting time of T_Q (see Figure 12.4) expired, the host controller still cannot get the signal ABSR from low to high which could be a problem of wiring disconnection.
- ⑤. After the host controller detects that ABSR is high, the data is fetched. The ABSQ will be set to signal high to inform the drive after dada read.
- 6. After confirming time T_N for ABSQ kept high, the servo drive will maintain ABSR to low for signaling the host controller to be ready for accessing next bit.
- (7). The host will set ABSQ to low when it detects that ABSR is low for requesting the next bit from drive.
- ®. The servo drive will repeat the steps 3 to 4 to put its data at ABSD for next bit communication
- (9). By repeating steps 5 t o 7, the host controller will get the data, bit, and have an acknowledgement to the servo drive.
- ①. The third bit data is ready on the servo drive side.
- ①. After the data is ready and has been held for time T_R, the servo drive still does not see the signal ABSQ controlled by the host controller, and then the servo drive will have a communication error flag ABSW raise to terminate the communication procedure.
- ②. The host controller will set the ABSE to low for restart the communication cycle after getting the communication error message from the servo drive.
- (3). The communication error flag on servo drive side will be reset after detecting a low signal ABSE from the host controller.
- (4). A new communication cycle on host controller will be restarted after the buffering time T_B.
- (i). Repeat the step 1 for the host controller to start a new communication cycle.

(ii). If there doesn't have any error occurred during communication course for the host controller to finish bit 0 to bit 79 (80 bits data), the functions of DI4, DO2, DO3 will be changed back to their original functions before communication cycle started.




If ABSW does not go back to high level signal after the changing of ABSE for signal low to high that is a sign of error occurring, there must be some other errors existing. Please check if the coordinate data still there, the voltage level of battery, or overflowing on the coordinate value.

A new communication cycle can be started only all of these errors been removed.

12-22 Revision February, 2017

12.3.7 Use Parameter to Read the Absolute Coordinate Data

The servo drive will update its encoder status to P0-50 and encoder position to P0-51 and P0-52 when the parameter P0-49 is set. The Bit 1 of P2-70 is used to select which type of the data will be read, PULSE or PUU. While the servo motor is stalling, it is always maintaining its position with a very tiny forward and backward movement. At the moment the encoder data read, the coordinate data in servo drive side will be reset to the current position of motor if P0-49=2 where it is just read without changing any from the servo motor when P0-49=1. For example of P0-49=2, if the motor is positioning at the place of 20000, it will move around position from 19999 to 20001 normally. The command for reading the encoder data is put when the motor is at the place 20001, and the data 20001 will be read and the coordinate data in servo drive will be revised to 20001. There will avoid the error from the data at encoder side and the data at drive side. The P0-49 will be reset to 0 when all the encoder data put in P0-50 to P0-52 is ready, and it means that the host controller can get the data now. When the status already signals absolute coordinate data lost or overflow of number for turns in P0-50, the values in P0-51 to P0-52 are not correct. A homing or system reset procedure is necessary now.



12.4 Related Parameters for Absolute System

P2-69•

ABS	Absolute Encoder Set	solute Encoder Setting		
Operatio Interface	·Danal / Caftwara	Communication	Related Section: N/A	
Defaul	t: 0x0		1 1 2 2	
Con Mode	· A I I			
Uni	it: N/A			
Range	e: 0x0 ~ 0x1			
Data Size	e : 16-bit			
Forma	t : Hexadecimal			

Settings: 0: Incremental mode. Servo motor with absolute encoder can be operated as incremental motor.

1: Absolute mode. (This setting is only available for the servo motor with absolute encoder. When an incremental servo motor is connected, if P2-69 is set to 1, AL.069 will occur.)

NOTE This parameter is effective only after the servo drive is re-powered on.

P2-70	MRS F	Read Data Format Sel	nd Data Format Selection		
	Operation Interface	Danal / Software	Panel / Software Communication		
	Default	: 0x0			
	Conti Mode	rol ALL		1 : : : : : :	
	Unit	: N/A	N/A		
; ;	Range	0x00 ~ 0x07			
Data Siz		: 16-bit			
	Format	: Hexadecimal			

Settings:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8

Bit 0: Data unit setting of digital input/output (DI/DO);

1: Pulse, 0: PUU

Bit 1: Communication data unit setting; 1: Pulse, 0: PUU

Bit 2: Overflow warning; 1: No overflow warning, 0: Overflow warning,

12-24


AL.289 (PUU), AL.062 (pulse). Bit 3 ~ Bit 15: Reserved. Must be set to 0.

P2-71∎	CAP	Absolute Position Ho	Address: 028EH 028FH	
	Operation Interface	Donal / Coffware	Communication	Related Section: N/A
	Defaul	t : 0x0	0x0	
	Cont Mode	· Δ I I	ALL	
	Uni	t : N/A	N/A	
	Range :	e: 0x0 ~ 0x1		
	Data Size	e: 16-bit		
	Forma	t : Hexadecimal		

Settings: When P2-71 is set to 1, the current position will be set as home position. This function is the same as the digital input, ABSC. This function can be enabled only when parameter P2-08 is set to 271.

P0-49∎	UAP F	Renew Encoder Abso	lute Position	Address: 0062H 0063H
	Operation Interface	Danal / Coffware	Communication	Related Section: N/A
	Default	: 0x0		
	Control Mode :	rol ALL		
	Unit	: N/A		
	Range : Data Size :	: 0x00 ~ 0x02		
		: 16-bit		
	Format	: Hexadecimal		
	~			

Settings: This parameter is used to renew the absolute position data of the encoder.



Parameter Renew Setting:

- 1: Renew the encoder data to parameters P0-50~P0-52 only.
- 2: Renew the parameters P0-50~P0-52, and clear the position error as

well. While this setting is activated, the current position of the motor will be reset as the target position of position command (same function as CCLR).

P0-50★

APSTS	Absolute Coordinate S	osolute Coordinate System Status			
Operation Interfac	Danal/Caffurana	Communication	Related Section: N/A		
Defau	It: 0x0				
Con Mod					
Un	it: N/A				
Rang	e: 0x00 ~ 0x1F				
Data Siz	e: 16-bit				
Forma	t : Hexadecimal		7 1 1 1 1		

Settings:

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8

Bit0: Absolute position status

Bit0=0: Normal

Bit0=1: Absolute position is lost

Bit1: Voltage level of battery

Bit0=0: Normal

Bit0=1: Low battery

Bit2: Status of encoder multiturn

Bit0=0: Normal

Bit0=1: Overflow

Bit3: Status of PUU

Bit0=0: Normal

Bit0=1: Overflow

Bit4: Absolute coordinate system status

Bit0=0: Normal

Bit0=1: Absolute coordinate system has not been set

Bit5 ~ Bit15: Reserved. Must be set to 0.

12-26

Format : Decimal

P0-51★	APR Er	ncoder Absolute Po	Address: 0066H 0067H	
	Operationa Interface :	l Panel / Software	Communication	Related Section: N/A
	Default :	0x0		7 : : :
	Contro Mode :	I. ALL		
	Unit :	rev		: : : :
	Range :	-32768 ~ +32767		
	Data Size :	32-bit		TE

Settings: While the Bit 1 of P2-70 is set to read the encoder pulse number, this parameter represents the turns of encoder absolute position. While the Bit 1 of P2-70 is set to read the PUU number, this parameter becomes disabled and the setting value of this parameter is 0.

P0-52★	ΔΡΡ Ι	coder Absolute Pos ulse number within	Address: 0068H 0069H	
	Operational Interface:	Panel / Software	Communication	Related Section: N/A
; ; ;	Default :	0x0		
;	Control Mode :	ALL		
	Unit :	Pulse or PUU		
:		0~1280000-1 (Pulse Number); -2147483648 ~ 2147483647 (PUU)		
; ;	Data Size :	32-bit		
	Format :	Decimal		

Settings: While the Bit 1 of P2-70 is set to read the pulse number, this parameter represents the pulse number of encoder absolute position. While the Bit 1 of P2-70 is set to read the PUU number, this parameter represents PUU number of motor absolute position.

P0-02

STS Dri	ive Status		Address: 0004H 0005H
Operational Interface :	Panel / Software	Communication	Related Section: 7.2
Default :	00		
Control Mode :	ALL		
Unit :	-		
Range :	00 ~ 127		
Data Size :	16-bit		
Format :	Decimal		

Settings: 00: Motor feedback pulse number (after the scaling of electronic gear ratio) [PUU]

01 : Input pulse number of pulse command (after the scaling of electronic gear ratio) [PUU]

02 : Deviation between control command pulse and feedback pulse number[PUU]

03 : The number of motor feedback pulse [Encoder unit, 1,280,000 Pulse/rev]

04 : Distance to command terminal (Encoder unit) [Pulse]

05 : Error pulse number (after the scaling of electronic gear ratio) (Encoder unit) [Pulse]

06: The frequency of pulse command input [Kpps]

07 : Motor speed [r/min]

08 : Speed command input [Volt]

09 : Speed command input [r/min]

10 : Torque command input [Volt]

11 : Torque command input [%]

12 : Average torque [%]

13 : Peak torque [%]


14 : Main circuit voltage (BUS voltage) [Volt]

15 : Load/motor inertia ratio [0.1times]

16: IGBT temperature

12-28

- 17: The frequency of resonance suppression
- 18 : The distance from the current position to Z. The range of the value is between -5000 and +5000;



The interval of the two Z-phase pulse command if 10000 Pulse.

19: Mapping Parameter #1: P0 - 25

20: Mapping Parameter #2: P0 - 26

21: Mapping Parameter #3: P0 - 27

22 : Mapping Parameter #4 : P0 - 28

23: Monitor Variable #1: P0 - 09

24: Monitor Variable #2: P0 - 10

25 : Monitor Variable #3 : P0 - 11

26: Monitor Variable #4: P0 - 12

38 : It display the battery voltage [0.1 Volt]. For example, if it displays 36, it means the battery voltage is 3.6 V.

72 : Analog speed command [0.1 r/min] (This is supported by A2-M/- U/-L.)

12.5 Digital Input (DI) Function Definition (for Absolute System)

Setting Va	Setting Value: 0x1D					
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode			
ABSE	When DI.ABSE is ON, it is in ABS mode. DI.ABSQ, DI.ABSC, DI.ABSR, DI.ABSD and DI.ABSC are enabled. When DI.ABSE is ON, the function of DI4, DO2, and DO3 will be	Level Triggered	ALL			
	disabled. Function of DI4 will be ASDQ, DO2 will be ABSR and DO3 will be ABSD.					

Setting Va	Setting Value: When DI.ABSE is ON, DI4 inputs ABSQ signal, function set by P2-13 is disabled.				
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode		
ABSQ is always inputted by DI4	During I/O transmission, Handshaking signal will be sent to the servo drive by the controller. When DI.ABSQ is OFF, it means the controller issues Request; DI.ABSQ is ON means the controller has already recdived ABSD signal. When DI.ABSE is ON, this DI is enabled. Please refer to diagram 13.4 for detailed description.	Rising / Falling- edged Triggered	ALL		

Setting Value: 0x1F			
DI Name	Function Description of Digital Input (DI)	Trigger Method	Control Mode
	When DI.ABSC is ON, multi-turn data stored in absolute encoder will be cleared. When DI.ABSE is ON, this function is enabled.	Rising- edge Triggered	ALL

12-30 Revision February, 2017

12.6 Digital Output (DO) Function Definition (for Absolute System)

Setting Va	Setting Value: When DI.ABSE is ON, DO2 outputs ABSR signal, function set by P2-19 is disabled.		
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
ABSR is always outputted	DO.ABSR is OFF means the Request sent by ABSQ has been received. DO.ABSR is ON means the data that is outputted by ABSD is valid. When DI.ABSE is ON, this DO is enabled. Please refer to diagram 12.4 for detailed description.	Level Triggered	ALL
by DO2			

Setting Va	Setting Value: When DI.ABSE is ON, DO3 outputs ABSD signal, function set by P2-20 is disabled.			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode	
ABOD 13	Position data of ABS is outputted. The data is valid when ABSR is ON. When DI.ABSE is ON, this DO is enabled. Please refer to diagram 13.4 for detailed description.	Level Triggered	ALL	
outputted				
by DO3				

Setting Value: 0x0D			
DO Name	Function Description of Digital Output (DO)	Trigger Method	Control Mode
ABSW	Warning of absolute encoder.	Level Triggered	ALL

12.7 Alarms for Absolute System

Display	Alarm Name	Alarm Description
AL028	Encoder voltage error or the internal of the encoder is in error	Charging circuit of the servo drive is not removed and the battery voltage is higher than the specification (>3.8 V) or the encoder signal is in error.
AL029	Gray code error	Absolute position is in error.
AL060	The absolute position is lost	Due to battery under voltage or the failure of power supply, the encoder lost the internal record.
AL061	Encoder under voltage	The voltage of the absolute encoder is lower than the specification
AL062	The multi-turn of absolute encoder overflows	The multi-turn of absolute encoder exceeds the maximum range: -32768 ~ +32767
AL068	Absolute data transmitted via I/O is in error	The sequence is wrong when reading the absolute position via DIO.
AL069	Wrong motor type	Incremental motor is not allowed to activate the absolute function.
AL289	Feedback position counter overflows	Feedback position counter overflows.

12-32 Revision February, 2017

12.7.1 Causes and Corrective Actions

AL028: Encoder voltage error or the internal of the encoder is in error

Causes	Checking Method	Corrective Actions
Battery voltage is too high	 Check if the charging circuit exists in the servo drive. Check if the battery is correctly installed 	According to the procedure of Over voltage to check. When corrective actions are done, AL.028 will be cleared automatically.
The internal encoder is in error.	 Check if it is the absolute type encoder. Check if the servo is properly grounded. Check if the encoder cable separates from the power supply or the high-current circuit to avoid the interference. Check if the shielding cables are used in the wiring of the encoder. 	cable separates from the power supply or the high-current circuit.

AL029: Gray code error

Causes	Checking Method	Corrective Actions
Absolute position is in	Re-power on to operate the motor and	If the alarm occurs again,
error	check if the alarm will occur again.	please change the encoder.

AL060: Absolute Position Lost

Causes	Checking Method	Corrective Actions
Battery under voltage	Check if the voltage of the battery is lower than 2.8V.	After change the battery, conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.
Change the battery when the power is OFF which is controlled by the servo drive	Do no change or remove the battery when the power is OFF which is controlled by the servo drive.	Conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.
After activating the absolute function, the absolute coordinate initialization has not been completed.	 Install the battery. Check the wiring between the battery pack and the power cable of the servo drive. Check the wiring of the encoder. 	Conduct homing procedure. Please refer to the description of absolute coordinate initialization in Chapter 12.
Bad connection of the battery power circuit	 Check the wiring of the encoder. Check the wiring between the battery pack and the power cable of the servo drive. 	Connect or repair the wiring of the battery so as to supply the power to the encoder. Conduct homing procedure again. Please refer to the description

Causes	Checking Method	Corrective Actions
		of absolute coordinate initialization in Chapter 12.

AL062: Encoder under voltage

Causes	Checking Method	Corrective Actions
Battery under voltage	the paner is lower than 3.1 v (tentative	Do not change the battery when the power is ON which is controlled by the servo drive. After change the battery, AL061 will be cleared automatically.

AL062: The multi-turn of absolute encoder overflows

Potential Cause	Checking Method	Corrective Actions
range the absolute	Check if the operation distance exceeds the range, -32768 ~ +32767, the absolute encoder is able to record.	Conduct homing procedure again. Please refer to the description of absolute coordinate initialization in Chapter 12.

AL068: Absolute data transmitted via I/O is in error

Causes	Checking Method	Corrective Actions
Sequence error	 Switch OFF DI ABSQ should wait until DO ABSR is OFF. Switch ON ABSQ should wait until DO ABSR is ON. 	Correct the reading sequence of I/O
Reading time out	Check if the time between switching ON DO ABSR and switching ON ABSQ exceeds 200ms.	After switching ON DO ABSR (the absolute position data is ready), read DO ABSD and switch ON DI ABSQ within 200ms so that to inform the servo drive data reading is completed.

AL069: Wong motor type

Causes	Checking Method	Corrective Actions
Incremental motor is not allowed to activate the absolute function	 Check if the motor is incremental or absolute encoder. Check parameter P2-69. 	If the user desires to use absolute function, please choose absolute motor. If not, please set parameter P2-69 to 0.

AL289: Feedback position counter overflows

Causes	Checking Method	Corrective Actions
Feedback position counter overflows	This alarm will not occur at the moment. If it does, please contact the distributors.	NMT: Reset node or 0x6040.Fault Reset

12-34 Revision February, 2017

12.8 Related Monitoring Variables

Code	Monitoring Variables / Attribute	Explanation
038 (26h)	Voltage level of battery	The voltage level of battery for an absolute encoder.


(This page is intentionally left blank.)

12-36 Revision February, 2017


Appendix A Accessories

■ Power Connectors


Delta Part Number: ASDBCAPW0000 (for 200V series servo drive)




Delta Part Number: ASDBCAPW0100 (for 200V series servo drive, with brake contact)




Delta Part Number: ASD-CAPW5400 (for 400V series servo drive)




Delta Part Number: ASD-CAPW5100 (for 400V series servo drive, with brake contact)



Delta Part Number: ASD-CAPW1000




Delta Part Number: ASD-CAPW2000



Delta Part Number: ASD-CAPW4000


CLAMP: WPS3057-20A



Straight Plug WPS3106A-32-17S

Motor Brake Connector: ASD-CNBR1000


CLAMP: WPS3106A 10SL-4S-R



A-2 Revision February, 2017


■ Power Cables

Delta Part Number: ASD-ABPW0003, ASD-ABPW0005 (for 200V series servo drive)




Title	Part No.	L	
Title	Title Part No.		inch
1	ASD-ABPW0003	3000 ± 100	118 ± 4
2	ASD-ABPW0005	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW5403, ASD-CAPW5405 (for 400V series servo drive)




Title	Part No.	L		
Title	Fait NO.	mm	inch	
1	ASD-CAPW5403	3000 ± 100	118 ± 4	
2	ASD-CAPW5405	5000 ± 100	197 ± 4	

Delta Part Number: ASD-ABPW0103, ASD-ABPW0105 (for 200V series servo drive, with brake cable)



Title	Part No.	L	
Title	Title Fait No.		inch
1	ASD- ABPW0103	3000 ± 100	118 ± 4
2	ASD- ABPW0105	5000 ± 100	197 ± 4


Delta Part Number: ASD-CAPW5103, ASD-CAPW5105 (for 400V series servo drive, with brake cable)



Title	Part No.		-
Title	Pait No.	mm	inch
1	ASD- CAPW5103	3000 ± 100	118 ± 4
2	ASD- CAPW5105	5000 ± 100	197 ± 4


A-4 Revision February, 2017

Delta Part Number: ASD-CAPW1003, ASD-CAPW1005




Titlo	Part No.	Straight	L	
Title	Fait No.	Straight	mm	inch
1	ASD-CAPW1003	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW1005	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW1103, ASD-CAPW1105




Title	Part No.	Straight	L	
riue	Fait No.	Straight	mm	inch
1	ASD-CAPW1103	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW1105	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASDB-CAPW1203, ASDB-CAPW1205




Title	Part No.	Straight	L	
Title	raitino.		mm	inch
1	ASD-CAPW1203	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW1205	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW1303, ASD-CAPW1305




Title	Part No.	Straight	L	
Title	rait No.		mm	inch
1	ASD-CAPW1303	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW1305	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-A2PW1003, ASD-A2PW1005



Title	Part No.	Straight	L	
Title	Fait No.		mm	inch
1	ASD-A2PW1003	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-A2PW1005	3106A-20-18S	5000 ± 100	197 ± 4


Delta Part Number: ASD-A2PW1103, ASD-A2PW1105



Titlo	Part No.	Straight	L	
Title	Fait No.		mm	inch
1	ASD-A2PW1103	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-A2PW1105	3106A-20-18S	5000 ± 100	197 ± 4


A-6 Revision February, 2017






Title	Part No.	Straight	L	
Title	raitinu.	Straight	mm	inch
1	ASD-CAPW2003	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW2005	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW2103, ASD-CAPW2105




Title	Part No.	Straight	L	
TILLE	Fait No.		mm	inch
1	ASD-CAPW2103	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW2105	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW2203, ASD-CAPW2205




Title	Part No.	Straight	L	
Title	Fait NO.	Straight	mm	inch
1	ASD-CAPW2203	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW2205	3106A-20-18S	5000 ± 100	197 ± 4

Delta Part Number: ASD-CAPW2303, ASD-CAPW2305 (for motors with brake)



Title	Part No.	Straight	L	
Title	raitinu.	Straight	mm	inch
1	ASD-CAPW2303	3106A-20-18S	3000 ± 100	118 ± 4
2	ASD-CAPW2305	3106A-20-18S	5000 ± 100	197 ± 4


Delta Part Number: ASD-CAPW3203, ASD-CAPW3205 (for 4.5 kW models)



Title	Part No.	Straight	L	
Title	i ait ivo.	Straight	mm	inch
1	ASD-CAPW3203	MS 3106-24-11S	3000 ± 100	118 ± 4
2	ASD-CAPW3205	MS 3106-24-11S	5000 ± 100	197 ± 4

A-8 Revision February, 2017


Delta Part Number: ASD-CAPW3303, ASD-CAPW3305 (for motors with brake)




Item	n Part No. Straight		L		L1	
110111	r dit ito.	mm	inch	mm	inch	
1	ASD-CAPW3303	MS 3106-24-11S	3000±100	118 ± 4	3100±100	122 ± 4
2	ASD-CAPW3305	MS 3106-24-11S	5000±100	197 ± 4	5100±100	201 ± 4

■ Encoder Connectors

Delta Part Number: ASD-ABEN0000




Delta Part Number: ASD-ABEN1000




■ Incremental Type Encoder Cables

Delta Part Number: ASD-ABEN0003, ASD-ABEN0005



Title Part No.			_
riue	Part No.	mm	inch
1	ASD-ABEN0003	3000 ± 100	118 ±4
2	ASD-ABEN0005	5000 ± 100	197 ± 4

Delta Part Number: ASD-ABEN1003, ASD-ABEN1005




Title	Part No.	Straight	L	
Title	rait No.	Straight	mm	inch
1	ASD-CAEN1003	3106A-20-29S	3000 ± 100	118 ± 4
2	ASD-CAEN1005	3106A-20-29S	5000 ± 100	197 ± 4

A-10 Revision February, 2017


■ Absolute Type Encoder Cables

Delta Part Number: ASD-A2EB0003, ASD-A2EB0005



Title Part No.	L		
Tille	Fait No.	mm	inch
1	ASD-A2EB0003	3000 ± 100	118 ± 4
2	ASD-A2EB0005	5000 ± 100	197 ± 4


Delta Part Number: ASD-A2EB1003, ASD-A2EB1005



Title	Title Model Name		_
TILLE	Model Name	mm	inch
1	ASD-A2EB1003	3000 ± 100	118 ± 4
2	ASD-A2EB1005	5000 ± 100	197 ± 4


■ Battery Box Cord AW (Connects to the battery side of the encoder cable)

Delta Part Number: 3864573700



■ Battery Box Cord IW (Connects to CN8)

Delta Part Number: 3864811900




A-12 Revision February, 2017

■ Battery Boxes

Single Battery Box


Delta Part Number: ASD-MDBT0100







Dual Battery Box

Delta Part Number: ASD-MDBT0200








Units: mm

■ I/O Signal Connector


Units: mm


Delta Part Number: ASD-CNSC0050




■ I/O Terminal Block Module


Delta Part Number: ASD-BM-50A







■ RS-232 Communication Cable





■ Communication Cable between Drive and Computer (for PC)






Titlo	Part No.		L
Title		mm	inch
1	DOP-CAUSBAB	1400 ± 30	55 ±1.2

■ CANopen Communication Cable

Delta Part Number: TAP-CB03, TAP-CB05





Title	Part No.		
TILLE	Fait NO.	mm	inch
1	TAP-CB03	300 ± 10	11 ± 0.4
2	TAP-CB05	500± 10	19 ± 0.4


A-14 Revision February, 2017

■ CANopen Distribution Box

Delta Part Number: TAP-CN03









■ RS-485 Connector

Delta Part Number: ASD-CNIE0B06



■ CN1 Convenient Connector

Delta Part Number: ASD-IF-SC5020



A-16 Revision February, 2017

■ Optional Accessories - 220V Series

100W Servo Drive and 50W Low Inertia Servo Motor

Servo Drive	ASD-A2-0121-□
Low Inertia Servo Motor	ECMA-C∆040F□S
Motor Power Cable (Without Brake)	ASD-ABPW000X
Power Connector (Without Brake)	ASDBCAPW0000
Motor Power Cable (With Brake)	ASD-ABPW010X
Power Connector (With Brake)	ASDBCAPW0100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

100W Servo Drive and 100W Low Inertia Servo Motor

Servo Drive	ASD-A2-0121-□
Low Inertia Servo Motor	ECMA-C∆0401□S
Motor Power Cable (Without Brake)	ASD-ABPW000X
Power Connector (Without Brake)	ASDBCAPW0000
Motor Power Cable (With Brake)	ASD-ABPW010X
Power Connector (With Brake)	ASDBCAPW0100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

200W Servo Drive and 200W Low Inertia Servo Motor

Servo Drive	ASD-A2-0221-□
Low Inertia Servo Motor	ECMA-C∆0602□S
Motor Power Cable (Without Brake)	ASD-ABPW000X
Power Connector (Without Brake)	ASDBCAPW0000
Motor Power Cable (With Brake)	ASD-ABPW010X
Power Connector (With Brake)	ASDBCAPW0100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

400W Servo Drive and 400W Low Inertia Servo Motor

Servo Drive	ASD-A2-0421-□
	ECMA-C∆0604□S
Low Inertia Servo Motor	ECMA-C∆0604□H
	ECMA-C∆0804□7
Motor Power Cable (Without Brake)	ASD-ABPW000X
Power Connector (Without Brake)	ASDBCAPW0000
Motor Power Cable (With Brake)	ASD-ABPW010X
Power Connector (With Brake)	ASDBCAPW0100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

400W Servo Drive and 500W Medium Inertia Servo Motor

Servo Drive	ASD-A2-0421-□
Medium Inertia Servo Motor	ECMA-E∆1305□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-18 Revision February, 2017

400W Servo Drive and 300W High Inertia Servo Motor

Servo Drive	ASD-A2-0421-□
High Inertia Servo Motor	ECMA-G△1303□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

750W Servo Drive and 750W Low Inertia Servo Motor

Servo Drive	ASD-A2-0721-□
	ECMA-C∆0807□S
Low Inertia Servo Motor	ECMA-C∆0807□H
	ECMA-C∆0907□S
Motor Power Cable (Without Brake)	ASD-ABPW000X
Power Connector (Without Brake)	ASDBCAPW0000
Motor Power Cable (With Brake)	ASD-ABPW010X
Power Connector (With Brake)	ASDBCAPW0100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

750W Servo Drive and 500W Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-0721-□
Medium-High Inertia Servo Motor	ECMA-F△1305□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

750W Servo Drive and 600W High Inertia Servo Motor

Servo Drive	ASD-A2-0721-□
High Inertia Servo Motor	ECMA-G∆1306□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 1kW Low Inertia Servo Motor

Servo Drive	ASD-A2-1021-□
Low Inertia Servo Motor	ECMA-C∆1010□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1Kw Servo Drive and 1kW Low Inertia Servo Motor

Servo Drive	ASD-A2-1021-□
Low Inertia Servo Motor	ECMA-C∆0910□S
Motor Power Cable (Without Brake)	ASD-ABPW000X
Motor Power Cable (With Brake)	ASD-ABPW010X
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-20 Revision February, 2017

1kW Servo Drive and 1kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-1021-□
Medium Inertia Servo Motor	ECMA-E△1310□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 850W Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-1021-□
Medium-High Inertia Servo Motor	ECMA-F∆1308□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 900W High Inertia Servo Motor

Servo Drive	ASD-A2-1021-□
High Inertia Servo Motor	ECMA-G∆1309□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1.5kW Servo Drive and 1.5kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-1521-□
Medium Inertia Servo Motor	ECMA-E∆1315□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 2kW Low Inertia Servo Motor

Servo Drive	ASD-A2-2023-□
Low Inertia Servo Motor	ECMA-C△1020□S
Motor Power Cable (Without Brake)	ASD-A2PW100X
Motor Power Cable (With Brake)	ASD-A2PW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 2kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-2023-□
Medium Inertia Servo Motor	ECMA-E∆1320□S
Motor Power Cable (Without Brake)	ASD-A2PW100X
Motor Power Cable (With Brake)	ASD-A2PW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-22 Revision February, 2017

2kW Servo Drive and 2kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-2023-□
Medium Inertia Servo Motor	ECMA-E∆1820□S
Motor Power Cable (Without Brake)	ASD-CAPW200X
Motor Power Cable (With Brake)	ASD-CAPW210X
Power Connector	ASD-CAPW2000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 1.3kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Medium-High Inertia Servo Motor	ECMA-F∆1313□S
Motor Power Cable (Without Brake)	ASD-A2PW100X
Motor Power Cable (With Brake)	ASD-A2PW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 1.8kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Medium-High Inertia Servo Motor	ECMA-F∆1318□S
Motor Power Cable (Without Brake)	ASD-A2PW100X
Motor Power Cable (With Brake)	ASD-A2PW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

3kW Servo Drive and 3kW Low Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Low Inertia Servo Motor	ECMA-C∆1330□4
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

3kW Servo Drive and 3kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Medium Inertia Servo Motor	ECMA-E∆1830□S
Motor Power Cable (Without Brake)	ASD-CAPW200X
Motor Power Cable (With Brake)	ASD-CAPW210X
Power Connector	ASD-CAPW2000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

3kW Servo Drive and 3.5kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Medium Inertia Servo Motor	ECMA-E∆1835□S
Motor Power Cable (Without Brake)	ASD-CAPW200X
Motor Power Cable (With Brake)	ASD-CAPW210X
Power Connector	ASD-CAPW2000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-24 Revision February, 2017

3kW Servo Drive and 3kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-3023-□
Medium-High Inertia Servo Motor	ECMA-F∆1830□S
Motor Power Cable (Without Brake)	ASD-CAPW200X
Motor Power Cable (With Brake)	ASD-CAPW210X
Power Connector	ASD-CAPW2000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

4.5kW Servo Drive and 4.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-4523-□
Medium-High Inertia Servo Motor	ECMA-F△1845□S
Motor Power Cable (Without Brake)	ASD-CAPW320X
Motor Power Cable (With Brake)	ASD-CAPW330X
Power Connector	ASD-CAPW2000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

5.5kW Servo Drive and 5.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-5523-□
Medium-High Inertia Servo Motor	ECMA-F△1855□3
Motor Power Cable (Without Brake)	-
Motor Power Cable (With Brake)	-
Power Connector	ASD-CAPW4000
Brake Connector	ASD-CNBR1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

7.5kW Servo Drive and 7.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-7523-□
Medium-High Inertia Servo Motor	ECMA-F△1875□3
Motor Power Cable (Without Brake)	-
Motor Power Cable (With Brake)	-
Power Connector	ASD-CAPW4000
Brake Connector	ASD-CNBR1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

11kW Servo Drive and 11kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-1B23-□
Medium-High Inertia Servo Motor	ECMA-F1221B□3
Motor Power Cable (Without Brake)	-
Motor Power Cable (With Brake)	-
Power Connector	ASD-CAPW4000
Brake Connector	ASD-CNBR1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

15kW Servo Drive and 15kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-1F23-□
Medium-High Inertia Servo Motor	ECMA-F1221F□S
Motor Power Cable (Without Brake)	-
Motor Power Cable (With Brake)	-
Power Connector	ASD-CAPW4000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-26 Revision February, 2017

NOTE

1. The boxes (□) at the ends of the servo drive model names are for optional configurations. Please refer to the ordering information of the actual purchased product.

- 2. The boxes (△) in the model names are for encoder resolution types. Please refer to Chapter 1 for further information.
- 3. The boxes (\square) in the model names represent brake or keyway / oil seal.

Optional Accessories - 400V Series

750W Servo Drive and 400W Low Inertia Servo Motor

Servo Drive	ASD-A2-0743-□
Low Inertia Servo Motor	ECMA-J∆0604□S
Motor Power Cable (Without Brake)	ASD-CAPW540X
Power Connector (Without Brake)	ASD-CAPW5400
Motor Power Cable (With Brake)	ASD-CAPW510X
Power Connector (With Brake)	ASD-CAPW5100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

750W Servo Drive and 750W Low Inertia Servo Motor

Servo Drive	ASD-A2-0743-□
Lauria Camia Matan	ECMA-J∆0807□S
Low Inertia Servo Motor	ECMA-J∆0907□S
Motor Power Cable (Without Brake)	ASD-CAPW540X
Power Connector (Without Brake)	ASD-CAPW5400
Motor Power Cable (With Brake)	ASD-CAPW510X
Power Connector (With Brake)	ASD-CAPW5100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

750W Servo Drive and 500W Medium Inertia Servo Motor

Servo Drive	ASD-A2-0743-□
Medium Inertia Servo Motor	ECMA- K∆1305□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-28 Revision February, 2017

750W Servo Drive and 500W Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-0743-□
Medium-High Inertia Servo Motor	ECMA- L△1305□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 1kW Low Inertia Servo Motor

Servo Drive	ASD-A2-1043-□
Low Inertia Servo Motor	ECMA-J∆0910□S
Motor Power Cable (Without Brake)	ASD-CAPW540X
Power Connector (Without Brake)	ASD-CAPW5400
Motor Power Cable (With Brake)	ASD-CAPW510X
Power Connector (With Brake)	ASD-CAPW5100
Incremental Type Encoder Cable	ASD-ABEN000X
Absolute Type Encoder Cable	ASD-A2EB000X
Encoder Connector	ASD-ABEN0000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 850W High Inertia Servo Motor

Servo Drive	ASD-A2-1043-□
High Inertia Servo Motor	ECMA-L△1308□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1kW Servo Drive and 1kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-1043-□
Medium Inertia Servo Motor	ECMA-K∆1310□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1.5kW Servo Drive and 900W High Inertia Servo Motor

Servo Drive	ASD-A2-1543-□
High Inertia Servo Motor	ECMA-M△1309□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1.5kW Servo Drive and 1kW Low Inertia Servo Motor

Servo Drive	ASD-A2-1543-□
Low Inertia Servo Motor	ECMA-J△1010□S
Motor Power Cable (Without Brake)	ASD-CAPW100X
Motor Power Cable (With Brake)	ASD-CAPW110X
Power Connector	ASD-CAPW1000
Incremental Type Encoder Cable	ASD-CAEN100X
Absolute Type Encoder Cable	ASD-A2EB100X
Encoder Connector	ASD-CAEN1000

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-30 Revision February, 2017

1.5kW Servo Drive and 1.3kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-1543-□	
Medium-High Inertia Servo Motor	ECMA-L△1313□S	
Motor Power Cable (Without Brake) ASD-CAPW100X		
Motor Power Cable (With Brake)	ASD-CAPW110X	
Power Connector ASD-CAPW1000		
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable	ASD-A2EB100X	
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

1.5kW Servo Drive and 1.5kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-1543-□	
Medium Inertia Servo Motor	ECMA-K△1315□S	
Motor Power Cable (Without Brake)	ASD-CAPW100X	
Motor Power Cable (With Brake) ASD-CAPW110X		
Power Connector	ASD-CAPW1000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable ASD-A2EB100X		
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 2kW Low Inertia Motor

Servo Drive	ASD-A2-2043-□	
Low Inertia Servo Motor	ECMA-J∆1020□S	
Motor Power Cable (Without Brake)	ASD-CAPW120X	
Motor Power Cable (With Brake)	ASD-CAPW130X	
Power Connector	ASD-CAPW1000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable ASD-A2EB100X		
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 2kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-2043-□	
Medium Inertia Servo Motor	ECMA-K∆1320□S	
Motor Power Cable (Without Brake)	ASD-CAPW120X	
Motor Power Cable (With Brake)	ASD-CAPW130X	
Power Connector	ASD-CAPW1000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable	ASD-A2EB100X	
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

2kW Servo Drive and 2kW Medium Inertia Servo Motor

Servo Drive	ASD-A2-2043-□	
Medium Inertia Servo Motor	ECMA-K△1820□S	
Motor Power Cable (Without Brake)	ASD-CAPW220X	
Motor Power Cable (With Brake)	ASD-CAPW230X	
Power Connector	ASD-CAPW2000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable	ASD-A2EB100X	
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

3kW Servo Drive and 3kW Medium-Low Inertia Servo Motor

Servo Drive	ASD-A2-3043-□	
Medium-Low Inertia Servo Motor	ECMA-J△1330□4	
Motor Power Cable(Without Brake)	ASD-CAPW120X	
Motor Power Cable (With Brake)	ASD-CAPW130X	
Power Connector ASD-CAPW1000		
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable ASD-A2EB100X		
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

A-32 Revision February, 2017

3kW Servo Drive and 3kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-3043-□	
Medium-High Inertia Servo Motor	ECMA- L∆11830□S	
Motor Power Cable (Without Brake) ASD-CAPW220X		
Motor Power Cable (With Brake) ASD-CAPW230X		
Power Connector	ASD-CAPW2000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable	er Cable ASD-A2EB100X	
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

4.5kW Servo Drive and 4.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-4543-□	
Medium-High Inertia Servo Motor	ECMA-L∆1845□S	
Motor Power Cable (Without Brake) ASD-CAPW220X		
Motor Power Cable (With Brake) ASD-CAPW230X		
Power Connector ASD-CAPW2000		
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable ASD-A2EB100X		
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

5.5kW Servo Drive and 5.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-5543-□	
Medium-High Inertia Servo Motor	ECMA-L11855□3	
Motor Power Cable (Without Brake)	ASD-CAPW220X	
Motor Power Cable (With Brake)	ASD-CAPW230X	
Power Connector	ASD-CAPW2000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable ASD-A2EB100X		
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)

7.5kW Servo Drive and 7.5kW Medium-High Inertia Servo Motor

Servo Drive	ASD-A2-7543-□	
Medium-High Inertia Servo Motor	ECMA-L11875□3	
Motor Power Cable (Without Brake)	ASD-CAPW320X	
Motor Power Cable (With Brake)	ASD-CAPW330X	
Power Connector	ASD-CAPW2000	
Incremental Type Encoder Cable	ASD-CAEN100X	
Absolute Type Encoder Cable	ASD-A2EB100X	
Encoder Connector	ASD-CAEN1000	

(X=3 indicates that the cable length is 3m; X=5 indicates that the cable length is 5m)



- 1. The boxes (□) at the ends of the servo drive model names. For the actual model name, please refer to the ordering information of the actual purchased product.
- 2. The boxes (△) in the model names are for encoder resolution types. Please refer to Chapter 1 for further information.
- 3. The boxes (\Box) in the model names represent brake or keyway / oil seal.

Other Accessories (for ASDA-A2 series all models)

Description	Delta Part Number
50Pin I/O signal connector (CN1)	ASD-CNSC0050
Terminal Block Module	ASD-BM-50A
RS-232 Communication Cable	ASD-CARS0003
Communication Cable between Drive and Computer (for PC)	DOP-CAUSBAB
CANopen Communication Cable	TAP-CB03/TAP-CB05
CANopen Distribution Box	TAP-CN03
RS-485 Connector	ASD-CNIE0B06
Regenerative Resistor 400W 40Ω	BR400W040
Regenerative Resistor 1kW 20Ω	BR1K0W020
Regenerative Resistor 1.5kW 5Ω	BR1K5W005

A-34 Revision February, 2017

Appendix B Maintenance and Inspection

Basic Inspection

Item	Content
	Periodically check if the screws of the servo drive, the connection between the motor shaft and the mechanical system as well as the connection of terminal block and mechanical system are securely tightened.
General inspection	The gap of the control chamber and the installation of the cooling fan should free from oil, water or metallic particles. Also, the servo drive shall free from the cutting power of the power drill.
	If the control chamber is installed in the site which contains harmful gas or full of dust, please be ensured the servo drive is free from the harmful gas and dust.
	When making encoder cable or wire rods, please be ensured the wiring is correct. Otherwise, the motor may have sudden unintended acceleration or be burned.
	To avoid the electric shock, the ground terminal of the servo drive should firmly connect to the ground terminal of the control chamber. If the wiring is needed, wait at least 10 minutes after disconnecting the drive from the main supply power, or discharge electricity by discharge device.
	The splicing parts of the wiring terminal should be isolated.
	Make sure the wiring is correct so as to avoid the damage or any abnormity.
Inspection before operation	Check if the electric conductivity objects including sheetmetal (such as screws) or inflammable objects are not inside the servo drive.
(has not applied to the	Check if the control switch is in OFF status.
power yet)	Do not place the servo drive of external regenerative resistor on inflammable objects.
	To avoid the electromagnetic brake losing efficacy, please check if stop function and circuit break function can work normally.
	If the peripheral devices are interfered by the electronic instruments, please reduce electromagnetic interference with devices.
	Please make sure the external voltage level of the servo drive is correct.
Inspection before	The encoder cable should avoid excessive stress. When the motor is running, please be ensured the cable is not frayed or over extended.

running the servo drive (has already applied to the power)	Please contact with Delta if there is any vibration of the servo motor or unusual noise during the operation.
	Make sure the setting of the parameters is correct. Different machinery has different characteristic, please adjust the parameter according to the characteristic of each machinery.
	Please reset the parameter when the servo drive is in the status of SERVO OFF, or it may cause malfunction.
	When the relay is operating, make sure it can work properly.
	Check if the power indicator and LED display works normally.

Maintenance

- Please use and store the product in a proper site.
- Periodically clean the surface of the servo drive and servo motor so as to avoid the dust and dirt.
- Do not disassemble any mechanical part when in maintenance.
- Periodically clean the ventilation ports of the servo drive and do not use the product in a high-temperature site for a long time so as to avoid the malfunction.

The lifetime of machinery parts

■ DC Bus Capacitor

DC Bus Capacitor will be deteriorated by the affection of ripple current. Its lifetime is determined by the surrounding temperature and operating conditions. If it is operating in an air-conditioned site, its lifetime can up to 10 years.

Relay

The contact of switching power supply will wear and leads to poor contact. The lifetime of relay is influenced by the power supply capacity; thus, the accumulative time of switching power supply is about 100,000 times.

Cooling Fan

In continuous operation, the lifetime of the cooling fan is 2 to 3 years. However, if there is any unusual noise or vibration during inspection, place a new one is a must.

B-2 Revision February, 2017